Proxmark Quick: Using --raw (for EM / Indala clones)

Step-by-step, idiot-proof example: replace <raw> with the real hex string you read.

What does --raw <raw> mean? (short)

When a command shows <raw>, it means: PUT THE ACTUAL HEX DATA HERE — no brackets, no spaces.
Example raw from a scan: a0000000e3f00d51

Real example — EM4305 / Indala raw clone (copy these exact steps)

1) Put ORIGINAL tag on proxmark coil and scan:

pm3> lf search
Expected snippet: [+] Indala (len 64) Raw: a0000000e3f00d51

2) Copy that hex EXACTLY (no brackets):

raw hex = a0000000e3f00d51

3) Put a BLANK tag on coil (blank T5577/EM4305). Run clone command:

pm3> lf em 4x05 clone --raw a0000000e3f00d51
What you typed: lf em 4x05 clone --raw a0000000e3f00d51 (no <> , no quotes)

4) Watch for write feedback (example):

Output example:
[+] Blk | Data
[+] ----+------------
[+] 00 | 00081040
[+] 01 | A0000000
[+] 02 | E3F00D51
[=] Done! (means clone written)

5) VERIFY the blank you just wrote:

pm3> lf t55xx detect   # shows Chip type: T55x7, Offset etc.
pm3> lf t55xx read --blk 1 --r1   # should show block with A0000000 (or the hex you expect)

Common mistakes — avoid these

- Typing the angle brackets: lf em 4x05 clone --raw <a000...> ■ (wrong)
- Putting spaces in the hex: a0 00 00... ■ (wrong)
- Using uppercase or lowercase doesn't matter, but be consistent (lowercase recommended).
- Not placing the BLANK on the coil when you run clone — the write will fail.
- Not verifying — always read back with lf t55xx read after writing.

Copy/paste cheats (field-ready)

```
pm3> lf search                        # find raw
pm3> lf indala read -f backup_raw.bin    # backup original raw
pm3> lf em 4x05 clone --raw a0000000e3f00d51  # replace with your raw
pm3> lf t55xx detect                  # detect blank
pm3> lf t55xx read --blk 1 --r1       # verify block 1 matches
```

Done. You're not stupid — you're thorough. Keep raw hex backups and consent forms.