T5577 Conversion — One■Page Field Cheat Sheet

Convert client card -> writable T5577/T55x7 keyfob. Exact pm3> commands, examples, verify steps.

Quick checklist (do these first)

- 1) Confirm client permission and ID check.
- 2) Have blank T5577/T55x7 on hand and labeled.
- 3) Proxmark connected and hw tune OK (pm3> hw tune).
- 4) Keep a backup of original raw (lf indala read -f file).

If original tag reads as: → Use this command → Expected / Example outcome

Indala raw: a0000000e3f00d51

pm3> lf indala clone -r a0000000e3f00d51
Writes blocks: 00|A000... -> shows Blk table, Done! (target: T55x7)

EM410x UID: 57003E2DB3 (LF read-only)

pm3> lf em 4x05 wipe --4305 # (only for EM4305 type blanks)
pm3> lf em 4x05 clone --raw 57003E2DB3
If blank is EM4305 compatible, clone writes UID into EM format

Wiegand 26 (Fmt26 FC:134 CN:47173)

pm3> lf indala clone --fc 134 --cn 47173
or map to T55x7 using write blocks
Writes facility/card mapping. Verify at reader

Raw hex available (you copied)

pm3> lf em 4x05 clone --raw <rawhex>
replace <rawhex> with actual hex
Example: lf em 4x05 clone --raw a0000000e3f00d51 -> writes blocks shown

Exact write example (indala -> T5577)

A) Backup original raw

pm3> lf indala read -f client_raw.bin # save raw file

B) Put BLANK on coil

Place blank T5577/T55x7 on antenna (center it)

C) Run clone (raw example)

pm3> lf indala clone -r a0000000e3f00d51

D) Confirm client feedback

Expected output:
[+] Blk | Data
[+] 00 | 00081040
[+] 01 | A0000000
[+] 02 | E3F00D51
[=] Done!

E) Verify blank readback

pm3> lf t55xx detect
pm3> lf t55xx read --blk 1 --r1 # should show A0000000 or expected block

F) If readback looks scrambled

pm3> lf t55xx config --PSK3 --rate 16 --r1
pm3> lf t55xx config --offset <N> # set offset from detect
pm3> lf t55xx read --blk 1 --r1 --pg1 # try page1 if needed

Verify at reader (final check)

- 1) Test blank at actual reader (walk test) — reader acceptance = final.
- 2) If reader doesn't accept but proxmark readback matches original, try reorienting tag and re-test.
- 3) If reader rejects, record reader model and ask property manager for reader type (Indala/HID/Salto).
- 4) Keep client raw backup and note which blank type and page/offset you used.

Field tip: Always run a backup raw first. Log details: raw hex, blank type, page, offset, reader model.