Available CLI Commands

Time/RTC Commands

Command	Parameters	Description
getTime	none	shows current RTC date, time in format:
		'yyyymmddHHMMSS' and Status:
		xEE clock error
		0x11 synchronized
		0x22 running
		ox33 reset to default
setTime	[hours] [min] [seconds] [sync]	Sets the time portion of RTC.
		if par omitted default = 0, sync any value ->
		true
setDate	[year] [month] [day]	Sets the date portion of RTC.
getSeconds	none	Gets seconds ticked (timer with 12Mhz clock)
		since last reset
clkOut	[source] [divider]	Puts the internal clock on the CLKOUT (P1.27)
		pin
		source (default='CPU'):
		'OFF','CPU','OSC','IRC','USB','RTC'
		devider 116 (default=10)

Memory Commands

Command	Parameters	Description
crcFlash	[start] [len]	Calculates FlashChecksum from start to start+len
		if between 0x000000 and 0x0007FFFF
		(hex input ox possible)
eeWriteName	[name] [hwrev]	Writes device name and hardware revision to
		EEPROM1 status page.
		default: " and ''
eeStatus	none	Reads the devicename, hardwarerevision and
		some counters from EEPROM1 status page
readPage	mem pagenr	Reads one page of memory device 'mem'.
_		'EE1','EE2','EE3','FRA' (fram chip)
writePage	mem pagenr [fillbyte]	Fills and writes a page with fillbyte
		(default=0xAA)
fRead	flashNr adr len	Reads len bytes from adr in flash '1' or '2'.
fWrite	flashNr adr fillbyte len	Writes the fillbyte len times from adr in flash '1' or '2'
fErase	flashNr adr	Erases the Flash sector at adr in flash '1' or '2'
mRead	adr len	Reads len bytes at adr from MRAM chip.
mWrite	adr fillByte len	Writes the fillbyte len times at adr from MRAM chip.

Other Commands

Command	Parameters	Description
cliStat	none	Prints some status info of CLI module
simErr	tbd.	Provokes errors in checksums for radiation test checks. Do not
		use without reading current code !!!!