

Mitsubishi Electric

Wiring & Electrical Manual - MSY-Z

Category: Wiring | Pages: 36

SAFETY PRECAUTIONS

1. Switch off main breaker before any installation work.
2. Use proper grounding on all electrical components.
3. Use only approved refrigerant for this model.
4. Perform leak test before commissioning.
5. Do not install near flammable gas or heat sources.

REQUIRED TOOLS

- Torque wrench, Manifold gauge set, Vacuum pump
- Flaring tool, Pipe cutter, Level, Clamp meter

TECHNICAL SPECIFICATIONS

Brand: Mitsubishi Electric

Refrigerant: R32 or R410A

Power: 220V / 50Hz / Single Phase

Cooling Capacity: 9,000 to 36,000 BTU/h

Operating Temperature: -10C to 46C

PIPE SPECIFICATIONS

9,000-18,000 BTU: Liquid 1/4" Suction 3/8"

24,000-36,000 BTU: Liquid 3/8" Suction 5/8"

Maximum Pipe Length: 15 metres

Maximum Height Difference: 10 metres

WIRING & ERROR CODE REFERENCE

INDOOR UNIT TERMINAL BLOCK

L : Live - Phase wire

N : Neutral wire

1 : Signal to outdoor unit

E : Earth / Ground

COMMON ERROR CODES

E1/U4 : Communication error - check signal wire

E3 : High pressure protection - clean outdoor coil

E4 : Low pressure / refrigerant leak - check pressure

A6 : Indoor fan motor lock - inspect motor