

Carrier

Error Code Service Manual - X-Power Series

Category: Error Manuals | Pages: 62

SAFETY PRECAUTIONS

1. Switch off main breaker before any installation work.
2. Use proper grounding on all electrical components.
3. Use only approved refrigerant for this model.
4. Perform leak test before commissioning.
5. Do not install near flammable gas or heat sources.

REQUIRED TOOLS

Torque wrench, Manifold gauge set, Vacuum pump,
Flaring tool, Pipe cutter, Level, Clamp meter

TECHNICAL SPECIFICATIONS

Brand: Carrier

Refrigerant: R32 or R410A

Power: 220V / 50Hz / Single Phase

Cooling Capacity: 9,000 to 36,000 BTU/h

Operating Temperature: -10C to 46C

PIPE SPECIFICATIONS

9,000-18,000 BTU: Liquid 1/4in Suction 3/8in

24,000-36,000 BTU: Liquid 3/8in Suction 5/8in

Maximum Pipe Length: 15 metres

Maximum Height Difference: 10 metres

ELECTRICAL REQUIREMENTS

9,000 BTU: 10A breaker 1.5 sq.mm wire

12,000 BTU: 16A breaker 2.5 sq.mm wire

18,000 BTU: 20A breaker 4.0 sq.mm wire

24,000 BTU: 25A breaker 6.0 sq.mm wire

WIRING & ERROR CODE REFERENCE

INDOOR UNIT TERMINAL BLOCK

L : Live - Phase wire

N : Neutral wire

1 : Signal to outdoor unit

E : Earth / Ground

OUTDOOR UNIT TERMINAL BLOCK

L : Live input from breaker

N : Neutral

1 : Signal from indoor unit

E : Earth

COMMON ERROR CODES

E1/U4 : Communication error - check signal wire (terminals 1 to 1)

E3 : High pressure protection - clean outdoor coil

E4 : Low pressure / refrigerant leak - check pressure

A6 : Indoor fan motor lock - inspect motor and capacitor

L5 : Inverter overcurrent - check compressor amperage

H11 : Comm error Panasonic - check all wiring terminals

F93 : Compressor revolution error - IPM or compressor fault