

GNUSim8085 - 8085 Microprocessor Simulator

File Reset Assembler Debug Help



Registers			Flag
A	05		S 0
BC	02 00		
DE	00 00		Z 0
HL	00 00		AC 0
PSW	00 00		
PC	1F 4C		P 1
SP	FF FF		C 0
Int-Reg	00		

Decimal - Hex Conversion

Decimal	Hex
0	0
To Hex	To Dec

I/O Ports

0	-	00
Update Port Value		

Memory

0	-	00
Update Memory		

Load me at

```

1 LDA 0050
2 MOV B,A
3 LDA 8051
4 ADD B
5 STA 8052
6 HLT
    
```

Data Stack Keypad **Memory** I/O Ports

Start

Address (Hex)	Address	Data
1F72	8050	2
1F73	8051	3
1F74	8052	5
1F75	8053	0
1F76	8054	0
1F77	8055	0
1F78	8056	0
1F79	8057	0
1F7A	8058	0
1F7B	8059	0
1F7C	8060	0
1F7D	8061	0
1F7E	8062	0
1F7F	8063	0

Line No Assembler Message
0 Program assembled successfully

Simulator: Idle