

- (1) C8 optionnal to adjust sensitivity: 0pF = maximal sensitivity, 50pF = minimal sensitivity.
- (2) The RESET pin for UART connection requires a 100nF capacitor between the connector and the programmer.