



# DUST EXTRACTOR

- Clean filters before use
- Change full bags and place outside
  - Close any inlets not in use
  - Do not vacuum metal