



DUST EXTRACTOR

- Clean filters before use
- Change full bags and place outside
 - Close any inlets not in use
 - Do not vacuum metal