

CONVEYOR TIMER

Click quickly, then stop.
Pause 1 s = command sent (beep)

●

ON / OFF

1 click starts the last program

PROGRAMS

▶ run ■ rest

●●

▶ 90 s

P1

■ 6 min

●●●

▶ 90 s

P2

■ 12 min

●●●●

▶ 90 s

P3

■ 18 min

LAMP

blinks N times, pause = program N
dark = OFF, panel buttons manual
fast flicker = memory fault, call service

SOUND

2 s = on / program set · 0.5 s = off
15 s = auto OFF after 4 h of running
SOS at every power-on = call service

CONVEYOR TIMER

Click quickly, then stop.
Pause 1 s = command sent (beep)

●

ON / OFF

1 click starts the last program

PROGRAMS

▶ run ■ rest

●●

▶ 90 s

P1

■ 6 min

●●●

▶ 90 s

P2

■ 12 min

●●●●

▶ 90 s

P3

■ 18 min

LAMP

blinks N times, pause = program N
dark = OFF, panel buttons manual
fast flicker = memory fault, call service

SOUND

2 s = on / program set · 0.5 s = off
15 s = auto OFF after 4 h of running
SOS at every power-on = call service

CONVEYOR TIMER

Click quickly, then stop.
Pause 1 s = command sent (beep)

●

ON / OFF

1 click starts the last program

PROGRAMS

▶ run ■ rest

●●

▶ 90 s

P1

■ 6 min

●●●

▶ 90 s

P2

■ 12 min

●●●●

▶ 90 s

P3

■ 18 min

LAMP

blinks N times, pause = program N
dark = OFF, panel buttons manual
fast flicker = memory fault, call service

SOUND

2 s = on / program set · 0.5 s = off
15 s = auto OFF after 4 h of running
SOS at every power-on = call service