

CONVEYOR TIMER

Click quickly, then stop.
Pause 1 s = command sent (beep)

●

ON / OFF

1 click starts the last program

PROGRAMS

▶ run s ■ rest s

●●

P1

▶ 5 s
■ 5 s

●●●

P2

▶ 10 s
■ 10 s

●●●●

P3

▶ 15 s
■ 15 s

●●●●●

P4

▶ 20 s
■ 30 s

●●●●●●

P5

▶ 30 s
■ 60 s

LAMP

blinks N times, pause = program N
dark = OFF, panel buttons manual
fast flicker = memory fault, call service

SOUND

2 s = on / program set · 0.5 s = off
15 s = auto OFF after 4 h of running
SOS at every power-on = call service

CONVEYOR TIMER

Click quickly, then stop.
Pause 1 s = command sent (beep)

●

ON / OFF

1 click starts the last program

PROGRAMS

▶ run s ■ rest s

●●

P1

▶ 5 s
■ 5 s

●●●

P2

▶ 10 s
■ 10 s

●●●●

P3

▶ 15 s
■ 15 s

●●●●●

P4

▶ 20 s
■ 30 s

●●●●●●

P5

▶ 30 s
■ 60 s

LAMP

blinks N times, pause = program N
dark = OFF, panel buttons manual
fast flicker = memory fault, call service

SOUND

2 s = on / program set · 0.5 s = off
15 s = auto OFF after 4 h of running
SOS at every power-on = call service

CONVEYOR TIMER

Click quickly, then stop.
Pause 1 s = command sent (beep)

●

ON / OFF

1 click starts the last program

PROGRAMS

▶ run s ■ rest s

●●

P1

▶ 5 s
■ 5 s

●●●

P2

▶ 10 s
■ 10 s

●●●●

P3

▶ 15 s
■ 15 s

●●●●●

P4

▶ 20 s
■ 30 s

●●●●●●

P5

▶ 30 s
■ 60 s

LAMP

blinks N times, pause = program N
dark = OFF, panel buttons manual
fast flicker = memory fault, call service

SOUND

2 s = on / program set · 0.5 s = off
15 s = auto OFF after 4 h of running
SOS at every power-on = call service