

CONVEYOR TIMER

Click quickly, then stop.
Pause 1 s = command sent (beep)

● ON / OFF

1 click starts the last program

PROGRAMS ▶ run s ■ rest s

●● P1 ▶ 15 s

■ 15 s

●●● P2 ▶ 30 s

■ 60 s

●●●● P3 ▶ 45 s

■ 90 s

●●●●● P4 ▶ 60 s

■ 120 s

●●●●●● P5 ▶ 60 s

■ 240 s

LAMP

blinks N times, pause = program N
dark = OFF, panel buttons manual
fast flicker = memory fault, call service

SOUND

2 s = on / program set · 0.5 s = off
15 s = auto OFF after 4 h of running
SOS at every power-on = call service

CONVEYOR TIMER

Click quickly, then stop.
Pause 1 s = command sent (beep)

● ON / OFF

1 click starts the last program

PROGRAMS ▶ run s ■ rest s

●● P1 ▶ 15 s

■ 15 s

●●● P2 ▶ 30 s

■ 60 s

●●●● P3 ▶ 45 s

■ 90 s

●●●●● P4 ▶ 60 s

■ 120 s

●●●●●● P5 ▶ 60 s

■ 240 s

LAMP

blinks N times, pause = program N
dark = OFF, panel buttons manual
fast flicker = memory fault, call service

SOUND

2 s = on / program set · 0.5 s = off
15 s = auto OFF after 4 h of running
SOS at every power-on = call service

CONVEYOR TIMER

Click quickly, then stop.
Pause 1 s = command sent (beep)

● ON / OFF

1 click starts the last program

PROGRAMS ▶ run s ■ rest s

●● P1 ▶ 15 s

■ 15 s

●●● P2 ▶ 30 s

■ 60 s

●●●● P3 ▶ 45 s

■ 90 s

●●●●● P4 ▶ 60 s

■ 120 s

●●●●●● P5 ▶ 60 s

■ 240 s

LAMP

blinks N times, pause = program N
dark = OFF, panel buttons manual
fast flicker = memory fault, call service

SOUND

2 s = on / program set · 0.5 s = off
15 s = auto OFF after 4 h of running
SOS at every power-on = call service