

Faderpunk WIP Apps — UX Cheatsheet

Synced to test/p/layground (IDs 29–43) · 13 Aug 2026 · A4 print

Main — Fader alone	Alt — Shift + Fader	Third — Channel button held + Fader
Short — Tap button	Long — Hold button (long-press)	Shift+... — Global Shift + gesture

Jack CV Out / CV In (Heat Pump, Grooves, Golden Gate, Arp de Lévy, Chord Vamp, Echolot, Loop de Cay; Super LFO is 2-ch with CV on Ch0): **CV Out** = app drives the jack · **CV In** = jack modulates a **CV Dest** (attenuated by **CV Att** 0–100% where present). Device-cycle Dest: Heat Pump & Super LFO via **Shift+Short** (Grooves: Configurator only). Golden Gate + Jack=CV In → MIDI-first (no CV/gate outs).

ID 29Heat Pumpready

Clock-synced sidechain ducking envelope

FADERS	BUTTONS	LEDS / OTHER PARAMS
Main — Release (up = faster recovery) Alt — Duck depth (red LED) Third — Clock division (1/1 ... 1/32) JACK PARAMS - Jack: CV Out / CV In - CV Dest: Depth · Release · Duck - Dest colors: Red · Yellow · Cyan - CV Att 0–100%	Short — Manual duck trigger Long — Mute (freeze level; no snap to idle; dim red button) Shift+Short (CV Out) — Cycle clock division Shift+Short (CV In) — Cycle CV Dest (flash) Shift+Long — Invert duck direction	- Button metronome Mid→Low per division · Mute = dim red (not off) 1/1 uses Color param - Invert: white ↔ off fade - Color, Range, MIDI CH/CC, NRPN, MIDI Out

Manual. Clock-synced ducking envelope: each division pulse ducks, then recovers by Release. Depth sets how far. Mute freezes the envelope at its current level (clock triggers discarded). Invert flips duck direction. Third sets division directly; Shift+Short cycles division (CV Out) or CV Dest (CV In). CV Att scales modulation.

ID 30Groovesready

Multi-genre MIDI drum grooves with swing

FADERS	BUTTONS	PARAMS / LEDS
Main — Density (extra hits) Alt — Genre scrub (shared axis with Chord Vamp) Third — Swing (capped by Swing max %) GENRES - Dub → Disco → House → Techno → Trip-Hop → Hip-Hop → Jungle → UK Garage → Dubstep - LEDs: continuous open red→yellow→green→cyan→blue spectrum (same as Chord Vamp) - Sound morphs continuously between neighboring genres along the axis	Short — Mute (notes off) Shift+Tap — Genre fill until next downbeat (break at high density) Shift+Hold — Drum solo while held: 4-bar phrase (build → busier → peak → turnaround); resolves on release Long — Reset to downbeat JACK PARAMS - Jack: CV Out Any · CV Out Stacked · CV In Density · CV In Feel · CV In Reset - Stacked sums families — hats 1, snare 2, kick 4 of 10 units; Open Hat counts as hats, Clap as snare, toms as kick - The jack follows the groove, so it still pulses with every note switched off - Range, CV Att	- Notes: Kick, Snare, Hats, Open Hat, Low Tom, High Tom, Clap — note 0 switches a voice off - MIDI Ch is the base for all seven; Ch Map overrides it per voice (7 packed nibbles, 0 = follow base) - Groove, Swing max % (negative = reverse swing), GATE %, MIDI Out - Groove = pocket: 0 is dead on the grid; up adds per-family ms drift (kick tight → hats loosest), velocity bow and walking ghosts - GATE % is per voice — closed hats choke inside their step, open hats and toms may ring past it; CV pulse stays inside the 16th Button Main: genre hue sat half→full (density) + bar lightness; hit dips kick –50% / snare –30% / hats –10% Button Third: White→Color→Red (swing); same voice-weighted hit dips Button Alt: committed genre hue (Top/Bottom = live fader meters; color changes only after latch pickup)

Manual. Genre MIDI drums on the global clock, sharing its nine genres with Chord Vamp and Bassment; the genre scrub morphs continuously between neighbours instead of stepping. Groove is the pocket: at zero every voice sits exactly on the grid, so Grooves locks tight against other Faderpunk apps. Turning it up drifts each family by its own few milliseconds — kick tightest, hats widest, scaled by the genre — bows velocity across the bar and walks which ghost hits Density reveals, so repeated bars stop reading identically. At high Density, sparse doubles, flams, triplets and rolls layer onto written kick/snare/hat hits (kick stays conservative; hats genre-typical); sub-strokes land inside the same 16th after swing/microtiming, never re-applying global swing. Shift+Tap plays a genre fill that crescendos toward the bar line independent of Density; above roughly 60 % Density it turns subtractive and the floor drops out for a break, handed back on the one by a late snare pickup. Shift+Hold escalates into a four-bar solo — build, busier bar, peak, turnaround — with accents pinned to the one and the backbeat, so Feel adds jitter instead of randomising the dynamics. Each genre carries three fill, break and solo figures; low Feel locks to one, higher Feel rolls between them. Clap, Open Hat and the toms are optional layers derived from hits already in the groove and stay silent until you give them a note: Open Hat replaces an accented offbeat hat rather than doubling it, and the toms only appear in the back half of a fill, break or solo.

FADERS

- **Main** — Fibonacci depth
- **Alt** — Cycle length N
- **Third** — Local speed grid (16th → quarter; center = follow Speed param)

JACK PARAMS

- Jack: CV Out / CV In (In = MIDI-first, no outs)
- CV Dest: Depth · Cycle · Reset
- Range, CV Att

BUTTONS

- **Short** — Reset to downbeat
- **Long** — Mute
- **Shift+Short** — Reverse gap direction
- **Shift+Long** — Cycle Mode (Note/CC/Pitch/Phi)

MODE PARAM

- Note · CC · Pitch (12-TET) · Phi (ϕ pitch)
- Button color: default / orange / red / pink

PARAMS

- MIDI CH/Note/CC, GATE %, Speed, Color, MIDI Out

Manual. Fills cycle length N with Fibonacci gaps; deeper sets approach ϕ . Mode param selects Note/CC/Pitch/Phi; Shift+Long cycles the same on-device. Third overrides Speed locally. Short resets; Shift+Short reverses travel. Jack=CV In drops CV/gate outs and uses Dest for Depth/Cycle/Reset.

FADERS

- **Ch0 Main** — Morph · **Alt** — Attenuation (Amp)
- **Ch0 Third** — Skew
- **Ch1 Main** — Symmetry · **Alt** — Speed
- **Ch1 Third** — Phase-Warp

CV DESTINATIONS (CH0 SHIFT+SHORT)

- Blue Rate Mod · Pink Phase · Red Reset · Cyan Amp
- Yellow Speed · Orange Morph · Violet Skew
- Green Warp · Rose Symmetry

BUTTONS

- **Ch0 Short** — Freeze toggle (white)
- **Ch0 Long** — In mute
- **Ch0 Shift+Short** — Cycle CV Dest
- **Ch0 Shift+Long** — Cycle Mix Mode
- **Ch1 Short** — Phase reset
- **Ch1 Long** — Out mute
- **Ch1 Shift+Short** — Phase reverse
- **Ch1 Shift+Long** — Clock sync toggle

PARAMS

- Speed, Range, MIDI, Grid Lock
- Mix Mode: Xfade / Min / Max / Sum
- Osc B: Quad / Octave · Mix balance 0–100%
- Rate-mod depth 0–100% (Configurator) · CV Dest can modulate it
- Ch0 jack = CV In · Ch1 jack = CV Out

Manual. Dual-osc morphing LFO. Ch0 Morph/Amp/Skew on CV In; Ch1 Symmetry/Speed/Warp on CV Out. Shift+Short on Ch0 cycles CV Dest. Freeze holds the wave; In-mute silences CV-in; Out-mute silences output. Ch1 Shift+Long toggles clock sync (Grid Lock). Mix balance 0–100% (Xfade only).

FADERS

- **Main** — Delay (up = shorter / faster)
- **Alt** — Feedback
- **Third** — Pitch interval (± 24 st)

BUTTONS

- **Short** — Mute / ring-out
- **Long** — Panic (clear queue); skipped if Third used this hold

LEDS

- White flash on MIDI/gate in (~20% when muted)
- Ping-Pong: Top = Out A · Bottom = Out B

PARAMS

- I/O: MIDI→MIDI · MIDI→CV · CV→MIDI
- Delay: ms / Clock · Max delay
- Interval mode: Fixed / Stack / Bounce
- Routing: Single / Ping-Pong
- Signal: Pitch / Gate / CV→CC / Gate→Note
- MIDI In/Out A, Out Pong, CC, Note, Range, Color

Manual. Delay with feedback and optional pitch intervals. I/O picks MIDI/CV routing; Ping-Pong alternates MIDI Out A/B (MIDI→MIDI and CV→MIDI). Mute = ring-out (block new input; queue plays out). Long Panic clears the trail — Third interval edits never panic that hold. MIDI In always flashes white for diagnosis when muted.

FADERS

- **Main** — Evolve / mutation (0 = frozen)
- **Alt** — Texture (density / phrase / swing feel)
- **Third** — Lévy α / flight character

JACK PARAMS

- Jack: CV Out / CV In
- CV Out source (Jack=Out): Pitch · Gate · Velocity
- CV Dest (Jack=In): Evolve · Texture · Reroll
- Range, CV Att · V/Oct · Bypass quantizer

BUTTONS

- **Short** — Reroll note pool (+ reset)
- **Long** — Mute
- **Shift+Short (CV Out)** — Cycle CV Out source
- **Shift+Short (CV In)** — Reverse playback
- **Shift+Long** — Cycle octave span 1→2→3→4

OCTAVE LED

- Blue · Cyan · Yellow · Red

LEDS

- **Button / Top** — latch hue + level: Main = Color/Evolve · Alt = Orange/Texture · Third = Violet/ α ; mute = off
- **Bottom** — Pitch height in Color while gated (note activity)

PARAMS

- MIDI CH, Base Note, Color, MIDI Out
- Follow device tonic (default on)
- CV pitch + MIDI (dual path)

Manual. Generative arp whose pool evolves with Lévy-flight mutations. Main bottom freezes; raise to wander. Texture shapes phrase density/length; Third sets flight character (α). Shift+Long walks octave span (button color). Jack=CV Out: Shift+Short cycles Pitch/Gate/Velocity. Jack=CV In: Shift+Short reverses; CV modulates Evolve/Texture or fires Reroll. **Follow device tonic** (default on) makes the device Tonic a live transpose — hold the Scene button, move Fader 5, and the arp moves with Bassment, Contura, Chord Vamp and Venn. Because the pool holds absolute notes, it is *shifted* by the interval rather than rerolled, so the melodic shape it has evolved into survives the transpose. Takes effect at the next phrase start.

FADERS

- **Main (Perform)** — Scrub genre degrees × 3 octaves (pitch map)
- **Main (Auto)** — Tension (Meander only)
- **Alt** — Genre (+ Capture clip slot if clip exists)
- Shared axis: Dub → Disco → House → Techno → Trip-Hop → Hip-Hop → Jungle → UK Garage → Dubstep
- **Third (Auto)** — Feel (laid ↔ advanced stab length)
- **Third (Perform)** — Feel still stored; LEDs = blue / chord pitch

JACK PARAMS

- Jack: CV Out · CV In Macro · CV In Panic
- One enum — a CV In destination and CV Out were never live at once, and the freed slot is what lets Vamp grow
- Range, V/Oct, CV Att

BUTTONS

- **Perform hold** — Chord on; release = off (blue LEDs track pitch)
- **Auto short** — Play / pause
- **Shift+Short (Perform)** — Capture last N bars → Auto+Play
- **Shift+Short (Auto)** — Return to Perform
- **Auto Long** — Clear clip, reseed genre phrase
- **Shift+Long** — Panic (both modes)

PARAMS

- Root, Scale, Genre, Voicing, Velocity
- Follow device tonic (default on)
- Auto style: Repeat / Meander
- Start mode: Perform / Auto
- Capture: 16 / 8 / 4 / 2 / 1 bars
- LED: Perform = app color; Auto = orange; Hold Auto = rose (phrase pos)

SCENE STORAGE

- 8-slot vamp + Capture clip
- **Swing** 0–100 — genre-seeded; odd-16th delay (no Configurator param)
- Feel, scrub, tension, mode, play/pause

Manual. MIDI chord vamp with optional CV jack. Shared 9-genre axis with Grooves (Dub→...→Jungle→...→Dubstep). **Perform:** fader = genre-unique degrees ascending across ~3 octaves; hold plays the chord (blue = pitch). **Shift+Short** captures recent harmony (starts quantized to 16ths, lead-in cropped to first hit; hold lengths free) into a timed clip and arms Auto. **Auto:** genre rhythm phrase loops — multi-chord statement (~1–2 bars) then multi-bar rest; harmony Repeat or Meander; Feel sets short stab gate (rests fixed); Swing (scene, genre-seeded) delays odd 16ths on Auto + Capture. Short = play/pause; Long clears clip / reseeds; Shift+Short → Perform; Shift+Long = Panic in either mode. Alt = genre (+ Capture slot). CV Macro = scrub/tension; Panic from CV optional. **Follow device tonic** (default on) turns the device Tonic into a live transpose — hold the Scene button, move Fader 5, and the harmony moves with Bassment, Contura, Venn and Arp de Lévy; the pitch class comes from the device, the octave stays with Root, and it lands on the next chord. There is no scale-follow counterpart: Scale defines the progressions, and Vamp sits at the 16-param ceiling.

FADERS

- **Main** — Gate % (Note) or CC amount (CC mode)
- **Alt** — Clock division
- **Third** — Velocity / sensitivity

BUTTONS

- **Short** — Play / trigger held sample
- **Shift+Short** — Manual sample (capture now)
- **Long** (no fader move) — Soft mute (fade; no hard note-off)

PARAMS / LEDS

- Mode Note / CC, MIDI CH/CC, Color, Range, V/Oct
- Layer meters: IR→UV spectrum on Main/Alt/Third fader
- White flash on each sample; mute = red button

Manual. Clocked sample-and-hold. Capture on division or Shift+Short; Main shapes gate length or CC depth. Long soft-mutes so notes can ring out. Third sets how strongly velocity follows the sample.

FADERS

- **Main** — Chord type (Unison · Power · Min · Maj · Sus4 · Min7 · Dom7 · Maj7 · Min9 · Add9)
- **Alt** — Inversion (0–2) / open (top + octave)
- **Third** — Velocity

BUTTONS

- **Short** (no fader move) — Mute / unmute all voices
- **Alt+Short** — Cycle harmony octave (–1 / 0 / +1)
- **Alt+Long** — Step voicing preset

PARAMS / LEDS

- I/O: MIDI→MIDI · MIDI→CV · CV→MIDI; MIDI In/Out CH
- CV Gate: Sustain · ms · clock divisions
- Strum (ms), Color, Range, V/Oct, Bypass quantizer
- Near-0V CV = rest; unpatched stays silent until stable pitch
- LEDs: IR→UV spectrum per layer; mute = red; preset flash on Alt+Long

Manual. One root (last MIDI note or pitch CV) picks the chord root; the fader picks chord type (Unison · Power · Min · Maj · Sus4 · Min7 · Dom7 · Maj7 · Min9 · Add9); up to four MIDI voices sound (MIDI→CV follows the highest). Alt sets inversion (0–2) or open top. Not a polyphonic keyboard input. Mute is a short tap — use Third (button+fader) for velocity so mute and vel don't collide. Alt+Short cycles harmony octave; Alt+Long walks voicing presets (tight/dry → wide/slow). CV Gate: Sustain, fixed ms, or clock divisions. Near-0V CV = rest; unpatched float stays silent until a stable pitch.

FADERS

- **Main** — Pitch (span from Base Note); spectrum LED meter. In Pitch→MIDI it transposes the CV pitch, so centre = unchanged and an unpatched jack leaves the fader in charge
- **Alt** (Shift+Fader) — Decay strength: bottom = immortal, top ≈ 4 wraps (violet→red)
- **Third** (Btn+Fader; gate modes while muted) — Decay mode zones (IR→UV): Random Rose · Pitch Up Orange · Pitch Down Yellow · Vel+Root Lime · Pitch Root Cyan · Velocity Blue · Gate Violet

BUTTONS

- **Hold** (gate modes) — Note on; release = off (long notes OK). Hold+Fader = scale-degree glissando toward the fader (like Chord Vamp)
- **Shift+Short** — Cycle loop length 1→2→...→8 bars (amber→cyan flash)
- **Shift+Long** — Mute (red LED; decay pauses)
- **Short while muted** — Unmute (re-arms)
- **Shift+Long while muted** — Erase buffer (white flash)

PARAMS / LEDS

- Mode: Pitch→MIDI · Gate→MIDI · MIDI→MIDI · MIDI→CV · Fader→Both
- Decay Mode: Random · Pitch Up · Pitch Down · Vel+Root (default) · Pitch Root · Velocity · Gate
- MIDI CH / In / Out, Base Note, Span (semitones across fader)
- Color, Range, V/Oct
- Capture/playback hit: sharp button 80% dim (~2 PPQN) + Top white; layer meters on Top/Bottom/Button

Manual. Clocked overdub loop: play while armed to capture; each wrap applies Alt strength through the selected Decay Mode (0 = freeze forever). Pitch modes stay on the global scale. Random jitters scale pitch and only lowers velocity. Gate shortens duration toward a 16th floor. Hold the button for long notes — mute is Shift+Long. Hold+Fader glissandos through scale degrees toward the fader (Chord Vamp-style). Length is Shift+Short (1–8 bars), not Alt/Third. Third picks Decay Mode (Configurator sync). Quantized to 16ths.

FADERS

- **Main** — Attenuverter –100...+100 % (center deadband = 0)
- **Alt** (Shift+Fader) — Offset –100...+100 %
- **Third** (hold button + fader) — Slew 0...10 s

BUTTONS

- **Short click** (no fader move) — Mute toggle on release (sends Output Min)
- **Hold + fader** — edit Slew (suppresses mute)
- **Shift+Hold** — momentary Bypass (keeps Range / Min-Max / Rate)

PARAMS / LEDS

- Pipeline: Gate/CV → Att → Offset → Transfer → Slew → Steps → Min/Max → Rate
- Button LED only: Main = app color × out; Alt = red × |offset|; Third = cyan × slew (floor so hue stays visible at 0)
- Mute = off · Bypass = full · black blink on downbeat while out > Min

Manual. 1-channel CV→MIDI sculptor. Defaults are transparent (+100 % att, 0 offset, 0 slew, Linear, full CC window, 100 Hz). Gate mode runs a Schmitt threshold (0.1 V hysteresis) then the same pipeline. Mute sends Output Min once and goes silent; unmute resends the live value. Watch the button LED for level — fader LEDs stay dark. Uses clock ticker only (no CLOCK_PUBSUB). No clock → no downbeat blink.

FADERS

- **Main** — F0 pulses A · F1 pulses B (density; absolute pulse count, Bjorklund redistributes)
- **Alt** (Shift) — F0 Extent (scale-degree span 0–24 from Note A) · F1 Interval (0–12 diatonic steps above the line for Ch2)
- **Third** (Btn1 or Btn2 hold) — F0 length A · F1 length B (2–32; independent)
- Rotation fixed at 0 (slots freed for Extent / Interval)
- **Division** (config) — note values 4/1 ... 1/32T (default 1/16)

BUTTONS

- **Btn1 or Btn2 hold** — Third (length A/B on F0/F1)
- **Btn2 tap** (no fader move) — Mute both outs
- **Shift+Btn1** — Cycle Logic OR → AND → XOR → Accnt
- **Shift+Btn2** — Toggle post-logic invert (shadow); white↔none fade like Heat Pump

MELODY / LEDS

- Note A (config) = degree 0 of the device quantizer key; Length-A walks an arch through 0...Extent scale degrees; Ch2 = same line + diatonic Interval
- Extent 0 = monotone Note A; higher = wider arch through the A cycle (device key)
- Division (note values), GATE %, Prob %, Humanize (Vel jitter; 0 = fixed max), MIDI CH / Note A / Interval B / Out, Color
- Color = App Color on Btn1; Btn0 = Logic hue; Top A/B = App Color / complement (layer hits)
- Main Btn: logic / app color · density bright · soft hit dip
- Alt: Top+Btn dim→sat ∝ Extent / Interval (fixed hues) · Third: shortest hue btn→complement ∝ length
- Top flashes = layer hits (Main) · Bottom flashes = logic outs (Main)
- Jack0 = logic result + melodic line · Jack1 coupled (OR→∩, AND→△, XOR→∩, Accnt→accent) + Interval

Manual. Two independent Euclidean masks combined with boolean logic — the OXI GEN dual-layer idea with a scale-aware melodic line. Color sets Layer A; Layer B LEDs use a fixed complement. Btn1 shows logic mode, not Color. Different lengths per layer enable polyrhythmic XOR/AND patterns Euclid cannot make alone. Melody: Note A is degree 0 of the device quantizer key. Extent is the arch span in scale degrees through Length-A; Interval B is diatonic steps above that line for Ch2 (wire indices 0–12 unchanged). Extent 0 = monotone Note A. Needs clock. Prob % < 100 adds optional flakiness; 100 is fully deterministic. No pitch CV (use GenSeq for that). Venn always draws its degrees from the device Scale. **Follow device tonic** (default on) adds the missing half: hold the Scene button and move Fader 5 and both lines transpose, together with Bassment, Contura, Chord Vamp and Arp de Lévy. The pitch class comes from the device, the octave stays with MIDI Note A, and the change lands at the start of the next A-cycle rather than mid-pattern.

FADERS

- **Main** — Density (extra onsets + freer degrees)
- **Alt** — Genre scrub (shared axis with Grooves / Chord Vamp)
- **Third** — Feel / Groove (swing · microtiming · velocity · ghosts · gate; capped by Groove max %)

GENRES

- Dub → Disco → House → Techno → Trip-Hop → Hip-Hop → Jungle → UK Garage → Dubstep
- Alt scrub LEDs: continuous IR→UV spectrum (shared palette)

BUTTONS

- **Short** — Mute (notes off)
- **Shift+Tap** — Bass fill into next bar's chord (pedal break at high Density); white button LED
- **Shift+Hold** — Bass solo (+1–2 oct), re-rolls each bar; resolves on the next downbeat
- **Long** — Next Voice (flash = voice color)
- Previous Voice: Configurator only

JACK PARAMS

- Jack: CV Out (pitch V/Oct) · CV In Density · CV In Feel · CV In Reset
- One enum — a CV In destination and CV Out were never live at once
- Range, V/Oct, CV Att
- Filter CC — cutoff number (0 = off; 74 is typical); brightness = genre base + Voice bite + accent dynamics, lifted by fill / solo
- Groove max % carries the swing direction in its sign — negative swings the offbeats early
- High Density + Feel: genre ornaments (≤ 3 strokes/onset) — Voice shapes repeat, approach, ghost or octave pickup; filter CC only on the main strike

VOICES / LEDS

- Order = historical era: bebop → Motown → P-Funk → fusion → dub duo → alt-funk → quirk
- **Mingus** Violet — chromatic neighbors
- **Jamerson** Orange — pocket root/fifth
- **Bootsy** Pink — funk ghosts + octave drops
- **Jaco** Cyan — melodic approaches + leaps
- **Robbie** Green — dub pocket, sustained / sparse
- **Flabba** Lime — roots walk, roomy gates
- **Flea** Red — staccato + aggressive jumps
- **Claypool** Yellow — quirky leaps + chromatic nudges
- Button: genre hue in play; Long flash = voice color; fill/solo = white (dim = pedal break); hits duck Mid→Low

Manual. Genre MIDI bass on the global clock, sharing its nine genres with Grooves and Chord Vamp. Every sequenced hit retriggers with its own velocity and gate — including repeated pitches — so ornaments and ghosts stay audible. At high Density and Feel, genre-weighted doubles, flams, triplets and rolls add up to two monophonic sub-strokes per written onset (repeat, approach, ghost or octave pickup by Voice); fills and solos lean harder, filter CC coalesces on the main strike only. Phrases run eight bars in AA B A' form: the motif repeats while the harmony walks the genre's tropes, bars 5–6 answer, bar 7 ornaments, bar 8 breathes. At low Feel the line stays locked; raising it moves approaches, ghosts and octave punches from bar to bar — pickups appear before downbeats, soft notes drop out for air, ghosts turn into dead notes. Pocket Voices stay sparse in Jungle and UK Garage, busy ones thin out in Dub and Techno. Shift+Tap walks a fill toward the next bar's chord and lands its leading tone on the downbeat, the Voice picking the contour; at high Density it becomes a quiet held-root break. Shift+Hold lifts the register for a solo that re-rolls every bar while held and resolves on the next downbeat. Follow device tonic (on by default) turns the device Tonic into a live transpose, so Bassment changes key with Contura, Chord Vamp, Venn and Arp de Lévy on the next bar line while keeping Root's octave. Follow device scale does the same for Scale and ships off, because the scale is part of the genre character.

FADERS

- **Main** — interval width (stepwise ↔ 2–3 octave leaps across the pool)
- **Alt** (Shift) — phrase length only (3–28 steps)
- **Third** (Btn hold) — note density (sparse rests ↔ continuous; audible mid)

BUTTONS

- **Short** — mute / unmute
- **Shift+Short** — octave span 1→2→3→4
- **Long** — next scale set
- **Shift+Long** — previous scale set

SCALE SETS / LEDS

- Flat list of named 12-TET sets (Ionian...Folk) — conventional interval-pattern labels, not cultural claims
- Follow device tonic (default on); Follow device scale uses the global Key mask instead of the selected set
- Per-set melodic feel (contour / leap / sustain / ornament) — expressivity is not a fader
- Ornaments = short grace, turn or repeat from feel + phrase position — not genre clichés; off when Division is too fine
- Button hue cycles by scale index · Top = gate · Bottom = pitch height · Division via config (default 1/8)
- Jack = CV Out (pitch) · CV In Density · CV In Interval · CV In Reset — one enum, since a CV In destination and CV Out were never live at once; CV Att scales input

Manual. Generates melodic contour phrases over selectable 12-TET pitch-class sets, anchored to the device quantizer tonic. Phrase starts and endings pull harder toward the tonic (cadence grammar); mid-phrase follows each set's ScaleFeel. Scale feel also drives brief ornaments — grace neighbours, turns or echoes — when the division leaves enough MIDI space (disabled on the finest grids). Scale-set names are conventional labels for interval patterns (Western modes and other named collections on equal footing). They are not claims about living musical practice or authentic intonation. Needs a running clock. Jack = CV Out (pitch, 1V/oct) or CV In (Density / Interval / Reset + CV Att), set in the Configurator. Gates via MIDI note on/off. Phrases mix short, medium, and longer note lengths. **Follow device tonic** (default on) turns the device Tonic into a live transpose: hold the Scene button and move Fader 5 and Contura moves with Bassment, Chord Vamp, Venn and Arp de Lévy. The note pool is rebuilt on the change, so the cadence resolves in the new key; it takes effect at the next phrase start. **Follow device scale** (default off) swaps the Scale set for the device Scale.

FADERS

- **Main** — input trim on channel 0; attenuverter (CV) or threshold (Gate/Trigger) on channels 1–3
- **Alt** (Shift) — input offset on channel 0; output offset (CV) or hysteresis (Gate/Trigger) on channels 1–3
- **Third** (Btn hold) — input slew on channel 0; output slew (CV), minimum gate length (Gate) or pulse length (Trigger) on channels 1–3
- **Channel 0 while the internal LFO runs** — the three layers become morph, LFO speed and skew instead of trim, offset and slew

BUTTONS

- **Channel 0 short** — freeze the conditioned input value
- **Channel 0 Shift + short** — while the internal LFO runs: free-running or clock-synced (the button flashes when sync engages)
- **Channels 1–3 short** — mute/unmute that output (Shift not held); fader scrub while the button is held cancels the tap
- **Channels 1–3 Shift + long** — cycle that out through CV → Gate → Trigger; the new mode hue appears immediately and the configurator follows

SIGNAL / LEDS

- One CV input on channel 0, three outputs B/C/D on channels 1–3
- Five equidistant open-spectrum hues from blue to orange, one per operating mode: channel 0 on CV in, channel 0 on the internal LFO, then CV, Gate and Trigger on the outs
- Channel 0 is blue while CV in is active and one step warmer when the internal LFO runs; each out takes the hue of its current mode, so a mode swap shows up immediately
- With nothing patched into the input, channel 0 becomes an internal morphing LFO that feeds B/C/D — *Source* forces CV In or Internal LFO instead of that auto fallback
- *LFO Speed* shifts the whole speed range to Slow or Slowest
- CV mode uses the configured Range; Gate and Trigger modes drive the jack as a digital GPO and ignore Range
- Defaults: B = CV, C = Gate, D = Trigger (± 5 V on the CV path)
- Channel 0 LEDs dim with the active source amplitude in the source hue
- CV outs dim with the shaped output level; Gate/Trigger meter the conditioned input while low and flash full when high
- Button LEDs use the same mode hues and breathe with their signal level: channel 0 stays bright when frozen; channels 1–3 turn off when muted

Manual. One CV in, three shaped outs. Each out is independently CV, Gate or Trigger: CV gets attenuverter / offset / slew, Gate and Trigger get threshold / hysteresis / pulse length. Shift + long press on an out cycles it through the three modes right on the device, and the change is stored as a parameter, so the configurator stays in sync. Channel 0 freezes the conditioned input; B/C/D mute. With nothing patched into the input, channel 0 turns into a morphing LFO and drives B/C/D on its own — the same wave engine as Super LFO, with morph, speed and skew on the three channel 0 fader layers and Shift + short press for clock sync. The **Source** parameter overrides that fallback if you would rather force CV In or Internal LFO, and **LFO Speed** moves the whole rate range down to Slow or Slowest. LEDs use five equidistant hues along the open spectrum from blue to orange, one per operating mode. Channel 0 is blue while CV in feeds the outs and one step warmer once the internal LFO takes over; the outs take the remaining three steps by mode — CV, then Gate, then Trigger in orange — so a mode swap is visible the moment it lands. All four channels dim with signal amplitude.