SMARTCARE AI

Wi-Fi Troubleshooting Support Manual

A clear, structured knowledge base for customer-support agents and RAG applications

Purpose
This manual provides practical, customer-friendly checks for common Wi-Fi connection problems on Windows laptops. It is written as an original learning and support resource for the SmartCare AI prototype.

How to use this document
A support agent should identify the symptom, try the safest relevant checks first, record what was attempted, and ask the customer whether the issue improved. Do not claim a fix worked until the customer confirms it.

Version 1.0 | Prepared for educational prototype use | English

1. Start by identifying the problem

Before suggesting a fix, ask the customer a few focused questions. The answers help distinguish a laptop problem from a router, internet-service, or account problem.

Useful questions

• Can other devices, such as a phone, connect to the same Wi-Fi network?

• Can the laptop see the Wi-Fi network name, or is the network missing?

• Does the laptop connect but show “No internet” or “Connected, no internet”?

• Does the connection disconnect every few minutes, or does it never connect?

• Did the problem begin after a Windows update, driver update, router change, or password change?

• Are you using Windows 10 or Windows 11?

Interpretation: If every device has no internet, investigate the router or internet service first. If only one laptop is affected, focus on that laptop's Wi-Fi settings and network adapter.

2. Basic checks

2.1 Check Wi-Fi is turned on

1. Select the network or Wi-Fi icon in the Windows taskbar.

2. Make sure Wi-Fi is switched on.

3. If Airplane mode is on, switch it off.

4. Check whether the expected Wi-Fi network appears in the available networks list.

2.2 Move closer to the router

Move the laptop closer to the wireless router and test again. Walls, floors, metal objects, and distance can weaken the signal. If the connection improves nearby, the issue may be related to wireless coverage or interference.

2.3 Restart the laptop and router

1. Save work and restart the laptop.

2. If it is safe and permitted, unplug the router's power cable.

3. Wait about 30 seconds, reconnect power, and allow the router to finish starting.

4. Reconnect the laptop to Wi-Fi and test a website.

Important: Do not press the router's factory-reset button as a routine troubleshooting step. A factory reset can erase the network name, password, and provider settings. Only do this when the internet provider or network administrator instructs the customer.

3. Common problem: Wi-Fi network is missing

Use this section when the customer cannot see their Wi-Fi network in the available networks list.

1. Confirm that Wi-Fi is enabled and Airplane mode is disabled.

2. Move closer to the router and check whether the network appears.

3. Restart the laptop and router if appropriate.

4. Check whether another device can see the same network.

5. If no device can see the network, check the router's wireless settings or contact the internet provider.

6. If other devices can see it but the laptop cannot, investigate the laptop's wireless adapter and driver.

Escalate when: The Wi-Fi adapter is missing from Windows, the laptop has physical damage, or the network remains unavailable after basic checks.

4. Common problem: Connected, but no internet

Use this section when Windows says the laptop is connected to Wi-Fi but websites or online apps do not work.

1. Check whether other devices on the same Wi-Fi network can access the internet.

2. If no devices can access the internet, restart the router if permitted and check for an internet-service outage.

3. If other devices work, disconnect the laptop from Wi-Fi and reconnect.

4. Open a different website or app to check whether the issue affects only one service.

5. Run the Windows network troubleshooter, if available in the customer's Windows version.

6. If the problem continues, collect the exact Windows network status and error message before escalating.

Do not assume: “Connected” only confirms a Wi-Fi link. It does not guarantee that the router has working internet access.

5. Common problem: Wi-Fi disconnects repeatedly

Use this section when the laptop connects successfully but loses its Wi-Fi connection repeatedly.

1. Check whether the disconnections happen on other devices too.

2. Test the laptop near the router to check whether weak signal is involved.

3. Restart the laptop and router if appropriate.

4. If the issue affects only this laptop, note whether it began after a recent Windows or driver update.

5. Check Windows Update for available updates.

6. Use Device Manager to inspect the wireless network adapter for warning symbols. If a driver update is needed, use Windows Update or the laptop manufacturer's official support site.

7. After any change, reconnect and observe whether the disconnections continue.

Safety: Avoid downloading drivers from unofficial driver-download websites. Do not uninstall a working network driver unless you have a recovery plan or support guidance.

6. Common problem: Incorrect Wi-Fi password

1. Confirm the correct network name (SSID). Similar network names may belong to different routers.

2. Ask the customer to enter the current Wi-Fi password carefully, checking uppercase and lowercase letters.

3. If the password was recently changed, remove the saved network and reconnect using the new password.

4. If the customer does not know the current password, direct them to the router owner or network administrator. Do not guess or attempt to bypass network security.

7. Forget and reconnect to a Wi-Fi network

Use this when the laptop may have saved an old password or outdated network settings.

1. Open Windows Settings.

2. Go to Network & internet, then Wi-Fi, and open Manage known networks (the exact labels may vary by Windows version).
3. Select the affected network and choose Forget.
4. Return to the Wi-Fi list, select the network, and enter the current password.
5. Test the connection.

For a managed work or school laptop, check with the IT administrator before removing a saved network profile.

8. When to consider a network reset

A Windows network reset is a later troubleshooting step, not the first step. It removes and reinstalls network adapters and may reset networking settings. VPN software or other networking tools may need to be configured again.

• Try basic checks and reconnecting to the network first.

• Explain the possible effects to the customer before proceeding.

• For work or school devices, obtain IT approval.

• Follow the instructions for the customer's Windows version and record that a reset was performed.

9. Information to collect before escalation

If the issue is not resolved, record the following details for the next support person.

• Customer ID and device make/model (avoid collecting unnecessary personal data).

• Windows version, if known.

• Exact symptom and any displayed error message.

• Whether other devices can connect to the same Wi-Fi.

• Whether the laptop can see the network name.

• Approximate time and frequency of disconnections.

• Troubleshooting steps attempted and the result of each step.

• Whether the problem started after a recent change.

10. Support-agent decision guide

Observed result	Likely direction for investigation
No devices can access the internet	Router, modem, or internet-service issue
Other devices work; one laptop cannot connect	Laptop Wi-Fi settings or adapter
Laptop cannot see any Wi-Fi networks	Wi-Fi disabled, adapter, driver, or hardware
Laptop connects but no websites work	Internet access, DNS, proxy, or service-specific issue
Connection improves near router	Signal strength, distance, or interference
Only one website/app fails	That service or application may be the issue

11. Memory notes for SmartCare AI (Hindsight)

The knowledge in this manual is general support knowledge. It belongs in the RAG knowledge base. Hindsight should store customer-specific facts and outcomes from conversations, not copies of this manual.

Good memory examples

• Customer C101 reported repeated Wi-Fi disconnections on a Windows laptop.

• Router restart was attempted on 7 November and did not resolve the issue.

• The customer confirmed that updating the wireless adapter driver resolved the issue.

• The customer prefers short, step-by-step instructions.

Record outcomes accurately

Store a solution as successful only after the customer confirms it worked or a trusted diagnostic confirms the result. If the outcome is unknown, store it as “not yet confirmed.” Keep customer memories scoped to the correct customer ID and follow your organization's privacy and retention rules.

12. Suggested RAG metadata

When ingesting this manual, attach metadata to each chunk so the application can retrieve and cite the relevant section.

• source: SmartCare_WiFi_Troubleshooting_Manual.pdf

• topic: wifi_missing / no_internet / frequent_disconnect / password / network_reset

• section: the numbered section heading

• document_type: troubleshooting_guide

• version: 1.0

13. Source and usage note

This is an original, simplified educational support guide prepared for a SmartCare AI prototype. It is not an official Microsoft publication and does not replace the laptop manufacturer's instructions, an organization's IT policy, or advice from an internet service provider.

For current Windows-specific instructions, consult Microsoft's official support article: Fix Wi-Fi connection issues in Windows.

Before using this guide with real customers, review the steps for your supported Windows versions and service environment.