NodeID part	suffix	Meaning
OpenLCB vnode	0xFFFF	Emergency stop of all operations
OpenLCB vnode	0xFE00	Ident button combination pressed
	0xFDnn	Indicate capabilities (nn is the capability)
OpenLCB vnode	0xFD01	Node uses Display Protocol to make one or more displays available

xxxxxx means any node ID

xxxxxx	0xFFF8	Node recorded a new log entry (sample only)