

# User's Manual



Particle Analyzer



PN A51387AB March 2010





Multisizer™ 4
Particle Analyzer
PN A51387AB (March 2010)

Copyright © 2010 Beckman Coulter, Inc.

All rights reserved. No part of this document may be reproduced or transmitted in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, without prior written permission from Beckman Coulter, Inc.

Find us on the World Wide Web at: www.beckmancoulter.com

# **Table of Contents**

# Dimensions and Weight, xvii Environmental Conditions, xviii Operational Parameters, xviii Regulatory Compliance, xix Before You Start: Warnings and Cautions, xix Warnings, xix Electrical Warnings, xx Chemical Warnings, xx Mechanical Warnings, xx Fire Warnings, xx Cautions, xxi Electrical Cautions, xxi Chemical Cautions, xxi Analyzer Overview, 1-1 Overview, 1-1 New Multisizer 4 Features, 1-1 Bar Code Reader, 1-1 Sample Platform Beaker and Accuvette® Guides, 1-1 Automatic Stirrer Positioning, 1-1 Automatic Blockage Detection, 1-2 Extended Dynamic Range, 1-2 Multisizer 4 Components, 1-2 Power ON/OFF Switch, 1-3 Sample Compartment, 1-3 Control Panel, 1-3

Introduction, xv

**CHAPTER 1:** 

About the Multisizer 4, xv

Multisizer 4 Specifications, xvii

Electrolyte Jar, 1-3 Waste Jar, 1-4

Electrolyte and Waste Jar Fluid Levels, 1-4

Installing and Removing the Electrolyte and Waste Jars, 1-4

How the Multisizer 4 Works, xv

Displaying Multisizer 4 Data, xvii Multisizer 4 Components, xvii

Particle Size Determination, xvi

```
Control Panel, 1-5
    Disabling the Control Panel Buttons, 1-5
    Viewing Control Panel Actions in Run Information, 1-6
    ON Light, 1-6
    Analyzing and Attention Lights, 1-6
    Stir ON Button, 1-6
    Stirrer Direction Controls, 1-6
    Stirrer Speed Controls, 1-7
    Bar Code Reader, 1-7
Sample Compartment, 1-8
    Aperture Tube, 1-8
    Aperture Tube Knob, 1-8
    Sample Platform, 1-9
    Reversing the Sample Platform, 1-10
    Platform Release, 1-11
    External Electrode, 1-11
    Stirrer, 1-11
    Particle Trap, 1-12
    Status and Illumination Lights, 1-12
Accessories, 1-13
    Beakers, 1-13
    Accuvette® STs, 1-13
    Calibrators, 1-13
    Aperture Tubes, 1-14
         Handling Aperture Tubes, 1-14
Cleaning the Aperture Tube, Beakers, and Accuvette® STs, 1-15
Cleaning the Analyzer, 1-16
Pre-Filtering the Electrolyte and Cleaning Fluid, 1-17
Starting the Analyzer, 1-18
Preparing the Analyzer for Sample Runs, 1-18
Software Overview, 2-1
Opening the Multisizer 4 Software, 2-1
Connecting the Software to the Analyzer, 2-1
    Connecting Analyzer and Software on Startup, 2-1
    Connecting to the Analyzer Using the Software Main Menu, 2-2
    Disconnecting from the Analyzer Using the Software Main Menu, 2-2
Multisizer 4 Software Window, 2-2
Main Menu, 2-3
Main Toolbar Buttons, 2-5
    Default Main Toolbar Configuration, 2-5
    Main Toolbar Buttons: First Group, 2-6
    Main Toolbar Buttons: Second Group, 2-6
    Main Toolbar Buttons: Third Group, 2-7
```

**CHAPTER 2:** 

# Status Panel, 2-8 Viewing Area, 2-10 Run Menu, 2-10 Instrument Toolbar Buttons, 2-11 Instrument Toolbar: Run Buttons, 2-11 Instrument Toolbar: Reset Button, 2-12 Instrument Toolbar: Fluid Control Buttons, 2-12 Status Bar, 2-12 Installing and Calibrating an Aperture Tube, 3-1 Overview, 3-1 When to Install a New Aperture Tube, 3-1 Selecting an Aperture Size, 3-1 Installing an Aperture Tube, 3-2 Using Small Aperture Tubes (20 µm and 30 µm), 3-4 Handling Small Aperture Tubes, 3-4 Unblocking small aperture tubes, 3-5 Reducing Environmental Factors That Create Noise, 3-5 Create a dust-free lab environment, 3-5 Reduce acoustic noise levels, 3-5 Reduce vibration, 3-5 Block electrical interference, 3-5 Pre-Filtering the Electrolyte and Cleaning Fluid, 3-5 Cleaning the Analyzer Prior to Using a Small Aperture, 3-6 Cleaning System Components and Accessories, 3-6 Small Aperture Noise Profiles, 3-7 Using Appropriate Current and Gain Settings, 3-9 Storing Small Aperture Tubes, 3-9 Calibrating the Aperture, 3-10 Choosing the Calibrator Size, 3-10 Nano-Size Particle Calibration Standards, 3-11 Selecting Calibration Options, 3-11 Preparing the Analyzer for Calibration, 3-12 Running the Calibration, 3-13 Pausing or Stopping Calibration, 3-14 Completing the Calibration Run (Accepting the Kd), 3-15 Obtaining the Mean Kd, 3-16 Example, 3-17 Updating the Mean Kd Value, 3-17 Verifying the Calibration, 3-18 Saving the Calibration File, 3-21 The Change Aperture Tube Wizard, 3-21 Step 1: Select the new aperture tube, 3-23

Main Toolbar Buttons: Fourth Group, 2-8

**CHAPTER 3:** 

**CHAPTER 4:** 

```
Entering and Editing Aperture Tube Information, 3-23
    Step 2: Remove the Currently Installed Aperture Tube, 3-26
    Step 3: Install the New Aperture Tube, 3-26
    Step 4: Place a Beaker of Clean Electrolyte on the Platform, 3-27
    Step 5: Close the Door, 3-27
    Step 6: Fill the System, 3-28
    Step 7: Adjust the Metering Pump, 3-28
    Step 8: Set Current and Gain, 3-28
    Step 9: Measure Noise Level, 3-30
    Step 10: Verify Calibration, 3-31
    Step 11: All Done, 3-33
Running a Concentration Control Sample, 3-33
    Setting Control Sample Options, 3-33
    Running a Concentration Control Sample, 3-34
Selecting Analysis Settings: SOM and SOP, 4-1
Definitions: SOM, Preferences, and SOP, 4-1
Using a Standard Operating Method (SOM), 4-2
    Using the Create SOM Wizard, 4-2
    Standard Operating Method: Description, 4-3
         Creating Automatically Generated Analysis File Names, 4-4
         Using File Name Template Codes, 4-5
         Using Unique Numbers in Analysis Files, 4-6
         Write-Protecting Saved Analysis Files, 4-6
    Standard Operating Method: Control Mode, 4-6
    Standard Operating Method: Run Settings, 4-8
    Standard Operating Method: Stirrer Settings, 4-10
         Copying Manual Stirrer Settings, 4-11
    Standard Operating Method: Threshold, Current and Gain, 4-13
         Using the Current & Gain Tab in the Edit the SOM Window, 4-14
    Standard Operating Method: Pulse to Size Settings, 4-15
    Standard Operating Method: Concentration Information, 4-17
    Standard Operating Method: Blockage Detection, 4-18
    SOM Wizard: Summary of Settings, 4-21
    Saving an SOM to a File, 4-22
    Editing SOM Settings, 4-23
    The SOM Settings (SOP Loaded) Window, 4-25
    Differences between the SOM Wizard and Edit the SOM windows, 4-25
    Loading an SOM, 4-25
Using a Standard Operating Procedure (SOP), 4-26
    Creating an SOP, 4-26
    Loading an SOP, 4-28
```

# **CHAPTER 5:** Setting View and Print Preferences, 5-1

Creating a Preferences File, 5-1
Preferences: Printed Report, 5-2
Printing Sample Information, 5-3

```
Selecting Graphs, Statistics, and Data for Printing, 5-4
          Including a Size Distribution Graph in Printed Reports, 5-4
          Including Statistics in Printed Reports, 5-6
          Including Averaged Statistics in Printed Reports, 5-6
          Including a Comparison to Sample Specifications in Printed Reports, 5-6
          Including Overlay Statistics in Printed Reports, 5-6
          Including a Listing in Printed Reports, 5-7
          Including Interpolation Data in Printed Reports, 5-8
          Including Size Trend Information in Printed Reports, 5-10
          Including Size Statistics in Printed Reports, 5-12
          Including Filtration Efficiency in Printed Reports, 5-12
          Including Pulse Data in Printed Reports, 5-12
          Including Blockage Monitor Data in Printed Reports, 5-14
          Setting the Print Order for Reports, 5-15
     Preferences: Statistics, 5-15
          Using Statistical Category Names, 5-17
    Preferences: Averaging and Trend, 5-17
    Preferences: Export, 5-19
     Preferences: Page Setup, 5-20
    Preferences: Graph Options, 5-21
     Preferences: Fonts and Colors, 5-21
     Preferences: View Options, 5-23
     Reviewing Your Preferences Settings, 5-24
Saving a Preferences File, 5-25
Automatically Updating the Default Preferences File, 5-26
```

# **CHAPTER 6:** Analyzing a Sample, 6-1

Analyzing a Sample, 6-1 Analyzer Checklist, 6-1 Selecting Analysis Settings, 6-1 Loading an SOM, 6-2 Loading Preference Settings, 6-2 Loading an SOP, 6-2 Removing an SOP, 6-3 Verifying Preference Settings, 6-3 Verifying SOM Settings, 6-4 Entering Sample Information, 6-5 Editing Sample Information, 6-7 Using Sample Specifications, 6-7 Editing Sample Specifications, 6-9 Including Sample Specifications in a Printed Report, 6-9 Viewing Sample Specifications, 6-9 Editing Size Data, 6-10 Running an Analysis, 6-10 Sample Analysis Variations, 6-12 Running a Multi-Tube Overlap Analysis, 6-12 Determining Particle Concentration Using Time Mode, 6-13 **CHAPTER 7:** 

Using Blank Runs, 6-14

Running a Blank Analysis, 6-14

Enabling Blank Subtraction for Analysis Runs, 6-15

Disabling Blank Analysis Subtraction, 6-15 Loading a Blank Run into an Open Analysis File, 6-15 Removing a Blank Run from an Open Analysis File, 6-15 Working with Analysis Files, 7-1 Setting File Preferences, 7-1 Changing Print Settings, 7-1 Viewing Analysis Files, 7-2 Changing the Display of an Open File, 7-2 Run Menu Behaviors, 7-2 Graphs, 7-2 Listings and Interpolation, 7-2 Viewing Graphs, 7-2 Graph Menu, 7-2 Calculate Menu, 7-3 Display Menu, 7-3 Using Cursors in Graphs, 7-3 Viewing Listings, 7-4 Listing Menu, 7-4 Size Column Format, 7-4 Pulses Column Format, 7-5 Blockage Monitors Column Format, 7-6 Calculate Menu, 7-6 Viewing Interpolations, 7-6 Changing the Column Display, 7-8 Viewing Statistics, 7-8 Comparing Statistics to Sample Specifications, 7-9 Comparing an Analysis to a Standard Run, 7-9 Converting Pulses to Size, 7-9 Converting Pulses to Size Between Cursors, 7-11 Converting Pulses to Size for the Widest Distributions, 7-11 Printing Report(s) for One or More Analysis Files, 7-12 Printing a Report of an Open Analysis File, 7-14 Printing with Current Analysis Settings, 7-15 Saving an Analysis File, 7-16 Saving Analysis Data Automatically, 7-16 Saving Analysis Data Manually, 7-17 Opening a Saved Analysis File, 7-17 Importing a File, 7-18 Working with Multiple Analysis Files, 7-19 Using Overlay Files, 7-19 Saving an Overlay File, 7-20 Opening a Saved Overlay File, 7-20 Averaging Analysis Files, 7-20 Opening Files for Averaging, 7-21

Adding Data to an Average, 7-21
Saving Averaged Files, 7-21
Opening a Saved List of Averaged Files, 7-22
Creating a Size Trend Analysis, 7-22
Opening Files for a Size Trend, 7-23
Adding a File to a Size Trend, 7-23
Saving a Size Trend, 7-23
Opening a Size Trend, 7-24
Merging Runs, 7-24
Saving a Merged Run, 7-25
Moving Between Multiple Files (Cursor Menu and Shortcut), 7-25

Filtration Efficiency, 7-26

Saving a Filtration Efficiency Analysis, 7-26 Including Filtration Efficiency in a Printed Report, 7-26

# **CHAPTER 8:** Configuring Software and Security, 8-1

Configuration Overview, 8-1 Configuration Options, 8-1

Security Modes and Configuration, 8-1

Customizing Main Menus, 8-3

Customizing Run Menus, 8-5

Customizing Toolbars, 8-7

Customizing the Status Panel, 8-8

Customizing Sample Info Names, 8-10

Customizing Recent File and Folder Lists, 8-11 Selecting a New Folder from the Recent Folder List, 8-12 Adding a Folder to the Recent Folders List, 8-12

Customizing the Save Preferences Default Setting, 8-13

Choosing a Language, 8-13

Multisizer 4 Configuration Options, 8-14

Bar Code Reader Configuration Options, 8-15

Customizing Security Settings, 8-16

Logging In, 8-18 Logging Out, 8-18

Changing Your Password, 8-18

Administrator Menu Options, 8-19 Customizing User Privileges, 8-20

# **CHAPTER 9:** Troubleshooting, 9-1

Resolving Common Problems, 9-1 Reducing Noise, 9-1 Measuring the Noise Level, 9-2

**CHAPTER 10:** 

Adjusting the Metering Pump, 9-3 Setting the Vacuum Regulator, 9-3 Measuring Gain Stage Offsets, 9-3 Setting Custom Measurement Intervals, 9-4 System Error: Unable to Measure Gain Stage Offsets, 9-4 Resolving Error Messages on Software Startup, 9-5 Viewing Advanced Multisizer Settings, 9-6 Waste Tank Settings, 9-6 Calibrating Waste Tank Sensors, 9-6 Vacuum Settings, 9-7 Flow Rate Error Messages, 9-8 Adjusting Volumetric Flow Settings, 9-8 Fill, Flush, and Drain Settings, 9-9 Viewing System Flush Time, 9-9 Draining the System, 9-11 Aperture Resistance Settings, 9-12 Calibrating the Electrolyte and Waste Jars, 9-13 Working with Field Service, 9-15 Requesting Service and Technical Support, 9-15 Identifying the Instrument, 9-15 Updating Firmware and FPGA Software, 9-16 Viewing the Instrument Schematic, 9-17 Viewing the Error Log, 9-18 Opening Service Mode, 9-18 Regulatory Compliance, 10-1 Regulatory Compliance, 10-1 Electronic Signatures (21 CFR Part 11), 10-1 Electronic Records, 10-1 FDA Requirements, 10-1 Security Controls, 10-2 Electronic Controls, 10-2 System Validation, 10-2 Audit Trail, 10-3 File History and Audit Trail, 10-3 Accessing File History, 10-3 Setting Audit Trail Options, 10-4 Maintaining Electronic Signatures, 10-5 Generating Electronic Signatures, 10-5 Applying Electronic Signatures, 10-6 Additional Security Features, 10-7 Starting the Multisizer 4 with Security Enabled, 10-7

Purging the Metering Pump, 9-2

# List of Figures

1.1	Multisizer 4 Analyzer Components, 1-3
1.2	Installing the Waste Jar, 1-5
1.3	Control Panel, 1-6
1.4	Sample Compartment, 1-9
1.5	Platform in Loading Position: Beaker Side, 1-10
1.6	Platform in Loading Position: Accuvette® ST Side, 1-11
1.7	Reversing the Sample Platform, 1-11
1.8	Proper Handling of a Small Aperture Tube, 1-15
1.9	Cleaning an Aperture Tube, 1-16
1.10	Closed Circuit Filtration System, 1-17
3.1	Proper Handling of a Small Aperture Tube, 3-4
3.2	Closed-Circuit Filtration System, 3-6
3.3	Cleaning an ST Aperture Tube with a Squeeze Bottle, 3-7
3.4	Noise Profile, Clean System (20 µm aperture), 3-8
3.5	Noise Profile, Contaminated System (20 µm aperture), 3-

# List of Tables

2.I	Main Menu: Drop-Down Menus, 2-4
2.1	Main Toolbar: Buttons (First Group), 2-6
2.2	Main Toolbar Buttons (Second Group), 2-6
2.3	Main Toolbar: Buttons (Third Group), 2-7
2.4	Main Toolbar: Buttons (Fourth Group), 2-8
2.5	Instrument Toolbar: Run Buttons, 2-11
2.6	Instrument Toolbar: Function Buttons, 2-12
3.1	Aperture Sizes, 3-2
3.2	Choosing Calibrator Size, 3-10
3.3	Pausing / Stopping Calibration, 3-15
3.4	Obtaining Mean Kd Value, 3-17
3.5	Verifying Aperture Calibration, 3-22
3.6	Verify Aperture Calibration Window, 3-33
4.1	SOM Wizard (Step 1): Field Descriptions, 4-3
4.2	File Name Generation Codes, 4-5
4.3	Control Mode (Step 2): Selections, 4-7
4.4	Run Settings (Step 3): Entries and Selections, 4-8
4.5	Threshold, Current and Gain (Step 5): Entries or Selections, 4-13
5.1	Printing Sample Information in Reports, 5-3
5.2	Size Graphs Window: Selections, 5-4
5.3	Overlay Statisitcs Options, 5-6
5.4	Interpolation Display Data, 5-9
5.5	Statistics Display Preferences, 5-16
5.6	Preferences Wizard: Set View Options, 5-23
6.1	Copy and Print Preference Settings, 6-3
6.2	Verify SOM Settings, 6-4
6.3	Entering Sample Info for Next Run, 6-6
7.1	Using Cursors in Graphs, 7-3
7.2	Size Interpolation Data, 7-7
7.3	Open Analysis File Print Options, 7-15

# Introduction

### **About the Multisizer 4**

The Beckman Coulter Multisizer™ 4 is a flexible, multi-channel analyzer employing the industry standard Electrical Sensing Zone (ESZ) method, together with state-of-the-art Digital Pulse Processing (DPP) technology to provide both particle sizing and counting within an overall size range of 0.4 µm to 1600 µm. Data is acquired and processed using proprietary Digital Signal Processing (DSP) circuitry and may be archived, displayed, and re-analyzed on any PC equipped with a Pentium® II or similar microprocessor running Beckman Coulter's Multisizer™ 4 software on Microsoft Windows® operating system versions NT 4.0, 2000, or XP. <sup>1</sup>




Figure 1 Multisizer 4 Analyzer

### How the Multisizer 4 Works

The Multisizer 4 uses a unique, mercury-free "isolated piston" system to draw suspensions through the aperture at a steady rate and to meter these liquid volumes precisely enough to measure accurate particle concentrations. The instrument is also equipped with a continuous flow alternative for applications where accuracy of liquid metering is less important or less critical, as well as options that allow the user to define analysis parameters based on elapsed time or particle count.

PN A51387AB XV

<sup>1</sup> All trademarks are the property of their respective owners.

By using the very latest in digital pulse measurement techniques, an entire analysis (which may consist of many thousands of particle pulses) can be stored either in memory or on disk for recall and reprocessing without the need to re-run the sample. Each pulse is stored at maximum resolution so that, for the first time, the genuine resolution of an analysis can be increased up to a hundred-fold in real-time by narrowing the size range of interest, eliminating the need to re-run the sample. The Convert Pulses to Size feature in the software allows measurements from the lowest to the highest possible resolution to be made on just one pass of sample through the aperture.

Storing the individual values of pulse heights means that it is not necessary to predetermine the number of size classes (also called "channels" or "size bins") into which any size distribution can be divided. This choice is at the discretion of the operator and can be chosen either before or after the analysis or even changed during analysis. Any number of channels from 4 up to 400 may represent a partial or full range of an aperture. A smaller number may improve the appearance of a size distribution by reducing statistical scatter in the results, while details in the results may be enhanced by increasing the number of size classes in regions of particular interest. A higher number of channels provides more detail about the size of the particles. The advanced digital electronics used in the Multisizer 4 allow the number of channels to be changed in real time without losing any of the information acquired with other channel spacing.

Results can also be stored in a fully processed (abridged) form that conserves disk space. Although in this form the raw pulse data is lost and cannot be re-analyzed at a different resolution, the processed results still can be enlarged, or a region of interest selected, using the Zoom facility in the software.

Both number data and size distributions are corrected by proprietary algorithms for the occurrence of multiple particle passage (coincidence) in the aperture. An indicator provides real time particle concentration in the analysis suspension. The Multisizer 4 software includes a pulse monitor window that offers a guide to the electronic behavior of the aperture. The time base of this window can be adjusted to show either pulse concentration or the shapes of individual pulses. Electronic pulse editing facilities ensure that very narrow size distributions can be highly resolved by minimizing the effect of line width broadening in the sensing aperture.

### **Particle Size Determination**

In industrial applications, historically it has been common practice to report particle "size" in linear terms, and so the volume of a particle is converted into an equivalent spherical diameter (ESD). In this case, the "particle size" is the diameter of a sphere whose volume is equal to that of the particle. The biological and biomedical sciences traditionally (when reporting the results of cellular analyses) are more accustomed to using actual volumetric metric units, and in these applications "particle size" is usually presented in terms such as femtoliters or cubic microns (fL, or  $\mu m^3$ ).

Particle surface areas can be calculated, with the assumption that the surface area is that derived from (and equates to) the surface area of a perfect sphere whose ESD is the same as that of the volume of the particle.

The International Standard ISO 13319 Determination of Particle Size Distributions—Electrical Sensing Zone Methods describes and gives guidance on the measurement of the size distribution of particles using the Coulter Principle.

XVÍ PN A51387AB

# **Displaying Multisizer 4 Data**

The Multisizer 4 can display data graphically as number, volume, mass, and surface area size distribution plots, or as tables of values versus size. Both display types can show data as differential or cumulative frequencies. Full data reduction facilities are included for statistical and trend analysis, with export and import capabilities to text and spreadsheet programs via disk files or the Windows Clipboard. The Multisizer 4 can print results using any printer compatible with the Windows platform and drivers installed on the system.

A report facility allows results to be combined with sample information in a user-selectable way to produce a systematic reporting configuration. Report formats can be individually named for ease of archiving and retrieval. Number and date formats are supported in both conventional as well as in ISO 9276-1 forms.

# **Multisizer 4 Components**

The Multisizer 4 system comprises an integrated fluid handling and pulse processing unit (the Analyzer Module) and a personal computer with a monitor with a minimum resolution of 1024 by 768. A keyboard, mouse and an ink-jet printer are also part of the system.

# **Multisizer 4 Specifications**

Multisizer 4 dimensions and weight, environmental conditions, and operational parameters are listed in this section.

# **Dimensions and Weight**

Weight, dimensions and power (excluding computer):

- *Unpacked weight:* 45 kg (99 lb)
- Width: 45 cm (18 in)
- Depth: 60 cm (24 in)
- Height: 60 cm (24 in)
- Input Voltage within Set Ranges: 100–120 VAC; 230–240 VAC ± 10%; single phase
- Supply Frequency: 47 to 63 Hz inclusive
- Power: Less than 55 VA (watts)
- Fuse types: 240 V, IEC ( $5 \times 20 \mu m$ ), Time delay (T), 3.15 A

#### NOTE

The use of other fuse types may result in damage to the instrument.

PN A51387AB XVII

### **Environmental Conditions**

- This instrument is safe for indoor use only.
- Installation category: II
- Pollution degree: 1
- Operating Temperature: 5°C to 40°C
- Relative Humidity: 10% to 80% without condensation
- Altitude: Up to 2000 m (5500 ft). Above 7300 m (20,000 ft) unpressurized transport may damage the monitor.
- *Electrolyte Solutions:* All aqueous and non-aqueous electrolyte solutions devised for use with aperture technology are suitable for use with the Multisizer 4. Electrolytes should be compatible with glass, fluoropolymers, fluoroelastomers, and stainless steel.

# **Operational Parameters**

- Particle Size Range: 0.4 µm to 1600 µm in diameter
- *Volume:*  $0.034 \, \mu m^3$  to  $2144.66 \times 10^6 \, \mu m^3$

### **NOTE**

The upper size limit is dictated by solution viscosity and particle density, and the lower limit by the aperture size, solution conductivity, and environmental conditions.

- Displayable size units: µm, µm<sup>2</sup>, µm<sup>3</sup>, fL
- Number of channels: Pulse data is stored in unchannelized form and can displayed in up to 400 size classes for any selected size range. The number of channels and their range can be reprocessed as necessary.
- Digital pulse processor: High-speed digitalization of the signal allows the definition of pulses by a number of characteristics. This information may be used at a later time to recalculate the size distribution using different pulse parameters.
- Pulse data: Up to 525,000 pulses per analysis
- Linearity for 2% to 60% of aperture diameter (10% to 80% of aperture diameter for a 2000-μm aperture):
   ± 1% for diameter, ± 3% for volume
- Aperture tube sizes:  $20-\mu m$  to  $2000-\mu m$  apertures (nominal sizes). Each size allows the measurement of particles in a range of 2% to 80% of aperture diameter, except the  $2000-\mu m$  aperture, which is capable of 10% to 80% of aperture diameter.

XVIII PN A51387AB

Aperture (Nominal Diameter, µm)	Diameter Range (μm)			Volume Range μm³ or fL		
	Total	Standard	Extended	Total	Standard	Extended
20*	0.4–16	0.4–12	12–16	0.034-2.14×10 <sup>3</sup>	0.034–905	905–2.14×10 <sup>3</sup>
30*	0.6–24	0.6–18	18–24	0.113-7.24×10 <sup>3</sup>	0.113-3.05×10 <sup>3</sup>	3.05×10 <sup>3</sup> –7.24×10 <sup>3</sup>
50	1.0–40	1.0–30	30–40	0.524-33.5×10 <sup>3</sup>	0.524-14.1×10 <sup>3</sup>	14.1×10 <sup>3</sup> –33.5×10 <sup>3</sup>
70	1.4–56	1.4–42	42–56	1.44-92.0×10 <sup>3</sup>	1.44–38.8×10 <sup>3</sup>	38.8×10 <sup>3</sup> –92.0×10 <sup>3</sup>
100	2.0-80	2.0–60	60–80	4.19–268×10 <sup>3</sup>	4.19–113×10 <sup>3</sup>	113×10 <sup>3</sup> –268×10 <sup>3</sup>
140	2.8–112	2.8–84	84–112	11.5-736×10 <sup>3</sup>	11.5-310×10 <sup>3</sup>	310×10 <sup>3</sup> –736×10 <sup>3</sup>
200	4.0–160	4.0–120	120–160	33.5–2.14×10 <sup>6</sup>	33.5–905×10 <sup>3</sup>	905×10 <sup>3</sup> –2.14×10 <sup>6</sup>
280	5.6–224	5.6–168	168–224	92.0-5.88×10 <sup>6</sup>	92.0-2.48×10 <sup>6</sup>	2.48×10 <sup>3</sup> –5.88×10 <sup>6</sup>
400	8.0–320	8.0–240	240–320	268–17.2×10 <sup>6</sup>	268-7.24×10 <sup>6</sup>	7.24×10 <sup>6</sup> –17.2×10 <sup>6</sup>
560	11.2–448	11.2–336	336–448	736–47.1×10 <sup>6</sup>	736–19.9×10 <sup>6</sup>	19.9×10 <sup>6</sup> –47.1×10 <sup>6</sup>
1000**	20–800	20–600	600–800	4189–268×10 <sup>6</sup>	4189–113×10 <sup>6</sup>	113.1×10 <sup>6</sup> –268×10 <sup>6</sup>
2000**	200–1600	200–1200	1200–1600	4.19×10 <sup>6</sup> –2.14×10 <sup>9</sup>	4.19×10 <sup>6</sup> –905×10 <sup>6</sup>	905×10 <sup>6</sup> –2.14×10 <sup>9</sup>

<sup>\*</sup> Range depends on system cleanliness and environmental electrical noise.

- *Aperture current range:* 30 μA to 6000 μA in 0.2-μA steps
- Aperture current accuracy: ± 0.4% of setting
- Polarity error: Less than 0.5%
- *Time mode range:* 0.01 to 1000 seconds, selectable in 10-ms increments
- *Metering system:* Mercury-free wide range metering pump
- Metered sample volumes (volumetric mode only): Continuously selectable from 50  $\mu$ L to 2000  $\mu$ L
- Volumetric pump accuracy: Better than 99.5%

# **Regulatory Compliance**

This software is FDA 21 CFR part 11 compliant.

# **Before You Start: Warnings and Cautions**

# Warnings

In this document, a red header box alerts you to a warning message.

PN A51387AB xix

<sup>\*\*</sup> Range depends on sample density.



A warning message describes either a potentially hazardous situation which, if not avoided, could result in death or serious injury to the operator.

### **Electrical Warnings**

- High voltages are present inside the instrument. Always disconnect the instrument from the power supply before removing the cover.
- The instrument must be grounded properly.

### **Chemical Warnings**

- Do not use any electrolyte solutions that are not compatible with the materials of construction.
   Consult Beckman Coulter, Inc. or its local representative before using any concentrated acids or alkalis in the instrument.
- Toxicity, safety, and proper handling procedures for electrolyte and reagents used in particle and cell analysis should be adhered to at all times. Consult appropriate safety manuals and Material Safety Data Sheets for the items.
- Care should be taken when mixing or exchanging solutions. Reactions can occur between incompatible solvents and electrolyte salts, and may be violent.
- Do not use azide and cyanide salts in acid solutions.
- Flammable electrolyte solutions should be prepared for use in an appropriate environment and brought to the instrument only when required for an analysis.

### **Mechanical Warnings**

- Do not interfere with or attempt to disable the interlocks incorporated in the door and platform assembly.
- Do not use force to remove or replace any glass item. In the event of difficulty, consult Beckman Coulter, Inc. or its local representative.
- Replace an aperture tube empty of electrolyte. Do not attempt to pre-fill a tube before placing it in the aperture tube connector.

### **Fire Warnings**

- Many non-aqueous electrolyte solutions are flammable and contain organic salts that can support or enhance fire. Where possible choose less flammable alternatives.
- Prepare and filter flammable solvents and electrolyte solutions away from the Multisizer 4, preferably under a suitable fume hood. Extinguish all open flames in the vicinity and observe normal precautions against ignition by hot surfaces or electrical sparks.

XX PN A51387AB

### **Cautions**

In this document, a yellow header box alerts you to a caution message:



A caution message describes a potentially hazardous situation, which if not avoided, may result in minor or moderate injury. It can also be used to alert against unsafe practices.

### **Electrical Cautions**

• Power must be largely free from interference. The Multisizer 4 is CE, UL and CSA compliant with regards to electrical interference but some circumstances may benefit from a constant voltage transformer or regulator.

### **Chemical Cautions**

- If Beckman Coulter ISOTON® II is used, the Multisizer 4 must be drained and flushed through with distilled water before carrying out a sodium hypochlorite solution (bleach) disinfection procedure.
- If the Multisizer 4 has been subjected to a bleach disinfection procedure, the instrument must be drained and flushed through with distilled water before refilling with ISOTON® II.
- Never stand containers of liquids on top of the Multisizer 4. Repair of instruments damaged or affected by spilled liquids will not be covered by any warranty or guarantee.

### **NOTE**

The Multisizer 4 performs best when it has reached a steady working temperature. This typically takes 15 minutes from powering on the Analyzer.

PN A51387AB XXI

### Introduction

Before You Start: Warnings and Cautions

XXİİ PN A51387AB

# Analyzer Overview

### Overview

### **New Multisizer 4 Features**

New Multisizer 4 features allow the operator to ensure consistent and accurate results.

### **Bar Code Reader**

The Bar Code Reader allows the operator to:

- Identify expired Beckman Coulter ISOTON® II by recording lot number and expiration date
- Enter sample information automatically
- Prompt the software to load the Beckman Coulter ST aperture tube size, serial number, and Kd value after the tube has been calibrated
- Enter the Multisizer 4 Smart Technology Beaker size, which prompts the Analyzer to move the stirrer into the ideal position for uniform particle distribution.

### Sample Platform Beaker and Accuvette® Guides

Beaker guides on the sample platform align Multisizer 4 Smart Technology Beakers and Accuvette® STs relative to the aperture tube for optimal and repeatable results. For more information on the Beaker and Accuvette® guides, see *Sample Platform*, page 1-9.

### **Automatic Stirrer Positioning**

Software controls automatically position the stirrer based on beaker and aperture tube size for consistent results (see *Standard Operating Method: Description*, page 4-3). In addition, the software allows the operator to select stirrer speed and direction for uniform particle suspension. The Multisizer 4 software records stirrer position, speed, and direction, including adjustments made during an analysis run, so that you can easily reproduce analysis results (see *Viewing Control Panel Actions in Run Information*, page 1-6).

### **Automatic Blockage Detection**

The Multisizer 4 automatic blockage detection feature monitors analysis runs for aperture blockage and can automatically unblock the aperture and continue a run without operator intervention. The Multisizer 4 allows the operator to select blockage detection settings based on current run data or reference runs, view a blockage monitoring graph during analysis runs, and review blockage monitoring data after a run is complete.

# **Extended Dynamic Range**

The Multisizer 4 is capable of measuring particles in the range of 2% to 80% of the aperture diameter, and in the range of 10% to 80% of the aperture diameter for a 2000- $\mu$ m aperture tube. The standard range is 2% to 60%; an extended dynamic range of 60% to 80% is available to examine broad distributions that extend above the 60% threshold. This feature is intended for examining particles in the small "tail" of a distribution that extends above 60%. For best results and to minimize blockage, it is recommended to use a larger aperture size for samples that contain a significant concentration of particles above 60% of the aperture diameter.

# **Multisizer 4 Components**

The convenient design of the Beckman Coulter Multisizer 4 places the Sample Compartment, Control Panel, and Electrolyte and Waste Jars at the front of the instrument.

Analyzer components are labeled in Figure 1.1 (below).

- A Sample Compartment
- **B** Control Panel
- C Waste and Electrolyte Jar Compartment
- **D** Electrolyte Jar
- E Waste Jar




Figure 1.1 Multisizer 4 Analyzer Components

1-2 PN A51387AB

### Power ON/OFF Switch

The ON/OFF switch is located next to the power cable on the rear panel of the instrument.



Make sure that the Analyzer has been powered down for at least 20 seconds before restarting. This ensures that the power supply has been depleted of voltage and allows the processor to reset.

### NOTE

The Multisizer 4 performs best when it has reached a steady working temperature. This typically takes 15 minutes from powering on the Analyzer.

# **Sample Compartment**

The Sample Compartment is located at the front of the Analyzer on the right as you face the instrument (Figure 1.1, A).

The door of the Sample Compartment consists of two layers of glass laminated on either side of a conductive material. When closed, the conductive material in the door reduces electrical noise created by electromagnetic fields (EMFs) in the vicinity. For information on other causes of noise in sample analyses, see *Reducing Noise*, page 9-1.

### NOTE

The Multisizer 4 software will display an error message if you attempt to start a sample run while the door is open.

For information on components inside the Sample Compartment, see *Sample Compartment*, page 1-3.

### **Control Panel**

The Control Panel is located in the center of the front panel (Figure 1.1, B). For information on Control Panel buttons, status lights, and the Bar Code Reader, see *Control Panel*, page 1-5.

# **Electrolyte Jar**

The Electrolyte Jar is located next to the Control Panel on the front of the Analyzer (Figure 1.1, D). Electrolyte is used to fill the system, flush particles out of the system, rinse the aperture tube, and unblock the aperture.

It is preferable that you use the same electrolyte solution in both the Electrolyte Jar and the sample beaker or Accuvette® ST. When running an analysis, however, the Analyzer draws only sample beaker electrolyte solution through the aperture orifice.

Electrolyte solution passes through the orifice only during the unblock procedure, when the Analyzer pushes fluid through the aperture in reverse to remove particles.

### Waste Jar

The Waste Jar is the larger of the two jars, located to the left of the Electrolyte Jar (Figure 1.1, E). During an analysis, the Analyzer fills the Waste Tank with electrolyte solution drawn through the aperture tube. You can empty the Waste Tank fluid into the Waste Jar using settings in the Multisizer 4 software (see *Waste Tank Settings*, page 9-6).

# **Electrolyte and Waste Jar Fluid Levels**

The Multisizer 4 software displays the fluid levels in the Electrolyte Jar and Waste Jars on the Status Panel (*Status Panel*, page 2-8).

The fluid levels in the Electrolyte and Waste Jars are calculated by weight. It is usually necessary to calibrate the weight sensors only once, when you set up the Analyzer. If you switch to an electrolyte with significantly different density, however, you may need to recalibrate the Electrolyte and Waste Jar sensors (see *Calibrating the Electrolyte and Waste Jars*, page 9-13).

# Installing and Removing the Electrolyte and Waste Jars

The lids of the Electrolyte and Waste Jars remain attached to the Analyzer.

### To install an Electrolyte or Waste Jar:

- 1. Place the Electrolyte or Waste Jar tube inside the jar.
- 2. Lift the jar until the lid is in place.
- 3. Hold the jar from the bottom and slide the jar into the appropriate compartment (Figure 1.2).

### To remove an Electrolyte or Waste Jar:

- 1. Hold the bottom of the jar.
- 2. Lift the jar slightly and pull the jar away from the Analyzer.
- 3. Tilt the jar and pull the jar away from the lid and tube.




Figure 1.2 Installing the Waste Jar

1-4 PN A51387AB

# **Control Panel**

The Control Panel includes an ON light, status lights, stirrer control buttons, and the Bar Code Reader.

Control Panel functions are labeled in Figure 1.3 (below).

- A Analyzer ON Light
- **B** Analyzing (Green) and Attention (Amber) Lights
- **C** Stirrer ON button
- **D** Stirrer Direction buttons (CW and CCW)
- **E** Stirrer Speed buttons
- F Bar Code Reader




Figure 1.3 Control Panel

# **Disabling the Control Panel Buttons**

You can use the Control Panel buttons during a sample run to turn the stirrer on or off, reverse the stirrer direction, and increase or decrease the stirrer speed.

To disable the stirrer control buttons during sample runs, use the Edit the SOM (Standard Operating Method) window in the Multisizer 4 software.

### To disable the Control Panel stirrer buttons:

- 1. In the Multisizer 4 software Main Menu, select SOP > Edit the SOM.
- 2. In the Edit the SOM (Standard Operating Method) window, select the Stirrer tab.
- 3. On the Stirrer tab, check the box next to Disable instrument keypad during run, and click (OK).

### NOTE

If Accuvette® ST or Parked out of beaker is selected, Disable will not be available.

# **Viewing Control Panel Actions in Run Information**

If you use Control Panel buttons to adjust stirrer operation during an analysis run, the Multisizer 4 software stores all changes in stirrer operation, direction, and speed with sample run information.

### To view sample and run information:

- 1. Open an analysis file.
- 2. Select **RunFile** > **Get Info** on the Run Menu bar.

# **ON Light**

The blue **ON** light is located at the top of the Control Panel (Figure 1.3, A)

# **Analyzing and Attention Lights**

There are two status lights (Figure 1.3, B): Analyzing and Attention, below the ON light.

- The green Analyzing light is on when the Analyzer is running an analysis. It duplicates the function of the green LED light in the Sample Compartment.
- The amber Attention light flashes when an error prevents the Analyzer from starting a run (for example, when the door is open or the sample platform is not in place). The amber Attention light duplicates the function of the amber LED light in the Sample Compartment. When the amber light flashes, the Multisizer 4 software displays an error message.

### Stir ON Button

The **Stir ON** button is located below the Analyzing and Attention lights on the Control Panel (Figure 1.3, C). The toggle button turns the stirrer on or off. It is lit when the stirrer is **ON**. The Stirrer operates only when the platform is in the raised position for sample analysis. It will not spin when the platform is in the loading position.

### **Stirrer Direction Controls**

You can select or change stirrer direction before or during an analysis run using the clockwise (CW) or counter-clockwise (CCW) button (Figure 1.3, **D**).

The direction of the stirrer influences particle suspension. The clockwise (CW) direction circulates fluid and sample particles downwards and inwards toward the base of an ST Beaker. The counter-clockwise (CCW) direction circulates fluid and particles upwards and outwards toward the edges of the beaker.

1-6 PN A51387AB

### NOTE

Beckman Coulter recommends the clockwise (CW) direction when using the stirrer. In general, the counter-clockwise (CCW) direction is less effective in maintaining uniform particle distribution and suspension.

For information on changing the stirrer direction using Standard Operating Method settings, see *Standard Operating Method: Stirrer Settings*, page 4-10.

# **Stirrer Speed Controls**

You can increase or decrease the stirrer speed using the Control Panel Speed buttons, + and - (Figure 1.3, E).

### **Bar Code Reader**

You can use the Bar Code Reader (Figure 1.3, F) to scan information about the following directly into the Multisizer 4 software:

- Beckman Coulter ISOTON® II labels
- Beckman Coulter Smart Technology Aperture Tubes (size and serial number)
- Sample
- Beckman Coulter Multisizer 4 Smart Technology Beakers

To configure the bar code reader, see *Bar Code Reader Configuration Options*, page 8-15.

### To use the Bar Code Reader:

In the Multisizer 4 software, a Bar Code Reader symbol indicates that you can use the scanner to enter information automatically into appropriate text fields.





- 1. When you see the Bar Code Reader symbol in a window, hold the ISOTON® II label, ST Aperture Tube, beaker, or sample bar code in front of the Bar Code Reader.
- 2. The bar code information appears in the correct fields in the Multisizer 4 software window.

# **Sample Compartment**

Sample Compartment components are labeled in Figure 1.4 (below).

- A Aperture tube
- **B** Aperture tube knob
- C Sample Platform
- **D** Platform Release
- **E** External Electrode
- **F** Stirrer
- **G** Particle Trap
- **H** LED green, amber, and white status lights




Figure 1.4 Sample Compartment

# **Aperture Tube**

The aperture tube, when in place, is located in the upper left corner of the Sample Compartment (Figure 1.4, A).

For information on installing or removing an aperture tube, see *Installing an Aperture Tube*, page 3-2.

# **Aperture Tube Knob**

The aperture tube knob (Figure 1.4, B) secures the aperture tube in place. The knob is in the locked position when pointing up (12 o'clock position). To remove an aperture tube, first unlock the aperture tube knob by turning the knob in either direction until it points down (6 o'clock position).

1-8 PN A51387AB

# **Sample Platform**

The sample platform (Figure 1.4, C) holds a Multisizer 4 Smart Technology Beaker (ST Beaker) or Accuvette® ST. To ensure consistent results, the sample platform locks into position for analysis runs. ST Beakers and Accuvette® STs are designed to ensure optimal fluid use and circulation with the locked platform height.

To lower the platform, use the platform release (page 1-11).

The platform rotates and has two usable sides. One side of the platform has a guide for Multisizer 4 Smart Technology Beakers (Figure 1.5). The other side of the platform has a built-in guide for Accuvette® STs (Figure 1.6).

The guides ensure that a beaker or Accuvette® ST will be in the correct position relative to the aperture tube, external electrode, and stirrer when you raise the platform. The guides ensure consistent results by maintaining an optimal distance for fluid circulation between the aperture tube and the side and base of the beaker or Accuvette® ST.

For information on how to turn the platform, see *Reversing the Sample Platform*, page 1-10.




Figure 1.5 Platform in Loading Position: Beaker Side




Figure 1.6 Platform in Loading Position: Accuvette® ST Side

# **Reversing the Sample Platform**

To turn the sample platform from the beaker to Accuvette® ST side, or vice versa:

1. Lower the platform to the loading position, if necessary.

### **NOTE**

Rotate the platform only when it is located at or near the loading position. This ensures that the platform does not bump the aperture tube or stirrer while rotating.

- 2. Grasp the platform and lift the platform slightly. It is not necessary to use the platform release.
- 3. Pull the platform toward you. You will feel the resistance of a spring mechanism.
- **4.** Continuing to hold the platform away from the rear of the sample compartment, turn the platform until it contacts the stop pin (Figure 1.7).
- 5. Slowly release the platform.

1-10 PN A51387AB




Figure 1.7 Reversing the Sample Platform

### **Platform Release**

The platform release is located on the left edge of the Sample Compartment, above the sample platform in its lowered position (Figure 1.4, D).

To lower the platform from its locked analysis position, push the top of the release towards the rear of the compartment.

It is not necessary to use the platform release when raising the platform to the analysis run position.

### **External Electrode**

The external electrode is located in the upper left corner of the Sample Compartment, just behind or to the side of the aperture tube (Figure 1.4, E).

The external electrode creates an electrical current that passes through the aperture orifice. As particles suspended in the electrolyte solution flow through the orifice during an analysis run, the Analyzer determines particle size by measuring the electrical pulse generated by each particle.

### Stirrer

The stirrer is located at the top of the Sample Compartment, to the right of the aperture tube and electrode (Figure 1.4, F).

### **NOTE**

The Multisizer 4 software automatically determines stirrer position for sample runs based on Standard Operating Method (SOM) settings. To change the stirrer position, or park the stirrer outside the beaker, select the appropriate checkboxes in the **Edit the SOM > Stirrer** tab. For information on the Edit the SOM (Standard Operating Method) window, see *Standard Operating Method: Stirrer Settings*, page 4-10. It is possible to manually reposition the stirrer if you are not using Multisizer 4 ST Beakers and Accuvette® STs.

# **Particle Trap**

The Particle Trap is located at the far right of the Sample Compartment (Figure 1.4, G).

The Particle Trap is designed to keep large particles from entering the system, where they could block the system or abrade valves. Electrolyte and sample fluid from the aperture enter the Particle Trap, where large particles drift to the bottom.

### NOTE

Beckman Coulter recommends that you clean the Particle Trap when particles have settled and filled one-quarter of the Trap. If you allow particles to collect above the one-quarter mark, large particles may recirculate and damage the system.

# **Status and Illumination Lights**

There are two LED status lights located at the right of the Sample Compartment, next to the Particle Trap (Figure 1.4, H).

- The green (Analyzing) light is on when the Analyzer is running an analysis.
- The amber (Attention) light flashes when the Analyzer cannot start a run (for example, because the door is open or the sample platform is not in place). When the amber light flashes, the Multisizer 4 software displays an error message.

There are two lights that illuminate the Sample Compartment:

- The light on the right side of the Sample Compartment, next to the Particle Trap, illuminates the Sample Compartment when the door is open. When you close the door, the light turns off after a 10-second delay.
- The light on the left side of the Sample Compartment illuminates the aperture tube. This light
  is on when the Sample Compartment door is open; when a sample run is in progress; and when
  the system is filling, flushing, or draining.

1-12 PN A51387AB

### **Accessories**

### **Beakers**

Multisizer 4 Smart Technology Beakers (ST Beakers) are available in 100 mL, 200 mL, and 400 mL sizes.

The unique design of ST Beakers optimizes particle suspension. A spherical interior interrupted by a raised cone creates an unstable area below the stirrer that provides uniform particle distribution.

The base of each ST Beaker is designed to fit a built-in guide on the sample platform (see *Sample Platform*, page 1-9). When the platform is raised to the analysis position, the guide positions the beaker for optimum fluid circulation, ensuring that the aperture tube is approximately 1/8 inch from the beaker wall. The raised base of the beaker maximizes the volume of fluid the Analyzer is able to extract before drawing air through the aperture orifice.

The combination of ST Beakers and the built-in guide allows the Multisizer 4 to deliver consistent, optimal results not possible to obtain with beakers designed by other manufacturers.

#### NOTE

If you are using a beaker produced by another manufacturer, it may be necessary to manually adjust the position of the beaker on the platform. Variations in the position of the beaker relative to the aperture tube, electrode, and stirrer during analysis runs can produce inconsistent results.

### Accuvette® STs

Beckman Coulter Accuvette® STs are disposable and include a secure lid to prevent spills and contamination. Rounded corners in the interior encourage re-suspension of settled particles.

Use a 20 mL Accuvette® ST in combination with an aperture tube 100 µm or smaller.

The base of each Beckman Coulter Accuvette® ST is designed to fit a built-in guide on the sample platform (see *Sample Platform*, page 1-9). When the platform is raised to the analysis position, the guide positions the Accuvette® ST for optimum results and maximizes the volume of fluid the Analyzer is able to extract before drawing air through the aperture orifice.

The combination of Accuvette® STs and the built-in guide allows the Multisizer 4 to deliver consistent, optimal results not possible to obtain with sample vials designed by other manufacturers.

### **Calibrators**

Beckman Coulter provides calibrator beads in sizes ranging from 2  $\mu$ m to 90  $\mu$ m. For information on calibrating the aperture tube and selecting the appropriate calibrator size, see *Calibrating the Aperture*, page 3-10.

### **Aperture Tubes**

Beckman Coulter manufactures Smart Technology Aperture Tubes designed specifically for the Multisizer 4 Analyzer. Aperture tubes designed for use with the Multisizer 3 will not fit the Multisizer 4.

Multisizer 4 Smart Technology Aperture Tubes:

- Include size and serial number information in a bar code on the tube for automatic data entry (for more information, see *Bar Code Reader*, page 1-7).
- Are compatible with ST Beakers and Accuvette® STs, and work in concert with the enhanced Multisizer 4 sample platform design (see *Sample Platform*, page 1-9).
- Are designed for convenience and to ensure consistent and accurate results.

For information on selecting the appropriate aperture tube size for your sample range, see *Selecting* an *Aperture Size*, page 3-1.

Aperture tubes are fragile and require proper handling. For information on small Aperture Tube handling, cleaning, and operating procedures, see *Using Small Aperture Tubes* (20  $\mu m$  and 30  $\mu m$ ), page 3-4.

### **Handling Aperture Tubes**

It is highly recommended that you wear powder-free latex or nitrile gloves when handling aperture tubes. Hold the aperture tube near the top during installation and removal (Figure 1.8), and avoid touching the aperture tube at the bottom, near the orifice.




Figure 1.8 Proper Handling of an Aperture Tube

1-14 PN A51387AB

### Cleaning the Aperture Tube, Beakers, and Accuvette® STs

Before operating the Analyzer, rinse all system components and accessories in pre-filtered ISOTON® II (see *Pre-Filtering the Electrolyte and Cleaning Fluid*, page 1-17).



- If Beckman Coulter ISOTON® II is used, the Multisizer 4 must be drained and flushed through with distilled water before carrying out a sodium hypochlorite solution (bleach) disinfection procedure.
- If the Multisizer 4 has been subjected to a bleach disinfection procedure, the instrument must be drained and flushed through with distilled water before refilling with ISOTON® II.

System components and accessories include:

- Electrolyte Jar
- ST Aperture Tube
- External Electrode
- Particle Trap
- ST Beaker or Accuvette® ST

When handling Aperture Tubes and other system components, it is highly recommend that you wear powder-free latex or nitrile gloves.

#### To clean the aperture tube and electrode:

- 1. Press the platform release (Figure 1.4, D) towards the back of the Sample Compartment and lower the platform to the loading position.
- 2. Use a squeeze bottle filled with clean or pre-filtered ISOTON® II to rinse the aperture tube, external electrode, and the stirrer (Figure 1.9, below).
- 3. Select an ST Beaker that is at least one size larger than the size you used for the previous run (or a 400-mL ST Beaker if you used that size for the previous run).
- **4.** Fill the clean ST Beaker with clean or pre-filtered ISOTON® II or de-ionized water (see *Pre-Filtering the Electrolyte and Cleaning Fluid*, page 1-17). Make sure that the fluid level is higher than the fluid level during the previous run.
- 5. Lift the ST Beaker to immerse the aperture tube and electrode in the ST Beaker's filtered liquid. Swish to remove remaining particles.
- **6.** Place the ST Beaker on the platform below the aperture tube and allow remaining liquid to drip into the ST Beaker.




Figure 1.9 Cleaning an Aperture Tube

### **Cleaning the Analyzer**

Clean the system thoroughly before running analyses. An effective cleaning procedure includes filling and draining the system multiple times and in multiple cycles, alternating between deionized water and 98% Isopropyl Alcohol (IPA).

#### Drain the system:

- 1. On the Multisizer 4 software Main Menu bar, select Run > Drain System.
- 2. Remove and empty the Electrolyte and Waste Jars.
- 3. Replace the Waste Jar.

#### Clean the system with de-ionized water:

- 4. Rinse and fill the Electrolyte Jar with clean or pre-filtered de-ionized water.
- 5. Replace the Electrolyte Jar.
- 6. On the Multisizer 4 software Instrument Toolbar, click (Empty) to empty the Waste Tank.
- 7. On the Multisizer 4 Main Menu bar:
  - a. Select Run > Fill System, or click the (Fill) button on the Instrument Toolbar.
  - b. When the system has filled, select Run > Drain System.
  - c. Fill and drain the system two more times (for a total of three times).
- 8. Remove and empty the Electrolyte Jar.

1-16 PN A51387AB

#### Clean the system with 98% Isopropyl Alcohol:

- 9. Fill the Electrolyte Jar with 98% Isopropyl Alcohol.
- 10. Repeat Steps 5 through 8 above.

### Clean the system with de-ionized water:

- 11. Rinse and fill the Electrolyte Jar with de-ionized water.
- 12. Repeat Steps 5 through 8 above.

### Flush the system:

- 13. Fill the Electrolyte Jar with filtered ISOTON® II.
- **14.** On the Multisizer 4 software Instrument Toolbar, click the (Flush) button to flush the aperture tube.
- 15. Flush the aperture tube three times.

### **Pre-Filtering the Electrolyte and Cleaning Fluid**

When working with small apertures, it is necessary to pre-filter de-ionized water and/or ISOTON® II used to fill, flush, or clean the system and accessories.

Filter the Isoton II or diluent solution with a compatible 0.2- $\mu$ m filter. A 0.1- $\mu$ m filter can also be used in series with a 0.2- $\mu$ m filter for additional filtering. Contact a filtration supplier to determine the appropriate filtration components for your application. One possible configuration for filtering large amounts of diluent is shown in the diagram below (Figure 1.10).





Figure 1.10 Closed Circuit Filtration System

### **Starting the Analyzer**

#### To start the Analyzer:

- 1. Power ON the Analyzer.
- 2. Empty the Waste Jar, if necessary.
- **3.** Fill the Electrolyte Jar with electrolyte, if necessary.
- **4.** Open the Multisizer 4 software and connect the software to the Analyzer.
- On the Multisizer 4 software Main Menu bar, select Run > Instrument Start-Up.
- **6.** In the Instrument Start-Up dialog box:
  - **a.** Select checkboxes for each function you would like the Analyzer to perform on startup.
  - b. Click (Start).



#### NOTE

The Multisizer 4 performs best when it has reached a steady working temperature. This typically takes 15 minutes from powering on the Analyzer.

### **Preparing the Analyzer for Sample Runs**

#### To prepare the analyzer for a calibration, control, or sample analysis run:

- 1. Start the Analyzer and connect the software to the Analyzer (see *Starting the Analyzer*, page 1-18).
- 2. Wash the ST Aperture Tube and ST Beaker or Accuvette® ST (see *Cleaning the Aperture Tube, Beakers, and Accuvette® STs*, page 1-15).
- 3. Fill an ST Beaker or Accuvette® ST with clean electrolyte solution.

1-18 PN A51387AB

#### **NOTE**

For aperture tubes up to 100  $\mu$ m, you can use an Accuvette® ST (20 mL). Use an ST Beaker for any aperture tube size larger than 100  $\mu$ m.

- **4.** Add a few drops of the calibrator, control sample, or sample to the electrolyte solution.
  - For more information on calibration, see *Calibrating the Aperture*, page 3-10.
  - For more information on control sample runs, see *Running a Concentration Control Sample*, page 3-33.
  - For more information on running a sample analysis, see *Analyzing a Sample*, page 6-1.
- 5. If necessary, use the platform release and lower the platform to the loading position.
- **6.** If necessary, turn the platform so that the correct side (ST Beaker or Accuvette® ST) is on top (see *Sample Platform*, page 1-9).

#### NOTE

The sample platform has two usable sides. The ST Beaker side has a built-in guide to ensure that a Multisizer 4 Smart Technology Beaker of any size is in the correct position when you raise the platform. The Accuvette® ST side has a smaller guide for Accuvette STs. The guides ensure that the ST Beaker or Accuvette® ST will be in the correct position relative to the aperture tube, electrode, and stirrer when you raise the platform.

- 7. Place the ST Beaker or Accuvette® ST on the sample platform.
- **8.** Raise the platform.

#### NOTE

It is not necessary to use the platform release to lift the platform into position.

**Analyzer Overview**Preparing the Analyzer for Sample Runs

1-20 PN A51387AB

## Software Overview

### **Opening the Multisizer 4 Software**

#### To open the Multisizer 4 software:

- 1. On your desktop, double click the Multisizer 4 software shortcut, or select the program from your program list.
- 2. The Beckman Coulter Multisizer 4 startup window opens. The window displays the software version, the current date and time, and your security configuration.



### **Connecting the Software to the Analyzer**

### **Connecting Analyzer and Software on Startup**

To connect the software to the Analyzer:

1. In the Beckman Coulter Multisizer 4 dialog box, select the Connect to Multisizer 4 checkbox.

### 2. Click (OK).

If you do not want to connect on startup, you can select **Run > Connect to Multisizer 4** in the Main Menu after you have opened the software.

#### NOTE

If the Administrator has selected a security mode that requires a username and password, a Login window will appear when the software opens. If the user does not have a valid username or password, it will be necessary to exit the system. For more information, see *Logging In*, page 8-18.

### Connecting to the Analyzer Using the Software Main Menu

To connect the software to the Analyzer, select Run > Connect to Multisizer 4 on the Main Menu bar.

### **Disconnecting from the Analyzer Using the Software Main Menu**

To disconnect the software from the Analyzer, select **Run > Disconnect from Multisizer 4** on the Main Menu bar.


### **Multisizer 4 Software Window**

The Multisizer 4 software window is illustrated below.

- A Main Menu
- **B** Main Toolbar
- **C** Status Panel
- **D** Viewing Area
- E Run Menu
- **F** Instrument Toolbar
- **G** Status Bar

2-2 PN A51387AB

All Multisizer 4 software functions are available from drop-down menu items in the Main Menu (A) and Run Menu (E). Many menu item functions are duplicated by shortcut buttons on the Main Toolbar (B) or the Instrument Toolbar (F).



### Main Menu

The Main Menu bar appears in the upper left corner of the Multisizer 4 software window. For information on Main Menu bar drop-down menus, see the table below.

The Main Menu bar and its drop-down menu items change based on security settings. For example, if you are running the Multisizer 4 software in no security mode, a Configuration drop-down menu appears. If you are running the Multisizer 4 software in security mode with Administrator or Supervisor privileges, an Administrator or Supervisor drop-down menu appears that includes configuration and other security-related items.

Menu items in the Configuration, Administrator, or Supervisor drop-down menu allow the user to remove items from the drop-down menus (see *Customizing Main Menus*, page 8-3).

#### NOTE

If you are running the Multisizer 4 software in security mode, certain menu items will appear only to user types with sufficient privileges. The system administrator sets privileges for each user type.

In the table below, Main Menu items that may not be available based on security settings are italicized.

Table 2.I Main Menu: Drop-Down Menus

The menu	Allows you to				
File	<ul> <li>Open a file</li> <li>Open a file for overlay</li> <li>Use File Tools to merge runs, create a size trend, overlay analyses, or to access other file functions (see Working with Multiple Analysis Files, page 7-19)</li> <li>Select a recently used file or folder, or create a new folder</li> <li>Print a report, the open window, or the current screen</li> <li>Select print settings</li> <li>Exit the software</li> </ul>				
Calibration	<ul> <li>Calibrate the aperture</li> <li>Verify aperture calibration</li> <li>Run a concentration control sample</li> <li>Change aperture calibration options</li> <li>Change control sample options</li> </ul>				
Sample	<ul> <li>Enter, load and save sample information</li> <li>Create sample specifications</li> <li>Load or remove a blank run</li> </ul>				
SOP	<ul> <li>Create, remove, or load a Standard Operating Procedure</li> <li>Create, edit, or load a Standard Operating Method</li> <li>Create, edit, or load Preferences</li> <li>Review or print SOM information</li> <li>Review or print Preference information</li> </ul>				
Run	<ul> <li>Start, stop, cancel, pause, resume, reset, preview, repeat, or start a 60% to 80% run</li> <li>Initiate system functions (empty the Waste Tank, fill the system, unblock the aperture tube, etc.)</li> <li>Turn the stirrer and lamp on and off</li> <li>Select Analyzer start-up functions</li> <li>Enter electrolyte information</li> <li>Use the Change Aperture Tube Wizard</li> <li>Troubleshoot system functions</li> <li>Disconnect from the Analyzer</li> <li>Many Run menu items duplicate functions available as shortcuts in the Instrument Toolbar.</li> </ul>				
Configuration	<ul> <li>Customize menu items</li> <li>Customize sample information terms</li> <li>Customize the default Preferences save setting</li> <li>Set the security level</li> <li>Choose a language</li> <li>Configure file and User's Manual locations</li> <li>Change Multisizer 4 connection parameters</li> <li>Configure Bar Code Reader</li> </ul>				

2-4 PN A51387AB

Table 2.1 Main Menu: Drop-Down Menus

The menu	Allows you to			
Windows	<ul> <li>Copy or save the current window as a bitmap</li> <li>Select view options for open files</li> <li>Minimize or restore all open files to the Viewing Area</li> <li>Customize the Main Toolbar and Instrument Toolbar</li> <li>Customize the Status Panel</li> <li>Select the file that will appear in the Viewing Area (if more than one file is open)</li> </ul>			
Help	<ul> <li>Open the Multisizer 4 User's Manual</li> <li>Convert particle sizes (using diameter, surface area, or volume)</li> <li>View certification information, if available</li> <li>View log-in information, if running in security mode</li> <li>Contact Beckman Coulter Field Service</li> <li>View software version information</li> </ul>			

### **Main Toolbar Buttons**

The Main Toolbar is located below the Main Menu at the top of the Multisizer 4 software window. The Main Toolbar buttons are shortcuts that duplicate functions available in the Main Menu.



You can remove buttons from the Main Toolbar, re-order buttons, change button appearance, or remove the Main Toolbar as a whole by selecting **Windows > Toolbars** on the Main Menu bar (see *Customizing Toolbars*, page 8-7).

### **Default Main Toolbar Configuration**

In the default Main Toolbar configuration, buttons are organized in four groups:

- The first group duplicates features available in the File drop-down menu and SOP >
   Edit Preferences window.
- The second group duplicates features available in the File drop-down menu and SOP > Edit Preferences (Graph Options) window.
- The third group duplicates features available in the Main Menu and Run Menu.
- The fourth group duplicates features available in the Calibration drop-down menu.

### **Main Toolbar Buttons: First Group**

The first group, at the far left, duplicates features available in the File drop-down menu and the **SOP > Edit Preferences** window.

Table 2.1 Main Toolbar: Buttons (First Group)

Click	То			
(Open)	Open a file.			
	To change the folder that automatically opens when you click this button, go to <b>File</b> > <b>Change Folder</b> in the Main Menu, or use the (Up) button. The current folder is displayed in the Status Bar in the bottom left corner of the Multisizer 4 software window.			
(Overlay)	Open files for overlay.			
(Up)	Change the current folder for files to the folder one level above.			
	The current folder is displayed in the Status Bar in the bottom left corner of the Multisizer 4 software window.			
(Fonts)	Open the Fonts & Colors tab of the Edit Preferences window.			
	This button allows you to change fonts for the file currently open in the Viewing Area, and save these settings for future use.			

### **Main Toolbar Buttons: Second Group**

The second group duplicates features available in the File drop-down menu and the SOP > Edit Preferences (Graph Options) window.

This group of buttons is active only when one or more analysis files are open in the Viewing Area.

Table 2.2 Main Toolbar Buttons (Second Group)

Click	То			
(Overlay)	Open files for overlay.			
(Save)	Save the open file. If the file has not been saved previously, the Save As window opens.			
(Save As)	Save the open file with a new name.			
(Print)	Print the open file. The Multisizer 4 software will print the report using current Preferences settings.			
(Report)	Open the Print Report window. The Print Report window allows you to change print settings or update Preferences before printing.			
(Color)	Change the appearance of the analysis file in the Viewing Area. Toggle to display graph lines in color or black and white. This button is only available when viewing a graph.			

2-6 PN A51387AB

**Table 2.2** Main Toolbar Buttons (Second Group)

Click	То	
(Cursor)	Bring a different graph line to the forefront of an overlay file. This button a shortcut for the Cursor menu on the Run Menu bar. The button is only available if you have opened multiple files for an average, overlay, or trend.	
	For more information, see <i>Moving Between Multiple Files (Cursor Menu and Shortcut)</i> , page 7-25.	
(Legend)	Move the legend from corner to corner in the open analysis, or remove the legend. This button is only available when viewing a graph.	

### **Main Toolbar Buttons: Third Group**

The third Main Toolbar group duplicates functions available in the Main Menu (**Sample** drop-down menu items) and the Run Menu (**RunFile** and **View** drop-down menu items). The Run Menu appears at the top of an open analysis file.

This group of buttons is active only when an analysis file is open in the Viewing Area.

#### NOTE

If you are running the Multisizer 4 software in security mode, certain Main Toolbar buttons will appear only to user types with sufficient privileges (for example, the (Sample) button). The system administrator sets privileges for each user type.

In the table below, Main Toobar buttons that may not be available based on security settings are italicized.

 Table 2.3 Main Toolbar: Buttons (Third Group)

Click	То			
(Get Info)	Display sample and run information associated with the open analysis file.			
(Sample)	Open the Edit Sample Info window to update sample information for the open analysis file. The Edit Sample Info window is available only in no security mode and to Administrator and Supervisor user types.			
(Graph)	Display the open analysis file as a graph.			
(Listing)	Display the open analysis file as a listing.			
(Stats)	Display statistics associated with the open analysis file.			
(Trend)	View a size trend graph or listing.			
	The (Trend) button is greyed out when the open file does not have trend data. Only trend and average files, which end in .#tr or .#av, have trend data.			
(Size)	Display the particle size distribution as a graph or listing.			

**Table 2.3** Main Toolbar: Buttons (Third Group)

Click	То			
(Pulses)	Display electrical pulses as a graph or listing.			
(Zoom)	Display only the area of the graph between two cursors. Before clicking the (Zoom) button, first insert two cursors on a graph as follows: a single click within the graph area creates a single cursor. Click, drag, and un-click to create two cursors: one at the click point, the other at the un-click point. After displaying a zoomed image, you can click the (Zoom) button again to view the full size distribution, or insert new cursors and click the (Zoom) button to see a smaller portion of the size distribution.			

### **Main Toolbar Buttons: Fourth Group**

The fourth group, at the far right of the Main Toolbar, duplicates functions available in the Calibration drop-down menu.

#### NOTE

If you are running the Multisizer 4 software in security mode, certain Main Toolbar buttons will appear only to user types with sufficient privileges (for example, the (Kd Calib.) button). The system administrator sets privileges for each user type.

In the table below, Main Toobar buttons that may not be available based on security settings are italicized.

Table 2.4 Main Toolbar: Buttons (Fourth Group)


Click	То			
(Kd Calib.)	Open the Calibrator Size window and calibrate the aperture.			
(Kd Verify)	Open the Calibrator Size window and verify aperture calibration.			
(CC Conc.)	Open the Concentration Control window and run a concentration control sample.			

### **Status Panel**

The Status Panel, located on the left side of the Multisizer 4 software window, displays elapsed run time, particle count, and concentration information during an analysis run.

2-8 PN A51387AB

Before an analysis run begins, the Status Panel displays READY or RUN COMPLETE if the Analyzer is not busy.



The Status Panel displays three panes with basic information: the name of the SOP (if loaded), Sample Information (if entered), and SOM information (if entered).

- In the SOP pane, click (Load SOP) to load a Standard Operating Procedure.
- In the Sample Information pane, click (Edit Info) to enter or update sample information.
- In the SOM pane, click (Edit SOM) to make changes to the Standard Operating Method.

Below the SOP, Sample Information, and SOM panes, the Status Panel displays the status of the stirrer and fluid levels in the Waste Tank, Waste Jar, and Electrolyte Jar.

#### Customizing the Status Panel

You can customize colors and other aspects of the Status Panel display. For more information, see *Customizing the Status Panel*, page 8-8.

### **Viewing Area**

The Viewing Area, located in the middle of the Multisizer 4 software window, displays analysis files as graphs, listings, or interpolations.


During an analysis run, the Viewing Area displays a graph or listing showing the particle size distribution in progress.

You can work with multiple analysis files. To change how the Viewing Area displays multiple files, open the Windows drop-down menu in the Main Menu bar and select one of the following options:

- Cascade
- Tile
- Tile Horizontal
- Tile Vertical
- Minimize All
- Restore All

### Run Menu

The Run Menu bar is located in the Viewing Area, at the top of each open analysis file.



Items displayed on the Run Menu bar vary based on selections made in the View drop-down menu. For more information on Run Menu behaviors, see *Viewing Analysis Files*, page 7-2.

2-10 PN A51387AB

### **Instrument Toolbar Buttons**

The Instrument Toolbar is located at the bottom of the Multisizer 4 software window, below the Viewing Area.

Instrument Toolbar buttons duplicate functions also available in the Run drop-down menu. The buttons are divided into three sections:

- (Run) buttons
- (Reset) button
- (Fluid control) buttons

### **Instrument Toolbar: Run Buttons**

The Instrument Toolbar Run buttons allow you to preview, start, repeat, stop, pause, resume, continue, or cancel an analysis run.

Table 2.5 Instrument Toolbar: Run Buttons

Click	То			
(Preview)	Preview an analysis run to check concentration. If you adjust the concentration, the Analyzer automatically continues the preview run when you shut the Sample Compartment door.			
(Start)	Start an analysis run.			
(Repeat)	Repeat an analysis run with the same settings.			
(Pause)	Pause an analysis run.			
(Resume)	Resume an analysis run after pausing.			
	If you pause a 30-second timed analysis after 10 seconds, the (Resume) button will run only the 20-second remainder of the analysis time. If you pause a run and then press (Continue), the software will re-run the 30-second analysis with your original settings, and add the data to the data already gathered during the abbreviated 10-second analysis.			
(Continue)	Continue a run from the beginning, adding the data to data previously gathered from a run with the same settings.			
(Cancel)	Cancel an analysis run.			
	If you click the (Cancel) button, the software will cancel the run and display Run Canceled above the analysis in the Viewing Area. You will not be able to save data from the analysis.			
(Stop)	Stop an analysis run.			
	If you click the (Stop) button, the software will stop the analysis currently in progress and display Run Complete above the analysis data in the Viewing Area. You can save the analysis file.			

### Instrument Toolbar: Reset Button

Click the (Reset) button to clear the Viewing Area of analysis data after running a sample.

If you have not canceled the run, the software will prompt you to save the analysis data before clearing the Viewing Area.

#### **Instrument Toolbar: Fluid Control Buttons**


The Instrument Toolbar fluid control shortcuts allow you to empty the Waste Tank into the Waste Jar and use electrolyte solution to unblock the aperture, flush the system of particles, or fill the system.

Table 2.6 Instrument Toolbar: Function Buttons

Click	То			
(Unblock)	Reverse the flow of electrolyte solution through the aperture orifice to unblock the aperture tube.			
(Empty)	Empty the Waste Tank fluid into the Waste Jar.			
(Flush)	Flush the system with electrolyte solution to remove particles.			
(Fill)	Fill the system with electrolyte solution.			

### **Status Bar**

The Status Bar is located in the lower left corner of the Multisizer 4 software window.



The Status Bar text displays the current path and folder (if you are not mousing over a drop-down menu item) or a brief description of a highlighted menu item.

2-12 PN A51387AB

# Installing and Calibrating an Aperture Tube

#### Overview

### When to Install a New Aperture Tube

Install a new aperture tube if:

- You are using the Analyzer for the first time
- You are using different aperture tube sizes to obtain different particle size distributions
- Your aperture tube has broken

### To install a new aperture tube:

- 1. Select an aperture tube size
- 2. Use the Change Aperture Tube Wizard to install the new aperture tube

### **Selecting an Aperture Size**

Select an aperture tube size based on the size of the particles you will be measuring. The Analyzer can accurately measure particles between 2% and 80% of the aperture size, and in the range of 10% to 80% of the aperture diameter for a 2000- $\mu$ m aperture tube.



If you select a 20- $\mu$ m or 30- $\mu$ m aperture, Beckman Coulter recommends that you follow special cleaning, handling, and operating procedures to accommodate the sensitivity of small apertures. For more information, see *Using Small Aperture Tubes* (20  $\mu$ m and 30  $\mu$ m), page 3-4.

Table 3.1 Aperture Sizes

Aperture	Diameter Range (μm)		Volume Range μm <sup>3</sup> or fL			
(Nominal Diameter, μm)	Total	Standard	Extended	Total	Standard	Extended
20*	0.4–16	0.4–12	12–16	0.034-2.14×10 <sup>3</sup>	0.034–905	905–2.14×10 <sup>3</sup>
30*	0.6–24	0.6–18	18–24	0.113-7.24×10 <sup>3</sup>	0.113-3.05×10 <sup>3</sup>	3.05×10 <sup>3</sup> –7.24×10 <sup>3</sup>
50	1.0–40	1.0–30	30–40	0.524-33.5×10 <sup>3</sup>	0.524-14.1×10 <sup>3</sup>	14.1×10 <sup>3</sup> –33.5×10 <sup>3</sup>
70	1.4–56	1.4–42	42–56	1.44-92.0×10 <sup>3</sup>	1.44-38.8×10 <sup>3</sup>	38.8×10 <sup>3</sup> –92.0×10 <sup>3</sup>
100	2.0–80	2.0-60	60–80	4.19–268×10 <sup>3</sup>	4.19–113×10 <sup>3</sup>	113×10 <sup>3</sup> –268×10 <sup>3</sup>
140	2.8–112	2.8-84	84–112	11.5–736×10 <sup>3</sup>	11.5–310×10 <sup>3</sup>	310×10 <sup>3</sup> –736×10 <sup>3</sup>
200	4.0–160	4.0–120	120–160	33.5-2.14×10 <sup>6</sup>	33.5–905×10 <sup>3</sup>	905×10 <sup>3</sup> –2.14×10 <sup>6</sup>
280	5.6–224	5.6–168	168–224	92.0-5.88×10 <sup>6</sup>	92.0-2.48×10 <sup>6</sup>	2.48×10 <sup>3</sup> –5.88×10 <sup>6</sup>
400	8.0–320	8.0–240	240–320	268–17.2×10 <sup>6</sup>	268-7.24×10 <sup>6</sup>	7.24×10 <sup>6</sup> –17.2×10 <sup>6</sup>
560	11.2–448	11.2–336	336–448	736–47.1×10 <sup>6</sup>	736–19.9×10 <sup>6</sup>	19.9×10 <sup>6</sup> –47.1×10 <sup>6</sup>
1000**	20–800	20–600	600–800	4189–268×10 <sup>6</sup>	4189–113×10 <sup>6</sup>	113.1×10 <sup>6</sup> –268×10 <sup>6</sup>
2000**	200–1600	200–1200	1200–1600	4.19×10 <sup>6</sup> –2.14×10 <sup>9</sup>	4.19×10 <sup>6</sup> –905×10 <sup>6</sup>	905×10 <sup>6</sup> –2.14×10 <sup>9</sup>

<sup>\*</sup> Range depends on system cleanliness and environmental electrical noise.

## **Installing an Aperture Tube**

This section describes how to correctly place an aperture tube in the Analyzer. After installing the aperture tube, you will need to:

- Calibrate the aperture
- Follow the step-by-step guide provided in the Change Aperture Tube Wizard. The Change
  Aperture Tube Wizard allows you to verify calibration, test aperture settings, and enter the new
  aperture tube size and serial number in the Multisizer 4 software.

### To install an aperture tube:

1. Clean the new ST Aperture Tube. For instructions on the proper aperture cleaning procedure, see *Cleaning the Aperture Tube, Beakers, and Accuvette® STs*, page 1-15.


3-2 PN A51387AB

<sup>\*\*</sup> Range depends on sample density.

### **∴** CAUTION

Small apertures (20  $\mu$ m and 30  $\mu$ m) are fragile. Beckman Coulter recommends that you handle them with great care. For more information on small aperture handling, cleaning, and operating procedures, see *Using Small Aperture Tubes* (20  $\mu$ m and 30  $\mu$ m), page 3-4.

- 2. If you have not already done so, power on the Analyzer, open the Multisizer 4 software, and connect the software to the Analyzer.
- 3. In the Multisizer 4 software, select Run > Change Aperture Tube Wizard on the Main Menu bar.
- **4.** In the Change Aperture Tube Wizard, click (Aperture Tube). The Select Aperture Tube window opens. For more information, see *Step 1: Select the new aperture tube*, page 3-23.
- 5. Hold the ST Aperture Tube bar code in front of the Bar Code Reader on the Control Panel.
  - If an operator has already calibrated the aperture and entered ST Aperture Tube information in the software, the software highlights the aperture tube size, serial number, and Kd. Click (OK).
  - If the ST Aperture Tube has not been entered into the system, the software displays the aperture tube size and serial number. To enter this information, use the Add New Aperture Tube window.
- **6.** Open the Sample Compartment door.
- 7. Lower the platform to the loading position using the platform release (see *Platform Release*, page 1-11).
- **8.** Turn the aperture tube knob in either direction until it points down. The aperture knob is locked only when the knob points up (12 o'clock position).
- 9. If necessary, remove the currently installed ST Aperture Tube, and click (Next).
- **10.** Insert the new ST Aperture Tube in the connection head with the logo facing you. Insert the tube as far as possible (0.88 in/22 mm).



Do not grease the aperture tube. The Multisizer 4 aperture tube connection forms a greaseless seal with O-rings.

- 11. Turn the aperture tube knob until it points up in the vertical position. Turning the knob until it is precisely vertical (in the 12 o'clock position) locks the aperture tube in place.
- 12. Return to the Change Aperture Tube Wizard and proceed through the remaining steps.

### Using Small Aperture Tubes (20 μm and 30 μm)

Small apertures (20  $\mu$ m and 30  $\mu$ m) are fragile and require special handling, cleaning, and operating procedures.

Because small apertures measure extremely small particles, it is necessary to take steps to safeguard the aperture tube and reduce electrical noise.

- Handle the aperture tube properly
- Remove environmental factors that can contribute to electrical noise
- Pre-filter cleaning fluids and electrolyte
- Clean the system thoroughly prior to using a small aperture tube
- Clean ST Beakers, Accuvette® STs, jars, ST Aperture Tubes, and other accessories
- Run a noise profile to verify a low background count
- Use appropriate current and gain settings
- Store the aperture tube properly
- Adhere to nano-particle calibration standards, if applicable

### **Handling Small Aperture Tubes**

Always wear powder-free latex or nitrile gloves when handling small aperture tubes and other system components and accessories, such as the Electrolyte Jar, ST Beakers, and Accuvette® STs.

Hold the aperture tube near the top during installation and removal (Figure 3.1). Avoid touching the aperture tube at the bottom, near the orifice.




Figure 3.1 Proper Handling of a Small Aperture Tube

3-4 PN A51387AB

### **Unblocking small aperture tubes**

The orifices of 20 µm and 30 µm aperture tubes block easily. To unblock the aperture, use the Unblock button in the Instrument Toolbar, or use Standard Operating Method settings to automatically unblock the aperture (see *Standard Operating Method: Blockage Detection*, page 4-18).



Never use an object or your finger to unblock the aperture.

### **Reducing Environmental Factors That Create Noise**

When measuring extremely small particles with a 20  $\mu$ m or 30  $\mu$ m aperture tube, take steps to ensure that the background count produced by electrical noise remains as low as possible.

Follow the instructions below to reduce environmental causes of electrical noise. For further information on possible sources of electrical noise, see *Reducing Noise*, page 9-1.

#### Create a dust-free lab environment

It will be almost impossible to obtain accurate particle counts if the instrument is located in a dust-laden atmosphere. Minimize Analyzer exposure to dust, debris, and airborne contaminants.

#### Reduce acoustic noise levels

Small apertures are extremely sensitive to ambient noise (banging, fan motors, even loud voices). Power off other machines and equipment in the vicinity, if possible.

#### **Reduce vibration**

Do not place the Analyzer on a table top that transmits vibrations from another machine.

#### **Block electrical interference**

Use an AC line conditioner on the Analyzer power cord to block electrical interference as required by local power conditions.

### **Pre-Filtering the Electrolyte and Cleaning Fluid**

When working with small apertures, it is necessary to pre-filter de-ionized water and/or ISOTON $^\circ$  II used to fill, flush, or clean the system and accessories. Filter the Isoton II or diluent solution with a compatible 0.2- $\mu$ m filter. A 0.1- $\mu$ m filter can also be used in series with a 0.2- $\mu$ m filter for additional filtering. Contact a filtration supplier to determine the appropriate filtration components for your application. One possible configuration for filtering large amounts of diluent is shown in Figure 3.2.




Figure 3.2 Closed-Circuit Filtration System

### Cleaning the Analyzer Prior to Using a Small Aperture

Before running analyses with a small aperture tube, clean the system. An effective cleaning procedure includes filling and draining the system multiple times and in multiple cycles, alternating between pre-filtered, de-ionized water and 98% isopropyl alcohol. For step-by-step instructions, see *Cleaning the Analyzer*, page 1-16.

### **Cleaning System Components and Accessories**

Before operating the system, rinse all system components and accessories in pre-filtered ISOTON® II (see *Pre-Filtering the Electrolyte and Cleaning Fluid*, page 3-5).

System components and accessories include:

- Electrolyte Jar
- Aperture Tube
- Electrode
- Particle Trap
- ST Beaker or Accuvette® ST

When handling small aperture tubes and other system components, wear powder-free latex or nitrile gloves.

#### To clean the aperture tube and electrode:

- 1. Press the platform release towards the back of the Sample Compartment and lower the platform to the loading position.
- 2. Use a squeeze bottle filled with clean or pre-filtered ISOTON® II to rinse the aperture tube, external electrode, and the stirrer (Figure 3.3, below).
- 3. Select a beaker that is at least one size larger than the size you used for the previous run (or a 400 mL beaker if you used that size for the previous run).

3-6 PN A51387AB

- **4.** Fill the clean beaker with clean or pre-filtered ISOTON® II or de-ionized water (see *Pre-Filtering the Electrolyte and Cleaning Fluid*, page 3-5). Make sure that the fluid level is higher than the fluid level during the previous run.
- 5. Lift the beaker to immerse the aperture tube and electrode in the beaker's filtered liquid. Swish to remove remaining particles.
- **6.** Place the beaker on the platform below the Aperture Tube and allow remaining liquid to drip into the beaker.

Figure 3.3 illustrates how to use a squeeze bottle filled with clean or pre-filtered ISOTON® II to clean an Aperture Tube. This is a convenient cleaning method that can be used to supplement the beaker immersion cleaning method.




Figure 3.3 Cleaning an ST Aperture Tube with a Squeeze Bottle

### **Small Aperture Noise Profiles**

The images below illustrate a typical noise profile obtained using a clean system, and a noise profile obtained using a system that requires additional cleaning.

The noise profile obtained using a clean Analyzer system (Figure 3.4) shows a background count primarily in the region between 0.4 and 0.5  $\mu$ m. Some background noise remains when using small apertures.

The noise profile obtained using an Analyzer system that has not been properly cleaned (Figure 3.5) shows a high background count due to system contamination.

Both profiles were obtained using a 20  $\mu m$  ST Aperture Tube and filtered ISOTON® II. Runs were completed in time mode (30 seconds) with current set to 600  $\mu A$  and gain set to 4. For information on current and gain settings appropriate for small apertures, see page 3-28.

If you are unable to obtain results similar to those in Figure 3.4 after thoroughly cleaning the system (see *Cleaning the Analyzer*, page 1-16), your aperture tube may be damaged or blocked.

#### NOTE

Figure 3.4 is an example of a clean noise profile. Factors such as aperture size, current and gain settings, and electrolyte can affect results. The noise profile graphs below show the relative difference between a system that is performing well Figure 3.4 and one that may need cleaning Figure 3.5.

For information on subtracting a blank run to obtain a noise profile, see *Using Blank Runs*, page 6-14.




Figure 3.4 Noise Profile, Clean System (20 μm aperture)

3-8 PN A51387AB




Figure 3.5 Noise Profile, Contaminated System (20 μm aperture)

### **Using Appropriate Current and Gain Settings**

The recommended current setting for 20  $\mu m$  and 30  $\mu m$  aperture tubes is 600  $\mu A$ . Higher currents can damage the aperture orifice and create noise as a result of the electrolyte overheating or boiling.

Beckman Coulter recommends that you set the gain to 4 and the current to 600 µA.

You can set current and gain using the Change Aperture Tube Wizard (see *Step 8: Set Current and Gain*, page 3-28) or the Edit the SOM window (see *Standard Operating Method: Threshold, Current and Gain*, page 4-13).

### **Storing Small Aperture Tubes**

### To store an aperture tube:

- 1. Remove the aperture tube from the Sample Compartment.
- **2.** Rinse the tube (inside and outside) several times with pre-filtered, de-ionized water (see *Cleaning System Components and Accessories*, page 3-6).
- 3. Fill the ST Aperture Tube with pre-filtered, de-ionized water.
- **4.** Fill a beaker with pre-filtered, de-ionized water.
- 5. Place the Aperture Tube in a clean beaker filled with pre-filtered, de-ionized water.
- **6.** Seal the top of the ST Aperture Tube with parafilm or plastic film.
- 7. Store in a dust-free environment.

### **Calibrating the Aperture**

When you calibrate the aperture, the Multisizer 4 runs an analysis to measure calibrator beads of a predetermined size (ranging from a nominal modal value of 2  $\mu$ m to 400  $\mu$ m). Calibrate the aperture with a particle standard that is 10% to 20% of the aperture size (20% is preferred).

Variations in the Analyzer's measurement of the calibrator beads determine the calibration constant (Kd) required for the Analyzer to measure the beads at their actual size.

The Kd takes into account many factors associated with the instrument and the aperture tube, including fluid flow characteristics, electrical resistance with the electrolyte, and imperfections of the orifice such as chip damage or wear.

When you verify aperture calibration (page 3-18), the Multisizer 4 Analyzer uses the Kd (or the mean Kd, if you have obtained 10 Kd values and calculated the mean) to verify that the instrument is measuring calibrator bead size accurately. Unlike the aperture calibration procedure, which returns a calibration constant (Kd) for the aperture orifice, the verification procedure returns the measured calibrator bead size.

#### NOTE

Calibration options are only available to user types with sufficient security privileges. If the Multisizer 4 software is running with no security, every operator can calibrate the aperture, create an SOP, and configure the software.

Calibrate the aperture after you:

- 1. Select a new aperture tube size (page 3-1)
- 2. Install the new aperture tube (page 3-2)

### **Choosing the Calibrator Size**

Before you calibrate the aperture, use the table below to choose the appropriate calibrator size. Beckman Coulter recommends that you calibrate the aperture with a particle standard that is 10% to 20% of the aperture size (20% is preferred).

The calibrator beads supplied with the Multisizer 4 Analyzer are suitable for use with a 100- $\mu$ m Aperture Tube.

Table 3.2 Choosing Calibrator Size

Calibrator Mean or Modal Size (µm)
2 – 4
3 – 6
5 – 10
7 – 14
10 – 20
14 – 28

3-10 PN A51387AB

Table 3.2 Choosing Calibrator Size

Aperture Size (μm)	Calibrator Mean or Modal Size (µm)
200	20 – 40
280	28 – 56
400	40 – 80
560	56 – 112
1000	100 – 200
2000	200 – 400



Sizing and statistical errors will occur if you do not use the proper procedure and/ or calibrator size.

#### **Nano-Size Particle Calibration Standards**

If you use polystyrene nano-particle calibrators, Beckman Coulter recommends that you keep the concentration level below 2%.

Polystyrene nano-particles can bind to system components. After the Multisizer 4 has analyzed a high concentration of nano-particles, it is necessary to clean the aperture tube and external electrode thoroughly.

Systems with high levels of nano-particle contamination will require several filling and draining cycles to return background counts to normal levels. For information on the recommended cleaning procedure, see *Cleaning the Analyzer*, page 1-16.


### **Selecting Calibration Options**

*To select calibration options:* 

1. Select Calibration > Aperture Calibration Options on the Main Menu bar. The Aperture Calibration Options window opens.

#### **NOTE**

The **Calibration > Aperture Calibration Options** menu item is only available to user types with sufficient security privileges. If the Multisizer 4 software is running with no security, every operator can calibrate the aperture.



- 2. In the Aperture Options window:
  - **a.** In the Calibrate using pane, select the basis for calibration (for example, the Mean Diameter or Modal Diameter). Beckman Coulter recommends that you calibrate the system using the standards on the assay sheet supplied with the calibrator.
  - **b.** If you would like the Multisizer 4 software to prompt the operator to verify calibration at regular intervals:
    - Select Verify Aperture Calibration.
    - In the Day(s) field, enter the number of days between reminders.
  - c. Click (OK).

### **Preparing the Analyzer for Calibration**

#### To prepare the Analyzer for calibration:

1. Fill a clean ST Beaker or Accuvette® ST with electrolyte solution.

#### **NOTE**

For aperture tubes up to 100  $\mu$ m, you can use an Accuvette® ST (20 mL) and pre-filtered ISOTON® II (see *Pre-Filtering the Electrolyte and Cleaning Fluid*, page 3-5). Use an ST Beaker for any aperture tube size larger than 100  $\mu$ m.

- 2. Add a few drops of the calibrator to the electrolyte solution.
- 3. If necessary, use the platform release (page 1-11) and lower the platform to the loading position.
- **4.** If necessary, turn the platform so that the correct side (with the ST Beaker or Accuvette® ST guide) is on top (page 1-11).

3-12 PN A51387AB

#### **NOTE**

The beaker or Accuvette® ST guide on the platform ensures that the aperture tube, electrode, and stirrer are correctly positioned inside the beaker or Accuvette® ST when you raise the platform.

- 5. Place the filled Accuvette® ST or beaker on the platform.
- **6.** Raise the platform.

#### **NOTE**

It is not necessary to use the platform release to lift the platform into position.

- 7. Select Run > Preview on the Main Menu bar. The Status Panel displays Progress.
- **8.** On the Status Panel, verify that the Concentration index bar shows a value as close as possible to 10%.

#### NOTE

Start with a low concentration and build up to 10%. It may be difficult to clean a high concentration of calibrator beads from the system. If necessary, dilute the sample to lower the concentration to an acceptable level.

If the concentration of calibrator beads is greater than 10%, the Concentration index bar will display High. If the concentration of particles is too low, calibration time will increase. In either case, stop the calibration, adjust the calibrator concentration, and recalibrate the aperture.



If you are using a polystyrene nano-particle calibrator, keep the concentration level below 2%.

### **Running the Calibration**


Before you run the calibration, select a calibrator size and prepare the Analyzer for calibration.

#### *To calibrate the aperture:*

1. Select Calibration > Calibrate Aperture on the Main Menu bar. The Calibrator Size window opens.

#### NOTE

The **Calibration > Calibrate Aperture** menu item is only available to user types whose security settings allow them to create a Standard Operating Procedure (SOP). If the Multisizer 4 software is running with no security, every operator can calibrate the aperture.



2. In the Calibrator Size window, enter the Modal diameter of calibrator. This value appears on the assay sheet supplied with the calibrator.

To select the appropriate calibrator for your aperture tube size, see *Choosing the Calibrator Size*, page 3-10.

#### **NOTE**


The recommended calibrator size range is 10% to 20% of the aperture diameter; however, the software allows entries from 3% to 50% of the aperture diameter.

- 3. Click (Start).
- **4.** On the Status Panel, verify that the Concentration index bar shows a value as close as possible to 10%.

#### NOTE

Start with a low concentration and build up to 10%. It may be difficult to clean a high concentration of calibrator beads from the system. If necessary, dilute the sample to lower the concentration to an acceptable level.

If the concentration of calibrator beads is greater than 10%, the Concentration index bar will display High. If the concentration of particles is too low, calibration time will increase. In either case, stop the calibration, adjust the calibrator concentration, and recalibrate the aperture.



If you are using a polystyrene nano-particle calibrator, keep the concentration level below 2%.

### **Pausing or Stopping Calibration**

During calibration, the Multisizer 4 software displays a graph in the Viewing Area. The Status Panel displays elapsed time, total particle count, and particle concentration.

#### To pause or stop calibration:

In the Instrument Toolbar, click (Pause), (Stop), or (Cancel) to interrupt the calibration process.

3-14 PN A51387AB


Table 3.3 Pausing / Stopping Calibration

Click	То
(Pause)	Pause the calibration.
(Stop)	Stop the calibration. The Multisizer 4 software displays calibration results from the stopped run in the Calibrate Aperture window.
(Cancel)	Cancel the calibration. The Multisizer 4 software does not display calibration results. To restart calibration, select <b>Calibration</b> > <b>Calibrate Aperture</b> on the Main Menu bar.

### Completing the Calibration Run (Accepting the Kd)

### To complete the calibration run:

1. When the calibration run is complete or stopped, a Calibrate Aperture window opens.



2. In the Calibrate Aperture window, the Kd pane displays the Old and New Kd values.

#### **NOTE**

If this is the first calibration run, the Old Kd value is assigned an estimated value based on aperture size.

- a. Click (Find Peak) to place cursors at or on either side of the peak of the calibration graph. If you are performing a modal calibration, clicking (Find Peak) automatically places a cursor on the modal channel. If you are performing a mean calibration, (Find Peak) automatically places two cursors on the graph, one on either side of the peak. The cursor(s) define the mode or median used to calculate the new Kd.
- b. Click (Print) to print the window. This button does not display a dialog box or allow you to change print settings.
- **c.** In the Use New Kd for pane, select an option to use the new Kd for the next analysis run only, all subsequent runs, or to update the aperture list.
- d. Click (Accept New Kd) to enter the new Kd and close the window.

#### NOTE

When you calibrate the aperture, the Multisizer 4 runs an analysis to measure calibrator beads of a predetermined size (ranging from a nominal modal value of 2  $\mu$ m to 90  $\mu$ m). Deviations in the Analyzer's measurement of the calibrator beads determine the calibration constant (Kd) required for the Analyzer to measure the beads at their actual size.

The Kd takes into account many factors associated with the instrument and the aperture tube, including fluid flow characteristics, electrical resistance with the electrolyte, and imperfections of the orifice such as chip damage or wear.

### **Obtaining the Mean Kd**

For consistent results, perform the aperture calibration procedure at least 10 times and calculate the mean calibration constant (Kd). In future calibration runs, the Kd should be within 4% (+ or -) of the mean Kd value.

#### To obtain the mean Kd:

- 1. Calibrate the aperture.
- 2. Record the Kd value.
- 3. Repeat the calibration procedure nine times until you have 10 Kd values.
- **4.** Add the 10 values and divide by 10 to obtain the mean value.

#### NOTE

The mean Kd value is valid only for the aperture tube, electrolyte, and Analyzer combination used for the calibration.

3-16 PN A51387AB

### **Example**

This example uses a 10 µm calibrator and a 100 µm Aperture Tube.

Table 3.4 Obtaining Mean Kd Value


Run	Kd
1	124.15
2	125.82
3	125.13
4	125.23
5	125.43
6	125.13
7	124.25
8	125.62
9	124.25
10	125.03
MEAN	125

### **Updating the Mean Kd Value**


If you have calculated the mean calibration constant (Kd) value for the aperture (page 3-16), you can manually enter the Kd value using the Change Aperture Tube Wizard.

#### To enter the mean Kd value:

- 1. Select Run > Change Aperture Tube Wizard on the Main Menu bar.
- 2. In the Change Aperture Tube Wizard, click (Aperture Tube) to the right of the Select a new aperture tube step. The Select Aperture Tube window opens.



3. In the Select Aperture Tube window, click (Edit List). The Edit Aperture Tube List window opens.



- 4. In the Edit Aperture Tube List window:
  - a. In the Diameter/Serial Number/Kd/Comment box, click the row you want to edit.
  - b. Enter the new mean Kd in the Kd field.
  - c. Click (Update).
  - **d.** Click OK to return to the Select Aperture Tube window.

#### **NOTE**

If you enter a Kd value that is too low or too high for the expected operation, the software will display a warning message.

- **5.** In the Select Aperture Tube window:
  - **a.** In the Diameter/Serial Number/Kd box, click to highlight an Aperture Tube.
  - **b.** Click (OK) to return to the Wizard.
- **6.** Click (Close) to exit the Wizard.

### **Verifying the Calibration**

When you verify aperture calibration, the Multisizer uses the Kd (or the mean Kd, if you have obtained 10 Kd values and calculated the mean) to verify that the instrument is measuring calibrator bead size accurately. Unlike the aperture calibration procedure (page 3-13), which returns a calibration constant (Kd) for the aperture orifice, the verification procedure returns the measured calibrator bead size.


Because the Analyzer uses constant current, the instrument holds the calibration for an indefinite time, provided that the working conditions are stable and you are using the same aperture tube and electrolyte combination. If working conditions are not stable, you can select an option to prompt

3-18 PN A51387AB

the operator to verify the calibration at regular intervals using the Aperture Calibration Options window (page 3-11).

#### To verify aperture calibration:

- 1. Select Calibration > Verify Aperture Calibration on the Main Menu bar.
- 2. In the Calibration Size window, enter the Modal diameter of calibrator in the field. This value appears on the assay sheet supplied with the calibrator.



To select the appropriate calibrator for your aperture tube size, see *Choosing the Calibrator Size*, page 3-10.

#### NOTE

The recommended calibrator size range is 10% to 20% of the aperture diameter; however, the software allows entries from 3% to 50% of the aperture diameter.

- 3. Click (Start).
- **4.** On the Status Panel, verify that the Concentration index bar shows a value as close as possible to 10%.


#### **NOTE**

Start with a low concentration and build up to 10%. It may be difficult to clean a high concentration of calibrator beads from the system.

If the concentration of calibrator beads is greater than 10%, the Concentration index bar will display High. If the concentration is too low, calibration time will increase. In either case, stop the calibration, adjust the calibrator concentration, and recalibrate the aperture.



If you are using a polystyrene nano-particle calibrator, keep the concentration level below 2%.



5. When the run is complete, the Verify Aperture Calibration window opens.

**6.** In the Verify Aperture Calibration window:

Table 3.5 Verifying Aperture Calibration

If the window displays	Then
The Calibration is OK	The measured particle size is within 3% of the actual calibrator size, and the calibration was successful.
	Click (Close) to exit the window.
The instrument needs to be recalibrated	The measured variation is too great, and the calibration was not successful.
	1. Click (Close) to exit the window.
	2. In the Instrument Toolbar, click (Reset).
	<b>3.</b> If necessary, adjust the amount of calibrator in the electrolyte solution.
	4. Restart the calibration procedure.

- If desired, click (Find Peak) to place cursors at or on either side of the peak of the calibration graph. If you are performing a modal calibration, clicking (Find Peak) automatically places a cursor on the modal channel. If you are performing a mean calibration, (Find Peak) automatically places two cursors on the graph, one on either side of the peak. The cursor(s) define the mode or median used to calculate the new Kd.
- If desired, click (Print) to print the window. This button does not display a dialog box or allow you to change print settings.

3-20 PN A51387AB

# **Saving the Calibration File**

After you have calibrated the aperture (page 3-10), the calibration results appear in the Viewing Area. Results are displayed as a size graph.

#### To save the calibration run:

- 1. Select RunFile > Save on the Run Menu bar, or click (Save) in the Main Toolbar.
- 2. In the Save As window, navigate to the appropriate folder.
- 3. In the File name field, enter a name for the calibration file.

#### **NOTE**

The Multisizer 4 software uses the .#m4 extension for all run data files, including calibration runs.

4. Click (Save).

# The Change Aperture Tube Wizard


The Change Aperture Tube Wizard in the Multisizer 4 software provides step-by-step instructions to guide you through the steps you need to follow when installing a new aperture tube. The Wizard allows you to verify aperture calibration, test aperture settings, and enter the new aperture tube size and serial number.

Use the Change Aperture Tube Wizard after you have:

- Powered ON the Analyzer and connected the software to the Analyzer
- Selected the aperture tube size
- Calibrated the aperture, and
- Emptied the Waste Tank

#### To use the Change Aperture Tube Wizard:

Select **Run > Change Aperture Tube Wizard** on the Main Menu bar. The Change Aperture Tube Wizard window opens.



The following sections describe how to use the Change Aperture Tube Wizard:

- Step 1: Select the new aperture tube, page 3-23
- Step 2: Remove the Currently Installed Aperture Tube, page 3-26
- Step 3: Install the New Aperture Tube, page 3-26
- Step 4: Place a Beaker of Clean Electrolyte on the Platform, page 3-27
- Step 5: Close the Door, page 3-27
- Step 6: Fill the System, page 3-28
- Step 7: Adjust the Metering Pump, page 3-28
- Step 8: Set Current and Gain, page 3-28
- Step 9: Measure Noise Level, page 3-30
- Step 10: Verify Calibration, page 3-31
- Step 11: All Done, page 3-33

3-22 PN A51387AB


In the Change Aperture Tube Wizard window, click (Next) at the top of the window to proceed to the next step. Click (Back) to return to the previous step.

## Step 1: Select the new aperture tube

When you install a new aperture tube, you will need to enter the aperture tube size and serial number in the Multisizer 4 software.

#### To select the aperture tube:

1. In the Change Aperture Tube Wizard, click (Aperture Tube) to the right of the Select a new aperture tube radio button. The Select Aperture Tube window opens.




- 2. If the aperture tube (identified by size, serial number, and Kd) has been entered into the software, click to highlight the correct aperture tube. To ensure that you select the correct aperture tube serial number and Kd, you can scan the aperture tube bar code. For information on using the Bar Code Reader, see page 1-7.
  - If the aperture tube does not appear in the list, you will need to enter the aperture tube size, serial number, and Kd (after aperture tube calibration). See *Entering and Editing Aperture Tube Information*, page 3-23.
- 3. Click OK to return to the Wizard. The Wizard automatically highlights the next step, Remove the currently installed aperture tube (page 3-26).

## **Entering and Editing Aperture Tube Information**

To enter or update the size, serial number, and Kd of a new aperture tube in the Multisizer 4 software, use the Change Aperture Tube Wizard.

#### To add a new aperture tube:

- 1. In the Change Aperture Tube Wizard, click (Aperture Tube).
- 2. In the Select Aperture Tube window, click (Add New Tube). The Add New Aperture Tube window opens.



3. In the Add New Aperture Tube window, select the aperture size from the Diameter drop-down list and enter the Serial Number and mean Kd value.

To enter the tube size and serial number automatically, hold the aperture tube bar code in front of the Bar Code Reader. The Multisizer 4 software will enter the aperture Diameter, Serial Number, and estimated Kd value in the appropriate text fields. For information on using the Bar Code Reader, see page 1-1.

#### **NOTE**

For information on aperture tube calibration, see page 3-10. For information on obtaining the mean Kd, see page 3-16.


- **4.** Click (OK) to return to the Select Aperture Tube window.
- 5. In the Select Aperture Tube window:
  - **a.** In the Diameter/Serial Number/Kd/Comment box, click to highlight the aperture tube you will be installing.
  - **b.** Click **OK**) to return to the Wizard.

The Wizard automatically highlights the next step, Remove the currently installed aperture tube (page 3-26).

3-24 PN A51387AB

#### To edit the aperture tube list:

- 1. In the Change Aperture Tube Wizard, click (Aperture Tube).
- 2. In the Select Aperture Tube window, click (Edit List). The Edit Aperture Tube List window opens.



- 3. In the Edit Aperture Tube List window:
  - a. In the Diameter/Serial Number/Kd/Comment box, click the row you would like to edit.
  - **b.** Enter a new Serial Number and/or the mean Kd in the text fields (see *Obtaining the Mean Kd*, page 3-16).
  - c. Click (Update).
- **4.** Click OK to return to the Select Aperture Tube window.
- 5. In the Select Aperture Tube window:
  - **a.** In the Diameter/Serial Number/Kd/Comment box, click to highlight the row displaying serial number and Kd of the aperture tube you installed.
  - **b.** Click (OK) to return to the Wizard.

The Wizard automatically highlights the next step, Remove the currently installed aperture tube (page 3-26).

# **Step 2: Remove the Currently Installed Aperture Tube**

The Change Aperture Tube Wizard prompts you to remove the currently installed aperture tube from the Sample Compartment, if necessary.



For information on removing an aperture tube, see Installing an Aperture Tube, page 3-2.

In the Change Aperture Tube Wizard, click (Next) to proceed to the next step, Install the new aperture tube (page 3-26).

# **Step 3: Install the New Aperture Tube**

After you remove the previously installed aperture tube from the Sample Compartment, the Change Aperture Tube Wizard prompts you to install the new aperture tube.

For instructions, see *Installing an Aperture Tube*, page 3-2.



In the Change Aperture Tube Wizard, click (Next) to proceed to the next step, Place a beaker of clean electrolyte on the platform.

3-26 PN A51387AB

## Step 4: Place a Beaker of Clean Electrolyte on the Platform

It is necessary to place a beaker of clean electrolyte on the platform before filling the system. If the aperture is not immersed in electrolyte while the system fills, the Analyzer will draw air through the aperture and into the system during the fill procedure.



#### To place a beaker of clean electrolyte on the platform:

- **1.** Wash the beaker. For instructions on the proper cleaning method, see *Cleaning the Aperture Tube*, *Beakers, and Accuvette® STs*, page 1-15.
- 2. Fill the beaker with electrolyte solution.
- 3. Open the Sample Compartment door.
- **4.** If necessary, press the platform release (see *Platform Release*, page 1-11) and lower the platform to the loading position.
- 5. Place the beaker on the platform (beaker side up). The beaker guides ensure that a Multisizer 4 Smart Technology Beaker of any size will be in the correct position in relation to the aperture tube, electrode, and stirrer when you raise the platform.
  - If you are using an Accuvette® ST, reverse the platform to use the Accuvette® ST guide (see *Sample Platform*, page 1-9).
- **6.** Raise the platform until it locks into position for an analysis run. It is not necessary to use the platform release when you raise the platform.
- 7. Fill the Electrolyte Jar with the same electrolyte solution used in the ST Beaker.

In the Change Aperture Tube Wizard, click (Next) to proceed to the next step, Close the door (page 3-27).

# Step 5: Close the Door

If the software detects that the Sample Compartment door is closed, the Wizard will skip this step.

If the Sample Compartment door remains open when you attempt to start an analysis run, the amber light will flash, and the software will display an error message.

In the Change Aperture Tube Wizard, click (Next) to proceed to the next step, Fill the System.

## **Step 6: Fill the System**

When you install a new aperture tube, it is necessary to remove air from the system. The system fills from the Electrolyte Jar into the Waste Tank. (Electrolyte does not pass through the aperture orifice unless you are using the Unblock function to clear the orifice.) This procedure is similar to flushing the system to remove particles.

#### To fill the system:

- 1. In the Change Aperture Tube Wizard, click (Next) until you reach the step Fill the system if it is not already highlighted.
- 2. In the Status Panel, verify that the Waste Tank is empty. If the Waste Tank is not empty, exit the Change Aperture Tube Wizard and click (Empty) in the Instrument Toolbar. Re-open the Wizard and click (Next) until the (Fill System) button is selected.
- 3. To the right of the Fill the system step, click (Fill System).
- **4.** The Status Panel displays progress while the system is filling.
- 5. When the process is complete, the Status Panel displays READY and the Wizard automatically highlights the next step, Adjust the metering pump (page 3-28).

# **Step 7: Adjust the Metering Pump**

This step appears in the Change Aperture Tube Wizard only if you are using an aperture tube smaller than 400  $\mu$ m. The metering pump is required only when using volumetric mode. Aperture tubes 400  $\mu$ m and larger can be used only in time and count modes.

For information on control modes (volumetric, time, and count) see *Standard Operating Method: Control Mode*, page 4-6.

#### To adjust the metering pump:

- 1. In the Change Aperture Tube Wizard, click (Next) until you reach the Adjust the metering pump step if it is not already highlighted.
- 2. To the right of the Adjust the metering pump step, click (Metering Pump).
- 3. The Status Panel displays Adjusting Metering Pump.
- **4.** When the process is complete, the Status Panel displays READY and the Wizard automatically highlights the next step, Set current and gain (page 3-28).

## **Step 8: Set Current and Gain**

Setting current and gain determines the electrical pulse size (current) and amplification (gain) that the Analyzer will use as particles pass through the aperture. Unless you are running Service Mode (page 9-18), the Multisizer 4 software sets current and gain automatically.


3-28 PN A51387AB



If you are using a 20-μm or 30-μm aperture tube, the recommended current setting is 600 μA. Higher currents can erode the aperture and create electrical noise. Beckman Coulter recommends that you set the gain to 4, and the current to 600 μA. For information on how to change current and gain settings, see *Standard Operating Method: Threshold, Current and Gain*, page 4-13.

#### To set current and gain:

- 1. In the Change Aperture Tube Wizard, click (Next) until you reach the step Set Current and Gain if it is not already highlighted.
- 2. To the right of the Set Current and Gain step, click (Current & Gain). The Current and Gain Settings window opens.



- 3. In the Current and Gain Settings window, click ( $\overline{\text{Auto-Set}}$ ). If you are using 20- $\mu$ m or 30- $\mu$ m aperture tubes, Auto-Set is not available. Use the system defaults by clicking the ( $\overline{\text{Defaults}}$ ) button.
  - **a.** The window expands to display automatic settings for particles and cells.
  - **b.** The Analyzer measures electrical resistance through the aperture. MEASURING RESISTANCE appears in the Status Panel.
    - During the Measuring Resistance procedure, the software selects a current setting based on the size of the aperture tube and the concentration of the electrolyte solution. Using an electrolyte solution at a lower concentration increases the electrical resistance and

requires a higher current setting. If you are using a more concentrated electrolyte solution, the software will select a lower current setting.

A low current with high gain will increase the noise level. A current set too high could saturate the amplifier, damage the aperture orifice, distort your results, or damage cells. The Auto-Set feature selects the optimum conditions based on the aperture size and electrolyte solution.

#### **NOTE**

A blocked aperture or air in the aperture tube will raise resistance and cause an error message to display. Click (Cancel) to close the wizard, then, in the Instrument Toolbar, click (Unblock) to clear the aperture orifice, or click (Flush) to flush particles out of the system before proceeding.

When the system finishes the unblocking process, re-open the wizard by selecting **Run** > **Calibrate Aperture Tube Wizard** and clicking (Next) until Set Current and Gain is selected. Click the (Current & Gain) button, then click (Auto-Set).

**4.** In the expanded Current and Gain Settings window, select Particles or Cells. If you select Cells, enter the Maximum Cell Volume.



Selecting Particles when you are analyzing Cells can cause cell damage due to a higher current setting.

- 5. To return to system default settings, click (Defaults).
- 6. Click OK to return to the Change Aperture Tube Wizard.
- 7. The Wizard automatically highlights the next step, Measure noise level (page 3-30).

# **Step 9: Measure Noise Level**

When the system sets current and gain (page 3-28), the software selects an electrical current setting based on the size of the aperture tube and the concentration of the electrolyte solution. If you are using a small aperture tube or a concentrated electrolyte solution, the software will select a low current/high gain setting.

For information on reducing noise levels when using small apertures, see *Reducing Environmental Factors That Create Noise*, page 3-5.

For information on current and gain settings appropriate for small apertures, see *Using Appropriate Current and Gain Settings*, page 3-9.

#### To measure the noise level:

- 1. In the Change Aperture Tube Wizard, click (Next) until you reach the step Measure noise level if it is not already highlighted.
- 2. To the right of the Measure noise level step, click (Measure Noise).
- 3. The Status Panel displays MEASURING NOISE LEVEL.

3-30 PN A51387AB

**4.** When the process is complete, the Status Panel displays READY. The noise level is displayed as a percentage of aperture size below the Measure noise level step (in grey text). The Wizard automatically highlights the next step, Verify Calibration (page 3-31).


# **Step 10: Verify Calibration**

This step in the Change Aperture Tube Wizard assumes that you have already calibrated the currently installed aperture tube (page 3-10). The Multisizer 4 software will automatically verify the calibration of the aperture tube using the serial number you entered in *Step 1: Select the new aperture tube*, page 3-23.

If you have not calibrated the aperture tube, exit the Wizard and calibrate the aperture (page 3-10).

#### To verify aperture tube calibration:

- 1. In the Change Aperture Tube Wizard, click (Next) until you reach the step Verify Calibration.
- 2. To the right of the Verify Calibration step, click (Verify). The Calibrator Size window opens.



- **3.** Enter the appropriate calibrator size.
- 4. Prepare the Analyzer for calibration.
- 5. In the Calibrator Size window, click (Start). For more information on the verification procedure, see *Verifying the Calibration*, page 3-18.

Verify Aperture Calibration

Date: 17 Oct 2007 Instrument Serial Number: EP003
Aperture: 100 μm Aperture Serial Number: 7852

Modal diameter of calibrator: μm

Measured Size: 19.78 μm Change: -1.1%

Find Peak

Close

Print The calibration is OK

6. When the verification is complete, the Verify Aperture Calibration window opens.

7. In the Verify Aperture Calibration window:

**Table 3.6** Verify Aperture Calibration Window

If the window displays	Then
The calibration is OK	The measured particle size is within 3% of the actual calibrator size, and the calibration was successful.
The instrument needs to be recalibrated	The measured variation is too great, and the calibration was not successful.
	1. Click (Close) to exit the window.
	2. In the Instrument Toolbar, click (Reset).
	<b>3.</b> If necessary, adjust the amount of calibrator in the electrolyte.
	4. Restart the calibration procedure.

- If desired, click (Find Peak) to place cursors at or on either side of the peak of the calibration graph. If you are performing a modal calibration, clicking (Find Peak) automatically places a cursor on the modal channel. If you are performing a mean calibration, (Find Peak) automatically places two cursors on the graph, one on either side of the peak. The cursor(s) define the mode or median used to calculate the new Kd.
- If desired, click (Print) to print the window. This button does not display a dialog box or allow you to change print settings.

When you click Close to exit the Verify Aperture Calibration window, the Change Aperture Tube Wizard closes.

3-32 PN A51387AB

# Step 11: All Done

Click (Close) or (Done) to exit the Wizard. If you have verified calibration, the Wizard closes automatically when verification is complete.

# **Running a Concentration Control Sample**

Analyzing a concentration control sample at regular intervals allows you to verify count accuracy.

The software automatically uses the following settings when running a control sample:

- Electrolyte solution volume: 20 mL (Accuvette® ST only)
- Calibrator volume: 0.2 mL (200 µL)
- Dilution factors: none
- Mode: Volumetric (500 µL)
- Flush before run: Yes
- Number of runs: 1
- File save, print, or export: Off
- Size bins: 400 log diameter size bins from 8 μm to 12 μm
- Coincidence correction: On
- Edit: Off
- View: Differential number size graph, linear diameter X axis; graph displays number per mL when run is complete

# **Setting Control Sample Options**


To specify a control sample run and set recurring reminders:

1. Select Calibration > Control Sample Options on the Main Menu bar.

#### NOTE

The Control Sample Options menu item is only visible to user types with sufficient security privileges. The system administrator configures security settings. If the Multisizer 4 software is running with no security, every operator can set control sample options, create an SOP, and configure the software.

2. In the Control Sample Options window:




- a. Select Run a Control Sample.
- **b.** If you would like the Multisizer 4 software to prompt you to run a control sample at regular intervals:
  - Select Hours or Days for the intervals between reminders.
  - In the Every field, enter the number of hours or days between control sample runs.
- c. Click (OK).

# **Running a Concentration Control Sample**

To run a concentration control sample:

- 1. Fill a clean Accuvette® ST with 20 mL electrolyte solution and 0.2 mL (200 µL) calibrator.
- 2. Place the Accuvette® ST on the Analyzer platform and raise the platform. For more information on preparing the Analyzer, see *Preparing the Analyzer for Sample Runs*, page 1-18.
- 3. Select Calibration > Run Concentration Control on the Main Menu bar. The Concentration Control window opens.



3-34 PN A51387AB

- **4.** In the Concentration Control window, enter the Lot Number, the Concentration Assay Value, and the Expiration Date listed on the assay sheet.
- 5. Click (Start) to begin the concentration control run.
- **6.** The Multisizer 4 software flushes the system and begins the run.
- 7. When the run is complete, a second Concentration Control window opens and displays results. The window displays a message that the concentration is low or high if the Analyzer measurement deviates from the concentration control by 10% or more. If this occurs, contact Beckman Coulter Service. For information on how to do this, see *Working with Field Service* on page 9-15.
- 8. Click (Close).

# **Installing and Calibrating an Aperture Tube**Running a Concentration Control Sample

3-36 PN A51387AB

# Selecting Analysis Settings: SOM and SOP

# **Definitions: SOM, Preferences, and SOP**

## Standard Operating Method (SOM)

Use a Standard Operating Method (SOM) to specify sample analysis settings such as the control mode, file name, pulse settings (current and gain), the number of size bins, and sample concentration information.

For more information on creating a Standard Operating Method, see *Using the Create SOM Wizard*, page 4-2.

#### **Preferences**

Create a Preferences file to specify view and print settings, including graph, statistics, trend, page setup, and export settings.

You can save your Preferences to a file and load the Preferences file into the Multisizer 4 software when needed. You can also include the Preferences file in a Standard Operating Procedure (SOP).

For more information on setting Preferences, see *Creating a Preferences File*, page 5-1.

#### Standard Operating Procedure (SOP)

A Standard Operating Procedure (SOP) combines one Preferences file and one Standard Operating Method (SOM) into an overall settings file for a particular type of analysis. Within the SOP, the SOM file determines sample run settings, while the Preferences file determines view and print specifications.

If you have saved default or custom SOM and Preferences files, you can create one or more Standard Operating Procedures (SOPs). Standard Operating Procedures are helpful if you are running several types of analyses that require different settings.

For more information on creating a Standard Operating Procedure, see *Creating an SOP*, page 4-26.

# **Using a Standard Operating Method (SOM)**

# **Using the Create SOM Wizard**

If you are creating a Standard Operating Method (SOM) for the first time, use the Create SOM Wizard.

If you are already familiar with using an SOM, or if you are changing only a few settings, bypass the Wizard and select **SOP** > **Edit the SOM** on the Main Menu bar (see *Editing SOM Settings*, page 4-23).

#### **NOTE**

The Multisizer 4 software will not allow you to open the SOM Wizard if a Standard Operating Procedure (SOP) is loaded. To remove an SOP, click (Remove SOP) in the Status Panel, or select SOP > Remove the SOP on the Main Menu bar.

#### To use the Standard Operating Method (SOM) Wizard:

- If you have not connected to the Analyzer, select Run > Connect to Multisizer 4 on the Main Menu bar.
- 2. Select **SOP** > **Create SOM Wizard** on the Main Menu bar. The SOM (Standard Operating Method) Wizard opens.

The SOM Wizard includes the following steps:

- Standard Operating Method: Description, page 4-3
- Standard Operating Method: Control Mode, page 4-6
- Standard Operating Method: Run Settings, page 4-8
- Standard Operating Method: Stirrer Settings, page 4-10
- Standard Operating Method: Threshold, Current and Gain, page 4-13
- Standard Operating Method: Pulse to Size Settings, page 4-15
- Standard Operating Method: Concentration Information, page 4-17
- Standard Operating Method: Blockage Detection, page 4-18
- SOM Wizard: Summary of Settings, page 4-21

4-2 PN A51387AB

#### **NOTE**

You can exit the SOM Wizard at any time; however, your changes will be lost unless you save them. Go to Step 9 in the SOM Wizard, and click (Save).

## **Standard Operating Method: Description**

Use Step 1 of the SOM Wizard (page 4-2) to enter descriptive information, aperture and electrolyte specifications, and automatic file name defaults. You can also enter file name settings using the Run Settings tab in the Edit the SOM window (page 4-23).




Table 4.1 SOM Wizard (Step 1): Field Descriptions

In the field	Enter or select
SOM Author	An author or operator name, if desired. Information entered in this field is displayed when you select <b>RunFile</b> > <b>Get Info</b> on the Run Menu bar.
SOM Description	A description for the SOM. Information entered in this field is displayed when you select <b>RunFile &gt; Get Info</b> on the Run Menu bar.
Sample Description	A description of the sample, if desired. Information entered in this field is displayed when you select <b>RunFile</b> > <b>Get Info</b> on the Run Menu bar.
Aperture	Aperture size. Select the aperture size from the drop-down list. This list includes all aperture sizes that have been entered in the Change Aperture Tube Wizard (page 3-21).
Electrolyte	The type of electrolyte. Enter the electrolyte name or select the electrolyte from the drop-down list.
Dispersant	The type of dispersant, if applicable. Enter the dispersant name or select the dispersant from the drop-down list.

#### *In the Description window:*

- Click (File Name) to set automatic file name generation settings (page 4-4).
- Click (New SOM) to set all fields to their default values and enter a new Standard Operating Method.
- Click (Load SOM) to load previously saved SOM settings into the Wizard.

## **Creating Automatically Generated Analysis File Names**


To automatically generate a file name, you will need to enter sample information before each analysis run (or set of analysis runs). To enter sample information, select **Sample > Enter Sample Info** on the Main Menu bar. For more information, see *Entering Sample Information*, page 6-5.

By selecting file name options when you create a Standard Operating Method (SOM), you can use information entered in the Enter Sample Info for Next Run text fields to create individual or sequential file names that will help you organize your data.

#### To automatically generate a file name for each analysis:

- 1. Select **SOP** > **Create SOM Wizard** on the Main Menu bar.
- 2. In Step 1 of the SOM Wizard, click (File Name). The File Name Generation window opens.

  If you are creating or updating an SOM using the Edit the SOM window (page 4-23), the (File Name) button is located on the Run Settings tab.



3. In the File Name Generation window, select each sample information field you want to include in file names. As you select text fields to include, associated template codes appear in the

4-4 PN A51387AB

Template field at the bottom of the window. For information on these codes, see *Using File Name Template Codes*, page 4-5.

#### NOTE

If necessary, you can change the Template field by entering new information manually. The character range specified below the Template field will change automatically based on the number of fields and character limits you select.

- **4.** For File ID, Sample ID, Operator, and Bar Code, you can limit the number of characters that will be included in the file name. To set a limit, enter the maximum number of characters for each selected field in the Up to field.
- 5. In the Instrument Extension pane, accept the defaults or, if desired, enter the extension you would like to use for your analysis files in the Multisizer 4 field.

#### **NOTE**

File extensions do not affect file format. You can open any Multisizer 4 analysis with Multisizer 2 or 3 software. Features specific to the Multisizer 4 will not be available when opened in earlier software versions.

**6.** Click (OK) to save your settings.

## **Using File Name Template Codes**

In the File Name Generation window (page 4-4), each sample information field is preceded by a code that the Multisizer 4 software uses when creating a template for the file name. For example, the template:

will create the following file name:

#### FileID\_Sample\_RunNumber\_UniqueNumber.Extension

In this example, the File ID and Sample ID (<F10> and <S10>, respectively) will be included up to a maximum of 10 characters. The Run number will have a maximum of one digit, and the Unique Number will have a maximum of two digits.

Table 4.2 File Name Generation Codes

Code	Enter Sample Info Field
<f#></f#>	File ID (Group Name)
<s#></s#>	Sample ID
<0#>	Operator
<b#></b#>	Bar Code
<d#></d#>	Date (when run was saved)
<t#></t#>	Time (when run was saved)
<r#></r#>	Run Number

Table 4.2 File Name Generation Codes

Code	Enter Sample Info Field
<u#></u#>	Unique Number (File Name Generation window only). Including a unique number is recommended to avoid accidental file overwrites (see <i>Using Unique Numbers in Analysis Files</i> , page 4-6).
<x></x>	File Extension. You can select the Multisizer 4 default (#M4) or choose a new extension.

## **Using Unique Numbers in Analysis Files**

Adding a Unique Number to file names ensures that analysis files are not accidentally overwritten.

For example, if you perform more than one run on a sample with the same File ID and Sample ID, or if you accidentally reset the Run Number to one (1) in the Enter Sample Information window before you have completed the total number of sample runs, it is possible that the Multisizer 4 software could overwrite run files.

## **Write-Protecting Saved Analysis Files**

To ensure that an analysis file is not overwritten:

- 1. Open the file in the Multisizer 4 software.
- 2. Select RunFile > Save or RunFile > Save As on the Run Menu bar.
- 3. In the Save As dialog box, enter a new file name or location, if desired.
- 4. In the middle of the window, select Save as read-only, and click (Save).

In the SOM Wizard, click (Next) to proceed to the next step.

# **Standard Operating Method: Control Mode**

Use Step 2 of the SOM Wizard (page 4-2) or the Control Mode tab of the Edit the SOM window (page 4-23) to enter settings that will determine when an analysis run will end. The Multisizer 4 can end an analysis run based on elapsed time, total count, modal count, or the volume of sample that has passed through the aperture.

4-6 PN A51387AB




Table 4.3 Control Mode (Step 2): Selections

Select and specify	To end the run when
Time	The specified number of seconds have elapsed since the run began. Enter any time from 1 to 999 seconds, or select a number from the drop-down list. When you click (Next), the valid range is displayed.
	Time mode uses constant pressure to move sample through the orifice for a pre-determined length of time.
Volumetric	The specified volume of electrolyte has passed through the aperture tube. Enter a volume from 50 to 2000 $\mu$ L, or select a number from the drop-down list. When you click (Next), the valid range is displayed.
	Use Volumetric mode to move a precise volume of sample through the orifice of the aperture tube with a metering pump.
	NOTE Volumetric mode is not allowed on aperture sizes greater than 360 $\mu m.$ The largest standard aperture size allowed is 280 $\mu m.$
Total Count	The specified number of particles or cells (corrected for coincidence) has passed through the aperture. Enter a number from 50 to 500,000.
	NOTE To specify particles or cells, exit the SOM Wizard and select SOP > Edit Preferences on the Main Menu bar. In the Edit Preferences window, select the View Options tab and under Measuring, select Particles or Cells. To save changes you made in the Wizard, go to step 9 and click (Save) before exiting. Re-open the Wizard and return to Control Mode, step 2.
Modal Count	The specified number of particles or cells has accumulated in the modal channel. Enter a number from 10 to 100,000.

Click (Waste Tank) to specify how often the Waste Tank will empty. In the Waste Tank window, select the intervals by run or time. If you do not select an option to automatically empty the Waste Tank, you can do so manually whenever a run is not in progress by clicking (Empty) on the Instrument Toolbar (page 2-5).

#### **NOTE**

For particle concentration analyses, use volumetric mode. For size distribution analyses, use any available control mode.


In the SOM Wizard, click (Next) to proceed to the next step.

# **Standard Operating Method: Run Settings**

Use Step 3 of the SOM Wizard (page 4-2) or the Run Settings tab of the Edit the SOM window (page 4-23) to specify pre-run prompts; determine the number of runs; and enter post-run settings (including automatic file save, export, and print settings).

#### NOTE

While Preferences allows you to specify how you will view and print analysis results, Step 3 in the SOM Wizard allows you to specify whether files will automatically print or export to another file type after a run. Print and export settings will be based on your selections in Preferences (page 5-1).



**Table 4.4** Run Settings (Step 3): Entries and Selections

Enter or select	То
Enter Sample Info before first run	Display the Enter Sample Info window before the first run.
Flush Aperture Tube before first run	Automatically flush the aperture tube before the first run. Flushing the aperture tube removes heavy particles that remain trapped in the aperture tube.

4-8 PN A51387AB

 Table 4.4 Run Settings (Step 3): Entries and Selections

Enter or select	То
Number of Runs	Determine how many times the sample will run. To activate this option, enter the number of runs.
Wait between Runs	Enter the number of seconds between runs.
Flush Aperture Tube after each run	Automatically flush the aperture tube after each run. Flushing the aperture tube removes any heavy particles that remain trapped in the aperture tube.
Save File	Automatically save analysis results to a file. The results will include pulse data only if Include Pulse Data is selected. Files will use name parameters specified in Step 1 of the SOM Wizard (page 4-4). The Multisizer 4 software will save the file to the folder displayed in the Status Bar (at the lower left corner of the screen). To change the destination folder, click (Folder).
Include Pulse Data	Save pulse data in the file with analysis results. Saving pulse data allows you to change range, resolution, and other parameters of the analysis without re-running the sample.  NOTE
	Including pulse data increases the size of saved files.
Export Data	Automatically export analysis results to an external file type, based on Export settings in Preferences.
Print Report	Automatically print analysis results in a report. Statistics, graph, and page setup options will be determined by the Print Report settings in the current Preferences file.
Compare to Sample Specifications	Include a comparison to sample specifications in the printed report. Use this option only if you have entered specifications (select <b>Sample</b> > <b>Create Sample Specifications</b> on the Main Menu bar). For more information, see <i>Using Sample Specifications</i> , page 6-7. Click the Load button to select the sample specifications to compare to.
Save Average of All Runs	Save an average size distribution or particle concentration, based on the total number of runs.
Print Average Report	Print the average size distribution or particle concentration, based on the total number of runs.
BUTTON: Folder	Change the default folder in which the Multisizer 4 software will automatically save new analysis files. For information on automatic file name generation, see <i>Creating Automatically Generated Analysis File Names</i> , page 4-4.
BUTTON: Load	Load sample specifications. This button is only available if you select Compare to Sample Specifications.

## NOTE

When using multiple runs in the Run Settings of the SOM, ensure that the waste tank and waste jar are prepared to handle the total volume of fluid for the series of runs. If the waste tank or waste jar becomes full during a run, the series will not be completed, and an error will result. Empty the waste tank and the waste jar prior to starting a series of multiple runs.

In the SOM Wizard, click (Next) to proceed to the next step.

# Standard Operating Method: Stirrer Settings


Use Step 4 of the SOM Wizard (see *Standard Operating Method: Stirrer Settings* on page 4-10) or the Stirrer tab of the Edit the SOM window (see *Editing SOM Settings* on page 4-23) to enter beaker size and stirrer position.

You can also use the Stirrer window to disable stirrer buttons on the Analyzer Control Panel for the duration of a run. If not disabled, these Control Panel buttons allow the operator to modify stirrer speed or direction and turn the stirrer on or off (see page 1-5).

The Edit the SOM / Stirrer tab includes an additional feature that allows the operator to copy manual settings into the SOM (see *Copying Manual Stirrer Settings* on page 4-11).

#### **NOTE**

The Multisizer 4 will automatically position the stirrer based on the beaker size you select in the SOM. Beckman Coulter recommends that you use Multisizer 4 Smart Technology Beakers with automatic stirrer positioning to ensure consistency and accuracy of results.



#### To use the SOM/Stirrer Settings window:

- 1. In the Sample Beaker pane, select Accuvette® ST or the beaker size you will be using. To enter the beaker size automatically, hold the bar code in front of the Bar Code Reader on the Analyzer Control Panel. For more information on the Bar Code Reader, see page 1-7.
  - In the Other field, enter a description (maximum length: 40 characters) for a non-standard beaker size.
- 2. In the Stirrer Position pane:
  - Select Automatic to automatically position the stirrer inside the beaker or Accuvette® ST. For consistency and accuracy of results, Beckman Coulter recommends that you use Smart Technology Beakers with automatic stirrer positioning.
    - You can turn the stirrer off by pressing the stirrer ON/OFF button on the Analyzer Control Panel or by selecting **Run > Stirrer Off** on the Main Menu bar.

4-10 PN A51387AB

- Select Parked out of beaker to position the stirrer outside the beaker during the run.
- Select Manual to set the angle of the stirrer when you are using a beaker not manufactured by Beckman Coulter. The Manual radio button is available only if you have selected Other and entered a non-standard beaker size in the Sample Beaker pane.
- In the Manual field, enter the stirrer position in degrees (from -20 to 10) or select an angle from the drop-down list. Zero (0) degrees is vertical, and the stirrer will touch the aperture tube at approximately 10 degrees. A negative position is farther from the aperture tube and is useful for larger, non-standard beakers.
- 3. Select Disable instrument keypad during run if you would like to prevent the operator from using buttons on the Analyzer Control Panel to change the speed or direction of the stirrer, or turn the stirrer on or off (see *Control Panel*, page 1-5). This option is not available if you select Parked out of beaker.
- **4.** Select Use Stirrer to run an analysis with the stirrer positioned inside the beaker and rotating at the speed you select. This checkbox is available only if you select Automatic or Manual in the Stirrer Position pane.
- 5. In the Speed field, enter the stirrer rotation speed as any integer between 1 and 60, or select the speed from the drop-down list.
  - To find the appropriate speed for your beaker size and electrolyte combination, position the stirrer and adjust the stirrer speed using the Speed (+ and -) buttons on the Analyzer Control Panel. In the Edit SOM / Stirrer Settings window (see *Editing SOM Settings*, page 4-23), the Speed field will automatically display the number corresponding to the actual stirrer speed.
- **6.** Select CW (clockwise) or CCW (counterclockwise) to determine stirrer direction. For information on choosing stirrer direction, see *Stirrer Direction Controls*, page 1-6.

Before you raise the platform, the Analyzer will automatically position the stirrer at the correct angle. If you need to change the stirrer position, lower the platform and enter the correct settings in the Edit SOM / Stirrer Settings window. To set a specific angle for the stirrer position, select Other and enter the angle in the Manual field in the Stirrer Position pane.

#### NOTE

After you save stirrer settings, it is not possible to reposition the stirrer using the SOM Wizard. To reposition the stirrer, or to adjust stirrer speed using buttons on the Analyzer Control Panel, use the Edit SOM / Stirrer Settings window (see *Editing SOM Settings*, page 4-23).

## **Copying Manual Stirrer Settings**


The Edit the SOM / Stirrer tab includes an additional feature that allows you to copy manual stirrer settings into the SOM.

#### NOTE

The Multisizer 4 software allows the operator to position the stirrer manually only when the operator has entered a non-standard beaker size.

#### To copy manual settings:

- 1. Select **SOP** > **Edit the SOM** on the Main Menu bar.
- 2. In the Edit the SOM window, select the Stirrer tab.



- 3. On the Stirrer tab, select Other in the Sample Beaker pane and enter a non-standard beaker size.
- 4. In the Stirrer Position pane, select Manual.
- 5. In the Sample Compartment, manually position the stirrer.
- **6.** If desired, change stirrer speed and direction.
- 7. In the Current Settings pane, click (Copy). The current stirrer angle appears in the Manual field.
- 8. Click (Apply) or (Save SOM) to save your settings. The stirrer will move after you click (Apply).

4-12 PN A51387AB

# **Standard Operating Method: Threshold, Current and Gain**

Use Step 5 of the SOM Wizard (page 4-2) or the Current and Gain tab of the Edit the SOM window to enter the lower limit of a size distribution as well as the electrical pulse size (current) and amplification (gain) that the Analyzer will use as particles pass through the aperture.




Table 4.5 Threshold, Current and Gain (Step 5): Entries or Selections

In the field	Enter or select
Sizing Threshold	The size above which particles are counted (or the lower limit of a size distribution). If the size entry is high or low, a warning message is displayed as follows:
	"Low" message is displayed for sizes less than 1.9% of aperture diameter "Too Low" message is displayed for sizes less than 1.5% of aperture diameter "High" message is displayed for sizes greater than 20% of aperture diameter
	"Too High" message is displayed for sizes greater than 50% of aperture diameter
	NOTE This setting cannot be changed during or after an analysis.
Aperture Current	The current that will pass through the aperture. Click (Defaults) to set the current and gain automatically for the aperture size you are using. If the aperture current entry is high or low, a warning message is displayed as follows:
	"Low" message is displayed for sizes less than 100 $\mu$ A "Too Low" message is displayed for sizes less than 10 $\mu$ A "High" message is displayed for sizes greater than 800 $\mu$ A when measuring cells "High" message is displayed for sizes greater than 3200 $\mu$ A "Too High" message is displayed for sizes greater than 6000 $\mu$ A
	If you are using a small aperture, current set too high can damage the aperture. For information on small aperture settings, see <i>Using Small Aperture Tubes (20 µm and 30 µm)</i> , page 3-4.
Preamp Gain	The amplification factor. Click (Defaults) to set the current and gain automatically for the aperture size you are using.
Extended Size Range	Controls what happens if particles larger than 60% of the aperture diameter are detected. You can specify the large particle count either as an absolute number, as a percentage of the total count, or turn off this feature.

Click (Defaults) to set current and gain, and sizing threshold, automatically, based on the aperture size.


In the SOM Wizard, click (Next) to proceed to the next step.

## Using the Current & Gain Tab in the Edit the SOM Window

The Edit the SOM / Current & Gain tab differs from the SOM Wizard / Threshold, Current and Gain window. Unlike the Wizard, the Edit the SOM / Current & Gain tab allows you to interact with the


4-14 PN A51387AB

Analyzer as you edit settings. You can use the (Threshold) and (Current & Gain) buttons on the Current & Gain tab to measure noise level and resistance using the currently installed aperture tube.



# **Standard Operating Method: Pulse to Size Settings**

Use Step 6 of the SOM Wizard (page 4-2) or the Pulse to Size Settings tab of the Edit the SOM window (page 4-23) to enter the number of bins (channels), bin spacing, and other information that will determine the range and resolution of analysis results. After running the analysis, you can change these settings by selecting **Calculate > Convert Pulses to Size** on the Run Menu bar. The aperture information on this screen changes accordingly, depending on the size of the aperture tube you are using.



- 1. In the Size Bins field, enter the number of bins you want to use, or select the number of bins from the drop-down list (from 4 to 400).
- 2. In the from and to fields, enter the low and high limits for the range of particle diameter sizes you will be analyzing. The defaults are 2% to 60% of aperture diameter (10% to 80% of aperture diameter for a 2000-µm aperture).
  - The smallest bin must be greater than or equal to sizing threshold (normally, 2% of aperture diameter or 10% of aperture diameter for a 2000-µm aperture).
  - The largest bin must be less than or equal to 60% of aperture diameter.
- 3. In the Bin Spacing pane, select how the Multisizer 4 software will determine bin spacing:
  - By an incremental count of particle diameters (Linear Diameter)
  - By a geometric progression of particle diameter sizes (Log Diameter)
  - By a linear progression of particle volume (Linear Volume)
  - By a geometric progression of particle volume size (Log Volume)
- **4.** In the Options pane, select one or both of the following options:
  - Pulse Edit. Select this option if you have a narrow distribution and would like to ensure
    accurate analysis results by eliminating large pulses. Particles that do not pass through the
    center of the aperture tend to produce wider and larger pulses. Pulse Edit removes the
    widest pulses from statistical analysis and display results. When the ratio of largest bin
    diameter to smallest bin diameter is greater than 6, a warning message appears.
  - Use Shape Factor. Select this option if you would like to match your results to another particle sizing instrument, or if you need to adjust analysis results based on a known factor. Entering a shape factor of 1.03, for example, increases particle diameter by 3%.
- 5. Click (2% to 60%) to select a size range from 2% to 60% (or (10% to 60%)) to select a size range from 10% to 60% for a 2000- $\mu$ m aperture).
- 6. Click (Defaults) to return the settings to Multisizer defaults.

4-16 PN A51387AB


In the SOM Wizard, click (Next) to proceed to the next step.

## **Standard Operating Method: Concentration Information**

Use Step 7 of the SOM Wizard (page 4-2) or the Concentration tab of the Edit the SOM window (page 4-23) to enter information about sample volume, density, and dilution.

#### NOTE

For particle concentration analyses, use volumetric mode. For size distribution analyses, use any available control mode.



- 1. In the Sample Amount pane:
  - Select Volume if you are entering the volume of a sample suspended in liquid. Enter the volume of liquid sample in the mL field.
  - Select Mass if you are entering the mass of a dry sample of particles. Enter the density of the dry sample in the Density field (available in a chemical handbook).
- 2. Select Use Pre-dilution Factor if you are diluting your sample (for example, if you are adding electrolyte to a dry sample) before you add the sample to the electrolyte solution in the beaker. Enter the ratio of electrolyte solution to sample (the pre-dilution factor).
  - If you select Use Pre-dilution Factor, the software will not allow you to enter a dilution factor. The only possible combination is Pre-dilution factor (ratio of electrolyte solution to sample) added to electrolyte solution volume.
- 3. In the Analytic Volume text field, enter the volume of electrolyte solution and sample that will pass through the aperture during the run.
  - To enter an accurate value in the Analytic Volume field, it is necessary to run your analysis in volumetric mode. If it is not possible to use volumetric mode (for example, if your aperture is larger than 360  $\mu$ m) you can estimate the analytic volume. To estimate analytic volume, run a timed analysis several times and average the volume of sample that passes through the orifice.


- **4.** In the Electrolyte Volume field, enter the volume of electrolyte in the beaker. If you enter the volume of electrolyte in this field, the software will not allow you to calculate a dilution factor in the Use Dilution Factor field.
- 5. Select Use Dilution Factor if you are entering the ratio of electrolyte to sample. Dilution factor is an alternative to entering the electrolyte volume. If you select Use Dilution Factor and enter a dilution factor, the software will not allow you to enter a pre-dilution factor.
- **6.** In the SOM Wizard, click (Next) to proceed to the next step.

# **Standard Operating Method: Blockage Detection**

Use Step 8 of the SOM Wizard or the Blockage tab of the Edit the SOM window (page 4-23) to enter blockage detection settings. Based on your settings, the Multisizer 4 will automatically unblock the aperture or stop the run when the system detects a blockage.




Do not attempt to unblock the aperture using an object or your finger. The Multisizer 4 unblock procedure uses a reverse flow of electrolyte through the aperture orifice to remove stuck particles. Any other method of removing the trapped particles could damage the aperture. For more information, see *Handling Small Aperture Tubes*, page 3-4.



4-18 PN A51387AB


### To enter blockage detection settings:

In the SOM Wizard - Blockage window, review the Blockage Detection and Blockage Action settings. To change either of these settings, click (Blockage Detection). The Blockage Detection Settings window opens.



In the Blockage Detection Settings window:

- 1. In the Blockage Detection pane:
  - Select Off to disable automatic blockage detection.
  - Select Automatic (from reference run) to set blockage detection based on previous run data. To select the previous run, click (Select Reference Run) and browse to select the file. The reference run must use the same aperture tube size.
  - Select Automatic (from start of run) to set blockage detection based on current run data.
- 2. In the Blockage Action pane, select Cancel the run; Cancel and Unblock the aperture; or Cancel, Unblock and Restart the analysis. If you select the final option, enter the number of times to repeat the unblock procedure in the Up to [X] times field.



3. Select Show Details to see detailed blockage detection settings. The window expands.

The expanded Blockage Detection Settings window displays the Flow Rate, Count Rate, Aperture Resistance, and Concentration settings that will alert the Multisizer 4 to an aperture blockage and trigger the unblock procedure.

- Flow Rate. This field is available only in volumetric mode. A low flow rate or a significant change in flow rate can indicate aperture blockage. A high flow rate can result from air passing through the aperture, indicating that the sample fluid level is too low.
- Count Rate. In general, the count rate will decrease if the aperture is blocked. With some small aperture and particle combinations, however, the count rate can increase.
- Aperture Resistance. Unusually high electrical resistance can indicate blockage (when particles trapped in the aperture act as an electrical insulator) or air in the aperture (when sample fluid level is too low).
- Concentration. A brief spike in particle concentration indicates aperture blockage. If the concentration returns to normal, it is possible that the blockage has cleared. You can set the number of seconds for a momentary blockage If other parameters (flow, aperture resistance, and/or count) indicate a blockage, however, you can assume that the aperture remains blocked.

#### *In the expanded Blockage Detection Settings window:*

- 1. If you are using 20-μm and 30-μm aperture tubes, click (Defaults) to set the defaults automatically for the aperture size you are using. The default settings are:
  - Automatic (from start of run)
  - Cancel Unblock and Restart, Up to 4 times
  - Use change from start of run, Flow rate: 35%
  - Use change from start of run, Count rate: 40%

4-20 PN A51387AB


- Use change from start of run, Aperture Resistance: 40%
- Use Concentration
- Blocked for at least 4 seconds
- 2. In the Use Minimum & Maximum column, select each parameter you want to use. In the corresponding fields, enter the Nominal, Minimum, and Maximum values that will trigger an unblock procedure. Flow Rate is only available when you are running volumetric mode.

  To set default values in the selected fields, click the (Default Nominal) or (Default Min/Max)
- 3. In the Use change from start of run column, select Flow Rate, Count Rate, or Aperture Resistance. In the corresponding fields, enter the percentage of change that will trigger an unblock procedure. To set default values in the selected fields, click (Default Change). Flow Rate is only available when you are running volumetric mode.
- **4.** You can specify that a momentary blockage occurring for fewer than a preset number of seconds be ignored. Enter the number of seconds in the Blocked for at least [X] seconds field.
- 5. Click  $\overline{(OK)}$  to accept the blockage detection settings.
- **6.** In the SOM Wizard, click (Next) to proceed to the next step.

# **SOM Wizard: Summary of Settings**

button.

Step 9 of the SOM Wizard displays a summary of your Standard Operating Method settings. To see a summary of SOM settings when you are not using the SOM Wizard, select SOP > SOM Info on the Main Menu bar.



- Return to any previous step by clicking the step number in the Return to Previous Step pane.
- To save the SOM settings to a file, click (Save).
- To print the SOM settings, click (Print).

You can print the SOM summary in its entirety, or specify a range of lines to print. To print selections from the SOM settings, first highlight the lines you would like to print in the Summary of Settings window, click (Print), and select Print selected lines.

You can also use the (Print) button to copy the SOM settings, or selected settings, to the clipboard.

Click (Done) to exit the SOM Wizard.

# Saving an SOM to a File

To save a Standard Operating Method to a file that you can load into the Multisizer 4 software, you can use the SOM Wizard or the Edit SOM window.

#### NOTE

The Multisizer 4 software will not allow you to open the SOM Wizard or load, edit, or save SOM settings using the Edit the SOM window if a Standard Operating Procedure (SOP) is loaded. To remove an SOP, click (Remove SOP) in the Status Panel, or select SOP > Remove the SOP on the Main Menu bar.

#### If you are using the SOM Wizard:

- 1. Select SOP > Create SOM Wizard on the Main Menu bar.
- 2. In the SOM Wizard, click (Next) until you reach Step 9: Summary of Settings.
- 3. In the Summary of Settings window, click (Save).
- **4.** In the Save a Standard Operating Method (SOM) window:
  - **a.** Navigate to the appropriate folder (the Multisizer 4 default is the SOP folder).
  - **b.** Enter a file name in the File Name field, and click (Save).

#### **NOTE**

SOM files are identified by the extension .som.

### If you are using the Edit the SOM window:

- 1. Select **SOP** > **Edit the SOM** on the Main Menu bar.
- 2. In the Edit the SOM window, click (Save SOM). This button appears on each tab.
- 3. In the Save a Standard Operating Method (SOM) window:
  - **a.** Navigate to the appropriate folder (the Multisizer 4 default is the SOP folder).
  - b. Enter a file name in the File Name field, and click (Save).

#### NOTE

SOM files are identified by the extension .som.

4-22 PN A51387AB

# **Editing SOM Settings**


If you are familiar with SOM settings or have already created an SOM using the SOM Wizard (page 4-2), you can edit SOM settings.

#### NOTE

The Multisizer 4 software will not allow you to load, edit, or save SOM settings if a Standard Operating Procedure (SOP) is loaded. To remove an SOP, click (Remove SOP) in the Status Panel, or select SOP > Remove the SOP on the Main Menu bar.

To edit the current SOM:

Select **SOP** > **Edit the SOM** on the Main Menu bar. The Edit the SOM window opens.



The Edit the SOM window displays tabs that duplicate Step 2 through Step 8 of the SOM Wizard (page 4-2).

The tabs include:

- Control Mode. Select control mode settings to determine when an analysis run will end. The Multisizer 4 can end a run based on elapsed time, total count, modal count, or the volume of sample that has passed through the aperture.
  - For more information on the Control Mode window as it appears in the SOM Wizard, see *Standard Operating Method: Control Mode*, page 4-6.
- Run Settings. Select run settings to specify pre-run prompts, determine the number of runs, and enter post-run settings (including automatic file save, export, and print settings).

  For more information on the Run Settings window as it appears in the SOM Wizard, see *Standard Operating Method: Run Settings*, page 4-8.

• **Stirrer.** Use the Stirrer tab to enter stirrer settings or disable stirrer buttons on the Analyzer Control Panel for the duration of a run.


For more information on the Stirrer window as it appears in the SOM Wizard, see *Standard Operating Method: Stirrer Settings*, page 4-10.



The Multisizer 4 will automatically position the stirrer based on the Smart Technology Beaker size you select in the SOM.

- Current & Gain. Enter the lower limit of a size distribution as well as the electrical pulse size (current) and amplification (gain) that the Analyzer will use as particles pass through the aperture.
  - For more information on the Current and Gain window as it appears in the SOM Wizard, see *Standard Operating Method: Threshold, Current and Gain*, page 4-13. For information on additional features available in the Edit the SOM window, see *Using the Current & Gain Tab in the Edit the SOM Window*, page 4-14.
- Pulse to Size Settings. Enter the number of bins (channels), bin spacing, and other information
  that will determine the range and resolution of analysis results. After running the analysis, you
  can change these settings by selecting Calculate > Convert Pulses to Size on the Main Menu bar.
  For more information on the Pulse to Size Settings window as it appears in the SOM Wizard, see
  Standard Operating Method: Pulse to Size Settings, page 4-15.
- Concentration. Enter information about sample volume, density, and dilution. For more information on the Concentration window as it appears in the SOM Wizard, see *Standard Operating Method: Concentration Information*, page 4-17.
- **Blockage.** Enter settings that will alert the software to an aperture blockage and select steps the Multisizer 4 will follow when it detects a blockage.

For more information on the Blockage window as it appears in the SOM Wizard, see *Standard Operating Method: Blockage Detection*, page 4-18.



Do not attempt to unblock the aperture using an object or your finger. The Multisizer 4 unblock procedure uses a reverse flow of electrolyte through the aperture orifice to remove stuck particles. Any other method of removing the trapped particles could damage the aperture. For more information, see *Handling Small Aperture Tubes*, page 3-4.

Click (Save SOM), available on every tab, to save the current SOM settings.

4-24 PN A51387AB

# The SOM Settings (SOP Loaded) Window

If you select **SOP** > **Edit the SOM** on the Main Menu bar and the SOM Settings (SOP Loaded, no changes allowed) window opens, remove the SOP before editing current SOM settings.

To remove an SOP, click (Remove SOP) in the Status Panel, or select SOP > Remove the SOP on the Main Menu bar.

### Differences between the SOM Wizard and Edit the SOM windows

The seven tabs of the Edit the SOM window duplicate Step 2 through Step 8 of the SOM Wizard.

The first and last steps of the SOM Wizard (Step 1 - Description and Step 9 - Summary of Settings) do not appear on the Edit the SOM tabs.

If you are not using the SOM Wizard:

- To enter electrolyte and dispersant information, use the Edit the SOM / Control Mode tab.
- To set automatic file name generation settings (page 4-4), use the Run Settings tab.
- To view current SOM settings, select **SOP** > **SOM Info** on the Main Menu bar.
- To manually set the stirrer position and copy the angle into the SOM, use the Edit the SOM / Stirrer tab.

Click (Save SOM), available on every tab, to save the current SOM settings.

# **Loading an SOM**

If you saved different Standard Operating Methods to one or more file(s), you can load a different SOM depending on the type of analysis you will be running.

#### NOTE

If a Standard Operating Procedure (SOP) is loaded, the Multisizer 4 software will not allow you to edit, save, or load an SOM. To remove an SOP, click (Remove SOP) in the Status Panel, or select SOP > Remove the Sop on the Main Menu bar.

To load a saved SOM file:

- 1. Select **SOP** > **Load SOM** on the Main Menu bar.
- 2. In the Load Standard Operating Method (SOM) window, navigate to the appropriate folder.
- 3. Select the desired SOM, and click (Open).

#### NOTE

SOM files are identified by the extension .som.

# **Using a Standard Operating Procedure (SOP)**

# Creating an SOP

A Standard Operating Procedure (SOP) combines one Preferences file and one Standard Operating Method (SOM) into an overall settings file for a particular type of analysis. Within the SOP, the SOM file determines sample run settings, while the Preferences file determines view and print specifications.

If you have saved default or custom SOM and Preferences files, you can create one or more Standard Operating Procedures (SOPs). Standard Operating Procedures are helpful if you are running several types of analyses that require different settings.

#### **NOTE**


If you are running the Multisizer 4 software in security mode, the option to create a Standard Operating Procedure will not be available to all user types.

#### To create a Standard Operating Procedure:

1. Select **SOP** > **Create SOP Wizard** on the Main Menu bar. The SOP (Standard Operating Procedure) Wizard - Description window opens.

#### **NOTE**

If you are running the Multisizer 4 software in security mode, the **SOP > Create SOP Wizard** menu item will appear only to user types with sufficient privileges. The system administrator sets privileges for each user type.




- 2. In the SOP Description field, enter a description to identify the SOP. This field is used as the default SOP file name.
- 3. In the SOP Author field, enter the name of author.

#### **NOTE**


You can exit the SOP Wizard at any time; however, your changes will be lost unless you save them. Go to Step 4 in the Wizard, and click (Save).

4-26 PN A51387AB

4. Click (Next) to proceed to the next window in the Wizard, Select an SOM File.




- 5. In the Select an SOM File window, click (Select).
- 6. In the Load a Standard Operating Method (SOM) window, navigate to the SOM you want to include, and click (Open). The name of the selected SOM file appears in the Wizard.
- 7. Click (Next) to proceed to the next window in the Wizard, Select a Preference File.



- 8. In the Select a Preference File window, click (Select).
- 9. In the Load Preferences window, navigate to the Preferences file you would like to include, and click (Open). The name of the selected Preferences file appears in the Wizard.
- **10.** Select Do not allow operator to change preferences to safeguard the format of print and view settings.

11. Click (Next) to proceed to the final step, Summary of Settings.



- 12. In the Summary of Settings window, click (Save).
- 13. In the Save a Standard Operating Procedure window, navigate to the appropriate folder (the Multisizer 4 default is the SOP folder), and click (Save).
- **14.** To print the SOP summary, click (Print).
- 15. To close the SOP, click (Done).

# **Loading an SOP**

To load a saved SOP file:

- 1. Select **SOP** > **Load an SOP** on the Main Menu bar.
- 2. In the Load a Standard Operating Procedure (SOP) window, navigate to the appropriate folder.
- 3. Select the desired SOP, and click (Open).

#### **NOTE**

SOP files are identified by the extension .sop.

4-28 PN A51387AB

# Setting View and Print Preferences

# **Creating a Preferences File**

To set viewing, exporting, and printing preferences for analysis files, you can use the Create Preferences Wizard or the Edit Preferences window.

You can save your preferences to a file or create a default preferences file. After saving a preferences file, you can include the file in a Standard Operating Procedure. When you load the Standard Operating Procedure (SOP), preference settings in the SOP will determine how analysis graphs and data appear, both on-screen and in printed reports.

If you use the Create Preferences Wizard, the Multisizer 4 software guides you through nine steps. You will only be able to save your preferences in the last step of the Wizard.

If you use the Edit Preferences window, you can move between eight tabs to create or change specific settings. You can save your changes from any tab within the window.

#### NOTE

If you open an analysis file and change its appearance using options on the Run Menu bar, the format of the printed report will not change. To change the format of a printed report, use the Create Preferences Wizard or the Edit Preferences window. Samples of data file formats are included in a subfolder of the Multisizer 4 software called Demodata.

### To create or change your preferences using the Wizard:

- 1. If the software is not connected to the Analyzer, select Run > Connect to Multisizer 4 on the Main Menu bar.
- 2. Select **SOP** > **Create Preferences Wizard** on the Main Menu bar. The Create Preferences Wizard opens.

#### NOTE

If you have not connected the Multisizer 4 software to the Analyzer, the Create Preferences Wizard is available by selecting **Preferences > Create Preferences Wizard** on the Main Menu bar. Different drop-down menus appear in the Main Menu bar when the software is not connected to the Analyzer.

The Create Preferences Wizard guides you through the following steps:

Step 1: Printed Report

Step 2: Statistics

- Step 3: Averaging and Trend
- Step 4: Export
- Step 5: Page Setup
- Step 6: Graph Options
- Step 7: Fonts and Colors
- Step 8: View Options
- Step 9: Summary of Settings

# To create or change your preferences using the Edit Preferences window:

- 1. If the software is not connected to the Analyzer, select Run > Connect to Multisizer 4 on the Main Menu bar.
- 2. On the Main Menu bar, select **SOP** > **Edit Preferences**. The Edit Preferences window opens.

#### **NOTE**

If the Multisizer 4 software to the Analyzer is not connected, the Edit Preferences window is available by selecting **Preferences > Edit Preferences** on the Main Menu bar. Different drop-down menus appear in the Main Menu bar when the software is not connected to the Analyzer.

The Edit Preferences window displays the following tabs:


- Printed Report
- Statistics
- Averaging and Trend
- Export
- Page Setup
- Graph Options
- Fonts and Colors
- View Options

To see a summary of currently loaded preferences, select **SOP > Preferences Info** on the Main Menu bar.

# **Preferences: Printed Report**

Use Step 1 of the Create Preferences Wizard (Printed Report) or the Printed Report tab of the Edit Preferences window to select analysis data, graphs, or listings that will appear on the screen and in printed reports.

5-2 PN A51387AB



# **Printing Sample Information**

The Enter Sample Info dialog box allows you to print either an extensive or short version of the sample information in your report.

#### *To choose all sample information:*

To print all sample and run information in the report, including information previously entered in the Enter Sample Info dialog box (page 6-5), check the Sample Info box in the top left corner of the Printed Report window.

# To choose less sample information:

To include less information, select both Sample Info and Short at the top of the Printed Report window.

The table below shows the information that will print if you select Sample Info or both Sample Info and Short.

**Table 5.1** Printing Sample Information in Reports

	Sample Info	Sample Info and Short
Date	Х	Х
File name	Х	Х
Group ID	Х	Х
Sample ID	Х	Х

**Table 5.1** Printing Sample Information in Reports

	Sample Info	Sample Info and Short
Operator	Х	
Run number	Х	
Electrolyte	Х	
Dispersant	Х	
Aperture diameter	Х	
Aperture current	Х	
Size bins	Х	Х
Total count	Х	Х
Count	Х	
Control method	Х	
Acquired	Х	Х
Electrolyte volume	Х	
Analytic volume	Х	
Sample	Х	
Background run	Х	Х

# **Selecting Graphs, Statistics, and Data for Printing**


In the Preferences / Printed Report window, options in the Size pane allow you to select the analysis graphs and data you want to print. When you select an option in the Size pane, the selection appears in Report Printing Order at the right of the window.

# **Including a Size Distribution Graph in Printed Reports**

To include a size distribution graph in the report:

- 1. In the Size pane of the Print Report window (page 5-2), select Graphs.
- 2. Click (Select) to choose different options for viewing the size distribution. The Size Graphs window opens.

5-4 PN A51387AB



3. In the Size Graphs window, select each type of graph you want to print. You can select up to 12 different graph types. Selections appear in the Graph Printing Order field at the bottom of the window.

Table 5.2 Size Graphs Window: Selections

Select	To plot a graph using
Differential	The number of particles, total volume, or total surface area in each bin.
Cumulative	The total number of particles, volume, or surface area below or above each bin edge.
Mass	Differential or cumulative results by particle mass (volume times density).
Number	Differential or cumulative results based on the number of particles in each bin.
Volume	Differential or cumulative results by particle volume.
Surface Area	Differential or cumulative results by particle surface area.

- **4.** In the X Axis pane, select whether you want to use a linear or a logarithmic X axis to display bin sizes.
- 5. In the Smoothing pane, select the amount of smoothing in each graph. Smoothing averages each bin with its neighbors (in groups of three, five, or seven bins) to reduce the resolution and increase clarity.
- **6.** Select Log Y Axis to use a logarithmic Y axis to display the amounts in each bin.
- 7. Select Multisizer Cursors to print cursors in each graph where they were placed when you saved the analysis.
- **8.** Select Y/Dx Diff. Graphs to normalize the height of each bin based on the bin's width. This option is useful when the bins are not evenly spaced.
- 9. Select Use Sample ID As Title to include a sample ID title in printed reports. You can select a different analysis title in Preferences / Page Setup window by selecting Include Custom Title.
- **10.** Click **OK** to save your changes.

#### **Including Statistics in Printed Reports**

In the Size pane of the Preferences / Printed Report window (page 5-2), select Statistics to include statistical information in printed reports. You can choose which statistics to include in Step 2 of the Create Preferences Wizard or the Statistics tab of the Edit Preferences window.

### **Including Averaged Statistics in Printed Reports**

If you have completed several sample runs and averaged the results, you can include these results in printed reports. In the Size pane of the Preferences / Printed Report window (page 5-2), select Averaged Statistics to include this information.

# **Including a Comparison to Sample Specifications in Printed Reports**


The Multisizer 4 software allows you to compare data files to previously entered sample specifications (page 6-9). In the Size pane of the Preferences / Printed Report window (page 5-2), select Compare to Sample Specifications to include this information in printed reports.

#### **Including Overlay Statistics in Printed Reports**

If you have created an overlay file (page 7-19), you can include overlay statistics in printed reports.

#### To include overlay statistics:

- 1. In the Size pane of the Preferences / Printed Report window (page 5-2), select Overlay Statistics.
- 2. Click (Select) to choose the overlay statistics that will appear in the report. The Overlay Statistics window opens.



5-6 PN A51387AB

3. In the Overlay Statistics window, select each statistic you want to include.

Table 5.3 Overlay Statistics Options

Select	To print
Total Amount	Total number, volume, or surface area in each distribution (the sum of the bins).
Mean	The mean of each distribution.
Median	The median of each distribution.
D(p,q)	Results of a formula used to calculate particle size, surface area, weight, or volume based on particle diameter. Set the D(p,q) formula on the Preferences Statistics tab (page 5-15).
Mode	The mode of each distribution.
S.D.	The statistical deviation.
Variance	The variance of each distribution.
C.V.	The co-efficient of variation.
Skewness	The degree of asymmetry in the frequency distribution.
Kurtosis	The steepness of the graphical curve near the mean of the distribution.
Specific Surface Area	The specific surface area.
d10, d50, d90	The particle diameter that divides the distribution by percentage (for example, d10 is the diameter at which 10% of the particles are smaller and 90% are larger; d50 is the median).
Kd	The calibration constant.

- 4. To print all statistics, click (Set All). To clear the fields, click (Clear All).
- **5.** Click **(OK)** to save your settings.


# **Including a Listing in Printed Reports**

You can print analysis results as a listing.

# To include a list of data for each size distributions bin:

1. In the Size pane of the Preferences / Printed Report window (page 5-2), select Listing.

2. Click (Select) to choose which data will appear in the report. The Size Listing window opens.



- 3. In the Size Listing window, select each statistic you want to include. You can select up to seven columns of statistics.
  - **a.** In the Columns pane:
    - Select Bin Number to include the bin number next to each bin value.
    - Select Lower Edge, Upper Edge, or Center to print the smallest, largest, or median particle size, volume, or surface area in each bin.
    - Select up to seven columns of statistics.
  - **b.** In the Bin Grouping pane:
    - Enter a number in the Group Size field to group bins, if desired. Grouping bins shortens the listing. Select First Bins in Group to display the value of the first bin in each group, or select Sum Bins in Group to display the value of the sum of the bins in each group.
    - Select All Bins to display results from the full range of the analysis.
    - Select Between Cursors to display only results between your defined cursors. For information on setting and moving cursors, see page 7-3.
    - Select From and enter specific points in the From and to fields to define statistical limits.
- **4.** To clear all fields, click (Clear All).
- 5. Click (OK).

# **Including Interpolation Data in Printed Reports**


You can create sample data reports that display statistical results within defined boundaries, or interpolation points.

Using interpolation points allows you to define your own bin edges and create any number of bins, of different or equal sizes. Interpolations are similar to percentiles, but are more flexible. Percentiles are limited to eight equally spaced bins.

5-8 PN A51387AB

#### To include a list of interpolation point data:

- 1. In the Size pane of the Preferences / Printed Report window (page 5-2), select Interpolation.
- 2. Click (Select) to set the interpolation points and range. The Size Interpolation window opens.



- 3. In the Interpolation Type pane of the Size Interpolation window:
  - **a.** Select Size to if you want to create interpolation points based on particle diameter size (that is, particle diameters define bin edges). You can select up to nine statistics to display based on particle size interpolation points.
  - **b.** Select to Size if you want to create interpolation points based on the statistic you select in the Interpolation Type pane (Number, Volume, Surface Area). You can select only one statistical interpolation point to correlate to particle size.
  - c. Select Number, Volume, Surface Area, %, and/or /mL to display selected statistics in columns.
  - **d.** Select Under (<), Over (>), or (if you selected Size to), Differential.

Table 5.4 Interpolation Display Data

If you select	Then columns will display
Under (<)	Statistical results below the interpolation point. The interpolation point becomes the upper edge of the bin.
Over (>)	Statistical results above the interpolation point. The interpolation point becomes the lower edge of the bin.
Differential	The number of particles between interpolation points.

- **4.** In the Interpolation Points pane:
  - a. To add an interpolation point, enter the new point and click (Add).
  - b. To delete an interpolation point, select the point and click (Delete).


- 5. In the Range pane:
  - **a.** Select All to display results from the full range of the analysis.
  - **b.** Select Between Cursors to display only results between your defined cursors. For information on setting and moving cursors, see page 7-3.
  - **c.** Select From and enter specific points to limit the range without inserting cursors in a graph.
- 6. Click OK to return to the Create Preferences Wizard.

# **Including Size Trend Information in Printed Reports**

In the Size Trend pane of the Preferences / Printed Report window (page 5-2), select Graph, Listing, or both to include size trend information in printed reports. For more information on creating a trend analysis from multiple files, see page 7-22.

#### To include a trend graph:

- 1. In the Size Trend pane of the Preferences / Printed Report window (page 5-2), select Graph.
- 2. Click (Select). The Trend Graph window opens.



3. In the Trend Graph window, select variables for the X and Y axes.


5-10 PN A51387AB

To change the d0 values to custom percentages, click (Custom Points) and enter new values in the Custom Trend Points window. These values allow you to divide the particle distribution of each run by percentage of particle size above and below a certain diameter. For example, d10 divides the particle distribution by the diameter at which 10% of the particles are smaller and 90% are larger.

**4.** Click **OK** to save your settings.

#### To include a Trend Listing:

- 1. In the Size Trend pane of the Preferences / Printed Report window (page 5-2), select Listing.
- 2. Click (Select). The Trend Listing window opens.



- 3. In the Trend Listing window, select variables to display in columns.
  - To change the d0 values to custom percentages, click (Custom Points) and enter new values in the Custom Trend Points window. These values allow you to divide the particle distribution of each run by percentage of particle size above and below a certain diameter. For example, d10 divides the particle distribution by the diameter at which 10% of the particles are smaller and 90% are larger.
  - Select Use Trend Limits to use the trend limits selected in the Preferences / Averaging and Trend window (page 5-17).
    - Select Use Trend Limits if you want the software to recalculate trend limits based on all
      included runs when you add one or more analysis runs to your trend file.
    - Deselect Use Trend Limits if you do not want trend limits to display automatically on the graph when you open a trend file.

**4.** Click **OK** to save your settings.

# **Including Size Statistics in Printed Reports**


You can select the type of size distribution for printing or on-screen display. In the Size Statistics pane of the Preferences / Printed Report window (page 5-2), select whether you want to include data on Mass, Number, Volume, and Surface Area by %, and/or mL.

# **Including Filtration Efficiency in Printed Reports**

In order to include filtration efficiency in printed reports, you will need to compare two or more sample analyses so that the Multisizer 4 software can calculate filtration efficiency.

#### To include filtration efficiency data:

- 1. In the upper right of the Preferences / Printed Report window (page 5-2), select Filtration Efficiency.
- 2. Click (Sizes) to the right of Filtration Efficiency. The Filtration Efficiency Sizes window opens.



- 3. In the Filtration Efficiency Sizes window:
  - **a.** In the New Size field, enter a particle size for which you want to show filtration efficiency.
  - b. Click (Add).
  - c. Repeat Step a and Step b for each particle size.
  - **d.** Select Show filtration efficiency at each size to include filtration efficiency data for each particle size you entered. If this option remains deselected, the printed report will display overall filtration efficiency.
  - e. Click OK to save your settings.

### **Including Pulse Data in Printed Reports**

If you selected the option to save pulse data when you created a Standard Operating Method (page 4-15), you can use the Pulse Data pane in the Preferences / Printed Report window (page 5-2) to select how pulse data will appear in the printed report. You can display pulse data as a Graph, a Listing, or both.

5-12 PN A51387AB

#### To show pulse data in a graph:


- 1. In the Pulse Data pane of the Preferences / Printed Report window (page 5-2), select Graph.
- 2. Click (Select). The Pulse Graph window opens.



- 3. In the Pulse Graph window, select variables for the X and Y axes.
- **4.** Click **OK** to save your settings.

#### To show pulse data in a listing:

- 1. In the Pulse Data pane of the Preferences / Printed Report window (page 5-2), select Listing.
- 2. Click (Select). The Pulse Listing window opens.



- 3. In the Pulse Listing window:
  - a. In the Columns pane, select the values you want to include in the listing.
  - b. In the Pulses to List pane, enter the Group Size.
    - Select All Pulses to display results from the full range of the analysis.
    - Select Between Cursors to display only results between your defined cursors. For information on setting and moving cursors, see page 7-3.
    - Select From pulse and enter specific points to limit the range without inserting cursors in a graph.
- **4.** Click **OK** to save your settings.

# **Including Blockage Monitor Data in Printed Reports**


Use the Blockage Monitors pane in the Preferences / Printed Report window (page 5-2) to select how blockage monitor information will appear in the printed report. You can display blockage monitor data as a Graph, a Listing, or both.

#### NOTE

The Multisizer 4 software saves blockage monitor data with every analysis. Printed reports can display blockage monitor data independently of blockage settings in the SOM.

#### To show blockage monitor data in a graph:


- 1. In the Pulse Data pane of the Preferences / Printed Report window (page 5-2), select Graph.
- 2. Click (Select). The Blockage Monitor Graph window opens.



- 3. In the Blockage Monitor Graph window:
  - **a.** Select how blockage monitor data will appear for Volumetric Runs and Non-Volumetric Runs.
  - **b.** Select By Time or By Sequence.
  - c. Click OK to save your settings.

#### To show blockage monitor data in a listing:

- 1. In the Blockage Monitor Data pane of the Preferences / Printed Report window (page 5-2), select Listing.
- 2. Click (Select). The Blockage Monitor Listing window opens.



5-14 PN A51387AB

- 3. In the Blockage Monitor Listing window, select the blockage monitor data you want to include in the listing. The display sequence appears in the lower left corner of the window.
- **4.** To clear all selections, click (Clear All).
- 5. Click (OK) to save your settings.

# **Setting the Print Order for Reports**

When you select data and display options in the Preferences / Printed Report window (page 5-2), the options you select appear in the Report Printing Order pane.

# To change the order of printed report data:

- 1. In the Report Printing Order field, click the row you want to move.
- 2. Click (First), (Last), (Move Up), or (Move Down) to move the row to the desired position.


### **Preferences: Statistics**

Use Step 2 of the Create Preferences Wizard (Statistics) or the Statistics tab of the Edit Preferences window to select the statistics you want to display on-screen and in printed reports.

To proceed from Step 1 to Step 2, click (Next).

#### NOTE

When you open an analysis file, you can select different statistics and viewing options using the Run Menu bar (page 2-10). Display changes you make using Run menu items will not change the content of the printed report.



**Table 5.5** Statistics Display Preferences

Statistic Type	Description
Percentile	To display percentiles, select < less than and > greater than and enter percentile boundaries. You can define up to eight percentiles.
Range	<ul> <li>Select All to display results from the full range of the analysis</li> <li>Select Between Cursors to display only results between your defined cursors. For information on setting and moving cursors, see page 7-3.</li> <li>Select From and enter specific points to limit the range without inserting cursors in a graph.</li> </ul>
Results to Print	Select the variables you want to display. Your selections determine both printed statistics and the statistics that display when you select <b>Calculate</b> > <b>Statistics</b> in the Analysis menu.
Statistics Type	Select Arithmetic or Geometric.  NOTE  Select Arithmetic if you selected a Linear X axis in the Preferences / Printed Report window. Select Geometric if you chose a Logarithmic X axis.
Results on Graph	If you selected Graphs in Step 1 of the Wizard (Printed Report), select the statistics you want to display with a graph. Your selections will display in a box of statistics overlaid on each graph.
Location and Size	Specifies the placement and size of the text box containing the statistics you selected in the Results on Graph pane.


5-16 PN A51387AB

# **Using Statistical Category Names**

In the Preferences / Statistics window, click (Categories) to define and name size categories. Size category specifications allow you to simplify statistical results for easy interpretation in printed reports.

#### To define and name statistical categories:

1. In the Preferences / Statistics window, click (Categories). The Edit Category Specifications window opens.




- 2. In the Edit Category Specifications window:
  - a. In the Categorize by pane, select Mean, Median, or Modal Size.
  - **b.** In the Category Size Range column, enter the upper limit for each category. The software displays the upper limit you enter as the lower limit for the next category.
  - c. In the Category Name column, enter the name of each category.
  - d. Click (OK) to return to the Preferences / Statistics window (page 5-2).

# **Preferences: Averaging and Trend**

Use Step 3 of the Create Preferences Wizard (Averaging and Trend) or the Averaging & Trend tab of the Edit Preferences window to select statistics from averaged or trend analyses that you want to display on-screen and in printed reports.

To proceed from Step 2 to Step 3, click (Next).

For more information on averaging and trend statistics, see *Averaging Analysis Files*, page 7-20 and *Creating a Size Trend Analysis*, page 7-22.



In the Preferences / Averaging and Trend window:

- In the Average Weighting pane, select how you will look at analysis results (typically Number/mL) when multiple files are averaged.
- In the Distribution pane:
  - Select Differential to view the number of particles, total mass, total surface area, or total volume in each bin.
  - Select Cumulative < or Cumulative > to view the total number of particles, mass, surface area, or volume below or above each bin edge, respectively.
- In the Limits pane, select trend limit specifications.

Select other options as desired.

#### NOTE

Select Use Blank Subtract to include blank runs previously saved with analysis data when the software averages the runs. After the software has averaged the data (with or without a blank subtract), you cannot change how you view the results.

Use Blank Subtract only applies when you select analysis files for an average or trend file. It functions independently of the **Sample > Load Blank Run** menu item on the Main Menu bar, which applies to new analysis runs.


5-18 PN A51387AB

- In the Custom Trend Points pane, set trend percentiles, if desired. d[X] values allow you to divide the particle distribution of each run by percentage of particle size above and below a certain diameter. For example, d10 divides the particle distribution by the diameter at which 10% of the particles are smaller, and 90% larger.
- In the Pulse Averaging pane, select pulse data to be included when viewing pulses as average pulse height or average pulse width.

# **Preferences: Export**

Use Step 4 of the Create Preferences Wizard (Export) or the Export tab of the Edit Preferences window to select statistics you want to export to another file type, such as a Microsoft Excel spreadsheet.

To proceed from Step 3 to Step 4, click (Next).



#### To export statistics to another file type:

- 1. Select the statistics you want to export.
- 2. In the Data Format pane, select the type of list formatting you want. Exported list items can be separated by commas, tabs, or blank spaces, or converted into an HTML table.
- If you select HTML, select table formatting for the exported file in the HTML Format pane.
- **4.** In Export Extension, enter the three-letter extension for the destination file type (for example, XLS for Microsoft Excel). The most common file types are CSV and TXT.
- 5. In the Numeric Format pane, select the numbers format you want.

**6.** In the Export Folder pane, allow the Current folder (default) or select the Custom folder and browse to a new file location. The new file path appears in the field.


The exported file name is the analysis file name with the export extension. For information on automatically generated analysis file names, see *Creating Automatically Generated Analysis File Names*, page 4-4.

# **Preferences: Page Setup**

Use Step 5 of the Create Preferences Wizard (Page Setup) or the Page Setup tab of the Edit Preferences window to select formatting options and page elements that will appear in the printed report.

To proceed from Step 4 to Step 5, click (Next).

For information on how to open the Create Preferences Wizard and the Edit Preferences windows, see *Creating a Preferences File*, page 5-1.



#### **NOTE**

In the Graph Size pane, select Full Page to print each graph using an entire page. Click Fill Page to print a graph on a page if the page is empty or less than half full.


5-20 PN A51387AB

# **Preferences: Graph Options**

Use Step 6 of the Create Preferences Wizard (Graph Options) or the Graph Options tab of the Edit Preferences window to select display, style, and color options for printed graphs.

To proceed from Step 5 to Step 6, click (Next).

For information on how to open the Create Preferences Wizard and the Edit Preferences windows, see *Creating a Preferences File*, page 5-1.




### **Preferences: Fonts and Colors**

Use Step 7 of the Create Preferences Wizard (Fonts and Colors) or the Fonts & Colors tab of the Edit Preferences window to change fonts, text color, and background color for headings, graphs, and statistics in printed reports and on-screen.

To proceed from Step 6 to Step 7, click (Next).

For information on how to open the Create Preferences Wizard and the Edit Preferences windows, see *Creating a Preferences File*, page 5-1.



#### To change font style and size in printed reports:

- 1. Click (Graphs), (Listings), (Statistics), (Header).
- 2. In the Font window, click to select a Font, Font style, and Size.
- 3. Click OK to save your settings.

### To change text color on the screen and in printed reports:


- 1. In the Window Colors pane, select Graphs, Graph Statistics, Statistics, Listings, or Warning Text.
- 2. To change text colors for the selection only (for example, Graphs):
  - a. Click (Default Colors) to return to Multisizer 4 defaults.
  - **b.** Click (<u>Text Color</u>) to open the Color window. Select a color in the palette or define a custom color.
  - **c.** Click **(OK)** to save your settings.
- 3. To change the background color, click (Background Color) to open the Color window. Select a color in the palette or define a custom color.

5-22 PN A51387AB

# **Preferences: View Options**

Use Step 8 of the Create Preferences Wizard (View Options) or the View Options tab of the Edit Preferences window to select the default graph or listing type that will appear when you complete an analysis, and to select other analysis viewing preferences. These settings will apply to both onscreen graphs or listings and printed reports.

For information on how to open the Create Preferences Wizard and the Edit Preferences windows, see *Creating a Preferences File*, page 5-1.



**Table 5.6** Preferences Wizard: Set View Options

View Preferences	Description
Default View	Select one option in each column to choose how the analysis run is first displayed when the run is complete. You can select Interpolation view only if you select Size in the left column.
Measuring	Select Particles or Cells to change the description that appears on graphs and listings. This setting will not affect analysis specifications.
Multisizer Pulse Data	Select a maximum number of pulses to appear in a graph or listing.
Size Results Representation	Use ISO 9276-1 specifications for Size graph axis labels.
Z2 Data	Select Suppress last channel.
Size X Axis	Select the value that will automatically appear on the X axis of the graph (Diameter, Volume, or Surface Area).
Liter Symbol	Select the symbol you want to use.


Table 5.6 Preferences Wizard: Set View Options

View Preferences	Description
Volume Units	Select the volume unit you want to use.
Specific Surface Area Units	Select the surface area units you want to use.
Blank Subtract	Select Allow negative results if you want to display the negative result when a bin in the blank run contains more particles than a bin in the sample run. If you do not select this option, the displayed value will be zero (0).
Numbers	Select the numerical format you want to use.
Date Format	Select the date format you want to use.
Time Format	Select the time format you want to use.

# **Reviewing Your Preferences Settings**

To review your preferences using the Create Preferences Wizard:

- 1. Select **SOP** > **Create Preferences Wizard** on the Main Menu bar.
- 2. In the Create Preferences Wizard, click (Next) until you reach the Summary of Settings window (Step 9).



3. In the Summary of Settings window, review your settings. To change a setting, click (Back) or one of the numbered buttons below the text box to return to a previous step.

5-24 PN A51387AB

**4.** If you clicked (Back) and updated your preferences, click (Apply), then click (Finish) to exit the Wizard.

#### NOTE

In the Create Preferences Wizard / Summary of Settings window, (Finish) is not available until you click (Apply).

To view a summary of current preferences from the Main Menu bar:

Select **SOP** > **Preferences Info** on the Main Menu bar. The Preference Information window opens.

# **Saving a Preferences File**

If you will use different print and view preferences for different analysis types, you can save different preferences settings to a individual files and load them into the software.

If you are using only one set of preferences, you can configure the Multisizer 4 software to automatically save updates to your preferences to a default file when you exit the software.

To save your preferences using the Create Preferences Wizard:

- 1. Select **SOP** > **Create Preferences Wizard** on the Main Menu bar.
- 2. In the Create Preferences Wizard, click (Next) until you reach the Summary of Settings window (Step 9).
- 3. In the Summary of Settings window, click (Save).
- 4. In the Save Preferences dialog box, enter the Author name and Description, if desired.
- 5. Click (Save).
- **6.** In the second Save Preferences window, navigate to a new folder (if desired), and enter a file name in the File Name field. Preferences files use the extension .prf.
- 7. Click (Save).

# **Automatically Updating the Default Preferences File**

You can automatically save your printing preferences to the default preferences file when you exit the Multisizer 4 application.

### To save printing preferences:

1. Select **Configuration > Configure Preferences** on the Main Menu bar. The Configure Preferences window opens.

#### **NOTE**

If you are running the Multisizer 4 software in security mode, certain user types may not have sufficient security privileges to view the Configuration menu. In security mode, the Configure Preferences menu item appears in the Administrator or Supervisor drop-down menu if the user has logged in as an administrator or supervisor, respectively. The Configuration menu is available to all users when running the software in no security mode.

2. In the Configure Preferences window, check the box to automatically save your preferences to the default .prf file when you exit the Multisizer 4 software.



If you check the Automatically save box, the Multisizer 4 software will overwrite previous default preference settings when you exit the application. If you will be working with different preference settings, save your preferences to files with different names (see *Saving a Preferences File*, page 5-25).

3. Click OK to save your settings.

5-26 PN A51387AB

# Analyzing a Sample

# **Analyzing a Sample**

### **Analyzer Checklist**

Beckman Coulter recommends that you follow this checklist before each sample run, even if no change in Analyzer settings is required. For information on preparing for a sample run, see *Preparing the Analyzer for Sample Runs*, page 1-18.

### Before starting a sample run:

- 1. Power on the Analyzer, open the Multisizer 4 software, and connect to the Analyzer (see *Opening the Multisizer 4 Software*, page 2-1).
- 2. Fill the system with electrolyte solution.
- 3. Secure the correct aperture tube in place (see Installing an Aperture Tube, page 3-2).
- **4.** Empty the Waste Tank, if necessary.
- 5. Place a Multisizer 4 Smart Technology Beaker or Accuvette® ST with clean electrolyte and sample on the platform.
- **6.** Raise the platform and make sure that the aperture is immersed in the electrolyte.
- 7. Close the Sample Compartment door.

# **Selecting Analysis Settings**

Before running an analysis, you can select settings for analyzing a sample and viewing analysis files using the SOM Wizard (page 4-2) and the Create Preferences Wizard (page 5-1).

If you saved default or custom SOM files and Preferences, you can create one or more Standard Operating Procedures (page 4-26). Standard Operating Procedures (SOPs) are helpful if you are running several types of analyses that require different settings.

A Standard Operating Procedure combines one Preferences file and one Standard Operating Method (SOM) into an overall settings file for a particular type of analysis. Within the SOP, the SOM file

determines sample run settings, while the Preferences file determines view and print specifications.

- For information on creating a Standard Operating Method, see page 4-2.
- For information on setting Preferences, see page 5-1.
- For information on creating a Standard Operating Procedure, see page 4-26.

### Loading an SOM

If you saved one or more Standard Operating Method(s), you can load an SOM specific to the type of analysis you will be running.

#### **NOTE**

If you loaded a Standard Operating Procedure (SOP), it is not possible to load a Standard Operating Method (SOM), make changes to the SOM, and save the SOM under another name. To edit run settings in the SOM and save it under another name, first remove the SOP (page 6-3).

### To load a saved SOM file:

- 1. Select **SOP** > **Load an SOM** on the Main Menu bar.
- 2. In the Load a Standard Operating Method (SOM) window, navigate to the appropriate folder, select the desired SOM, and click (Open).

### NOTE

SOM files are identified by the extension .som.

# **Loading Preference Settings**

If you saved different Preferences settings to one or more file(s), you can load a different Preferences file depending on how you want to view and print an analysis.

### To load a saved Preferences file:

- 1. Select **SOP** > **Load Preferences** on the Main Menu bar.
- 2. In the Load Preferences window, navigate to the appropriate folder, select the desired Preferences file, and click (Open).

#### NOTE

Preferences files are identified by the extension .prf.

# Loading an SOP

#### To load a saved SOP file:

- 1. Select **SOP** > **Load an SOP** on the Main Menu bar.
- 2. In the Load a Standard Operating Procedure (SOP) window, navigate to the appropriate folder, select the desired SOP, and click (Open).

6-2 PN A51387AB

#### NOTE

SOP files are identified by the extension .sop.

## Removing an SOP

When you load a Standard Operating Procedure, the Multisizer 4 software will not allow you to open an SOM, make changes to it, and then save it under another name.

The Create SOM Wizard menu item is not visible when an SOP is loaded. When you select Edit the SOM, a read-only window opens: SOM Settings (SOP loaded, no changes allowed).

There are two ways to remove an SOP:

- In the Status Panel, click (Remove SOP).
- Select **SOP** > **Remove the SOP** on the Main Menu bar.

# **Verifying Preference Settings**

To see the view and print Preferences currently in effect:

- 1. Select **SOP** > **Preference Info** on the Main Menu bar.
- 2. In the Preference Information window, use the scroll bar to see the complete list of preference settings.
- 3. Click (Close).

### To copy and print Preference settings:

To print your preferences or copy them to the clipboard, click (Print) in the Preference Information window. The following table describes the print and copy options.

Table 6.1 Copy and Print Preference Settings

If you want to	Then
Print the Preferences list	<ol> <li>Click (Print).</li> <li>In the Print or Copy List Box Contents window, select Print all lines.</li> <li>Click (OK).</li> </ol>
Print a portion of the Preferences list	<ol> <li>In the Preference Information box, drag to highlight the text you want to print.</li> <li>Click (Print).</li> <li>In the Print or Copy List Box Contents window, select Print selected lines.</li> <li>Click (OK).</li> </ol>

**Table 6.1** Copy and Print Preference Settings

If you want to	Then
Copy the Preferences list to the clipboard	<ol> <li>Click (Print).</li> <li>In the Print or Copy List Box Contents window, select Copy all lines to clipboard.</li> <li>Click (OK).</li> </ol>
Copy a portion of the Preferences list to the clipboard	<ol> <li>In the Preference Information box, drag to highlight the text you want to copy.</li> <li>Click (Print).</li> <li>In the Print or Copy List Box Contents window, select the Copy selected lines to clipboard.</li> <li>Click (OK).</li> </ol>

To change Preference settings, select **SOP** > **Edit Preferences** on the Main Menu bar (page 5-1) or select **SOP** > **Create Preferences Wizard**.

# **Verifying SOM Settings**

To see the Standard Operating Method currently in effect:

- 1. Select **SOP** > **SOM Info** on the Main Menu bar.
- 2. In the SOM (Standard Operating Procedure) Information window, use the scroll bar to see the complete list of SOM settings.
- 3. Click (Close).

### To copy and print SOM settings:

To print your SOM settings or copy them to the clipboard, click (Print) in the SOM Information window. There are four print and copy options.

**Table 6.2** Verify SOM Settings

If you want to	Then
Print the SOM settings	<ol> <li>Click (Print).</li> <li>In the Print or Copy List Box Contents window, select Print all lines.</li> <li>Click (OK).</li> </ol>
Print a portion of the SOM settings	<ol> <li>In the SOM Information box, drag to highlight the text you want to print.</li> <li>Click (Print).</li> <li>In the Print or Copy List Box Contents window, select Print selected lines.</li> <li>Click (OK).</li> </ol>

6-4 PN A51387AB

Table 6.2 Verify SOM Settings

If you want to	Then
Copy the SOM settings to the clipboard	<ol> <li>Click (Print).</li> <li>In the Print or Copy List Box Contents window, select Copy all lines to clipboard.</li> <li>Click (OK).</li> </ol>
Copy a portion of the SOM settings to the clipboard	<ol> <li>In the SOM Information box, drag to highlight the text you want to copy.</li> <li>Click (Print).</li> <li>In the Print or Copy List Box Contents window, select the Copy selected lines to clipboard.</li> <li>Click (OK).</li> </ol>

To change SOM settings and save the SOM under a new name, select **SOP** > **Edit the SOM** on the Main Menu bar (see *Using a Standard Operating Method (SOM)*, page 4-2), or select **SOP** > **Create SOP Wizard**.

### **Entering Sample Information**

Before you begin a run, enter sample information after selecting **Sample > Enter Sample Info** on the Main Menu bar.


No information that you enter in the Enter Sample Info window will affect analysis results, but it is helpful in organizing your data and preventing accidental file overwrites.

Identifying sample information is particularly important if you are completing more than one analysis run. You can use information entered in the Enter Sample Info for Next Run window to create sequential file names that will help you organize your data for comparing and overlaying files (see *Creating Automatically Generated Analysis File Names*, page 4-4).

When you create a Standard Operating Method (SOM), you can choose to display the Enter Sample Info window automatically before each analysis run to prompt the operator to enter sample information. For more information, see *Standard Operating Method: Run Settings*, page 4-8.

### To enter sample information before a run:

1. Select **Sample > Enter Sample Info** on the Main Menu bar. The Enter Sample Info for Next Run window opens.



2. In the Enter Sample Info for Next Run window, enter information in the text fields according to the table below. The maximum number of characters you can enter in these fields is specified either in Step 1 of the SOM Wizard or by selecting SOP > Edit the SOM.

Table 6.3 Entering Sample Info for Next Run

In the text field	Enter
File ID	A name or abbreviation that clearly identifies the group or general sample information.
	Information entered in this and other sample information fields can be used to automatically create part of the file name (page 4-4).
Sample ID	A name or abbreviation that identifies the current sample. Information entered in this and other fields can be used to automatically create part of the file name (page 4-4).
Operator	The operator's name or initials. If you are logged in, the software populates this field automatically.
Bar Code	Bar code information on the sample packet, if available. To enter the sample bar code, hold the bar code in front of the Bar Code Reader on the Analyzer Control Panel.
	To scan bar codes on sample packets, it may be necessary to configure the Bar Code Reader (see <i>Bar Code Reader Configuration Options</i> , page 8-15).
Comment	Detailed information about the sample as desired.
Run Number	The number of the run. In general, enter "1" in this field, and reset the run number to "1" if you are re-running the sample. The Multisizer 4 software will automatically increment the run number for multiple runs. You can use this field to create sequential file names for each run by setting file name preferences in the SOM (page 4-4).
Variable 1 and 2	Any variables your analysis requires. These fields will not affect analysis results. For example, you can use a variable field to record a pH value.

6-6 PN A51387AB

Select Control Sample if you are running a sample with known values for comparison.

#### NOTE

The File Name and the file name Template appear at the bottom of the window. The template codes are generated by settings in the Standard Operating Method (page 4-1). Using SOM settings, you can configure the Multisizer 4 software to automatically create file names based on information in the Enter Sample Info window. For information on automatically generated file names, see page 4-4.

### **Editing Sample Information**

After you complete an analysis run, you can enter or update sample information. For more on sample information, see *Entering Sample Information*, page 6-5.

#### NOTE

The option to edit sample information after a run is available only to user types with sufficient security privileges. If the Multisizer 4 software is running with no security, every operator can edit sample information.

### To update or enter sample information after an analysis run:

- 1. Open the analysis file for which you will be entering sample information.
- 2. Select **Edit > Edit Sample Info** on the Run Menu bar. The Edit Sample Info window opens.

#### NOTE

If the user does not have sufficient security privileges to edit sample information, the **Edit Sample Info** menu item will not appear in the Edit drop-down menu.


3. Enter information in the text fields and click (OK) to save your settings.

# **Using Sample Specifications**

For applications such as quality control, you can enter sample specifications before running an analysis to verify that the particle size and/or distribution of your sample(s) fall within specified parameters.

### To enter sample specifications:

1. Select **Sample > Create Sample Specifications** on the Main Menu bar. The Create Sample Specifications window opens.



- 2. In the Create Sample Specifications window:
  - **a.** In the Statistics Type pane, enter the type of bin weighing and the particle size range for comparison.

#### **NOTE**

Settings that you select in the Create Sample Specifications window will not affect or be affected by selections you make in Preferences page 5-1. Statistics you select in the Preferences Wizard or Edit Preferences window control view and print settings only.

- **b.** Enter a title for the sample specifications, if desired.
- c. Select one or more options to specify the sample specification value, and enter a Lower Limit, Upper Limit, and Nominal Value for the specifications you select.
- **d.** To save the sample specifications to a file, click (Save). Specifications files are identified with the extension .spec.
- e. Click (OK).

6-8 PN A51387AB

## **Editing Sample Specifications**

After completing an analysis run, you can enter or update sample specifications. For more information on sample specifications, see *Using Sample Specifications*, page 6-7.

#### NOTE

The option to edit sample specifications is available only to user types with sufficient security privileges. If the Multisizer 4 software is running with no security, every operator can edit sample specifications.

### To update or enter sample specifications after an analysis run:

- 1. Open the analysis file for which you will be editing sample specifications.
- 2. Select **Edit > Edit Sample Specifications** on the Run Menu bar. The Edit Sample Specifications window opens.

#### NOTE

If a user does not have sufficient security privileges to edit sample specifications, an Edit Sample Specifications (Read-Only) window opens.

3. Enter information in the text fields and click (OK) to save your settings.

### **Including Sample Specifications in a Printed Report**

To include sample specifications in a printed report:

- 1. Select **SOP** > **Edit Preferences** on the Main Menu bar. The Edit Preferences window opens.
- 2. In the Printed Report window (Size pane), select Compare to Sample Specifications.
- 3. Click (OK).

# **Viewing Sample Specifications**

To compare an analysis run to sample specifications:

- 1. Select **File > Open** on the Main Menu bar.
- 2. In the Open window, select an analysis file in the appropriate folder, and click (Open).
- 3. Select **Calculate > Compare to Sample Specifications** on the Run Menu bar. A new window opens and displays the comparison.

To update sample specifications, see Editing Sample Specifications, page 6-9.

### **Editing Size Data**

If necessary, you can manually edit size data after an analysis run. This feature is included primarily for compatibility with previous versions of the Multisizer software. Editing size data using the Edit Size Data window overrides analysis results.

To import size data from another instrument, use the file import feature (see *Importing a File*, page 7-18).

#### **NOTE**

The option to edit size data is available only to user types with sufficient security privileges. If the Multisizer 4 software is running with no security, every operator can edit size data.

#### To edit size data:

- 1. Open the analysis file for which you will be editing size data.
- 2. Select **Edit > Edit Size Data** on the Run Menu bar. The Edit Size Data window opens.

#### NOTE

If the user does not have sufficient security privileges to edit size data, the **Edit Size Data** menu item will not appear in the Edit drop-down menu.


- 3. Enter information in the text fields and click (Replace) to change measured data.
- **4.** Click OK to save your settings.

# **Running an Analysis**

To run an analysis, follow the steps below to prepare the Analyzer and Multisizer 4 software and run the analysis.

### To run an analysis:


- 1. Prepare the Analyzer (page 1-18).
- 2. Set view and print Preferences (page 5-1).
- 3. Create a Standard Operating Method (SOM) and a Standard Operating Procedure (SOP) (page 4-2).
- **4.** Enter sample information (page 6-5).
- 5. Enter sample specifications, if desired (page 6-7).
- 6. Select Run > Preview on the Main Menu bar (or click (Preview) in the Instrument Toolbar). Wait for the preview analysis to complete its run.
- 7. In the Status Panel, verify that the sample concentration is less than 10%.



If the concentration is greater than 10%, adjust the sample concentration and preview the analysis again.

6-10 PN A51387AB

- 8. Select Run > Start on the Main Menu bar (or click (Start) in the Instrument Toolbar).
  - If the Extended Size Range feature is enabled in the SOM (see Standard Operating Method: Threshold, Current and Gain) and the large particle count exceeds the specified threshold, a notification dialog will appear:



• If you click "Run 60% to 80%," then an extended dynamic range run will start and display the size distribution from 60% to 80% of the aperture diameter. This feature is intended for examining particles in the small "tail" of a distribution that extends above 60%.

#### **NOTE**

A 60% to 80% run uses special SOM settings which override some parameters that the user may have set, such as aperture current and sizing threshold. To obtain results for larger particles using customized settings, select a larger aperture tube.

#### NOTE

Aperture blockage is common when sample diameters are larger than 60% of the aperture diameter. The extended dynamic range should only be used for low concentrations of spherical particles larger than 60%. For best results, it is recommended to use a larger aperture size for samples that contain a significant concentration of particles above 60% of the aperture diameter.

# **Sample Analysis Variations**

### **Running a Multi-Tube Overlap Analysis**

A multi-tube overlap analysis allows you to combine up to five particle distributions using apertures of different sizes. After you filter the sample and run it through incrementally smaller aperture tubes, the Multisizer 4 software can merge these runs into one distribution that includes a range of particle sizes greater than can be measured with a single aperture.

### To run multiple analyses with different apertures:

You can run up to five analyses using different aperture sizes.

- 1. Select an aperture tube suitable for the largest particles in the sample (for information on selecting the correct aperture tube size, see page 3-1).
- 2. Follow the steps in the Change Aperture Tube Wizard to install a new tube and verify aperture calibration (page 3-18).
- 3. Run the analysis (page 6-10).
- **4.** When the analysis run is complete, save the file (select **RunFile > Save As** on the Run Menu bar) if you did not configure the Multisizer 4 software to automatically generate analysis file names. To set automatic file name generation, see (page 4-4).
- 5. After the analysis is complete, select and install a smaller aperture tube.
- **6.** Sieve, filter, or use another suitable method to remove the particles from the suspension that will block the smaller aperture.
- 7. Repeat Step 2 through Step 5. The Multisizer 4 can combine a maximum of five analyses in one multi-tube overlap file.

#### To create the multi-tube overlap file:

- 1. Select File > File Tools > Multi-tube Overlap on the Main Menu bar.
- 2. In the Multi-tube Overlap window:
  - a. In the Folders box, double-click a folder name. The folder contents appear in the Files box.
  - **b.** In the Files box, hold the Ctrl key down and select each analysis you want to include in the overlap file.
  - c. Click (Add). The files appear in the Selected Files box.
  - d. Click (OK).
- 3. In the Viewing Area, a graph or listing showing the offset points appears automatically.
- 4. To save the file, select **RunFile** > **Save As** on the Run Menu bar.
- 5. In the Save As dialog box, navigate to the appropriate folder and enter the new file name in the File Name field.
- 6. Click (Save).

6-12 PN A51387AB

### **Determining Particle Concentration Using Time Mode**

Because of stabilizing time before analysis and finishing time after, the volume of electrolyte that passes through the aperture is more than total analysis electrolyte. To calculate the amount of electrolyte used during the analysis run, you could do 30-, 60-, and 90-second runs and calculate the pre- and post-run volume, which will remain the same for every analysis length.

If you are measuring particle concentration using an aperture tube 360 µm or larger, it is necessary to use time mode. Using volumetric mode is not possible because the maximum volume allowed by the metering pump is 2 mL. In larger aperture tubes, this volume of fluid passes through the aperture too quickly to provide accurate statistical results.

#### **NOTE**

The Multisizer 4 uses small amounts of electrolyte for pre- and post-analysis stabilization. As a result, calculated volume is approximate.

#### NOTE

If you are measuring heavy particles, Beckman Coulter recommends that you thicken the electrolyte to increase particle suspension, reduce the flow rate, and produce less noise. Recommended thickening agents include glycerol and sucrose.

### To determine particle concentration using time mode:

- 1. Fill the beaker to approximately 9/10 of its capacity and measure the exact amount of electrolyte you will be using. Place the beaker on the platform.
- 2. If you have already loaded an SOP (page 4-28), select **SOP** > **Remove the SOP** on the Main Menu bar. Removing the SOP allows you to change Standard Operating Method Settings.
- 3. Select **SOP** > **Edit the SOM** on the Main Menu bar.
- **4.** In the Edit the SOM / Control Mode window, select Time, and then select 60 seconds.
- 5. Click (OK).
- 6. Select Run > Start on the Main Menu bar (or click (Start) in the Instrument Toolbar).
- 7. When the run is complete, measure the exact amount of electrolyte remaining in the beaker.
- **8.** Subtract the remaining electrolyte from the original electrolyte volume.
- 9. Select **Edit > Edit Sample Info** on the Run Menu bar. In the Analytic Volume field, enter the mL multiplied by 1000. The software automatically calculates concentration. To see particle concentration, graph or list the number, volume, or surface area per mL.

# **Using Blank Runs**

A blank run (also called a blank analysis or background analysis), is an analysis of electrolyte without sample material.

When analyzing low concentration samples, a background analysis is required for accurate results.

#### NOTE

Beckman Coulter recommends that you run a background (blank) analysis for every batch of analyses that uses the same electrolyte.

## **Running a Blank Analysis**

### To run a blank analysis:

1. Load the Standard Operating Procedure (page 4-28) or Standard Operating Method (page 4-25) you will be using for the sample analysis.

#### NOTE

If you set automatic file name generation (page 4-4), change the file name to indicate that the run is blank, either before or after the analysis run.

- 2. Prepare the Analyzer (page 1-18).
- 3. Fill a beaker with clean electrolyte and place the beaker on the sample platform.
- 4. Select Run > Start on the Main Menu bar (or click (Start) in the Instrument Toolbar).

### To save the blank analysis:

- 1. Leave the blank analysis open in the Viewing Area.
- 2. Select RunFile > Save As on the Run Menu bar.
- 3. In the Save As dialog box, enter a file name for the background, and then select Save as readonly.
- 4. Click (Save).

6-14 PN A51387AB

### **Enabling Blank Subtraction for Analysis Runs**

After you run a blank analysis (page 6-14), you can set the software to automatically subtract electrolyte background from sample analysis runs.

To subtract the electrolyte background from analysis runs:

- 1. Select Sample > Load Blank Run on the Main Menu bar.
- 2. In the Load a Blank Run window, navigate to the appropriate folder and select the desired blank analysis file.
- 3. Click (Open).

The blank analysis will be subtracted from each subsequent analysis until you select **Sample > Remove Blank** on the Main Menu bar.

### **Disabling Blank Analysis Subtraction**

To disable blank analysis subtraction, select **Sample > Remove Blank** on the Main Menu bar.

### Loading a Blank Run into an Open Analysis File

To load a blank run for a single analysis:

- 1. If the analysis is not open in the Viewing Area, open a saved analysis (page 7-17).
- 2. Select Calculate > Load Blank Run on the Run Menu bar.
- 3. In the Load a Blank Run window, navigate to the saved blank analysis and click (Open). The software automatically subtracts the background from analysis data.

# Removing a Blank Run from an Open Analysis File

To remove a blank run from the open analysis, select **Calculate > Remove Blank Run** on the Run Menu bar.

The **Remove Blank Run** menu item removes the blank run from the open analysis file only.

If you selected **Sample > Load Blank Run** on the Main Menu bar and want to disable blank analysis subtraction for all future analysis runs, select **Sample > Remove Blank** on the Main Menu bar.

# **Analyzing a Sample**Using Blank Runs

6-16 PN A51387AB

# Working with Analysis Files

# **Setting File Preferences**

When an analysis run is complete, there are a number of options for displaying statistical results. You can set viewing, printing, and statistical analysis defaults using the Create Preferences Wizard or the Edit Preferences windows (page 5-1).

If you save a set of Preferences, the saved Preferences file can be associated with one or more Standard Operating Procedures (SOPs). Creating SOPs allows you to set specific run, view, and print preferences for different types of analysis runs (page 4-26).

You can change how the Multisizer 4 software displays an analysis file in the following ways:

- To change default display preferences, or preferences associated with a specific type of analysis, select **SOP** > **Edit Preferences** on the Main Menu bar (page 5-1).
- To temporarily change the display of an open analysis file, select **View** on the Run Menu bar (page 2-10). You can use items in this menu to select display and analysis settings.
- Sample data files can be found in the *Demodata* file folder on the instrument controller. Use these files to practice the file preference options described in this chapter.
- The Run Menu bar changes based on the display and analysis options you select in the View drop-down menu (page 7-2).

# **Changing Print Settings**

Changes you make using drop-down menus on the Run Menu bar affect on-screen analysis settings only. If you select **RunFile > Print Report**, the Multisizer 4 will use print settings in the current Preferences file, not on-screen analysis view settings.

There are two options for changing print settings:

- If you want to change Printed Report defaults or save print settings and associate them with a Standard Operating Procedure, change settings in the Edit Preferences window. To open the Edit Preferences window:
  - Select SOP > Edit Preferences on the Main Menu bar.
  - Select RunFile > Print Report on the Run Menu bar. In the Print Report window, click (Report) to open the Edit Preferences window.

• If you want to print a graph or listing as it appears on the screen, without changing Print Report settings, select **RunFile > Print** on the Run Menu bar.

# **Viewing Analysis Files**

## Changing the Display of an Open File

To change the display of an open analysis file:

- 1. Select View on the Run Menu bar (located at the top of the open analysis file).
- 2. In the View menu, select one display type: **Graph**, **Listing**, or **Interpolation**.
- 3. In the View menu, select one analysis type: **Size** (particle size), **Pulse** (pulse height and width), or **Blockage Monitors** (aperture resistance over time or by sequence).

### **Run Menu Behaviors**

### **Graphs**

If you select View > Graph, three menus will appear to the right of the View menu (Graph, Calculate, and Display). The Graph drop-down menu, and the options available in the Calculate drop-down menu, will differ based on the analysis type you select (Size, Pulses, or Blockage Monitors).

### **Listings and Interpolation**

If you select **View > Listing** or **View > Interpolation**, the drop-down menu to the right of the **View** menu will change to Listing or Interpolation, respectively. Options available in the **Calculate** drop-down menu will vary depending on the analysis type you selected (**Size**, **Pulses**, or **Blockage Monitors**).

# **Viewing Graphs**

To display analysis results as a graph:

- 1. Select View > Graph on the Run Menu bar.
- 2. Select the View drop-down menu a second time and select the type of graph (Size, Pulses, or Blockage Monitors).

#### **Graph Menu**

The **Graph** drop-down menu offers different options for X and Y axis values based on the type of graph you select.

7-2 PN A51387AB

#### NOTE

If you select **Differential + Cumulative <** or **Differential + Cumulative >** in the **Graph** drop-down menu, a new **Cursor** menu appears to the right of the **Display** menu. The **Cursor** menu allows you to select the trace on the graph to which the cursor readout (below the graph) refers. When you are viewing overlaid or multiple runs, menu items also allow you to arrange the runs manually or by start time.

### Calculate Menu

For information on available menu items in the **Calculate** drop-down menu, see Viewing Statistics (page 7-8).

### **Display Menu**

The **Display** drop-down menu items allow you to change the appearance of the graph and select the scale of the X and Y axes.

# **Using Cursors in Graphs**

You can place one or two cursor points in a graph. Placing two cursors in a graph allows you to zoom in on one part of a graph or view statistics between two points.

Table 7.1 Using Cursors in Graphs

If you want to	Then
Insert one cursor (or the first cursor)	Click once in the graph to insert a cursor. The placement of the cursor on the X axis appears in numerical form below the graph.
Insert a second cursor	Left-click on the first cursor and drag it to another position on the graph. Un-click to create a second cursor. The first cursor will remain in place as you drag the second cursor line.
Reposition the cursor(s)	Click in the graph at the point you want to place the new cursor. You can use the left and right arrow keys to move the cursor, and use the Tab key to switch between cursors.
Remove the cursor(s)	Click outside the graph.
Change cursor lines from vertical to horizontal	Select View > Horizontal Cursors (pulse graphs ONLY).
Change cursor lines to box cursors	Select View > Box Cursors (pulse graphs ONLY).
View a portion of the graph between two cursor points	Select View > Zoom In. To return to the full graph, select View > Zoom Out.
View statistics between two cursor points	Select Calculate > Statistics.

## **Viewing Listings**

To display analysis data as a numerical list:

- 1. Select View > Listing on the Run Menu bar.
- 2. Open the View drop-down menu a second time and select the type of listing (Size, Pulses, or Blockage Monitors).


### **Listing Menu**

The Listing drop-down menu offers the following options: Column Format, Wrap Screen Listings, and Wrap Printer Listings.

When you select **Listing > Column Format**, a different window opens depending on which listing type you selected (**Size**, **Pulses**, or **Blockage Monitors**).

#### **Size Column Format**

If you select **View > Listing** then select **Size**, the Size Listing window opens when you select **Listing > Column Format**.



To select the columns of data that will appear in the size listing:


- 1. In the Columns pane:
  - a. Select Bin Number to include the bin number next to each bin value.
  - **b.** Select Lower Edge, Upper Edge, or Center to print the smallest, largest, or median particle size, volume, or surface area in each bin.
  - **c.** Select up to seven options to display columns of statistics.
- 2. In the Bin Grouping pane:
  - **a.** Enter a number in the Group Size text field to group bins, if desired. Grouping bins shortens the listing. Select First Bin in Group or Sum Bins in Group.
  - **b.** Select All Bins to display results from the full range of the analysis.

7-4 PN A51387AB

- c. Select Between Cursors to display only results between your defined cursors. For information on setting and moving cursors, see page 7-3.
- d. Select From and enter specific points in the From and to fields to define statistical limits.
- 3. To clear all selections, click (Clear All).
- 4. Click (OK).

#### **Pulses Column Format**

If you select **View > Listing** then select **Pulses**, the Pulses Listing window opens when you select **Listing > Column Format**.




### To select the columns of data that will appear in the pulse listing:

- 1. In the Pulse Listing window, select the statistics in the Columns pane that you want to display.
- 2. In the Pulse Grouping pane, enter the Group Size in the field.
  - **a.** Select All Pulses to display results from the full range of the analysis.
  - **b.** Select Between Cursors to display only results between your defined cursors. For information on setting and moving cursors, see page 7-3.
  - **c.** Select From and enter specific points to limit the range without inserting cursors in a graph.
- 3. Click (OK).

### **Blockage Monitors Column Format**

If you select **View > Listing** then select **Blockage Monitors**, the Blockage Monitor Listing window opens when you select **Listing > Column Format**.



### To select the data columns that will appear in the Blockage Monitor listing:

- 1. In the Blockage Monitor Listing window, select the data you want to display in the Columns pane.
- 2. Click (Clear All) to clear all selections.
- 3. Click (OK).

### Calculate Menu

For information on available menu items in the **Calculate** drop-down menu, see *Viewing Statistics*, page 7-8.

# **Viewing Interpolations**


An interpolation allows you to divide a particle size distribution into any number of bins (channels) of any size. Interpolation is similar to viewing results by statistical percentiles, but offers greater flexibility.

The **Interpolate** menu option on the Run Menu bar is only available if you are viewing results by particle size (**View** > **Interpolate** and **Size** is the only possible combination).

### To view an interpolation:

1. Select **View > Interpolation** on the Run Menu bar, then select **Size**.

7-6 PN A51387AB



2. Select Interpolation > Size Interpolation on the Run Menu bar.

- **3.** In the Size Interpolation window:
  - a. In the Interpolation Type pane, select Size to or to Size.
    - Select Size to if you want to create interpolation points based on particle diameter size (that is, particle diameters define bin edges). You can select up to nine statistics to display based on particle size interpolation points
    - Select to Size if you want to create interpolation points based on the statistic you select in the Interpolation Type pane (Number, Volume, Surface Area, %, and /mL). You can select only one statistical interpolation point to correlate to particle size.
  - b. Select one or more of these options: Number, Volume, and/or Surface Area, and select % and/or /mL for each selected interpolation type. If you are displaying statistics to Size, you can only select one option.
  - c. Select Under (<), Over (>), or (if you selected Size to), Differential.

Table 7.2 Size Interpolation Data

If you select	The columns will display
Under (<)	Statistical results below the interpolation point. The interpolation point becomes the upper edge of the bin.
Over (>)	Statistical results above the interpolation point. The interpolation point becomes the lower edge of the bin.
Differential	The number, volume, or surface area of particles between interpolation points.

- **d.** In the Interpolation Points pane:
  - To add an interpolation point, enter the new point in the field and click (Add).
  - To delete an interpolation point, select the point and click (Delete).

- e. In the Range pane:
  - Select All to display results from the full range of the analysis.
  - Select Between Cursors to display only results between your defined cursors. For information on setting and moving cursors, see page 7-3.
  - Select From and enter specific points to limit the range without inserting cursors in a graph.
- **4.** Click **OK**) to view the interpolation.

### **Changing the Column Display**

To wrap columns on the screen, select Interpolation > Wrap Screen Listings on the Run Menu bar.

To wrap columns in the printed report, select **Interpolation > Wrap Printer Listings** on the Run Menu bar.

When you select column wrapping, **Wrap Screen Listings** and **Wrap Printer Listings** remain checked until you clear them, or until you close the analysis file. These settings remain in effect when viewing both Listings and Interpolations.

### To print reports with column wrapping:

If you want to change the display of the open analysis file, but not report settings, select **Interpolation > Wrap Printer Listings** on the Run Menu bar. This setting will not change Printed Report options previously set in the Preferences window. To change printed report settings, see *Preferences: Printed Report*, page 5-2.

# **Viewing Statistics**

The **Calculate** drop-down menu on the Run Menu bar allows you to view statistics, regardless of whether the analysis window displays a graph, listing, or interpolation.

If you select **Pulses** or **Blockage Monitors** in the **View** drop-down menu, many of the options in the **Calculate** drop-down menu will not be available.

### NOTE

The statistics displayed in the pop-up window are based on preselected Preferences settings. To add or remove statistics, select **SOP** > **Edit Preferences** / **Statistics** on the Main Menu bar (page 5-15).

#### To view statistics between cursors (graph view only):

If you are viewing a graph and have inserted two cursor points, **Calculate > Statistics** will display results only for the portion of the analysis run included between the cursors.

If you have not included cursors, or if you have placed only one cursor in the graph, **Calculate** > **Statistics** will display statistics based on the complete analysis run.

For information on placing cursors, see *Using Cursors in Graphs*, page 7-3.

7-8 PN A51387AB

#### To save statistics:

To save statistics for the analysis you are viewing (for example, statistics between cursors):

- 1. Select Calculate > Statistics on the Run Menu bar.
- 2. In the Statistics window, click (Save). The Multisizer 4 will include the statistics you save when you save the analysis run.

The statistics you save in the **Calculate** > **Statistics** window will appear when you select **RunFile** > **Get Info** on the Run Menu bar.

### To view statistics on the screen (graph view only):

To view statistics together with a graph, select **Calculate > Show Statistics on Graph** on the Run Menu bar.

There are two ways to remove statistics from the graph view:

- Select Calculate > Hide Statistics on Graph on the Main Menu bar.
- Click the **X** in the upper right corner of the statistics box.

### **Comparing Statistics to Sample Specifications**

If you created sample specifications (page 6-7), select **Calculate** > **Compare to Sample Specifications** to see analysis results compared to your pre-set parameters.

# **Comparing an Analysis to a Standard Run**

If you have run an analysis as a standard for comparison with other analysis runs, you can use items on the Run Menu bar to compare the current analysis results to the standard.

### To compare with the standard:

- 1. Select Calculate > Compare to Standard on the Run Menu bar.
- 2. In the Open Standard Run window, navigate to where you saved the standard analysis file and click to select the file for comparison.
- 3. Click (Open).


All display and statistical options will include comparisons to the standard file until you remove the standard file. To remove the standard file, select **Calculate > Remove Standard**.

# **Converting Pulses to Size**


You can change the number of bins (channels) and select a range of particle sizes to display.

### To convert pulses to size:

 Select Calculate > Convert Pulses to Size on the Run Menu bar. The Convert Pulses to Size Settings window opens.



- 2. In the Convert Pulses to Size Settings window:
  - **a.** In the Size Bins field, enter the number of bins you want to use, or select a number of bins from the drop-down list.
  - **b.** In the from and to fields, enter the low and high limits for the range of particle diameter sizes you will be analyzing.
    - If you want to analyze the broadest possible distribution based on aperture size, click the (2% to 60%) button ((10% to 60%)) button if using a 2000- $\mu$ m aperture, as shown below).



- c. In the Bin Spacing pane, select how the Multisizer 4 will determine bin spacing:
  - By an incremental count of particle diameters (Linear Diameter)
  - By a geometric progression of particle diameter sizes (Log Diameter)
  - By a linear progression of particle volume (Linear Volume)
  - By a geometric progression of particle volume size (Log Volume)

7-10 PN A51387AB

- **d.** In the Options pane, select one or more of the following, if desired:
  - Pulse Edit. Select this option if you have a narrow distribution and want to ensure accurate analysis results by eliminating large pulses. Particles that do not pass through the center of the aperture tend to produce wider pulses. Pulse edit removes the widest pulses from statistical analysis and displayed results.
  - **Use Shape Factor.** Select this option if you want to match your results to another particle sizing instrument, or if you need to adjust analysis results based on a known factor. Entering a shape factor of 1.03, for example, increases particle diameter or volume by 3%.
- e. Click (OK).

### **Converting Pulses to Size Between Cursors**

To convert pulses to particle size between two cursor points on a graph:

- 1. Select bin size and other options in the Convert Pulses to Size Settings window (page 7-9).
- 2. In the graph view, place two cursors to delimit analysis results. For information on inserting cursors, see *Using Cursors in Graphs*, page 7-3.
- 3. Select Calculate > Convert Pulses between Cursors on the Run Menu bar. The graph view changes to display only results between the two cursor points.

#### **NOTE**

**Convert Pulses between Cursors** allows you to select a range of particle sizes for analysis based on cursor points. You can also enter specific diameter or volume limits in the Convert Pulses to Size Settings window. Limiting the particle size range using either cursors or text input allows you to increase the precision of your analysis by viewing the same number of size bins within a smaller distribution.

# **Converting Pulses to Size for the Widest Distributions**


To automatically analyze the widest possible distribution based on aperture size, select **Calculate** > **Convert Pulses (2% to 60%)**, or, if you're using a 2000-µm aperture tube, select **Calculate** > **Convert Pulses (10% to 60%)**.

To change the number of bins or other options associated with converting pulses, select **Calculate** > **Convert Pulses to Size** on the Run Menu bar. Enter new settings in the Convert Pulses to Size Settings window (page 7-9).

# **Printing Report(s) for One or More Analysis Files**

If you want to print reports for multiple analysis runs or for a single analysis run that is not open in the Viewing Area:


1. Select File > Print Reports on the Main Menu bar. The Print Reports window opens.



- 2. In the Print Reports window:
  - **a.** In the Folders box, double click the appropriate folder name. The folder contents appear in the Files box.
  - **b.** In the Files box, click to highlight the file(s) you want to print. To highlight multiple analysis files, hold the Ctrl key down while clicking each file name, or click one file and drag the files you want to include in the Selected Files box.
  - c. Click (Add). The files appear in the Selected Files box.

7-12 PN A51387AB

**d.** Click **OK**). A second Print Reports window opens.




3. In the Print Reports window, click (Print). For information on how to change printer settings or Preferences using the Print Report window, see page 7-14.

# Printing a Report of an Open Analysis File

To print a report for an analysis file that is open in the Viewing Area:

1. Select RunFile > Print Report on the Run Menu bar. The Print Report window opens.



2. In the Print Report window:

7-14 PN A51387AB

**Table 7.3** Open Analysis File Print Options

Select this option	То
Print a report for the current file only	Print a report for the open file in the Viewing Area only. This option is only available when multiple files are open.
Print a separate report for each file	Print a report for each open file in the Viewing Area.
Print an overlay report of all files	Print a report that includes statistics for all open files in the Viewing Area.
Landscape	Change the page orientation to Landscape (11 $\times$ 8.5). The page icon displays the current paper orientation (Portrait, or 8.5 $\times$ 11).
Include Custom Title	Enter a title for the report. Check this box only if you have not already included a title on the Preferences / Page Setup window (page 5-20).
Include Page Number	Include page numbering in the report. Page numbers appear in the upper right corner of each page.
	Checking this box and other boxes in the Printer Settings pane will override settings you entered previously in the Preferences / Page Setup window (page 5-20).
Restart numbering for each file	Include separate pagination for each file in an overlay file. This option is only available when you have opened an overlay, which consists of multiple files (page 7-19).
Include Date	Include the date you printed the report. The date will appear in the upper right corner of each page.
Include Time	Include the time you printed the report. The time will appear in the upper right corner of each page.
Graph Size	Use the drop-down list to select the size of graphs in the printed report.
	Selecting a new graph size will override the setting you entered previously in the Preferences / Page Setup window.
Print Graphs Using Screen Colors	Use the colors currently displayed in the on-screen graph.

- Click (Preview) to view the contents and layout of the report in a separate window before printing.
- Click (Report) to open the Edit Preferences window (page 5-1), where you can change print and view settings.
- Click (Printer Setup) to view printer settings.
- 3. Click (Print) to print the report.

# **Printing with Current Analysis Settings**

You can print a graph or listing as it appears on the screen without changing Preferences settings.

To print an analysis as it is displayed in the Viewing Area:

1. Select RunFile > Print on the Run Menu bar. The Print window opens.

- 2. In the Print window:
  - **a.** Select the graphs, listings, and statistics you want to print. In the Printing Order box, your selections are listed in the order in which they will appear.
  - b. In the Printer Settings pane, select print options. Click (Page Setup) to see more options, including margin and time/date settings.
  - c. When you have made your selections, including graph size, color, and font, click (Print).

### Saving an Analysis File


The Multisizer 4 can automatically save analysis data based on Standard Operating Method settings, or you can save sample data to a file when the analysis is complete.

### **Saving Analysis Data Automatically**

To automatically save analysis data, select appropriate Run Settings in the current Standard Operating Method and enter sample information before the run.

To save analysis data automatically:

- Select SOP > Edit the SOM on the Main Menu bar. The Edit the SOM (Standard Operating Method) window opens.
- 2. In the Edit the SOM window, click the Run Settings tab.



- 3. On the Run Settings tab, select Enter sample info before first run. When this option is selected, the software opens the Enter Sample Info window when the operator starts an analysis.
- 4. Select Save File and, if desired, Include Pulse Data.

7-16 PN A51387AB

#### **NOTE**

Selecting Include Pulse Data will increase the file size significantly.

- 5. Click (Folder). The Select the Run Folder window opens.
- **6.** In the Select the Run Folder window:
  - a. Select Use the current folder or Use a custom folder.
     If you are using a custom folder, click (Browse) and navigate to the desired folder.
  - **b.** Click (OK) to return to the Edit the SOM window.
- 7. In the Edit the SOM window, click (File Name). In the File Name Generation window:
- 8. Create the file name template by selecting components such as File ID, Date, and Time. For more information, see *Using File Name Template Codes*, page 4-5, and click (OK).

#### NOTE

The file name generation template fields draw information from the Enter Sample Info for Next Run window (page 6-5).

9. In the Edit the SOM / Run Settings window, click (OK).

### **Saving Analysis Data Manually**

If you have not used Standard Operating Method settings to save analysis data automatically (page 4-2), or if you want to save analysis data using a new name, you can save the file after the analysis is complete.

To save analysis data manually when an analysis is open in the Viewing Area:

- 1. Select RunFile > Save or RunFile > Save As on the Run Menu bar.
- 2. In the Save As window, navigate to the appropriate folder and enter a file name in the File Name field. If you want to write protect the analysis file, select Save as read-only in the middle of the window.
- 3. Click (Save).

#### NOTE

Analysis files are identified by the extension .#m4 or custom extensions created in the File Name Generation window (page 4-4).

# **Opening a Saved Analysis File**

To open a saved analysis file:


- 1. Select **File > Open** on the Main Menu bar or click **(Open)** in the Main Toolbar.
- 2. In the Open window, navigate to the appropriate folder and select the file name.
- 3. Click (Open).

### Importing a File

You can import data from another program or transfer a size distribution from another instrument.

### To import a file:

- 1. Select File > File Tools > Import Size Data on the Main Menu bar.
- 2. In the Import Size Data window:
  - **a.** Click the down arrow in the Files of Type text field to select the imported file type, or select All Files (\*.\*).
  - b. Navigate to the appropriate folder and select the file you want to import.
  - c. Click Open. An import file window displaying the path and name of the imported file opens.



- 3. In the import window, specify the type of size distribution to import.
- 4. Click and drag to select the data lines to import, or specify the lines in First Line and Last Line.
- 5. Click (OK).

7-18 PN A51387AB


# **Working with Multiple Analysis Files**

### **Using Overlay Files**

Opening files for overlay allows you to view multiple analysis results on the same graph.

### To open files for overlay:

1. Select **File > Overlay** on the Main Menu bar. The Overlay window opens.



- 2. In the Overlay window:
  - **a.** In the Folders box, double click the appropriate folder name. The folder contents appear in the Files box.
  - b. In the Files box, click to highlight the file(s) you want to open for overlay. To highlight multiple analysis files, hold the Ctrl key down while clicking each file name, or click one file and drag over the files to be included.
  - c. Click (Add). The files appear in the Selected Files box.
  - **d.** Click (OK). The sample analysis data appear on one graph in the Viewing Area.

#### NOTE

If the analyses you select have incompatible data or formatting, an incorrect file type error message will appear, and the files will open in individually tiled windows.

### To add a file to an open overlay:

- 1. Select RunFile > Open for Overlay on the Run Menu bar. The Open for Overlay window opens.
- 2. In the Open for Overlay window, navigate to the file you want to add to the open overlay, and click (Open).
- 3. The new analysis data appears on the graph.

# Saving an Overlay File

An overlay file is saved as a list. The saved file does not contain the data from the original files, but points to the files in their current location. If you move or delete the original files, the overlay file will not open.

- 1. Select RunFile > Save Overlay List on the Run Menu bar.
- 2. In the Save a List of Overlaid Files window, navigate to the appropriate folder and enter a file name in the File Name field.
- 3. Click (Save).

#### NOTE

Overlay files are identified by the extension .ovr.

# **Opening a Saved Overlay File**

To open a saved overlay file:

- 1. Select File > File Tools > Open Overlay List on the Main Menu bar.
- 2. In the Open Overlay List window, navigate to the overlay list you want to open.
- 3. Click (Open).

#### NOTE

An overlay file does not contain the data from the original files, but points to the files in their current location. If you move or delete the original files, the overlay file will not open.

# **Averaging Analysis Files**


The Multisizer 4 allows you to average the results of multiple analyses and view or print averaged statistics in a listing or graph.

7-20 PN A51387AB

### **Opening Files for Averaging**

To view the average of two or more analysis files:

1. Select File > File Tools > Average on the Main Menu bar. The Average window opens.



- 2. In the Average window:
  - **a.** In the Folders box, double click the appropriate folder name. The folder contents appear in the Files box.
  - b. In the Files box, click to highlight the file(s) you want to average. To highlight multiple analysis files, hold the Ctrl key down while clicking each file name, or click one file and drag over the files to be included.
  - c. Click (Add). The files appear in the Selected Files box.
  - d. Click (OK).

# Adding Data to an Average

To include data from another file in an averaged file:

- 1. Select RunFile > Open and Add to Average on the Run Menu bar. The Open window opens.
- 2. In the Open window, navigate to the file you want to add, and click (Open).
- 3. The new average appears on the graph or listing.

# Saving Averaged Files

You can save an average as a self-contained analysis file, or as a list of files (similar to an overlay file list, page 7-19). If you save an average as a list of files, the new file does not contain data from the

original files, but points to the original files in their current location. If you move or delete the original files, the average file will not open.

#### To save an average as a self-contained analysis file:

- 1. Select RunFile > Save or RunFile > Save As on the Run Menu bar.
- 2. In the Save As window, navigate to the appropriate folder and enter a file name in the File Name field. If you want to write protect the averaged file, select Save as read-only in the middle of the window.
- 3. Click (Save).

#### NOTE

Averaged analysis files are identified by the extension .#av.

#### To save an average as a list:

- 1. Select RunFile > Save List of Averaged Files on the Run Menu bar.
- 2. In the Save a List of Averaged Files window, navigate to the appropriate folder and enter a file name in the File Name field.
- 3. Click (Save).

#### **NOTE**

Average files saved as a list are identified by the extension .avg.

# **Opening a Saved List of Averaged Files**

To open a self-contained average file (extension .#av):

- 1. Select File > Open on the Main Menu bar, or click (Open) in the Main Toolbar.
- 2. In the Open window, navigate to the appropriate folder and select the file name.
- 3. Click (Open).

To open an average file saved as a list (extension .avg):

- 1. Select File > File Tools > Open a List of Averaged Files on the Main Menu bar.
- 2. In the Open a List of Averaged Files window, navigate to the average list you want to open.
- 3. Click (Open).

# **Creating a Size Trend Analysis**

Creating a size trend analysis allows you to see variations in particle size over time or in relationship to other variables (such as pH). A Size Trend analysis combines data from multiple analyses into one graph or listing. You can update a Size Trend by adding additional analysis files at any time.


You can also use a size trend analysis to track changes in calibration (changes in the calibration constant, or Kd). For more information on Kd values, see page 3-10.

7-22 PN A51387AB

### **Opening Files for a Size Trend**

To view size trend data for two or more analysis files:

1. Select **File > File Tools > Create Size Trend** on the Main Menu bar. The Create Size Trend window opens.



- 2. In the Create Size Trend window:
  - **a.** In the Folders box, double click the appropriate folder name. The folder contents appear in the Files box.
  - b. In the Files box, click to highlight the file(s) you want to include in the size trend analysis. To highlight multiple analysis files, hold the Ctrl key down while clicking each file name, or click one file and drag over the files to be included.
  - c. Click (Add). The files appear in the Selected Files box.
  - d. Click (OK).

# Adding a File to a Size Trend

To include data from another file to an open size trend analysis:

- 1. Select RunFile > Open and Add to Trend on the Run Menu bar. The Open window opens.
- 2. In the Open window, navigate to the file you want to add, and click (Open).
- 3. Analysis data from the new file is added to the size trend.

# Saving a Size Trend

A size trend is saved as a self-contained analysis file.

#### To save a size trend:

- Select RunFile > Save or RunFile > Save As on the Run Menu bar.
- 2. In the Save As window, navigate to the appropriate folder and enter a file name in the File Name field. If you want to write protect the trend file, select Save as read-only in the middle of the window.
- 3. Click (Save).

#### **NOTE**

Size trend files are identified by the extension .#tr.

### **Opening a Size Trend**

To open a size trend file:


- 1. Select File > Open on the Main Menu bar, or click (Open) in the Main Menu Toolbar.
- 2. In the Open window, navigate to the appropriate folder and select the file name.
- 3. Click (Open).

### **Merging Runs**

Merging runs allows you to view combined pulse data and size distributions for multiple runs.

#### To merge two or more analysis files:

1. Select File > File Tools > Merge Runs on the Main Menu bar. The Merge Runs window opens.



7-24 PN A51387AB

- 2. In the Merge Runs window:
  - **a.** In the Folders box, double click the appropriate folder name. The folder contents appear in the Files box.
  - b. In the Files box, click to highlight the file(s) you want to merge. To highlight multiple analysis files, hold the Ctrl key down while clicking each file name, or click one file and drag over the files to be included.
  - c. Click (Add). The files appear in the Selected Files box.
  - d. Click (OK).

### Saving a Merged Run

To save a merged run:

- 1. Select RunFile > Save or RunFile > Save As on the Run Menu bar.
- 2. In the Save As window, navigate to the appropriate folder and enter a file name in the File Name field. If you want to write protect the trend file, select Save as read-only in the middle of the window.
- 3. Click (Save).


#### NOTE

Merged files are saved as analysis files and are identified by the extension .#m3 or .#m4.

# **Moving Between Multiple Files (Cursor Menu and Shortcut)**

There are two ways to move between overlay files (page 7-19) when a graph of the overlay is open in the Viewing Area.

• In the Main Toolbar, click (Cursor). In the legend, the selected file (or cursor run) is underlined. As you click (Cursor), the software underlines each run in sequence.



• Select **Cursor** on the Run Menu bar. The drop-down menu displays all analysis files in the overlay. Select a file name to display the cursors and statistics for the run.

To see statistics associated with the selected file (cursor run), select **RunFile > Get Info** on the Run Menu bar.

# **Filtration Efficiency**

The Multisizer 4 allows you to measure filtration efficiency by comparing particle number and/or sizes in two runs, one before and one after filtering the sample.

For example, you can measure overall filtration efficiency. If the Analyzer counts 1000 particles in the first run, and, after applying the filter, counts 100 particles, then filtration efficiency is 90%.

For information on including filtration efficiency in printed reports, see *Preferences: Printed Report*, page 5-2.

#### To view filtration efficiency:

- 1. Select File > File Tools > Filtration Efficiency on the Main Menu bar. The Select Filtered and Unfiltered Runs window opens.
- 2. In the Select Filtered and Unfiltered Runs window:
  - **a.** In the Folders box, double click the appropriate folder name. The folder contents appear in the Files box.
  - **b.** In the Files box, click to highlight the two files you want to compare. To highlight both analysis files, hold the Ctrl key down while clicking each file name. Include the analyses in the order in which they were run (pre-filtration and post-filtration).
  - c. Click (Add). The files appear in the Selected Files box.
  - d. Click (OK).

# **Saving a Filtration Efficiency Analysis**

To save a filtration efficiency analysis:

- 1. Select RunFile > Save or RunFile > Save As on the Run Menu bar.
- 2. In the Save As window, navigate to the appropriate folder and enter a file name in the File Name field. If you want to write protect the file, select Save as read-only in the middle of the window.
- 3. Click (Save).

#### NOTE

Filtration efficiency files are saved as analysis files and are identified by the extensions .#m3 or .#m4.

# **Including Filtration Efficiency in a Printed Report**

To include filtration efficiency in a printed report:

- 1. Select **SOP** > **Edit Preferences** on the Main Menu bar.
- 2. In the Edit Preferences / Printed Report window, select Filtration Efficiency. For more information on selecting filtration efficiency sizes, see *Preferences: Printed Report*, page 5-2.
- 3. Click (OK).

7-26 PN A51387AB

# Configuring Software and Security

# **Configuration Overview**

The Configuration drop-down menu and certain configuration items in the Windows drop-down menu appear in the Multisizer 4 Main Menu bar only when you are running the software in No security mode. When running the software in a security mode, configuration menu items are available to Administrator and Supervisor accounts only. For information on Main Menu behavior in different security configurations, see *Security Modes and Configuration*, page 8-1.

### **Configuration Options**

Depending on your security settings, configuration options will appear in the Main Menu in the Configuration, Supervisor, or Administrator drop-down menu. Multisizer 4 configuration options allow you to remove drop-down menu items from the Main Menu and Run Menu, change default file locations, and set the security level on menu items.

On the Windows drop-down menu, you can use the Status Panel Settings or Toolbars items to customize the Status Panel, the Main Toolbar, and the Instrument Toolbar (see *Customizing the Status Panel*, page 8-8 and *Customizing Toolbars*, page 8-7).

# **Security Modes and Configuration**


If you are running one of four security modes (page 8-16), configuration options are available only if the user logs in as an Administrator or Supervisor. Menu items that appear in the Configuration drop-down menu when running the software with no security appear in the Administrator or Supervisor drop-down menu.

When a Reviewer, Operator, or Operator using advanced features opens the software and logs in (if necessary), no configuration options are available. The software displays a Security menu in the Main Menu bar.


Administrators can configure the security level to require different user types to log in with a username, username and password, or not at all. Depending on the security configuration the Administrator selects, items in the Security drop-down menu will change.

Possible Main Menu configurations for different user types and security levels are shown below.

**Main Menu: No security.** Not connected to the Analyzer. Configuration options are available to all users.



**Main Menu: Medium security, Operator Mode.** Username and password required. Configuration options are available to Administrator and Supervisor accounts only.




**Main Menu: Low security, Operator Mode.** Login required for Administrator and Supervisor accounts only. Configuration options are available to Administrator and Supervisor accounts only.



8-2 PN A51387AB

**Main Menu: Medium security, Supervisor Mode.** Login with username and password required. Configuration options are available in the Supervisor drop-down menu.




# **Customizing Main Menus**

The Multisizer 4 software allows users with sufficient privileges (and all users when running no security mode) to hide menu items in the File, Calibration, Sample, SOP, Run, and Configuration drop-down menus on the Main Menu bar.

When you remove a menu item, the corresponding shortcut button, if one exists, remains on the Main Toolbar. For information on removing Main Toolbar buttons, see *Customizing Toolbars*, page 8-7.

#### NOTE

When you hide a menu item, the Multisizer 4 software removes the item until you reinstate it using the Customize Main Menus window. Unlike menu items that are hidden, items that are temporarily unavailable during normal software function appear greyed out (for example, **Run > Last Run** is greyed out until you complete a first run).



#### To customize Main menus:

- 1. Select Configuration > Customize Main Menus on the Main Menu bar.
- 2. In the File pane, select the menu items you want to hide.

#### **NOTE**

Some items in the File pane are located in **File > File Tools**. These items are Average, Average from a List, Create Size Trend, Merge Runs, Multi-tube Overlap, Import Size Data, and Filtration Efficiency.

- 3. In the center pane, select the menu items you want to remove from the Calibration, Sample, SOP, and Run drop-down menus.
  - The following items in the center pane are located on the Calibration drop-down menu: Calibrate Aperture, Verify Aperture Calibration, Run Concentration Control, Aperture Calibration Options, and Control Sample Options.
  - Create Sample Specifications is located on the Sample drop-down menu.
  - Change Aperture Tube is located on the Run drop-down menu.
  - Create Preferences is located on the SOP drop-down menu.
  - Toolbars is located on the Windows drop-down menu. The Toolbars window allows you to customize button images and remove buttons on the Main Toolbar, remove the Main Toolbar, or remove the Instrument Toolbar.
  - Status Panel Settings is located on the Windows drop-down menu. The Status Panel
     Settings window allows you to change the appearance and/or location of the Status Panel.

8-4 PN A51387AB

- 4. In the center pane, select Status Bar to remove the status text that appears in the lower left corner of the Multisizer 4 window. The Status Bar describes selected menu items or displays the default folder.
- 5. In the Configuration pane, select the menu items you want to remove from the Configuration menu
- 6. In the Windows pane, select Show Windows on Submenu if you want to display the names of open analysis files in a submenu of the Windows drop-down menu. If this is not selected, open analysis files appear as items on the Windows drop-down menu.

# **Customizing Run Menus**

You can hide items in the RunFile, Edit, View, and Calculate drop-down menus on the Run Menu bar.


When you remove a drop-down menu item, the corresponding shortcut button, if one exists, remains on the Main Toolbar. For information on removing Main Toolbar buttons, see *Customizing Toolbars*, page 8-7.

#### To hide drop-down menu items:

- Select Configuration > Customize Run Menus on the Main Menu bar.
   If you are running security mode, select Customize Run Menus in the Administrator or Supervisor drop-down menu.
- 2. In the Customize Run Menus window, select the menu items you want to hide and click OK. For more information on items listed in the Customize Run Menus window, see the table below. Changes take effect immediately. You do not need to restart the Multisizer 4 software.

#### **NOTE**

When you hide a menu item, the Multisizer 4 software removes the item until you reinstate it using the Customize Main Menus window. Unlike hidden menu items, items that are temporarily unavailable during the normal functioning of the software appear greyed out (for example, Run > Repeat Last Run is greyed out until you complete a first run).



#### To customize Run menus:

- 1. In the RunFile pane, select menu items in the RunFile drop-down menu that you want to hide.
- 2. In the Edit pane, select menu items in the Edit menu that you want to hide.
- 3. In the View pane, select menu items in the View menu that you want to hide.
- In the Calculate pane, select menu items in the Calculate menu that you want to hide.
- 5. Select Graph/Listing/Interp. Menu to hide the drop-down menus that appear on the Run menu bar when you select Graph, Listing, or Interpolation in the View menu. These dynamically generated menus allow you to change view options for each type of analysis display. For more information on these menus, see *Viewing Analysis Files*, page 7-2.
- **6.** Select Display Menu to hide the Display drop-down menu that appears when you select Graph in the View menu. This dynamically generated menu appears only when you are viewing an analysis as a graph. For more information on the Display menu, see *Viewing Analysis Files*, page 7-2.
- 7. Select Show Close on Submenu to change the RunFile drop-down menu. If you are viewing multiple analysis files or overlay files (page 7-19), menu items appear at the bottom of the RunFile menu that allow you to close each of the open files. To move the Close items to a submenu, select Show Close on Submenu.


8-6 PN A51387AB

# **Customizing Toolbars**

You can remove the Main Toolbar and/or the Instrument Toolbar. On the Main Toolbar, you can customize button images, add and remove buttons, and change button order. When you remove a button from the Main Toolbar, the corresponding drop-down menu item remains on the Main Menu or Run Menu. For information on removing Main Menu items, see *Customizing Main Menus*, page 8-3. For information on removing Run Menu items, see *Customizing Run Menus*, page 8-5.


#### *To customize the toolbars:*

1. Select **Windows > Toolbars** on the Main Menu bar. The Toolbars window opens.



#### 2. In the Toolbars window:

- To remove the Main Toolbar, clear the Show Main Toolbar checkbox.
- To display the buttons without three-dimensional edges, select Flat Buttons.
- To display buttons with text below the button image, select Buttons with Text. To display buttons with images only, clear this checkbox.
- To remove the Instrument Toolbar, clear the Show Instrument Toolbar checkbox.
- To return to the default Multisizer 4 software button configuration, click (Default Buttons).
- To add or remove a Main Toolbar button, or to change the button order, click (Customize) The Customize Toolbar window opens.




- 3. In the Customize Toolbar window:
  - To add a button to the toolbar, select a button in the Available Toolbar Buttons box and click (Add).
  - To remove a button from the toolbar, select a button in the Current Toolbar Buttons box and click (Remove).
  - To reposition the button on the toolbar, select a button in the Current Toolbar Buttons box and click (Move Up) or (Move Down).
  - Click Close) to save your settings and return to the Toolbars window.
- **4.** In the Toolbars window, click **OK** when you are finished. Changes take effect immediately. You do not need to restart the Multisizer 4 software.

# **Customizing the Status Panel**

You can customize the colors that appear on the Status Panel, adjust warning levels, set the speed and volume of audible clicks, and change the location of the Status Panel.

#### To customize the Status Panel:

1. Select **Windows** > **Status Panel Settings** on the Main Menu bar. The Status Panel Settings window opens.



8-8 PN A51387AB

#### **NOTE**

**Windows > Status Panel Settings** is available only when the software is connected to the Analyzer.

#### 2. In the Concentration Bar pane:

- **a.** Select Concentration or Coincidence. If you select Concentration, the particle concentration will appear on the Status Bar. If you select Coincidence, the coincidence correction will appear on the Status Bar.
  - Coincidence correction adjusts for incidences of two particles passing through the aperture at the same time. Based on the size distribution, the Multisizer 4 adjusts the count by replacing large pulses with smaller pulses at a statistically correct size.
- b. In the Warning Level field, enter the concentration or coincidence correction percentage that will trigger a warning (that is, change the scale color to red or the warning color you select). The default maximum concentration is 10%. For more information on suggested concentration levels, see *Preparing the Analyzer for Calibration*, page 3-12.
- c. In the Full Scale field, enter the total concentration percentage that the scale will display. Beckman Coulter recommends that you enter a value that is twice the Warning Level percentage. The default Full Scale percentage is 20%.
- **d.** Click (Color) to change the scale color used to indicate that the concentration or coincidence correction level is within the acceptable range.

#### 3. In the Jar and Tank Bars pane:

- a. In the Warning Level box, enter the percent full that will trigger a warning (that is, change the Jar or Waste Tank display to red or the warning color you select). The default warning level is 80%.
- **b.** Click (Color) to change the color used to display Jar and Waste Tank fluid that is below the warning level.
- **4.** In the Warning Color, Distribution Graph, Progress Bar, Status Text Colors, and Blockage Monitor panes, select the desired Status Bar display options such as lines and colors.
- 5. In the Click pane:
  - **a.** In the Every [X] pulses field, enter the number of electrical pulses that will occur between audible clicks on your computer.
  - b. In the Level field, enter a value between 0 and 5 to set the desired volume of the clicks.
  - c. Click (Test) to test the volume level.
- **6.** In the Status Panel Location pane, select Left or Right to display the Status Panel on the left or right side of the Multisizer 4 software window.
- 7. Click (OK) when you are finished. Changes take effect immediately. You do not need to restart the Multisizer 4 software.

# **Customizing Sample Info Names**


You can change the default terms used for field names such as File ID, Operator, and Variable 1. For example, you can change Operator to Technician, or specify a variable you will use in sample runs by changing Variable 1 to pH.

The new terms you configure in the Multisizer 4 software will appear in the Enter Sample Info window, the Edit the SOM (Standard Operating Method) window, throughout the software, and in printed reports.

#### To customize software field names:

1. In the Main Menu bar, select **Configuration > Customize Sample Info Names**. The Customize Sample Info Names window opens.

If you are running security mode, select **Customize Sample Info Names** in the Administrator or Supervisor drop-down menu.



- 2. In the Customize Sample Info Names window:
  - **a.** For each field name you want to change, select it and enter a new name in the corresponding text field.
  - **b.** Click OK . Changes take effect immediately. You do not need to restart the Multisizer 4 software.

#### **NOTE**

If a Standard Operating Procedure (page 4-1) is currently loaded, the Multisizer 4 software will not allow you to change field names. If you have loaded an SOP, exit the Customize Sample Info Names window, click (Remove SOP) in the Status Panel, and return to the Configuration menu.

8-10 PN A51387AB

# **Customizing Recent File and Folder Lists**


You can select how many recently used files and folders will appear in the File drop-down menu or in File submenus (Recent Folders and Recent Files).

You can configure the Multisizer 4 software to include a file or folder in the Recent Folders or Recent Files list when the file or folder is opened, used in an overlay (page 7-19), and/or saved.

#### To configure Recent Files and Recent Folders lists:

1. Select **Configuration > Recent Files and Folders** on the Main Menu bar. The Recent Files and Folders window opens.

If you are running security mode, select **Recent Files and Folders** in the Administrator or Supervisor drop-down menu.



#### 2. Folder List pane options:

- In the on main menu field, enter the number of recently used folders you want to make available from the File drop-down menu. If you enter 0, no recently used folders will appear on the menu.
- In the on sub-menu field, enter the number of recently used folders you want to appear when the operator selects **File > Recent Folders**. If you enter 0, no submenu will appear.
- 3. File List pane options:
  - In the on main menu field, enter the number of recently used files you want to make available from the File drop-down menu. If you enter 0, no recently used files will appear on the menu.
  - In the on sub-menu field, enter the number of recently used files you want to appear when the operator selects **File > Recent Files**. If you enter 0, no submenu will appear.

### **4.** Run List pane options:

- In the on main menu field, enter the number of recent runs you want to access from the File drop-down menu in the Main Menu bar. Recent runs will appear only if you select the option to automatically save the run in the **Edit the SOM > Run Settings** tab (page 4-2).
- In the on sub-menu field, enter the number of recent runs you want to appear when the operator opens **File > Recent Runs**. If you enter 0, no submenu will appear. Including recent runs in the File submenu can help operators locate analysis files saved automatically (page 4-2). If you enter 0, no recent runs will appear.
- 5. In the Update Lists When pane, select options to define when the Multisizer 4 software will add a file or folder to the recently used list. By selecting a combination of checkboxes, you can choose to add a file to the list only when the file is saved, any time a file is opened, and/or when the operator adds a file to an overlay (page 7-19).
- **6.** In the Maximum name size field, enter the maximum number of characters that will display in the File drop-down list or the File submenus.


#### **NOTE**

The number of characters you select for display in the Maximum name size field will not affect the maximum file name length you selected in the Standard Operating Method (page 4-2).

### Selecting a New Folder from the Recent Folder List

Configuring the Multisizer 4 to display a list of recently used folders in the File drop-down menu or the Recent Folders submenu allows the operator to switch quickly between different folders.

The name of the folder that will open when you select **File > Open** or click **Open** in the Main Toolbar is displayed in the Status Bar. The Status Bar is located in the bottom left corner of the Multisizer 4 software window.



# Adding a Folder to the Recent Folders List

You can populate the list of folders that will appear in the File menu or the File > Recent Folders submenu.

#### To populate the recent folders list:

- 1. Select File > Change Folder on the Main Menu bar.
- 2. In the Change Folder window, select a folder and click (Add to List).
- 3. Click (OK).

8-12 PN A51387AB

# **Customizing the Save Preferences Default Setting**

You can determine whether the Multisizer 4 software will automatically save changes to default Preferences settings the operator makes during an analysis run session.

To automatically save new Preferences settings after each run session:

1. Select **Configuration > Configure Preferences** on the Main Menu bar. The Preferences window opens.

If you are running security mode, select **Configure Preferences** in the Administrator or Supervisor drop-down menu.

If you	Changes made by the operator
Select Automatically save preferences	Will be saved to the default preferences file when the operator exits the Multisizer 4 software, overwriting previous settings.
Clear Automatically save preferences	Will not be saved when the operator exits the Multisizer 4 software.
	To save changes to preferences settings, the operator will need to save the settings to an alternate preferences file.

2. After you made your selection, click (OK).

# **Choosing a Language**

You can choose the language that will appear in menus, windows, and printed reports.

#### To choose a language:

Select Configuration > Language on the Main Menu bar. The Language window opens.
 If you are running security mode, select Language in the Administrator or Supervisor drop-down menu.

#### NOTE

Select the Kanji Character Set if your system cannot display special characters such as the Greek mu  $(\mu)$  correctly.



2. Select a language listed in Choose your language and click (OK).

# **Multisizer 4 Configuration Options**


The Multisizer 4 Configuration window allows you to set default folder locations for SOM, SOP, and Preferences files. You can also use this window to select new Help files (User Manual, Appendix, and Bibliography) as updates become available. If the Multisizer 4 software cannot find Preferences, Standard Operating Method, and other settings files on startup, one or more error messages will appear. If one of these error messages appears, use the Multisizer 4 Configuration window to reset default folder(s) for settings, preferences, and run files.

### *To change default file locations:*

1. Select Configuration > Multisizer 4 Configuration on the Main Menu bar. The Multisizer 4 Configuration window opens.

8-14 PN A51387AB

If you are running security mode, select **Multisizer 4 Configuration** in the Administrator or Supervisor drop-down menu.



- 2. In the Folders pane, click (Browse) next to the Setup folder; SOP, SOM, Preferences; or Language DLL's. The Browse for Folder window opens.
- 3. Navigate to and select the appropriate folder, and click (OK) to close the Browse window.
- 4. Click (Select) next to User's Manual to select the location of the Multisizer 4 User Manual.
- 5. Select Enable Dialog Help to display a shortcut to context-sensitive online Help topics in Multisizer 4 software windows. Help topics are not available from all windows.
- **6.** Click **(OK)** to save your settings.

# **Bar Code Reader Configuration Options**

You can use the Bar Code Reader on the Analyzer Control Panel to scan:

- Beckman Coulter ISOTON® II
- Beckman Coulter Multisizer 4 Smart Technology Beakers
- Beckman Coulter Smart Technology Aperture Tubes
- Sample packets

The Bar Code Reader (page 1-7) allows the operator to:


• Identify expired Beckman Coulter ISOTON® II by verifying lot number and expiration date.

- Enter the Beckman Coulter Multisizer 4 Smart Technology Beaker size, which prompts the Analyzer to move the stirrer into the ideal position for uniform particle distribution.
- Prompt the software to load the Beckman Coulter ST Aperture Tube size, serial number, and Kd value after the tube has been calibrated.
- Enter sample information automatically.

#### To configure the Bar Code Reader:

1. Select Configuration > Bar Code Reader Configuration on the Main Menu bar. The Bar Code Reader Configuration window opens.

If you are running security mode, select **Bar Code Reader Configuration** in the Administrator or Supervisor drop-down menu.



- 2. In the Bar Code Reader Configuration window, select Use the Bar Code Reader.
- 3. Select a port from the Port drop-down list. Because the software maps USB to COM ports, the correct port may be difficult to determine. If necessary, select COM ports sequentially until you locate the correct port.
- **4.** In the Symbologies pane, select Aztec and Data Matrix. Select additional UPC symbologies only if you will be using the Bar Code Reader to scan sample packets that you know use the specific UPC symbologies. Click (OK).

# **Customizing Security Settings**

You can run the Multisizer 4 with no security or one of four levels of password-protected security. With the exception of 21 CFR Part 11 security, the administrator determines the user privileges that will be associated with each security level (Low, Medium, or High).

When selected, 21 CFR Part 11 security ensures that all settings meet the requirements of the Electronic Records and Electronic Signatures Rule (21 CFR Part 11). The FDA established the Rule to

8-16 PN A51387AB


define requirements for submitting documentation in electronic form and the criteria for approved electronic signatures. For more information, see *Regulatory Compliance*, page 10-1.

#### To create an Administrator account:

1. In the Main Menu bar, select **Configuration > Security Set-up**. The Security Set-up window opens.



- 2. In the Security Set-up window, select a security level.
- 3. If you selected Low, Medium, High, or 21 CFR Part 11 security, click (Add a User Account window opens.



- **4.** In the Add a User Account window, in the Full Name, Log-in Name, and ID fields, enter user information.
- 5. In the Password field, enter a password between 4 and 16 characters in length.
- **6.** Select Administrator from the Type drop-down list. The Administrator assigns privileges to each user type (Reviewer, Operator, Operator using advanced features, and Supervisor).
- 7. Click (OK). A dialog box reminds you to record the Administrator's log-in name and password.
- 8. Click OK to close the dialog box. A dialog box asks if you want to add a user account. Click OK to open the Add a User Account window or Cancel to close the window.

### **Logging In**

Some security settings require all operators to log in with a username or a username and password. When log-in is required, the Log In window will appear when a user opens the software. If the user does not have log-in privileges, the software is locked. He or she must click (Exit) to close the software.



- 1. In the Log In window, enter your Log-in Name and Password, if required.
- 2. In the Log-in Mode pane, select a user account type. You can select the user type the Administrator assigned to you (for example, Operator using advanced features) or any user type with lesser privileges.
- 3. Click (OK).

# **Logging Out**

- If you are logged in as a Reviewer, Operator, or Operator using advanced features, select **Security > Log Out** from the Main Menu.
- If you are logged in as a Supervisor, select **Supervisor > Log Out** on the Main Menu bar.
- If you are logged in as an Administrator, select **Administrator > Log Out** on the Main Menu bar.

# **Changing Your Password**


If you are logged in as a Reviewer, Operator, or Operator using advanced features, select **Security > Change Password** on the Main Menu bar.

8-18 PN A51387AB

# **Administrator Menu Options**

When a user with Administrator privileges logs in to the Multisizer 4 software, the Main Menu bar displays the Administrator drop-down menu. The Administrator drop-down menu allows you to:


- Configure security requirements and privileges for each user type (page 8-20)
- Add user accounts (page 8-16)
- Create electronic signature requirements (page 10-5)
- View audit trails and error logs (page 10-3)
- Configure the software interface (page 8-1)
- Change your password and log out.



### **Customizing User Privileges**

To set security level and customize user privileges:

- 1. Log in as Administrator.
- 2. Select Administrator > User Privileges on the Main Menu bar. The User Privileges window opens.



- 3. In the Set default user privileges pane, select a security level and click (Set). The software returns the security requirement and privileges to the default configuration for the security level you select.
- **4.** Select the security requirements and privileges for Reviewer, Operator, Operator using advanced features, Supervisor, and Administrator.
- 5. Click (OK).

8-20 PN A51387AB

# Troubleshooting

# **Resolving Common Problems**

### **Reducing Noise**

Noise often appears as an increased small particle count or varying particle counts that do not follow an expected size distribution.

Increasing or varying noise levels can be caused by:

- **Electrolyte solution.** If you are using a small aperture tube, increasing electrolyte salt concentration will increase the signal to noise ratio for particle sizes below 1 µm.
- Low aperture current. If you are using a small aperture tube or a concentrated electrolyte solution, the Multisizer 4 software will automatically select a low current/high gain setting.
- **High aperture current**. If the aperture current is set too high, the electrolyte solution in the aperture can heat or boil, causing noise. Reduce the current or increase the conductivity of the electrolyte solution.

# **CAUTION**

Current set too high can saturate the amplifier, damage the aperture orifice, distort your results, or damage cells.

- **Atmospheric interference**. A dust-laden environment, platform vibration, or a loud environment can increase noise levels.
- **Electrical interference.** Any form of electrical interference can cause random noise patterns and pulses. Move the Analyzer to a different power source or a different location.
- A damaged aperture. If noise levels are increasing or varying (particularly on blank runs), the aperture may be damaged. Install a new aperture tube (page 3-2).

Reducing the noise level is particularly important if you are using an aperture tube smaller than  $100 \mu m$ , or if you are measuring particles near the minimum threshold (2% or 10% of aperture diameter).


For instructions specific to 20  $\mu$ m and 30  $\mu$ m apertures, see *Using Small Aperture Tubes* (20  $\mu$ m and 30  $\mu$ m), page 3-4.

### Measuring the Noise Level

When you install a new aperture tube using the Change Aperture Tube Wizard (page 3-21), the Wizard prompts you to measure the noise level. After installing an aperture tube, you can measure the noise level at any time using the Troubleshooting menu.

#### To measure the noise level:

- 1. Place a beaker of clean electrolyte on the Analyzer platform.
- 2. Select Run > Troubleshooting > Check the Noise Level on the Main Menu bar. The Check Noise Level window opens.



- 3. In the Check Noise Level window, click (Measure Noise Level).
- **4.** When measurement is complete, the Check Noise Level window displays the noise level and threshold information (either Threshold is too low or Threshold is OK).

If the threshold is set too low, increase the threshold in the Create SOM Wizard (page 4-2) or the Edit the SOM window (page 4-23).

If noise levels remain high or variable after troubleshooting, contact Beckman Coulter Field Service (page 9-15).

# **Purging the Metering Pump**

Purging the metering pump removes air from a small chamber in the pump. Air can enter this chamber when the Analyzer is moved or shipped. When there is air in the metering pump, the Multisizer 4 software may display the following error message:

Flow Rate is too high, there may be air in the system. Try Flush Aperture Tube and Purge Metering Pump.

If this error message appears, select Run > Troubleshooting > Purge Metering Pump.

The Status Panel displays progress.

If troubleshooting does not resolve the problem, contact Beckman Coulter Field Service (page 9-15).

9-2 PN A51387AB

### **Adjusting the Metering Pump**

When you change the aperture size or adjust electrolyte viscosity, it is necessary to calibrate the metering pump for the new tube or fluid. If you use the Change Aperture Tube Wizard (page 3-21), this process occurs automatically when you click the Metering Pump button. When the metering pump requires calibration, the Multisizer 4 software may display the following error message:

Adjust the Metering Pump

If this error message appears, select Run > Troubleshooting > Adjust Metering Pump.

The Status Panel displays progress.

If adjusting the metering pump does not resolve the problem, contact Beckman Coulter Field Service (page 9-15).

### **Setting the Vacuum Regulator**

The Multisizer 4 software resets the Waste Tank vacuum on start-up and at regular intervals. A Waste Tank vacuum malfunction can result from a mechanical flaw in the Analyzer. When the Waste Tank vacuum is malfunctioning, the Multisizer 4 software may display the following error message:

Check the Vacuum Regulator

If this error message appears, select Run > Troubleshooting > Check Vacuum Regulator.

The Status Panel displays progress.

If resetting the vacuum regulator does not resolve the problem, contact Beckman Coulter Field Service (page 9-15).

# **Measuring Gain Stage Offsets**

The Analyzer circuits that measure pulse height contain eight gain stages calibrated relative to each other. By default, calibration of these gain stages occurs automatically:

- At start-up and/or when a temperature change of 3 degrees C is measured in the Analyzer.
- Every 60 minutes after start-up or a after change in temperature of 3 degrees C.
- Every 500 minutes.

To ensure the precision of current and gain, it is possible to manually calibrate gain stage offsets at any time.

If gain stage offsets do not calibrate automatically and require re-calibration, select **Run > Troubleshooting > Measure Gain Stage Offsets**.

If calibrating gain stage offsets does not resolve the problem, contact Beckman Coulter Field Service (page 9-15).

### **Setting Custom Measurement Intervals**

If you want to measure gain stage offsets more frequently, you can set custom intervals.


#### To reset the default measurement intervals:

1. Select Run > Troubleshooting > Enter Service Mode on the Main Menu bar.

#### **NOTE**

Entering Service Mode will allow you to change default settings in the Troubleshooting menu. If you do not enter Service Mode, the Gain Stage Offsets settings will appear as read-only values.

2. Select Run > Troubleshooting > Aperture Resistance Settings on the Main Menu bar. The Aperture Resistance Settings window opens.



- 3. In the Gain Stage Offsets pane, enter new values in the fields provided.
- **4.** If you are not running Service Mode, a (Read-only) button appears. If you are running Service Mode, click (OK) to save your settings.

### **System Error: Unable to Measure Gain Stage Offsets**

If the Analyzer is unable to measure gain stage offsets automatically, the Multisizer 4 software will display the following error message:

Unable to measure gain stage offsets

If this error message appears, power off the Analyzer, close the Multisizer 4 software, and restart the system. If restarting the system does not resolve the problem, contact Beckman Coulter Field Service.

9-4 PN A51387AB


### **Resolving Error Messages on Software Startup**

If the Multisizer 4 software cannot find Preferences, Standard Operating Method, and other files on startup, one or more error messages will appear. If one or more error messages appear on startup, use the Multisizer 4 Configuration window to reset default folder(s) for settings, preferences, and run files.

### *To change default file locations:*

Select **Configuration > Multisizer 4 Configuration** on the Main Menu bar. The Multisizer 4 Configuration window opens.

If you are running security mode, select **Multisizer 4 Configuration** in the Administrator or Supervisor drop-down menu.



For more information on using the Multisizer 4 Configuration window, see *Multisizer 4 Configuration Options*, page 8-14.

# **Viewing Advanced Multisizer Settings**

### **Waste Tank Settings**

When the software is connected to the Analyzer, the Status Panel displays the Waste Tank fluid level. You can manually empty the Waste Tank into the Waste Jar at any time by clicking (Empty) in the Instrument Toolbar or selecting Run > Empty Waste Tank on the Main Menu bar.

You can select settings in the Troubleshooting menu that will automatically empty the Waste Tank based on fluid level or number of completed runs. If you do not change default Waste Tank settings, the Analyzer will empty the Waste Tank when the tank is 60% full.

#### **NOTE**

You can change Waste Tank settings when you create or edit a Standard Operating Method (SOM). For information on setting automatic intervals for emptying the Waste Tank in the SOM, see *Standard Operating Method: Control Mode*, page 4-6.

#### To change default Waste Tank settings:

1. Select Run > Troubleshooting > Waste Tank on the Main Menu bar. The Waste Tank window opens.



- 2. In the Waste Tank window:
  - To empty the Waste Tank after a specified number of completed runs, select every [X] runs and enter the number of analysis runs.
  - To empty the Waste Tank when the fluid reaches a specified level, select when [X] % full and enter a maximum fluid percentage.
  - To accept system defaults, click (Defaults).
- 3. Click (OK).

#### **Calibrating Waste Tank Sensors**

If it appears that the Waste Tank is emptying too frequently or is not emptying at the correct fluid level, you may need to calibrate the Waste Tank sensors. This option is available in the Service Mode menu.

1. Select Run > Troubleshooting > Enter Service Mode on the Main Menu bar. The Service drop-down menu appears in the Main Menu bar.

9-6 PN A51387AB

2. Select SERVICE > Calibrate Waste Tank. The Status Panel displays CALIBRATING WASTE TANK.



Beckman Coulter does not recommend that you use the options available in Service Mode without the assistance of a trained Service Representative. To contact a representative, see *Requesting Service and Technical Support*, on page 9-15.

### **Vacuum Settings**


The Waste Tank and Metering Pump use vacuums to move fluid through the system. In both cases, the default vacuum is set to six inches of mercury (6.00" Hg) for most aperture sizes. If you are using time or count control mode and an aperture tube larger than 560  $\mu$ m, you may need to change the Waste Tank vacuum setting.



It is not possible to change vacuum or Metering Pump flow settings unless you are running Service Mode. Beckman Coulter does not recommend that you use the options available in Service Mode without the assistance of a trained Service Representative. To contact a representative, see *Requesting Service and Technical Support*, on page 9-15.

#### To view vacuum settings:

1. Select Run > Troubleshooting > Sample Delivery Settings on the Main Menu bar. The Sample Delivery Settings window opens.



- 2. In the Waste Tank pane, the Set Vacuum to field displays the current Waste Tank vacuum setting. Set this value to 6.00" Hg unless you are using an aperture tube that is 560 µm or larger.
- 3. The Vacuum Tolerance: +/- field displays the vacuum deviation (in inches of mercury) that will trigger the error message Check the Vacuum Regulator.
- **4.** In the Metering Pump pane, the Set Vacuum to field displays the current Metering Pump vacuum setting. This value must remain at the default, 6.00" Hg.
- 5. The Minimum Flow and Maximum Flow fields display the flow rates in mL/sec that will trigger error messages. For more information, see *Flow Rate Error Messages*, page 9-8.
- **6.** The Pre-flow Stabilizing Time and Total Stabilizing Time fields display the time, in seconds, that the Analyzer will use for stabilization before beginning particle analysis.
- 7. The (Read-Only) button indicates that settings in this window are for viewing only. It is not possible to change vacuum and flow settings unless you are running Service Mode (page 9-15).
- 8. Clicking (Defaults) displays system default settings. Although you can view the defaults, it is not possible to apply new settings unless you are running Service Mode (page 9-15).

### Flow Rate Error Messages

The default flow settings adjust for aperture tube size and are appropriate for most analyses. Under certain conditions—if you are using an unusually viscous electrolyte solution, for example, or if you have increased the vacuum for a large aperture tube—it may be necessary to adjust the flow rate to avoid unnecessary error messages.

When the flow rate is too low, the Multisizer 4 software will display one of the following error messages:

```
Flow Rate is too low, the aperture may be blocked
Flow Rate is too low. Unblock the Aperture?
Flow Rate and Pressure are too low, try unblocking the Aperture
```

When the flow rate is too high, the Multisizer 4 software will display the following error message:

Flow Rate is too high, there may be air in the system. Try Flush Aperture Tube and Purge Metering Pump.

If one of these error messages appears and the system is functioning properly (the aperture tube is not blocked and there is no air in the system), adjust the volumetric flow settings in the Sample Delivery Settings window (see *Adjusting Volumetric Flow Settings*, page 9-8).

### **Adjusting Volumetric Flow Settings**

Adjust Metering Pump flow settings if the Multisizer 4 software displays the following error message while analyzing in volumetric mode:

Adjust the Metering Pump

9-8 PN A51387AB


#### To adjust flow settings:

1. Select Run > Troubleshooting > Enter Service Mode on the Main Menu bar.

#### **NOTE**

Entering Service Mode will allow you to change default settings in the Troubleshooting menu. If you do not enter Service Mode, settings in the Troubleshooting menu will appear as read-only values.

2. Select Run > Troubleshooting > Sample Delivery Settings on the Main Menu bar. The Sample Delivery Settings window opens.



3. In the Metering Pump pane, enter new values in the Minimum Flow and Maximum Flow fields, and click (OK).

The Minimum Flow and Maximum Flow fields display the flow rates in mL/second that will trigger error messages. The default flow settings adjust for aperture tube size and are appropriate for most analyses. Under certain conditions—if you are using an unusually viscous electrolyte solution, for example, or if you have increased the vacuum for a large aperture tube—it may be necessary to adjust the flow rate to avoid unnecessary error messages.

# Fill, Flush, and Drain Settings


#### **Viewing System Flush Time**

You can select settings to automatically flush the system before and/or after each analysis run when you create a Standard Operating Method (see *Standard Operating Method: Run Settings*, page 4-8). Flushing the system regularly is recommended in order to remove particles that settle at the bottom of the aperture tube.

Standard Operating Method settings do not allow you to adjust the length of time the system will use for a system flush. This option is available only in the Troubleshooting menu.

#### To view the current flush time setting:

Select **Run > Troubleshooting > Fill, Flush and Drain Settings** on the Main Menu bar. The Fill, Flush and Drain Settings window opens and displays system Fill Time, Flush Time, and Drain Time in seconds.





It is not possible to change the system flush time setting unless you are running Service Mode. Beckman Coulter does not recommend that you use the options available in Service Mode without the assistance of a trained Service Representative (see Requesting Service and Technical Support, page 9-15).

#### To adjust system flush time:

1. Select Run > Troubleshooting > Enter Service Mode on the Main Menu bar.

#### **NOTE**

Entering Service Mode will allow you to change default settings in the Troubleshooting menu. If you do not enter Service Mode, settings in the Troubleshooting menu will appear as read-only values.

- 2. Select Run > Troubleshooting > Fill, Flush and Drain Settings on the Main Menu bar.
- 3. In the Fill, Flush and Drain Settings window, enter the new system flush time in the Flush Time field and click (OK).

#### **NOTE**

A longer flush time removes more particles from the aperture tube, and can improve the accuracy of analysis results. On the other hand, increasing the flush time requires more electrolyte. You will need to fill the Electrolyte Jar more frequently.

9-10 PN A51387AB

#### **Draining the System**




Draining the system is recommended only when cleaning, shipping, or repackaging the Analyzer. As fluid evaporates within the system, remaining electrolyte deposits salt crystals that can obstruct fluid flow and reduce instrument performance.

### To drain the system:

- 1. Select Run > Drain System on the Main Menu bar. A Beckman Coulter pop-up window directs you to remove or empty the Electrolyte Jar.
- 2. Remove or empty the Electrolyte Jar, then click (OK) in the pop-up window. The system drains.

#### To view system drain time:

Select **Run > Troubleshooting > Fill, Flush and Drain Settings** on the Main Menu bar. The Fill, Flush and Drain Settings window opens and displays system Fill Time, Flush Time, and Drain Time in seconds.





It is not possible to change the system drain time setting unless you are running Service Mode. Beckman Coulter does not recommend that you use the options available in Service Mode without the assistance of a trained Service Representative (see *Requesting Service and Technical Support*, page 9-15).

#### To adjust system drain time:

1. Select Run > Troubleshooting > Enter Service Mode on the Main Menu bar.

### NOTE

Entering Service Mode will allow you to change default settings in the Troubleshooting menu. If you do not enter Service Mode, settings in the Troubleshooting menu will appear as read-only values.

2. Select Run > Troubleshooting > Fill, Flush and Drain Settings on the Main Menu bar.

3. In the Fill, Flush and Drain Settings window, enter the new system drain time in the Drain Time field and click (OK).

#### **Aperture Resistance Settings**


The Multisizer 4 software measures aperture resistance automatically at the start of each run. If resistance is too high, it is likely that air is being drawn through the aperture tube. The electrolyte level may be too low. Reset Multisizer 4 aperture resistance defaults only if you are using an electrolyte with unusually high current resistance.



It is not possible to change aperture resistance settings unless you are running Service Mode. Beckman Coulter does not recommend that you use the options available in Service Mode without the assistance of a trained Service Representative (see *Requesting Service and Technical Support*, page 9-15).

To view aperture resistance settings:

1. Select Run > Troubleshooting > Aperture Resistance Settings on the Main Menu bar. The Aperture Resistance Settings window opens.



- 2. If Enable Aperture Resistance Checking is selected, the Multisizer 4 will check aperture resistance before each run based on values entered in the Maximum Resistance and Measurement Current fields.
  - The Maximum Resistance field displays the electrical resistance that will trigger the following error message:
    - Aperture Resistance High, check the Sample Level
  - The Measurement Current field displays the fixed current that the system will use to measure resistance.

9-12 PN A51387AB

# **CAUTION**

Do not change the default Measurement Current setting. The measurement current is not the current setting that will be used during analysis runs.

- In the Auto-Set Current and Gain pane, the Initial Current field displays the initial current in µA.
- If Enable Aperture Current Checking is selected, the Multisizer 4 software verifies that the system can supply the voltages selected in the Measurement Current, Initial Current, and analysis current and gain fields. If the current exceeds the setting in the Maximum Voltage field, the following error message will display:
  - Reduce Aperture Current or Preamp Gain
- The Gain Stage Offsets pane displays gain stage measurements. For information on these settings, see *Measuring Gain Stage Offsets*, page 9-3.
- Click (Defaults) to display system default settings. Although you can view the defaults, it is not possible to apply the settings unless you are running Service Mode (page 9-18).
- The (Read-only) button indicates that settings in this window are for viewing only. It is not possible to change aperture resistance settings unless you are running Service Mode (page 9-18).


#### To change aperture resistance settings:

1. Select Run > Troubleshooting > Enter Service Mode on the Main Menu bar.

#### **NOTE**

Entering Service Mode will allow you to change default settings in the Troubleshooting menu. If you do not enter Service Mode, settings in the Troubleshooting menu will appear as read-only values.

- 2. Select Run > Troubleshooting > Aperture Resistance Settings on the Main Menu bar.
- 3. In the Aperture Resistance Settings window, modify the fields as necessary and click OK. For more information on fields and values in the Aperture Resistance Settings window, see *Aperture Resistance Settings*, page 9-12.



Beckman Coulter does not recommend that you change aperture resistance settings without the assistance of a trained Service Representative (see *Requesting Service and Technical Support*, page 9-15).

## Calibrating the Electrolyte and Waste Jars

The fluid levels in the Electrolyte and Waste Jars are calculated by weight. It is usually necessary to calibrate the weight sensors only once, when you set up the Analyzer. If you switch to an electrolyte with significantly greater density, it is possible that you will need to recalibrate the Electrolyte and Waste Jar sensors.

#### To calibrate the Electrolyte Jar:

1. Select Run > Troubleshooting > Calibrate Electrolyte and Waste Jars on the Main Menu bar. The Calibrate Electrolyte Jar and Waste Jar Level Sensors window opens.

#### NOTE

When calibrating Electrolyte and Waste Jars, Beckman Coulter recommends that you calibrate the Electrolyte Jar empty, then full, to leave the jar in the full state. When calibrating the Waste Jar, calibrate the jar full, then empty, to leave the jar in the empty state.



- **2.** Place the empty Electrolyte Jar in the Analyzer compartment (see *Installing and Removing the Electrolyte and Waste Jars*).
- 3. In the Calibrate Electrolyte Jar and Waste Jar window, select Electrolyte Jar is Empty.
- **4.** In the Electrolyte Jar pane, click (Calibrate). When calibration is complete, Calibrated appears on the Electrolyte Jar is Empty line.
- 5. Remove the Electrolyte Jar, fill the jar, and replace the jar in the Analyzer.
- 6. In the Calibrate Electrolyte Jar and Waste Jar window, select Electrolyte Jar is Full.
- 7. In the Electrolyte Jar pane, click (Calibrate). When calibration is complete, Calibrated appears on the Electrolyte Jar is Full line.
- 8. Follow Steps 2 7 above to calibrate the Waste Jar (reversing the empty and full states), or click (Close) if you are finished.

9-14 PN A51387AB

#### To calibrate the Waste Jar:

Follow the steps to calibrate the Electrolyte Jar, above, reversing the empty and full states. Beckman Coulter recommends that you first calibrate the full Waste Jar, then empty the jar, to leave the Waste Jar in the empty state.

#### NOTE

In the Calibrate Electrolyte Jar and Waste Jar window, Unknown is selected by default to prevent accidental calibration when the Electrolyte or Waste Jar is not in the intended state (empty or full).

# **Working with Field Service**

### **Requesting Service and Technical Support**

To contact a Service Representative:

- 1. Select **Help > Contact Beckman Coulter** on the Main Menu bar.
- 2. In the Contact Beckman Coulter window:
  - Click (Service Support) to request help with instrument-related problems.
  - Click (Applications Support) to request help with problems related to the Multisizer 4 software.
  - Click (General Support) for all other questions.

Each button opens your default email editor and includes the email address of a Field Service Representative in your area.


# Identifying the Instrument

When you contact Beckman Coulter Field Service, the Service Representative will require software and firmware information in order to help you resolve the problem.

To obtain information about the Analyzer:

1. Select Run > Troubleshooting > Instrument Identification on the Main Menu bar.

2. The Instrument Identification window opens.



- IP Address (Internet Protocol Address) is used to connect the Analyzer to the computer running the Multisizer 4 software. If your Analyzer is connected to a network, a Service Technician may have changed the IP address to identify the instrument on your network or intranet.
- Firmware Version is the version of the software running in the Analyzer.
- FPGA Revision is the version of the software controlling electronic circuits in the Analyzer.
- Serial Number uniquely identifies the instrument.

The Service Representative will also require information about the Multisizer 4 software version you are currently running.

#### To locate the current version number:

- 1. Select **Help > About** on the Main Menu bar.
- 2. In the Beckman Coulter Multisizer 4 window, locate and record the software version number at the top of the window, and click (OK).

# **Updating Firmware and FPGA Software**

While the Multisizer 4 software runs on a PC connected to the instrument, firmware is the programming and software that runs within the Analyzer. If your firmware or FPGA software is out of date, the Multisizer 4 software will display one of the following error messages:

Contact service for newer Multisizer 4 firmware. Instrument is version [X], should be at least version [X].

Contact service for newer Multisizer 4 FPGA version. FPGA is revision [X], should be at least revision [X].

If one of these error messages appears, contact Beckman Coulter Field Service (page 9-15). A Service Representative will help you download a new version of the firmware or FPGA software to the Analyzer.


9-16 PN A51387AB

### **Viewing the Instrument Schematic**

The Instrument Schematic Diagram allows you to view Analyzer processes as they occur (for example, Metering Pump actions, vacuum pressure, and valve function). When you call Beckman Coulter Field Service, a Service Representative will often ask you to open the Instrument Schematic to identify the source of the problem.

#### To view the instrument schematic diagram:

Select **Run > Troubleshooting > Instrument Schematic** on the Main Menu bar. The Instrument Schematic window opens.



In the Instrument Schematic window, you can:

- Select Pump to turn the vacuum pump on. If you clear this section, Vacuum Pump Off appears in the Status Bar.
- Select Stirrer to turn on the stirrer. You can also turn the stirrer off or on by selecting Run > Stirrer Off or Run > Stirrer On on the Main Menu bar.
- Select Lamp to turn on the lamp. You can also turn the lamp off or on by selecting **Run** > **Lamp (on/off)** on the Main Menu bar.
- Select Always on top to keep the Instrument Schematic window visible during an analysis run. You may need to restart the Multisizer 4 software for this setting to take effect.

### **Viewing the Error Log**

When you contact Beckman Coulter Field Service, the Service Representative may ask you to open the error log.

### To open the error log:

- 1. Select Run > Troubleshooting > View Error Log on the Main Menu bar. The MS4ERROR.LOG window opens.
- 2. In the Show messages from pane, select the time period. You can add an error message manually, print error messages, or copy messages to the clipboard.
- 3. When you are finished, click (Close).

### **Opening Service Mode**

When you select **Troubleshooting > Open Service Mode** on the Main Menu bar, a new Service menu appears in the Main Menu bar. The Service menu includes advanced options for configuring and troubleshooting the Multisizer 4 software and Analyzer.



Beckman Coulter does not recommend that you use the options available in Service Mode without the assistance of a trained Service Representative (see *Requesting Service and Technical Support*, page 9-15).

9-18 PN A51387AB

# Regulatory Compliance

## **Regulatory Compliance**

### **Electronic Signatures (21 CFR Part 11)**

The Electronic Records and Electronic Signatures Rule (21 CFR Part 11) was established by the FDA to define the requirements for submitting documentation in electronic form and the criteria for approved electronic signatures. Organizations that choose to use electronic records to meet record-keeping requirements must comply with 21 CFR Part 11, which is intended to improve an organization's quality control while preserving the FDA's charter to protect the public. Because analytical instrument systems such as the Multisizer™ 4 generate electronic records, these systems must comply with the Electronic Records Rule.

This section describes the relevant portions of the 21 CFR Part 11 regulations and their implementation using the Multisizer 4 control software. For more information, see *Maintaining Electronic Signatures*, page 10-5.

#### NOTE

It is important to realize that implementation and compliance of the rule remains the responsibility of the organization or entity creating and signing the electronic records in question. Proper procedures and practices, such as GLP and cGMP, are as much part of overall compliance with these regulations as are the features of the Multisizer 4 control software.

#### **Electronic Records**

*Electronic record* refers to any combination of text, graphics, data, audio, pictorial, or other information representation in digital form that is created, modified, maintained, archived, retrieved or distributed by a computer system. This definition applies to any digital computer file submitted to the agency, or any information not submitted but which is necessary to be maintained. Public docket No 92S-0251 of the Federal Register (Vol.62, No 54) identifies the types of documents acceptable for submission in electronic form and where such submissions may be made.

#### **FDA Requirements**

The Multisizer 4 control software has been designed to allow users to comply to the electronic records and signatures rule. Any organization deciding to employ electronic signatures must declare to the FDA their intention to do so.

The FDA ruling includes these guidelines:

- The agency emphasizes that these regulations do not require, but rather permit, the use of electronic records and signatures. (General comments section)
- The use of electronic records as well as their submissions to FDA is voluntary. (Introduction to final ruling)
- If electronic submissions are made:

Persons may use electronic records in lieu of paper records or electronic signatures in lieu of traditional signatures....provided that: (1) The requirements of this part are met; and (2) The document or parts of a document to be submitted have been identified in public docket No. 92S-0251. (Section 11.2 subpart A).

Section 11.3 Subpart A describes two classes of systems; closed and open.

- A *closed system* is one where *system access* is controlled by persons who are responsible for the content of electronic records. The people and organization responsible for creating and maintaining the information on the system are also responsible for operating and administering the system.
- An open system is one where system access is not controlled by persons who are responsible for the content of electronic records.

A typical Multisizer 4 system can be regarded as a closed system.

### **Security Controls**

A Multisizer 4 installation needs to have a procedure designed to ensure proper operation, maintenance and administration for system security and data integrity. Persons who interact with the system, from administrators to users, must abide by these procedures. Therefore, the ultimate responsibility is with the organization generating electronic records and signatures. The Multisizer 4 software is a component, albeit a vital one, of the overall process.

The controls to be applied to a closed system are specified in Subpart B, Section 11.10.

#### **Electronic Controls**

The chief purpose of electronic controls is to ensure the authenticity, integrity, and, when appropriate, the confidentiality of electronic records, and to ensure that the signer cannot readily repudiate the signed record as not genuine. Many of the controls described in Section 11.10 refer to written procedures (SOPs) required by the agency for the purpose of data storage and retrieval, access control, training, accountability, documentation, record keeping, and change control.

### **System Validation**

Other controls are addressed either by the Multisizer 4 software itself, or in combination with enduser procedures. Most important is the *validation of systems to ensure accuracy, reliability, consistent intended performance, and the ability to discern invalid or altered records* [Section 11.10 Paragraph (a)]. The complete and overall validation of the system, as developed by the organization, ensures the integrity of the system and its data. The features of the Multisizer 4 software are designed to comply with the specifications of these regulations.

10-2 PN A51387AB

The Multisizer 4 software employs a system of usernames and passwords, consistent with the specifications of Subpart C, Section 11.300, to ensure that only authorized individuals can use the system, electronically sign a record, access the operation or computer system input or output device, alter a record, or perform the operation at hand.

#### **Audit Trail**

The Multisizer 4 software performs data input and operational checks that *determine*, as appropriate, the validity of the source of data input or operational instruction, and enforce permitted sequencing of steps and events (Subpart B, Section 11.10). These two features ensure that, as much as possible, valid data are entered into the system, and all required steps have been completed to perform the task at hand.

The purpose of all such data checking and validation is to allow the system to generate accurate and complete copies of records in both human-readable and electronic form suitable for inspection, review, and copying by the agency [Section 11.10, Paragraph (b)]. The Multisizer 4 software system is able to enforce strict procedures to record all changes that are made to data generated using the software [Section 11.10, Paragraph (e)]. See File History and Audit Trail, page 10-3.

# **File History and Audit Trail**

*File History* or auditing can be enabled for any file created by the Multisizer 4 software. After auditing has been enabled for a file, it cannot be disabled, nor can it be bypassed. Under these conditions, all changes made to a file are automatically recorded. These changes consist of computer-generated, time-stamped audit trails to independently record the data and time of operator entries and actions that create, modify, or delete electronic records.

When a change to a file is detected, the Multisizer 4 software automatically records the identity of the user making the change, the date and timestamp of the change, the parameter that has changed, the old value and the new value. The user is also required to "re-sign" the record electronically and enter a reason for the change, from a pre-defined list or as free text.

The audit trail is stored as File History inside the file itself, so that record changes shall not obscure previously recorded information, and so the file is suitable for inspection, review, and copying by the agency. This ensures that a complete and continuous record of all changes to the file is maintained. The file protection and archiving capabilities of the Multisizer 4 software ensure compliance with the requirement that audit trail documentation shall be retained for a period at least as long as that required for the subject electronic records [Section 11.10, Paragraph (e)].

# Accessing File History

To access the File History:

- 1. Select **File > Open** on the Main Menu bar and navigate to the file you want to open.
- 2. Select RunFile > Get File History on the Run Menu bar. The File History window opens.

3. Click (Close) to exit the window.

### **Setting Audit Trail Options**

In addition to the auditing associated with the electronic file itself, the Multisizer 4 software offers two additional levels of auditing. First, a general system audits records and stores information at a system level (for example, who logged in when, or when users were added to the system). Second, the Multisizer 4 software generates an error log that stores and records errors associated with the system (for example, missing files and bad communications).

#### To select audit trail settings:

1. Select File > Open on the Main Menu bar. The Audit Trail Settings window opens.



- 2. In the Audit Trail Settings window, select Enable audit trail.
- 3. In the Select events to monitor pane, select the required options.
- **4.** Click (Browse) to select the location of audit trail records.
- 5. Click (OK).

#### **NOTE**

The dialog has a button marked 21 CFR 11. When activated, this ensures all options are set so that the settings meet with the rules that apply to 21 CFR part 11.

10-4 PN A51387AB

# **Maintaining Electronic Signatures**

An *electronic signature* is a computer data compilation of any symbol or series of symbols executed, adopted, or authorized by an individual to be the legally binding equivalent of the individual's handwritten signature (Subpart A, Section 11.3). Each electronic signature shall be unique to one individual and shall not be reused by, or reassigned to, anyone else [Subpart C, Section 11.100, paragraph (a)].

An electronic signature represents a user's computer identity, developed to ensure the distinct and unique identity of that user. Before any such electronic representation is applied, the organization must first verify the identity of that individual. The subsequent use of electronic signatures as the *legally binding equivalent of traditional handwritten signatures* must be certified to the agency in writing (Section 11.100).

Multisizer 4 software supports non-biometric signatures. *Non-biometric signatures* are computer generated and *employ* at least two distinct identification components such as an identification code and password (Section 11.200)

#### NOTE

Biometric signatures are a method of verifying an individual's identity based on measurement of the individual's physical feature(s) or repeatable action(s) where those features and/or actions are both unique to that individual and measurable (Subpart A, Section 11.3). These methods generally require fingerprints or retinal scans, and require special scanning devices to read and interpret them.

## **Generating Electronic Signatures**

The Multisizer 4 software employs User IDs and passwords to verify the identification of each user logging into the system. The regulation requires maintaining the uniqueness of each combined identification code and password, such that no two individuals have the same combination of identification code and password (Subpart C, Section 11.300). This section also requires that the identification code and password issuances are periodically checked, recalled, or revised.

The Multisizer 4 software supports both of these provisions.

#### To add a user account:

- 1. Open the Multisizer 4 software and log in using an Administrator account.
- 2. Select Administrator > Add a User Account on the Main Menu bar.
- 3. In the Add a User Account window, enter the user's Full Name, Log-in Name, ID, and Password. Select a user type from the Type drop-down list.
- 4. Click OK).


The "identification code" or username of each Multisizer 4 user must be unique. Users must also supply a password to access the Multisizer 4 software. Passwords can be controlled to prohibit the use of duplicates and to force the selection of new passwords after a prescribed period of time.

#### To authorize a user type to generate electronic signatures:

- 1. Open the Multisizer 4 software and log in using an Administrator account.
- 2. Select Administrator > User Privileges on the Main Menu bar.
- 3. In the User Privileges window, select Can add an Electronic Signature. The checkboxes are aligned in five columns corresponding to user types.
- 4. Click (OK).

### To generate an electronic signature:

- 1. Select File > Open on the Main Menu bar and navigate to the file you want to open.
- 2. Select **Edit > Add Electronic Signature** on the Run Menu bar. The Add Electronic Signature window opens.



- 3. In the Add Electronic Signature window, enter your password and select a meaning you previously recorded.
- 4. Click (OK).

## **Applying Electronic Signatures**

Subpart C, Section 11.200 stipulates several requirements for the control of electronic signatures. The regulations require that electronic signatures be used only by their genuine owners, and that signatures are administered and executed to ensure that attempted use of an individual's electronic signature by anyone other than the genuine owner *requires collaboration of two or more individuals*. Through the application of Multisizer 4 user and password configuration procedures, the system can be configured to ensure that use of these identifiers by someone other than the owner can be performed only with the owners permission.

Section 11.200 further specifies the use of electronic signature components during a period when an individual executes a series of signings during a single, continuous period of controlled system access, and when an individual executes one or more signings not performed during a single, continuous period of controlled system access. This section of the document represents the "heart" of electronic signature application. To comply with these provisions, the Multisizer 4 software uses the application of the username and password to authenticate the user making and saving the changes, in conjunction with file history and audit trails, to independently record the date and time of operator entries and actions that create, modify, or delete electronic records.

10-6 PN A51387AB

# **Additional Security Features**

The Multisizer 4 software offers two important additional levels of security not required by the regulations. These levels make it easier to define and implement system policies:

- **Data Mirroring.** This feature, which can be accessed only in administrator mode, allows the administrator to securely store files in a separate location and in addition to locations specified by a user.
- *File Attributes.* This feature allows administrators to protect files in varying degrees using the file attribute options.

### Starting the Multisizer 4 with Security Enabled

After the Administrator has configured security settings, the user is prompted to enter a user name and password every time he or she opens the Multisizer 4 software.

# **Regulatory Compliance** Additional Security Features

10-8 PN A51387AB

# Index

Α	preparing for sample runs, 1-18
Accessories	starting, 1-18
Accuvette STs, 1-13	start-up dialog, 1-18
aperture tubes, 1-14	version number, 9-16
Beakers	Analyzing and Attention lights, 1-6
calibrators, 1-13	Aperture
Accuvette STs	calibrating, 3-10, 3-13
cleaning, 1-15, 3-6	choosing calibrator size, 3-10
Administrator account	Aperture calibration. See Calibration
creating, 8-16	Aperture current, 4-14
Administrator Menu, 8-19	Aperture resistance settings
Analysis	changing, 9-13
comparing to standard run, 7-9	viewing, 9-12
running, 6-10	Aperture Tube list
running a multi-tube overlap, 6-12	editing, 3-25
Analysis data	Aperture tubes, 1-14
saving automatically, 7-16	adding, 3-24
saving manually, 7-17	cleaning, 1-15, 3-6
Analysis files	handling, 1-14
adding unique numbers, 4-6	installing, 3-2, 3-26
averaging, 7-20	installing new, 3-1
creating automatically, 4-4	removing, 3-26
creating using file name template codes, 4-5	selecting, 3-23
loading a blank run, 6-15	selecting size, 3-1
merging two or more, 7-24	Aperture tubes. See also Small Aperture tubes
opening, 7-17	Audit trail, 10-3
printing report, 7-14	setting options, 10-4
removing a blank run, 6-15	Automatic Blockage Detection, 1-2
saving, 7-16	Averaged files
viewing, 7-2	including data from another file, 7-21
working with multiple, 7-19	opening, 7-22
write-protecting, 4-6	saving, 7-21
Analyzer	Averaged statistics
cleaning, 1-16, 3-6	including in reports, 5-6
connecting software to on startup, 2-1	
connecting software to using Main Menu, 2-2	В
disconnecting from using the Main Menu, 2-2	Background analysis. See Blank run
identifying, 9-15	Bar Code Reader, 1-1, 1-7
nrenaring for calibration 3-12	Dai Code Reduci, 1 1, 1 /

configuring, 8-15	Context-senstive neip. See Help, 8-15
Beakers	Control Panel, 1-3, 1-5
cleaning, 1-15, 3-6	buttons, 1-5
guides, 1-1	Control sample. See Concentration control sample
placing on platform, 3-27	Create Preferences Wizard, 5-1
Blank analysis. See Blank run	Averaging and Trend, 5-17
Blank run	Export, 5-19
enabling blank subtraction, 6-15	Fonts and Colors, 5-21
loading into analysis file, 6-15	Graph Options, 5-21
removing from analysis file, 6-15	Page Setup, 5-20
using, 6-14	Printed Report, 5-2
Blank subtraction	Statistics, 5-15
disabling, 6-15	Summary of Settings, 5-24
enabling, 6-15	View Options, 5-23
Blockage Detection	Current and Gain
settings, 4-18	setting, 3-28
Blockage Detection Settings window	Setting, 5-20
default settings, 4-20	
expanded window options, 4-20	D
	Drop-down menus
reference run, 4-19	hiding, 8-5
Blockage monitor data	11141115, 0 5
including in reports, 5-14	_
	E
C	Electrode
Calibration, 3-10	cleaning, 3-6
canceling, 3-14	Electrolyte and cleaning fluid
completing, 3-15	filtering, 3-5
<u>.                                      </u>	Electrolyte Jar, 1-3
nano-particle calibrators, 3-11	calibrating, 9-13
pausing, 3-14	cleaning, 3-6
running, 3-13	fluid levels, 1-4
saving, 3-21	installing and removing, 1-4
selecting options	Electronic controls, 10-2
stopping, 3-14	Electronic records, 10-1
verifying, 3-18, 3-31	
Calibration file	Electronic signatures
saving, 3-21	applying, 10-6
Calibration Menu, 2-4	generating, 10-5, 10-6
Calibrator	maintaining, 10-5
recommended calibrator size range, 3-14	Electronic signatures (21 CFR Part 11), 10-1
Calibrator size, 3-10	Error log
Change Aperture Tube Wizard, 3-21	opening, 9-18
Comparison data	
including in reports, 5-6	F
Concentration control sample	
running	FDA requirements, 10-1
settings, 3-33	Field names
specifying options, 3-33	customizing, 8-10
Configuration Menu, 2-4	Field Service, 9-15
Configuration options, 8-1, 8-14	File

importing, 7-18	including in reports, 5-7
File history, 10-3	Listing menu, 7-4
accessing, 10-3	Listings
File locations	viewing, 7-4
changing, 8-14	Logging in, 8-18
File Menu, 2-4	Logging out, 8-18
File name template codes, 4-5	
File preferences	M
setting, 7-1	М
Filtration efficiency, 7-26	Main Menu bar, 2-3
including in reports, 5-12, 7-26	drop-down menus, 2-4
saving, 7-26	Main menus
viewing, 7-26	customizing, 8-3
3,	Main Toolbar
	buttons, 2-5
G	first group, 2-6
Gain stage offsets	fourth group, 2-8
measuring, 9-3	second group, 2-6
setting custom measurement intervals, 9-4	third group, 2-7
Graph menu, 7-2	default configuration, 2-5
Graphs	Mean Kd
printing, 5-4	obtaining, 3-16
using cursors in, 7-3	updating, 3-17
viewing, 7-2	Merged run
3,	saving, 7-25
	Metering pump
Н	adjusting, 3-28, 9-3
Help	purging, 9-2
enabling, 8-15	Multisizer 4
	components, 1-2
	features, 1-1
1	Multisizer 4 accessories. See Accessories
Instrument Toolbar	Multisizer 4 software
Fluid Control buttons, 2-12	customizing field names, 8-10
Reset button, 2-12	Instrument Toolbar. See Instrument Toolbar
Run buttons, 2-11	opening, 2-1
Interpolation data	Run Menu, 2-10
including in reports, 5-8	Status Bar, 2-12
Interpolations	Status Bai, 2-12 Status Panel, 2-8
viewing, 7-6	updating, 9-16
-	· •
V	Viewing Area, 2-10
K	Multisizer 4 software window, 2-2
Kd	Main Menu, 2-3
accepting, 3-15	Multi-tube overlap analysis running, 6-12
L	
Language	N
choosing, 8-13	Nano-particle calibrators, 3-11
Listing	Noise level

measuring, 3-30, 9-2 reducing, 3-5, 9-1	converting, 7-9 converting between cursors, 7-11	
	converting for widest distributions, 7-11	
0		
ON light, 1-6	R	
Overlay files, 7-19	Recent files list	
moving between, 7-25	customizing, 8-11	
opening, 7-20	Recent Folders list	
saving, 7-20	customizing, 8-11	
Overlay statistics	Regulatory compliance, 10-1	
including in reports, 5-6	additional security features, 10-7	
meraum in reports, 3-0	audit trail, 10-3	
_	electronic controls, 10-2	
P	electronic records, 10-1	
Particle concentration	electronic signatures	
determining, 6-13	applying, 10-6	
Particle size, 3-11	generating, 10-5, 10-6	
Particle Trap	maintaining, 10-5	
cleaning, 3-6	file history, 10-3	
Particles	accessing, 10-3	
measuring small, 3-5	security controls, 10-2	
Password	setting audit trail options, 10-4	
changing, 8-18	system validation, 10-2	
Power ON/OFF switch, 1-3	user accounts	
Preferences, 4-1	adding, 10-5	
Averaging and Trend, 5-17	Reports	
copying, 6-3	for multiple analysis runs, 7-12	
customizing, 8-13	setting print order, 5-15	
Export, 5-19	Run Menu, 2-4, 2-10	
Fonts and Colors, 5-21	Run menus	
Graph Options, 5-21	customizing, 8-5	
Page Setup, 5-20	customizing, o s	
printing, 6-3		
setting, 5-1	S	
Statistics, 5-15	Sample	
Summary of Settings, 5-24	analyzing, 6-1	
verifying, 6-3	Sample Compartment, 1-3, 1-8	
View Options, 5-23	aperture tube, 1-8	
viewing summary, 5-25	aperture tube knob, 1-8	
Preferences file	external electrode, 1-11	
creating, 5-1	Particle trap, 1-12	
loading, 6-2	sample platform, 1-9	
saving, 5-25	platform release, 1-11	
updating, 5-26	reversing, 1-10	
Print settings	status and illumination lights, 1-12	
changing, 7-1	Stirrer, 1-11	
Pulse data	Sample Compartment door, 3-27	
including in reports, 5-12	Sample data	
Pulses to size	editing, 6-7	
	<del>-</del>	

entering, 6-5	Software configuration, 8-1
printing, 5-3	Software startup
Sample Info Names	resolving errors, 9-5
customizing, 8-10	SOM (Standard Operating Method) Wizard. See SOM
Sample Menu, 2-4	Wizard
Sample runs	SOM Wizard, 4-2
merging, 7-24	Blockage, 4-18
preparing for, 6-1	Concentration Information, 4-17
selecting analysis settings, 6-1	Control mode, 4-6
Sample specifications	Description, 4-3
editing, 6-9	Pulse to Size, 4-15
entering, 6-7	Size bins range, 4-16
	<u> </u>
including in reports, 6-9	Run settings, 4-8
viewing, 6-9	Stirrer settings, 4-10
Security, 8-1	Summary of Settings, 4-21 Threshold, Current and Gain, 4-13
additional features, 10-7	· · · · · · · · · · · · · · · · · · ·
Administrator Menu options, 8-19	SOP (Standard Operating Procedure) Wizard. See SOP
changing password, 8-18	Wizard
customizing, 8-16	SOP Menu, 2-4
logging in, 8-18	SOP Wizard, 4-26
logging out, 8-18	Description, 4-26
user privileges	Select a Preference File, 4-27
customizing, 8-20	Select an SOM File, 4-27
Security controls, 10-2	Summary of Settings, 4-28
Security modes, 8-1	Standard Operating Method (SOM), 4-1
Service mode	Blockage, 4-18
opening, 9-18	Concentration Information, 4-17
Size bins, 4-16	Control mode, 4-6
Size data	copying, 6-4
editing, 6-10	Description, 4-3
Size distribution graphs	editing settings, 4-23
including in reports, 5-4	loading, 4-25, 6-2
Size statistics	printing, 6-4
including in reports, 5-12	Pulse to Size, 4-15
Size trend	Run settings, 4-8
including in reports, 5-10	saving to file, 4-22
Size trend analysis	Stirrer settings, 4-10
adding a file to, 7-23	Summary of Settings, 4-21
creating, 7-22	Threshold, Current and Gain, 4-13
opening, 7-24	verifying, 6-4
opening files for, 7-23	Standard Operating Procedure (SOP), 4-1
saving, 7-23	creating, 4-26
Sizing threshold, 4-14	loading, 6-2
Small Aperture tubes	removing, 4-25, 6-3
current and gain settings, 3-9	using, 4-2, 4-26
handling, 3-4	Statistics
noise profiles, 3-7	comparing to sample specifications, 7-9
storing, 3-9	export formats, 5-19
unblocking, 3-5	exporting, 5-19
Smart Technology Aperture Tubes, 1-14	including in reports, 5-6

viewing, 7-8	reducing noise, 9-1
Status Bar, 2-12	resolving software startup errors, 9-5
Status Panel, 2-8	setting the vacuum regulator, 9-3
customizing, 8-8	updating Multisizer 4 software, 9-16
Stir On button, 1-6	viewing aperture resistance settings, 9-12
Stirrer	viewing instrument schematic diagram, 9-17
direction controls, 1-6	viewing system drain time, 9-11
positioning, 1-1	viewing system flush time, 9-9
positioning manually, 4-11	viewing vacuum settings, 9-7
speed controls, 1-7	working with Field Service, 9-15
Stirrer settings, 4-10	,
copying, 4-11	11
System	U
draining, 9-11	User accounts
filling, 3-28	adding, 10-5
removing air, 3-28	User privileges
System drain time	customizing, 8-20
adjusting, 9-11	
viewing, 9-11	V
System flush time	-
adjusting, 9-10	Vacuum regulator
viewing, 9-9	setting, 9-3
System validation, 10-2	Vacuum settings
oyotom vandacion, 10 2	viewing, 9-7
_	Vibration
Т	reducing, 3-5
Technical Support, 9-15	Viewing Area, 2-10
Threshold, Current and Gain, 4-13	
Aperture current range, 4-14	W
Threshold range, 4-14	
Toolbars	Waste Jar, 1-4
customizing, 8-7	calibrating, 9-13
Troubleshooting	fluid levels, 1-4
adjusting system drain time, 9-11	installing and removing, 1-4
adjusting system flush time, 9-10	Waste tank sensors
adjusting the metering pump, 9-3	calibrating, 9-6
adjusting volumetric flow settings, 9-8	Waste tank settings
calibrating the Electrolyte Jar, 9-13	changing, 9-6
calibrating the Waste Jar, 9-13	Wizards
calibrating waste tank sensors, 9-6	Change Aperture Tube, 3-21
changing aperture resistance settings, 9-13	Create Preferences, 5-1
changing waste tank settings, 9-6	SOM, 4-2
draining the system, 9-11	SOP, 4-26
flow rate errors, 9-8	
identifying the Analyzer, 9-15	
measuring gain stage offsets, 9-3	
measuring noise level, 9-2	
opening Service mode, 9-18	
opening the error log, 9-18	
purging the metering pump, 9-2	
r 0 0 0 r r	