

Hardware & Equipment Problems

Simple steps to check your devices and get help when equipment fails

1. Mobile Tower / Signal Equipment Problem (Cell Site Alarm)

What this means: The mobile tower serving your area has a fault or alarm. You may notice sudden signal loss or internet drops in your neighbourhood.

Step 1: Check if your neighbours in the same area also have no signal — if yes, it is a tower issue, not your phone.

Step 2: You do not need to do anything on your device — this is a network infrastructure issue.

Step 3: Raise a ticket and mention that multiple people in your area are affected.

Step 4: Our field engineers will be dispatched to inspect and fix the tower equipment.

Step 5: Use Wi-Fi calling at home as a workaround until the tower is fixed.

Step 6: Expected fix time: 2–6 hours depending on the severity.

■■ Tower equipment issues are automatically detected by our monitoring systems. Often our team is already aware and working on a fix before you raise a ticket.

2. Power / Battery Failure at Network Site

What this means: The equipment providing service in your area lost power due to a power cut or battery failure. This can cause complete signal loss in that area.

Step 1: Check if there is a power cut in your area — this can sometimes affect mobile towers too.

Step 2: This issue cannot be fixed by you — it requires our field team to restore power to the site.

Step 3: Raise a ticket mentioning 'no signal since [time]' and your area/pincode.

Step 4: Move to a nearby area with signal if you urgently need to make a call.

Step 5: Service will automatically restore once our team fixes the power supply at the site.

■■ Power failures are usually resolved within 4 hours. Our sites have backup batteries for short outages.

3. Router / Modem Not Working

What this means: Your home broadband router or modem is showing error lights or has stopped giving internet to your devices.

Step 1: Check the lights on your router. If the 'Internet' or 'WAN' light is red or off — there is a connection issue.

Step 2: Switch the router OFF, wait 1 full minute, then switch it back ON. Wait 2 minutes for it to fully start.

Step 3: Check all cables connected to the router — make sure they are firmly plugged in.

Step 4: Try connecting your phone directly to the router via Wi-Fi to test if it works.

Step 5: If lights are normal but internet still does not work, restart your phone or laptop too.

Step 6: If the router light stays red after restarting, call us. We will check remotely first and send a technician if needed.

Step 7: Do NOT try to open or repair the router yourself.

Router light guide:

Light Colour	What It Means	What To Do
All green / blue	Everything is working fine	No action needed
Internet light red	No internet connection from our end	Restart router, then call us
Internet light off	Cable may be loose or line issue	Check cables, then call us
Power light off	Router has no power	Check power cable and switch
All lights blinking fast	Router is restarting / updating	Wait 3 minutes

4. Transmission Equipment Fault

What this means: The underground or overhead equipment that carries internet signals between towers or exchange points has a fault. This is NOT something at your home.

Step 1: This is a network infrastructure issue — there is nothing you can do at your end to fix it.

Step 2: Raise a ticket with your area and pin code so our team can identify the affected route.

Step 3: Do not call repeatedly — our network team is automatically alerted and will begin repairs.

Step 4: Use mobile data as a backup for home internet if available.

Step 5: Expected fix time: 4–12 hours depending on the location of the fault.

■■ Transmission faults are often caused by external digging, road construction, or severe weather. Our team will update you via SMS.

5. Set-Top Box / Modem / CPE Device Issues

What this means: The device installed at your home by us (modem, ONT box, set-top box) is not working properly.

Step 1: Restart the device — switch it OFF, wait 1 minute, switch it back ON.

Step 2: Check all cables connecting the device to the wall socket and your router/TV.

Step 3: Make sure the device is getting power — check the power indicator light.

Step 4: If the device is making unusual sounds or smells burnt — immediately switch it OFF and do NOT use it.

Step 5: Do NOT try to open or self-repair the device — it will void the warranty.

Step 6: Call us or raise a ticket — we will replace a faulty device at no charge if it is within warranty.

Step 7: If the device is physically damaged by you (dropped, water damaged), a replacement fee may apply.

■ ■ Never try to repair network devices yourself. Faulty devices are replaced free of charge if the fault is not caused by physical damage.