

TITAN Project Scheduling Guide

Tweet Garot Mechanical · How to set up and manage a project schedule in TITAN

SCHEDULING MODE

Summary

One start date and one end date for the entire project. All trades and cost types share the same window. Default for all new projects.

Best for: Single-trade jobs, early-stage estimates, or any project where all field work runs one continuous schedule.

SCHEDULING MODE

Cost Type

Separate date windows per active cost type segment — labor trades (Sheet Metal, Pipefitter, Plumbing) and non-labor types (Material, Subcontracts, Rentals, MEP Equipment, General Conditions). Each segment's forecast is spread across its own window.

Best for: Multi-trade jobs where crews are on-site at different times or the GC schedule breaks out dates by trade.

SCHEDULING MODE

Phase

Every phase item from Vista drives its own revenue and labor forecast window. Highest precision. Can link directly to GC schedule activities.

Best for: Complex jobs with named phases (mobilization, rough-in, trim-out, commissioning) at different times of year.

▲ Low setup · Enter 2 dates

▲ Medium setup · 1 date range per active cost type segment

▲ High setup · Dates required on every phase

Switching modes is safe. Change the mode at any time from the Summary tab → *Forecast Scheduling Mode* selector. Dates saved on the Cost Type or Phase tabs are preserved in the background and restored when you switch back. The Labor Forecast updates immediately — no regeneration step needed.

HOW TO CHOOSE

Mode	Use when...	Forecast driven by	Setup effort
Summary	Single trade, lump-sum bid, or project just awarded with no detailed schedule yet	Project start date + end date (one window)	Low — 2 dates
Cost Type	Multiple trades with different on-site windows, or GC schedule shows dates by trade	Separate date range per active cost-type segment	Medium — 1 range per active cost type segment
Phase	Complex job with named phases that have meaningfully different crew sizes or timing	Each Vista phase item's own start + end date	High — all phases need dates

STEP-BY-STEP SETUP

Mode 1 — Summary Schedule

- Open the project → click **Schedule** in the left navigation.
- The page opens on the **Summary** tab. Confirm the **Forecast source** badge (top-right) reads *Summary*. If not, scroll to **Forecast Scheduling Mode** and select Summary.
- Under **Project Date Range**, click the **Start Date** field and enter the mobilization date.
- Click the **End Date** field and enter the completion date. Tab out of the field — saves automatically.
- Toast confirms: *Project dates saved*. Labor Forecast updates immediately.

Note: If the project has labor for more than one trade, a yellow banner appears suggesting a switch to Cost Type mode for more accurate forecasting. Dismiss it or click the link to jump to Cost Type.

Mode 2 — Cost Type Schedule

- Summary tab → **Forecast Scheduling Mode** → select **Cost Type**. The Forecast source badge updates.
- Click the **Cost Type** tab in the tab bar.
- The table shows one row per active segment, grouped as **Labor** (Sheet Metal Field/Shop, Pipefitter Field/Shop, Plumbing Field/Shop, Overhead, BAS) and **Non-Labor** (Material, Subcontracts, Rentals, MEP Equipment, General Conditions). Only segments with estimated hours or costs in Vista appear.
- For each row, click the **Start** date cell and enter the date that trade begins on-site.
- Click the **End** date cell and enter the finish date. Saves on blur — no Save button.
- Optionally set a **Contour** per row: Flat, Front-loaded, Back-loaded, or Bell curve.
- Repeat for every active segment. Headcount updates live.

Tip: If a trade runs the full project span, copy the project start and end dates. Only enter different dates for trades that diverge.

Mode 3 — Phase Schedule

- Summary tab → **Forecast Scheduling Mode** → select **Phase**.
- Click the **Phase** tab. A green bar confirms: *Phase dates are driving the revenue and labor forecast for this project*.
- Phase codes populate automatically from the Vista contract import — no manual entry needed.
- For each phase, click the **Start** cell and enter the phase start date.
- Click the **End** cell and enter completion. Duration calculates automatically.
- Optionally set a **Predecessor** (row ID of the preceding phase) to model sequential phases.
- Optionally set a **Contour** per phase.
- Phases without dates are excluded from the forecast. Enter dates on all phases that carry labor hours.

GC link: Click the GC chip icon on any phase row to link it to an activity on the uploaded GC schedule. Dates sync automatically on re-import. **Provisional phases:** Use *Add Phase* for phase codes not yet in Vista.

DECISION GUIDE

SUMMARY MODE

One window for the whole project

✓ Go — no hesitation: project just awarded, single trade, or early estimate before GC schedule exists

⚠ Upgrade to Cost Type when 2 or more trades appear on the contract with different site windows

✗ Not recommended once the GC schedule has been issued with a phase or milestone breakdown

COST TYPE MODE

Per-trade date windows

✓ Go — standard choice: multi-trade job with GC milestone dates available by trade or cost type

⚠ Consider Phase when the job has named phases with meaningfully different crew sizes across the project

✗ Overkill for a single-trade or simple one-phase project — Summary is sufficient

PHASE MODE

Per-phase date windows

✓ Go — maximum precision: complex job with detailed GC schedule in hand and phases vary significantly in timing

⚠ Verify coverage: phases without dates are excluded from the forecast — blank dates = missing headcount

✗ Not worth the effort for a small job, single phase, or pre-award estimate

TIPS & QUICK REFERENCE

Scheduling Principles

Always enter an end date — without one the system estimates from contract value and % complete, which is less accurate.

Contour shapes affect peak headcount. Flat is the safe default; use Front-loaded or Back-loaded only when you know the crew ramp plan.

Navigation Quick-Reference

Schedule page: Open any project → Schedule (left nav)

Mode selector: Summary tab → Forecast Scheduling Mode section

Active mode badge: Top-right of the Schedule page — shows current forecast source

- Start in Summary on award day. Upgrade to Cost Type or Phase once the GC schedule arrives.
 - The Labor Forecast reflects every saved date in real time — no publish step required.
- Labor Forecast:** Team Financials → Labor Forecast (real-time)

GC Schedule: Project → GC Schedule (upload GC schedule for phase linking)

Provisional phases: Phase tab → Add Phase (for codes not yet in Vista)

Set the mode at award, not at handoff. *A firm end date beats a computed one. Phase mode is only as good as the dates you enter.*