# Yaazh Super Store

Everything you want

Customer Care FAQ | Updated 2026-11-05

Covers: Washing Machine · Refrigerator · Air Conditioner · Dishwasher · Microwave Oven · Oven / Cooktop · Store Policies

## Section 1: Washing Machine

### Q1. Washing Machine: Error E21 / drain problems

Error E21 or 'dr' means the machine cannot drain.

1. Switch off and unplug.
2. Open the bottom-front filter cover, place a shallow tray, and unscrew the drain filter slowly.
3. Remove lint, coins and debris.
4. Check the drain hose for kinks and make sure it is no higher than 100 cm.
5. Refit the filter fully clockwise and run a Drain/Spin cycle. If E21 persists, the drain pump may need replacement - raise a service ticket.

### Q2. Washing Machine: Excessive vibration or walking

Level the machine using the four adjustable feet, tighten the lock nuts, and remove transit bolts at the back (required on new installations). Do not overload; maximum load is printed on the door label.

## Section 2: Refrigerator

### Q3. Refrigerator: Not cooling properly

Set fridge to 3-5 C and freezer to -18 C. Keep 5 cm clearance at the back and sides. Check the door gasket seals (paper-slip test). Clean condenser coils at the back/bottom every 6 months. Avoid placing hot food inside. Allow 24 hours to stabilise after changing the setting. If the compressor does not start or you hear repeated clicking, escalate to a technician.

### Q4. Refrigerator: Water pooling inside

A blocked defrost drain causes pooling. Locate the drain hole at the back of the fridge compartment and clear it with warm water and a soft pipe-cleaner. Do not use sharp objects.

## Section 3: Air Conditioner

### Q5. Air Conditioner: Water leaking from indoor unit

Common causes: dirty air filter, blocked drain pipe, or incorrect indoor-unit slope. Clean filters (wash with lukewarm water, dry in shade), then pour a cup of water into the drain tray to test flow. Ensure the drain pipe slopes downward. If water continues to leak, schedule a technician visit.

### Q6. Air Conditioner: Not cooling

Confirm mode is COOL and set temperature is 4-5 C below room temperature. Clean the filters, ensure the outdoor unit is unobstructed and the doors/windows are closed. Gas refill or compressor faults require a technician.

## Section 4: Dishwasher

### Q7. Dishwasher: Not draining

Run the Cancel/Drain cycle. Clean the bottom filter and spray arm holes, check the drain hose for kinks, and make sure the sink air-gap or disposal knockout plug is removed. Use only dishwasher detergent (never liquid soap).

## Section 5: Microwave Oven

### Q8. Microwave Oven: Sparks or arcing

STOP using the microwave immediately. Remove metal items, foil or damaged dishes. Wipe food splatter from the waveguide cover. If sparks continue with an empty (water-filled) cup, the waveguide cover or magnetron may be damaged. Do not operate - escalate to a technician.

## Section 6: Oven / Cooktop

### Q9. Oven / Cooktop: Smell of gas (SAFETY)

If you smell gas: do NOT switch any electrical item on or off, do NOT use flames. Open windows, turn off the cylinder regulator/main gas supply, leave the area, and call the emergency gas helpline. Then raise a CRITICAL ticket - a certified technician must inspect before further use.

## Section 7: Store Policies

### Q10. Warranty Policy

Standard warranty is 12 months comprehensive on all appliances, extended to 24 months on the compressor/motor (36 months for inverter ACs). Warranty is void for physical damage, unauthorised repair, or commercial use. Proof of purchase and serial number are required. Out-of-warranty visits cost INR 499 inspection + parts.

### Q11. Return and Refund Policy

Products can be returned within 10 days of delivery if unused and in original packaging. Refunds are processed to the original payment method within 5-7 business days after inspection. Installation-damaged items are not eligible for return.