

RIDO Emergency Breakdown and Incident Escalation SOP

1. Expressway Breakdown Protocol: Immediately steer vehicle to hard shoulder. Switch on hazard warning lights. Place fluorescent safety warning triangles 15 meters and 50 meters behind rear bumper.
2. Emergency SOS and Telematics Escalation: Driver must activate SOS button in RIDO terminal within 5 minutes of breakdown. Central dispatch automatically dispatches mobile repair unit and backup tow vehicle within 30 km radius.
3. Driver Fatigue and Night Driving Restrictions: Driving between 01:00 AM and 05:00 AM requires mandatory Level-4 Telematics Driver Monitoring for eyelid closure and lane departure. Maximum continuous night shift driving is capped at 3.5 hours.