

HP 8114A Programming Reference

Common Command Summary IEEE 488.2

Table 4-1.
HP 8114A IEEE 488.2 Common Command
Summary

4

Command	Parameter	Description
*CLS	—	Clear the status structure
*ESE	<0-255>	Set the Event Status Register Mask
*ESE?	<0-255>	Read the Event Status Register Mask
*ESR?	—	Read the Event Status Register
*IDN?	—	Read the Instrument's Identification string
*LRN?	—	Read the complete Instrument Setting
*OPC	—	Generate the Operation Complete message when all pending actions are complete
*OPC?	—	Set the Operation Complete bit when all pending actions are complete
*OPT?	—	Read the installed options
*RCL	<0-9>	Recall a complete Instrument Setting from memory
*RST ¹	—	Reset the instrument to standard settings
*SAV	<1-9>	Save the complete Instrument Setting to memory
*SRE	<0-255>	Set the Service Request Enable Mask
*SRE?	<0-255>	Read the Service Request Enable Mask
*STB?	—	Read the Status Byte
*TRG	—	Trigger
*TST?	—	Execute instrument's self-test
*WAI	—	Wait until all pending actions are complete

¹ See the default settings in table 4-13, at the end of this section.

SCPI Command Summary

Table 4-2. HP 8114A SCPI Command Summary

Command	Parameter	Description
:DISPlay [:WINDow] [:STATe]	ON OFF 1 0	Set/read frontpanel display state
:MMEMory :CATalog? :CDIRectory	[A:] [<name>]	Read directory of memory card Change directory on memory card
:COPY :DELete :INITialize	<source>[,A:],<dest>[,A:] <name>[,A:] [A:[,DOS]]	Copy a file on memory card Delete a file from memory card Initialize memory card to DOS format
:LOAD :STATe :STORe :STATe	<n>,<name>[,A:] <n>,<name>[,A:]	Load file from memory card to memory n Store memory n to memory card
:OUTPut [:STATe] :IMPedance [:INTernal] :EXTernal :POLarity	ON OFF 1 0 <value> <value> POSitive NEGative	Set/read channel output state Set/read internal source impedance of output Set/read expected external load impedance at output Set/read output polarity

Table 4-2.
HP 8114A SCPI Command Summary (continued)

Command	Parameter	Description
[[:SOURce] :CURRent ¹ [:LEVel] [:IMMediate] [:AMPLitude] <value> :BASeline <value> :HIGH <value> :LOW <value> :LIMit ¹ [:HIGH] :LOW :STATe ON OFF 1 0 :FREQuency [:CW]:FIXed] <value> :HOLD ¹ VOLT CURR :PHASe <value> [:ADJust] <value> :PULSe :DCYClE <value> :DELay <value> :HOLD TIME PRATio :UNIT S SEC PCT DEG RAD :DOUBle [:STATe] OFF ON :DELay <value> :HOLD TIME PRATio :UNIT S SEC PCT :HOLD WIDTH DCYClE TDELay		Set/read channel amplitude current Set/read channel baseline current Set/read channel high-level current Set/read channel low-level current Set/read maximum current limit Set/read minimum current limit Enable/Disable the current limits. Set/read frequency of pulses Switch between VOLTage and CURRent command subtrees Set/read channel phase Set/read channel duty-cycle Set/read channel delay (to leading edge) Hold absolute delay delay as period ratio fixed with varying frequency Set/read delay units Enable/disable double pulses per pulse-period Set/read delay between double pulses Hold absolute delay delay as period ratio fixed with varying frequency Set/read delay units Hold Width Duty-cycle Trailing edge delay fixed with varying frequency

¹ The CURRENT and VOLTage subsystems cannot be used at the same time. Use the :HOLD command to select between them.

The Standard HP 8114A cannot program current via the HP-IB bus. Convert the required current with the help of the Ohm's law into voltage and program the voltage.

With Option 001 installed the commands can be used.

Table 4-2.
HP 8114A SCPI Command Summary (continued)

Command	Parameter	Description
[:SOURce]		
:PULSe		(Continued from previous page)
:LIMIT		
[:WIDth]	<value>	Set Width limit on/off
:DCYCLe	<value>	Set Duty-cycle limit on/off
:STATe	OFF ON	Enable/disable limits
:PERiod	<value>	Set/read pulse-period
:TrailingDELay	,value>	Set/read trailing edge delay
:WIDTh	<value>	Set/read channel pulse width
:VOLTage ¹		
[:LEVel]		
[:IMMediate]		
[:AMPLitude]	<value>	Set/read channel amplitude voltage
:BASeline	<value>	Set/read channel baseline voltage
:HIGH	<value>	Set/read channel high-level voltage
:LOW	<value>	Set/read channel low-level voltage
:LIMit		
[:HIGH]		Set/read maximum voltage limit
:LOW		Set/read minimum voltage limit
:STATe	ON OFF 1 0	Enable/Disable the voltage limits.
:STATus		
:OPERation		
[:EVENT]?		Read Operation event register
:CONDition?		Read Operation condition register
:ENABle	Numeric	Set/Read Operation enable register
:NTRansition	Numeric	Set/Read Operation negative-transition register
:PTRansition	Numeric	Set/Read Operation positive-transition register
:PRESet		Clear and preset status groups

¹ The CURRENT and VOLTage subsystems cannot be used at the same time. Use the :HOLD command to select between them.

Table 4-2.
HP 8114A SCPI Command Summary (continued)

Command	Parameter	Description
:STATus		(Continued from previous page)
:QUESTionable		
[:EVENT]?		Read Questionable event register
:CONDition?		Read Questionable condition register
:ENABle	Numeric	Set/Read Questionable enable register
:NTRansition	Numeric	Set/Read Questionable negative-transition register
:PTRansition	Numeric	Set/Read Questionable positive-transition register
:SYSTem		
:ERRor?		Read error queue
:KEY	Numeric	Simulate key press
:KEY?	Numeric	Read last key pressed
:PRESet		Same as *RST, but display not affected
:SECurity	Block data	Set/read complete instrument
[:STATe]	ON OFF	Switch security on and off
:SET	Block data	Set/read complete instrument setting
:VERSion?		Read SCPI compliance version
:WARNing		
[:COUNT]?		Read number of active warnings
:STRing?		Read active warnings as concatenated string
:BUFFer?		Read maximum possible length of concatenated string
:TRIGger		
[:SEQUence :START]		
:COUNT	<value>	Set/read number of triggered periods to be generated in a burst
:EWIDth		
:STATe	ON OFF 1 0	Set/read External WQidth mode
:INHibit		
[:STATe]	ON OFF 1 0	Switch Inhibit Input on or off
:MODE	RISE FALL HIGH LOW	Inhibit on edge or level
:INPut	RESet SET	Reset or set inhibit (edge inhibit only)
:LEVel	<value>	Set/read threshold level at EXT INPUT
:SENSe	EDGE LEVel	Set/read trigger on edge or gate on level
:SLOPe	POS NEG EITH	Set/read trigger slope at EXT INPUT
:SOURce	IMM EXT MAN	Set/read trigger source (VFO EXT INPUT MAN key)