-2

-4

-60

-80

-100

-120

-140 | -80 | -80 | -60 | -40 | -40 | -20 | Scale is to calibrate actual printed dimension. Check both X and Y I Measure between tick 0 and las

