# **DVC6000 Series FIELDVUE® Digital Valve Controllers**

Introduction

Installation

375 Field Communicator Basics

3

2

**Basic Setup** 

4

**Detailed Setup** 

5

Calibration

6

Viewing Device Information

ewing Device information

8

Principle of Operation

\_

Maintenance

Parts

10

Loop Schematics/Nameplates

11

Glossary


Glossary

Index

Index

# This manual applies to:

	DVC	Model 375 Field Communicator		
Device Revision	Firmware Revision	Hardware Revision	Instrument Level	Device Description Revision
2	7	1	AC, HC, AD, PD, and ODV	1





Fast-Key Sequence for Instrument Level HC, AD, PD, and ODV

Function/Variable	Fast-Key Sequence	Coord- inates <sup>(1)</sup>	Function/Variable	Fast-Key Sequence	Coord- inates <sup>(1)</sup>
Actuator Style	1-2-6-4	4-D	Drive Signal Alert Enable	1-2-3-1-2-1	10-C
Alert Conditions	2-1	2-E	End Point Control Enable <sup>(3)</sup>	1-2-2-5-1	6-C
Alad Bassad E. II Essila	1-2-3-6-2	0.5	Fell or One of Feeble	1-2-3-6-5-1	10.0
Alert Record Full Enable	1-2-3-7-2 8-F		Failure Group Enable	1-2-3-7-5-1	10-G
Alert Record Not Empty Alert Enable	1-2-3-6-1	8-F	Feedback Connection	1-2-6-5	4-D
Aleit Necold Not Empty Aleit Enable	1-2-3-7-1	0-1	Firmware Revision	3-7-6	4-H
Analog Input	3-1	2-F	Flash ROM Shutdown	1-2-3-1-3-5	11-C
Analog Input Calibration	1-3-2-3	4-E	Hardware Revision	3-7-7	4-I
Analog Input Range Hi	1-2-5-3-1	6-H	HART Tag	1-2-5-1-1	6-F
Analog Input Range Lo	1-2-5-3-2	6-H	TIAITI Iag	3-7-1	4-H
Analog Input Units	1-2-5-2-3	6-H	HART Universal Revision	3-7-9	4-I
Auto Travel Calibration	1-3-1-1	4-E	Input Characterization	1-2-2-3	4-C
Autocalibration in Progress Enable	1-2-4-2-2	8-H	Instrument Date and Time	1-2-4-1-2	8-G
Auxiliany Input	3-6-1	5-G	Instrument Date and Time	1-2-5-8	5-F
Auxiliary Input	1-2-3-3-1-2	10-C	Instrument Level	3-7-8	4-I
Auxiliary Terminal Alert Enable	1-2-3-3-1-1	10-C	Instrument Mode	Hot Key-1	1-A
Auxiliary Terminal Mode	1-2-3-3-1-3	10-D	mstrument wode	1-2-1-1	4-B
Auxiliary Terminal Mode	1-2-5-7	5-F	Instrument Serial Number	1-2-5-1-6	6-F
Burst Command	1-2-1-4-3	5-B	Instrument Time Invalid Enable	1-2-4-1-1	8-G
Burst Enable	1-2-1-4-1	5-A	Integral Dead Zone	1-2-4-4-4	8-I
Calibration in Progress Enab	1-2-4-2-1	8-G	integral Dead Zone	1-2-2-1-2-1	9-A
Calibration Location	1-2-5-9-2	6-H	Integral Limit	1-2-4-4-3	8-I
Clear Record	1-2-3-6-4	8-G	Integral Limit	1-2-2-1-2-2	9-A
Clear Record	1-2-3-7-4	8-G	Integrator Saturated Hi Enable	1-2-4-4-1	8-H
Command 3 (Trending) Pressure	1-2-1-4-3	5-B	Integrator Saturated Lo Enable	1-2-4-4-2	8-H
Control Mode	Hot Key-2	1-A	Lag Time <sup>(5)</sup>	1-2-2-5-3	6-D
Control Mode	1-2-1-2	4-B	Last Calibration Status	1-2-5-9-1	6-H
Critical NVM Shutdown	1-2-3-1-3-4	11-C	Lead/Lag <sup>(3)</sup>	1-2-2-5-3	6-D
Cycle Count	1-2-3-5-1-2	5-F	Manual Travel Calibration	1-3-1-2	4-E
Cycle Count	3-6-5	3-H	Manufacturer	3-7-3	4-H
Cycle Count Alert Enable	1-2-3-5-1-1	10-F	Manuacturei	1-2-6-1	4-D
Cycle Count Alert Point	1-2-3-5-1-3	10-F	Maximum Supply Pressure	1-2-5-6	5-F
Date	1-2-5-1-4	6-F	Message	1-2-5-1-2	6-F
Dead Band (Cycle Count / Travel Accum)	1-2-3-5-2-1	10-F	Miscellaneous Group Enable	1-2-3-6-5-3	10-G
Define Custom Characteristic	1-2-2-4	4-C	Miscellarieous Group Erlable	1-2-3-7-5-3	10-G
Descriptor	1-2-5-1-3	6-F	Model	3-7-4	4-H
Device Description Information	3-8	2-G	Multi-Drop Alert Enable	1-2-4-3-2	8-H
Device ID	3-7-2	4-H	No Free Time Shutdown	1-2-3-1-3-6	11-C
Device Revision	3-7-5	4-H	Non-Critical NVM Alert Enable	1-2-3-1-3-3	11-B
Diagnostic Data Available Enable	1-2-4-2-4	8-H	Number of Dames Hea	2-3-4	4-F
Diagnostic in Progress Enable	1-2-4-2-3	8-H	Number of Power Ups	3-6-9	5-H
Dianley Decord	1-2-3-6-3	0.5	Offline/Failed Alert Enable	1-2-3-1-3-1	11-B
Display Record	1-2-3-7-3	8-F	Partial Stroke Test	2-5	2-F
Drive Current Shutdown	1-2-3-1-1	9-C	Partial Stroke Test Enable <sup>(3)</sup>	1-2-7-1	3-D
Drive Signal	3-4	3-F	Partial Stroke Test Pressure Limit <sup>(3)</sup>	1-2-3-6-1	8-F
Drive Signal	1-2-3-1-2-2	10-C	Partial Stroke Test Start Point <sup>(3)</sup>	1-2-2-5-2	8-C

NOTE: Italicized Fast-Key Sequence indicates fast-key sequence is only applicable for instrument level ODV.


1. Coordinates are to help locate the item on the foldout menu tree.


3. Instrument level ODV only.

5. Instrument level HC, AD, and PD only.

continued on facing page

# Model 375 Field Communicator Menu Tree for FIELDVUE® DVC6000 Instrument Level HC, AD, PD, and ODV





Fast-Key Sequence for Instrument Level HC, AD, PD, and ODV (continued)

Function/Variable	Fast-Key Sequence	Coord- inates <sup>(1)</sup>	Function/Variable	Fast-Key Sequence	Coord- inates <sup>(1)</sup>
Partial Stroke Test Variables View/Edit <sup>(3)</sup>	1-2-7-2	3-D	Temperature Sensor Shutdown	1-2-3-2-2	9-D
Performance Tuner <sup>(2)</sup>	1-1-2	2-B	Temperature Units	1-2-5-2-2	6-G
Performance Tuner -	1-2-2-1-1-5	8-A	Travel	3-3	2-F
Polling Address	1-2-5-1-7	6-F	Travel	1-2-3-4-1	10-D
Power Starvation Alert Enable	1-2-3-1-3-2	11-B	Travel / Pressure Cutoff Hi	1-2-3-4-7-3	12-F
Pressure A	3-5-1	4-G	Traver / Pressure Cuton Hi	1-2-2-2-1	9-B
Pressure B	3-5-2	4-G	Travel / Draggura Cutoff La	1-2-3-4-7-4	12-F
Pressure Control Active Enable	1-2-4-3-1	8-H	Travel / Pressure Cutoff Lo	1-2-2-2-2	9-B
Pressure Deviation Alert Enable <sup>(3)</sup>	1-2-3-6-2	8-F	Travel / Pressure Select	1-2-2-2-1	6-B
Pressure Deviation Alert Point <sup>(3)</sup>	1-2-3-6-3	8-F		3-6-6	6-H
Pressure Deviation Time <sup>(3)</sup>	1-2-3-6-4	8-F	Travel Accumulator	1-2-3-5-3-2	10-F
Pressure Differential	3-5-3	4-G	Travel Accumulator Alert Enable	1-2-3-5-3-1	10-F
Pressure Integral Control Enable	1-2-2-1-3-2	8-B	Travel Accumulator Alert Point	1-2-3-5-3-3	10-F
Pressure Integral Gain	1-2-2-1-3-3	8-B	Travel Alert Dead Band	1-2-3-4-3	10-E
Pressure MLFB Gain	1-2-2-1-3-1-3	10-B	Travel Alert Hi Enable	1-2-3-4-6-1	10-E
Pressure Proportional Gain	1-2-2-1-3-1-2	10-B	Travel Alert Hi Hi Enable	1-2-3-4-5-1	12-D
Pressure Range Hi	1-2-2-2-4-1	9-C	Travel Alert Hi Hi Point	1-2-3-4-5-3	12-D
Pressure Range Lo	1-2-2-4-2	9-C	Travel Alert Hi Point	1-2-3-4-6-3	12-E
Pressure Sat Time <sup>(3)</sup>	1-2-2-5-4	8-C	Travel Alert Lo Enable	1-2-3-4-6-2	12-E
Pressure Sensor Shutdown <sup>(2)</sup>	1-2-3-2-3	9-D	Travel Alert Lo Linable  Travel Alert Lo Lo Enable	1-2-3-4-5-2	12-L
Pressure Sensors—Calibration	1-3-2-1	9-D 4-E	Travel Alert Lo Lo Point	1-2-3-4-5-4	12-D
Pressure Set Point <sup>(3)</sup>		4-⊑ 8-C		1-2-3-4-5-4	12-D 12-E
	1-2-2-5-3		Travel Deviation Alart Frankla		
Pressure Tuning Set	1-2-2-1-3-1-1	10-B	Travel Deviation Alert Enable	1-2-3-4-4-1	12-D
Pressure Units	1-2-5-2-1	6-G	Travel Deviation Alert Point	1-2-3-4-4-2	12-D
Protection	Hot Key-3	1-A	Travel Deviation Time	1-2-3-4-4-3	12-D
	1-2-1-5	4-B	Travel Integral Control Enable	1-2-2-1-1-2	8-A
Raw Travel Input	3-6-7	5-H	Travel Integral Gain	1-2-2-1-1-3	8-A
Reference Voltage Shutdown	1-2-3-1-3-7	11-C	Travel Limit / Cutoff Hi Alert Enable	1-2-3-4-7-1	12-E
Relay Adjust	1-3-3	3-E	Travel Limit / Cutoff Lo Alert Enable	1-2-3-4-7-2	12-E
Relay Type	1-2-5-4	5-F	Travel Limit Hi	1-2-3-4-7-5	12-F
Restart Control Mode	1-2-1-3	4-B		1-2-2-3-1	8-B
Restore Factory Settings	1-3-4	3-E	Travel Limit Lo	1-2-3-4-7-6	12-F
Run Time	2-3-3	4-F		1-2-2-3-2	8-B
	3-6-8	5-H	Travel MLFB Gain	1-2-2-1-1-1-4	10-A
Set Point Rate Close	1-2-2-5-2	6-C	Travel Proportional Gain	1-2-2-1-1-1-2	10-A
Set Point Rate Open	1-2-2-5-1	6-C	Travel Sensor Adjust	1-3-2-2	4-E
Setup Wizard	1-1-1	2-B	Travel Sensor Motion	1-2-6-6	4-D
	Hot Key-4	1-A	Travel Sensor Shutdown	1-2-3-2-1	9-D
Stabilize/Optimize	1-1-3 <sup>(4)</sup>	2-B	Travel Set Point	1-2-3-4-2	10-E
	1-2-2-1-1-4	8-A	Haver Set Follit	3-2	2-F
Status	2-2	2-F	Travel Tuning Set	1-2-2-1-1-1	10-A
Stroke Valve	2-4	2-F	Travel Velocity Gain	1-2-2-1-1-3	10-A
Cumbi Process (2)	3-5-4	4-G	Value Craus Fack!	1-2-5-6-5-2	10.0
Supply Pressure <sup>(2)</sup>	1-2-3-3-2-2	10-D	Valve Group Enable	1-2-5-7-5-2	10-G
Supply Pressure Lo Alert Enable	1-2-3-3-2-1	10-D	Value Carial Number	1-2-5-1-5	6-F
Supply Pressure Lo Alert Point	1-2-3-3-2-3	10-D	Valve Serial Number	1-2-6-2	4-D
Temperature	3-6-2	5-G	Valve Style	1-2-6-3	4-D
·	3-6-3	5-G	Zero Power Condition	1-2-5-5	5-F
Temperature Maximum	2-3-1	4-F		ı	
			<b>{ </b>		
Temperature Minimum	3-6-4	5-H			

NOTE: Italicized Fast-Key Sequence indicates fast-key sequence is applicable only for instrument level ODV.

1. Coordinates are to help locate the item on the foldout menu tree.

2. Not available in instrument level HC.

3. Instrument level ODV only.

4. Instrument level HC only.

5. Instrument level HC, AD, and PD only.

#### Fast-Key Sequence for Instrument Level AC

Function/Variable	Fast-Key Sequence	Coordinates <sup>(1)</sup>	Function/Variable	Fast-Key Sequence	Coordinates <sup>(1)</sup>
Actuator Style	1-1-2-2-4	5-C	Durana Durana di arad Onio	1-1-2-3-2-2	6-D
Analog Input Calibration	1-3-1	3-F	Pressure Proportional Gain	1-2-3-4-1-2	6-G
Analog Input Range Hi	1-2-2-2	4-E	Pressure Range Hi	1-2-3-5-1	5-G
Analog Input Range Lo	1-2-2-3	4-E	Pressure Range Lo	1-2-3-5-2	5-G
Analog Input Units	1-2-2-1	4-E	Б. Т. О.	1-1-2-3-2-1	6-D
	1-1-2-3-4	5-D	Pressure Tuning Set	1-2-3-4-1-1	6-G
Auto Travel Calibration	1-3-2	3-F	Б	1-1-2-2-2	5-C
	1-1-1-3	4-B	Pressure Units	1-2-2-4	4-E
Calibration Location	1-3-5	3-F	Protection	Hot Key-2	1-B
Date	1-2-1-4	4-D		1-1-1-2	4-B
Descriptor	1-2-1-3	4-D	Relay Adjust	1-1-2-3-3	5-D
Device Description Revision	2-2	2-F		1-3-6	3-G
Device Identification	2-1-6	3-G	Relay Type	1-2-4	3-D
Device Revision	2-1-2	3-G	Restore Calibration	1-3-4	3-F
Feedback Connection	1-1-2-2-5	5-C	Setup Wizard	1-1-1-1	4-B
Firmware Revision	2-1-3	3-G	Travel Integral Gain	1-2-3-2-3	5-E
Hardware Revision	2-1-4	3-G	Travel Integral Enable	1-2-3-2-2	5-E
HART Tag	1-2-1-1	4-D		1-1-2-3-1-4	6-D
HART Universal Revision	2-1-1	3-G	Travel MLFB Gain	1-2-3-2-1-4	6-E
Input Characteristic	1-2-3-6	4-F		1-1-2-2-1	5-C
Instrument Level	2-1-5	3-G	Travel / Pressure Select	1-2-3-1	4-F
	Hot Key-1	1-B	5	1-1-2-3-1-2	6-D
Instrument Mode	1-1-2-1	4-C	Travel Proportional Gain	1-2-3-2-1-2	6-E
Instrument Serial Number	1-2-1-6	4-E	Travel Sensor Adjust	1-3-7	3-G
Integral Dead Zone	1-2-3-3-1	5-F	Travel Sensor Motion	1-1-2-2-6	5-C
Integral Limit	1-2-3-3-2	5-F		1-1-2-3-1-1	6-D
Manual Travel Calibration	1-3-3	3-F	Travel Tuning Set	1-2-3-2-1-1	6-E
Maximum Supply Pressure	1-1-2-2-3	5-C	o .	1-1-2-3-1-3	6-D
Message	1-2-1-2	4-D	Travel Velocity Gain	1-2-3-2-1-3	6-E
Polling Address	1-2-1-7	4-E	Valve Serial Number	1-2-1-5	4-D
Pressure Integral Control Enable	1-2-3-4-2	5-F	Valve Style	1-1-2-2-7	5-C
Pressure Integral Gain	1-2-3-4-3	5-F	Zero Power Condition	1-1-2-2-8	5-C
<del></del>	1-1-2-3-2-3	6-D		L	
Pressure MLFB Gain	1-2-3-4-1-3	6-G	1		
1. Coordinates are to help locate the item of	n the menu tree on the	e facing page.	11.		

6

#### Model 375 Field Communicator Menu Tree for Α FIELDVUE® DVC6000 AC Level Hot Key В 1 Instrument Mode Auto Setup 2 Protection 1 Setup Wizard **Basic Setup** 2 Relay Adjust 3 Auto Tvl Calib 1 Auto Setup 2 Manual Setup **Press & Actuator** 1 Tvl/Press Select Manual Setup 1-1-2 2 Pressure Units 1 Instrument Mode 1-1-2-2 3 Max Supply Press 2 Press & Actuator 4 Actuator Style 3 Tuning & Calib 5 Feedback Conn 6 Tvl Sensor Motion Valve Style 8 Zero Pwr Cond Tvl Tuning Set 1 Tvl Tuning Set Tuning & Calib 1 Tvl Tuning Set 1-1-2-3-1 2 Tvl Prop Ğain 1-1-2-3 3 Tvl Velocity Gain 4 Tvl MLFB Gain 2 Press Tuning Set-3 Relay Adjust General **Detailed Setup** 4 Auto Tvl Calib 1 HART Tag 1-2-1 **Press Tuning Set** 1 General 1-1-2-3-2 2 Message 1 Press Tuning Set Measured Var 3 Descriptor 2 Press Prop Gain 3 Response Control 4 Date 3 Press MLFB Gain 4 Relay Type 5 Valve Serial Num 6 Inst Serial Num 7 Polling Address Setup 1 Basic Setup -Measured Var 1-2-2 1 Analog Inp Units 2 Input Range Hi 2 Detailed Setup Е 3 Calibrate Tvl Tuning Tvl Tuning 3 Input Range Lo 4 Pressure Units 1 Tvl Tuning Set 2 Tvl Prop Gain 1 Tvl Tuning Set 2 Tvl Integ Enab 3 Tvl Velocity Gain Response Control Tvl Integ Gain 4 Tvl MLFB Gain 1 Tvl/Press Select Online 2 Tvl Tuning Integral Settings 3 Integral Settings Display 1 Integ DeadZ 4 Press Tuning Device Information DD Revision 2 Display 2 Integ Limit 5 Pressure Control Calibrate 6 Input Char Press Tuning 1 Press Tuning Set 2 Press Integ Enab Analog In Calib 2 Auto Tvl Calib 3 Man Tvl Calib 4 Restore Calib 3 Press Integral Gain 5 Calib Loc 6 Relay Adjust **Pressure Control** Tvl Sensor Adjust 1 Press Range Hi 2 Press Range Lo Device Information 1 HART Univ Rev **Press Tuning Set** G 1 Press Tuning Set 2 Press Prop Gain 2 Device Rev 3 Firmware Rev 3 Press MLFB Gain 4 Hardware Rev 5 Inst Level 6 Device ID Field Communicator 1 Offline 2 Online 3 Frequency Device 4 Utility Н Notes: 1-1-1 indicates fast-key sequence to reach menu 1 This menu is available by pressing the left arrow key from the previous menu.

2





THE FIELDVUE® DVC6000 SERIES DIGITAL VALVE CONTROLLER IS A CORE COMPONENT OF THE PLANTWEB® DIGITAL PLANT ARCHITECTURE. THE DIGITAL VALVE CONTROLLER POWERS PLANTWEB BY CAPTURING AND DELIVERING VALVE DIAGNOSTIC DATA. COUPLED WITH AMS "VALVELINK® SOFTWARE, THE DVC6000 PROVIDES USERS WITH AN ACCURATE PICTURE OF VALVE PERFORMANCE, INCLUDING ACTUAL STEM POSITION, INSTRUMENT INPUT SIGNAL AND PNEUMATIC PRESSURE TO THE ACTUATOR. USING THIS INFORMATION, THE DIGITAL VALVE CONTROLLER DIAGNOSES NOT ONLY ITSELF, BUT ALSO THE VALVE AND ACTUATOR TO WHICH IT IS MOUNTED.

FIELDVUE® DVC6000 Series Digital Valve Controller

#### 1

# **Section 1 Introduction**

Scope of Manual	1-2
Conventions Used in this Manual	1-2
Description	1-3
Specifications	1-3
Related Documents	1-4
Educational Services	1-4

January 2007 1-1

	DIAGNOSTIC LEVEL						
CAPABILITY	AC	HC	AD	PD	ODV		
Auto Calibration	Х	Х	Х	Х	Х		
Burst Communication		X	Х	X	Х		
Custom Characterization	X	X	Х	Х	X		
Alerts		X	Х	Х	X		
Step Response, Drive Signal Test & Dynamic Error Band			Х	Х	X		
Advanced Diagnostics (Valve Signature)			Х	X	Х		
Performance Tuner			Х	Х	Х		
Travel Control – Pressure Fallback			Х	X	Х		
Performance Diagnostics				X	Х		
Solenoid Valve Testing				Х			
Lead/Lag Input Filter <sup>(1)</sup>					Х		
1. Refer to brochure part # D351146X012/D351146X412 for information on	Fisher® optimized dig	gital valves for compresso	r antisurge applications.	II.	1		

Table 1-1. Instrument Level Capabilities

### **Scope of Manual**

This instruction manual includes specifications, installation, operating, and maintenance information for the DVC6000 Series FIELDVUE® digital valve controller, device revision 2, firmware revision 7, instrument level AC, HC, AD, PD, and ODV.

This instruction manual describes using the Model 375 Field Communicator with device description revision 1, used with firmware revision 7 instruments, to setup and calibrate the instrument. You can also use AMS™ ValveLink® Software version 7.3 or higher to setup, calibrate, and diagnose the valve and instrument. For information on using the AMS ValveLink Software with the instrument, refer to the AMS ValveLink Software help or documentation.

Do not install, operate, or maintain a DVC6000 digital valve controller without first ● being fully trained and qualified in valve, actuator, and accessory installation, operation and maintenance, and ● carefully reading and understanding the contents of this manual. If you have any questions concerning these instructions, contact your Emerson Process Management sales office before proceeding.



Figure 1-1. Sliding-Stem Control Valve with Type DVC6010 Digital Valve Controller



# Note

Neither Emerson, Emerson Process Management, nor any of their affiliated entities assumes responsibility for the selection, use, and maintenance of any product. Responsibility for the selection, use, and maintenance of any product remains with the purchaser and end-user.

#### **Conventions Used in this Manual**

Procedures that require the use of the Model 375 Field Communicator have the Field Communicator symbol in the heading.

Procedures that are accessible with the Hot Key on the Field Communicator will also have the Hot Key symbol in the heading.

**1-2** January 2007



Figure 1-2. Rotary Control Valve with Type DVC6020 Digital Valve Controller

Some of the procedures also contain the sequence of numeric keys required to display the desired Field Communicator menu. For example, to access the Setup Wizard, from the Online menu, press 1 (selects Configure / Setup) followed by a second 1 (selects Basic Setup) followed by a third 1 (selects Setup Wizard). The key sequence in the procedure heading is shown as (1-1-1). The path required to accomplish various tasks, the sequence of steps through the Field Communicator menus, is also presented in textual format. Menu selections are shown in italics, e.g., Calibrate. An overview of the Model 375 Field Communicator menu trees are shown at the beginning of this manual.

normal function of converting an input current signal to a pneumatic output pressure, the DVC6000 Series digital valve controller, using the HART® communications protocol, gives easy access to information critical to process operation. You can gain information from the principal component of the process, the control valve itself, using the Field Communicator at the valve, or at a field junction box, or by using a personal computer or operator's console within the control room.

Using a personal computer and AMS ValveLink Software or AMS Suite: Intelligent Device Manager, or a Model 375 Field Communicator, you can perform several operations with the DVC6000 Series digital valve controller. You can obtain general information concerning software revision level, messages, tag, descriptor, and date. Diagnostic information is available to aid you when troubleshooting. Input and output configuration parameters can be set, and the digital valve controller can be calibrated. Refer to table 1-1 for details on the capabilities of each diagnostic tier.

Using the HART protocol, information from the field can be integrated into control systems or be received on a single loop basis.

The DVC6000 Series digital valve controller is designed to directly replace standard pneumatic and electro-pneumatic valve mounted positioners.



### Note

375 Field Communicator menu sequences used in this manual are for instrument level HC, AD, PD, and ODV. Refer to the AC menu tree at the beginning of this manual for AC menu sequences.

# **Description**

DVC6000 Series digital valve controllers (figures 1-1 and 1-2) are communicating, microprocessor-based current-to-pneumatic instruments. In addition to the

# **Specifications**

Specifications for the DVC6000 Series digital valve controllers are shown in table 1-2. Specifications for the Field Communicator can be found in the product manual for the Field Communicator.

# **M** WARNING

This product is intended for a specific range of application specifications. Incorrect configuration of a positioning instrument could result in the malfunction of the product, property damage or personal injury.

January 2007 1-3

#### **Related Documents**

Other documents containing information related to DVC6000 Series digital valve controllers include:

- FIELDVUE® DVC6000 Series Digital Valve Controller (Bulletin 62.1:DVC6000)
- FIELDVUE<sup>®</sup> DVC6000 Series Digital Valve Controllers Quick Start Guide - Form 5654
- Supplement to HART® Based FIELDVUE®
   Digital Valve Controller Instruction Manuals—
   FIELDVUE® Digital Valve Controller Split Ranging –
   Form 5808
- Supplement to HART® Based FIELDVUE®
   Instrument Instruction Manuals—Using FIELDVUE®
   Instruments with the Smart HART® Loop Interface and Monitor (HIM) Form 5809
- Supplement to HART® Based FIELDVUE® Instrument Instruction Manuals— Audio Monitor for HART® Communications Form 5811
- Supplement to HART® Based FIELDVUE®
   Digital Valve Controller Instruction Manuals— HART®
   Field Communication Protocol Form 5812
- Supplement to HART® Based FIELDVUE®
   Instrument Instruction Manuals— Using the HART®
   Tri-Loop™ HART® -to-Analog Signal Converter with
   FIELDVUE® Digital Valve Controllers Form 5813
- Supplement to DVC5000 and DVC6000
   FIELDVUE® Digital Valve Controller Instruction
   Manuals— Hot Swap Procedure Form 5810

- Supplement to DVC6000 FIELDVUE® Digital Valve Controllers Instruction Manual— Implementation of Lock-in-Last Strategy Form 5805
- Supplement to DV6000 Series FIELDVUE<sup>®</sup>
   Digital Valve Controllers Instruction Manual— Model
   275 HART<sup>®</sup> Communicator Menu Trees for Firmware
   7 Digital Valve Controllers Form 5819
- DVC6000 Series FIELDVUE<sup>®</sup> Digital Valve Controllers for Safety Instrumented System (SIS) Solutions – Form 5807
- FIELDVUE® HF300 Series HART® Filters Instruction Manual Form 5715
- Type 2530H1 HART® Interchange Multiplexer Instruction Manual Form 5407
- AMS ValveLink® Software Help or Documentation

All documents are available from your Emerson Process Management sales office. Also visit our website at www.FIELDVUE.com.

#### **Educational Services**

For information on available courses for DVC6000 Series digital valve controllers, as well as a variety of other products, contact:

Emerson Process Management Educational Services, Registration P.O. Box 190; 301 S. 1st Ave. Marshalltown, IA 50158–2823 Phone: 800–338–8158 or

Phone: 641-754-3771 FAX: 641-754-3431

e-mail: education@emersonprocess.com

**1-∆** January 2007

#### Table 1-2. Specifications

#### **Available Configurations**

Type DVC6010: Sliding stem applications Type DVC6020: Rotary and long-stroke sliding-stem applications [over 102 mm (4-inch)

travell

Type DVC6030: Quarter-turn rotary applications

#### Remote-Mounted Instrument(1)

**DVC6005:** Base unit for 2-inch pipestand or wall mounting

DVC6015: Feedback unit for sliding-stem applications

DVC6025: Feedback unit for rotary or long-stroke sliding-stem applications

DVC6035: Feedback unit for quarter-turn rotary applications

DVC6000 Series digital valve controllers can be mounted on Fisher and other manufacturers rotary and sliding-stem actuators.

#### Input Signal

#### **Point-to-Point:**

Analog Input Signal: 4 to 20 mA dc, nominal Minimum Voltage Available at instrument terminals must be 10.5 volts dc for analog control, 11 volts dc for HART communication

Minimum Control Current: 4.0 mA

Minimum Current w/o Microprocessor Restart: 3.5 mΑ

Maximum Voltage: 30 volts dc

Overcurrent Protection: Input circuitry limits current to prevent internal damage.

Reverse Polarity Protection: No damage occurs from reversal of loop current.

Multi-drop:

Instrument Power: 11 to 30 volts dc at

approximately 8 mA

Reverse Polarity Protection: No damage occurs

from reversal of loop current.

#### Output Signal<sup>(2)</sup>

Pneumatic signal as required by the actuator, up to

full supply pressure.

Minimum Span: 0.4 bar (6 psig) Maximum Span: 9.5 bar (140 psig)

Action: Double, Single direct, and Single reverse

#### Supply Pressure<sup>(2,3)</sup>

**Recommended:** 0.3 bar (5 psi) higher than maximum actuator requirements, up to maximum supply pressure

Maximum: 10 bar (145 psig) or maximum pressure

rating of the actuator, whichever is lower

#### Steady-State Air Consumption<sup>(4,5)</sup>

#### Standard Relay:

At 1.4 bar (20 psig) supply pressure: Less than 0.38 normal m<sup>3</sup>/hr (14 scfh)

At 5.5 bar (80 psig) supply pressure: Less than 1.3 normal m<sup>3</sup>/hr (49 scfh)

#### Low Bleed Relay:

At 1.4 bar (20 psig) supply pressure: Average value 0.056 normal m<sup>3</sup>/hr (2.1 scfh)

At 5.5 bar (80 psig) supply pressure: Average value 0.184 normal m<sup>3</sup>/hr (6.9 scfh)

#### Maximum Output Capacity<sup>(4,5)</sup>

At 1.4 bar (20 psig) supply pressure: 10.0 normal m<sup>3</sup>/hr (375 scfh)

At 5.5 bar (80 psig) supply pressure: 29.5 normal m<sup>3</sup>/hr (1100 scfh)

#### Independent Linearity<sup>(2,6)</sup>

±0.75% of output span

#### Electromagnetic Interference (EMI)

Tested per IEC 61326-1 (Edition 1.1). Complies with European EMC Directive. Meets emission levels for Class A equipment (industrial locations) and Class B equipment (domestic locations). Meets immunity requirements for industrial locations (Table A.1). Immunity performance is shown in table 1-3.

#### Operating Ambient Temperature Limits<sup>(3)</sup>

-40 to 80°C (-40 to 176°F) for most approved valve-mounted instruments

-60 to 125°C (-40 to 257°F) for remote-mounted feedback unit.

-52 to 80°C (-62 to 176°F) for valve-mounted instruments utilizing the Extreme Temperature option (fluorosilicone elastomers)

#### **Humidity Limits**

0 to 100% condensing relative humidity

-continued-

#### Table 1-2. Specifications (continued)

#### **Electrical Classification**

#### **Hazardous Area:**



Explosion proof, Division 2, Dust-Ignition proof, Intrinsic Safety



Explosion proof, Non-incendive, Dust-Ignition proof, Intrinsic Safety

ATEX Flameproof, Type n, Intrinsic Safety

IECEx Flameproof, Type n, Intrinsic Safety

Refer to Special Instructions for Safe Use and Installation in Hazardous Locations in section 2, tables 1-4, 1-5, 1-6 and 1-7, and figures 11-1, 11-2 11-3, 11-4, 11-5, 11-6, 11-7, 11-8, 11-9 and 11-10 for specific approval information.

Pollution Degree 2, Overvoltage Category III per ANSI/ISA-82.02.01 (IEC 61010-1 Mod).

Electrical Housing: Meets NEMA 4X, CSA Type 4X, IEC 60529 IP66

#### **IEC 61010 Compliance Requirements** (Valve-Mounted Instruments only)

**Power Source:** The loop current must be derived from a Separated Extra-Low Voltage (SELV) power

**Environmental Conditions:** Installation Category I

#### Connections

Supply Pressure: 1/4-inch NPT female and integral pad for mounting 67CFR regulator Output Pressure: 1/4-inch NPT female **Tubina:** 3/8-inch metal, recommended

Vent: 3/8-inch NPT female

Electrical: 1/2-inch NPT female conduit

connection.

optional—M20 female conduit connection, spring

clamp terminal connection<sup>(7)</sup>

#### **Stem Travel**

**DVC6010, DVC6015:** 0 to 102 mm (4-inches) maximum travel span

0 to 9.5 mm (0.375 inches) minimum travel span

**DVC6020**, **DVC6025**: 0 to 606 mm (23.875 inches) maximum travel span

#### Shaft Rotation (DVC6020, DVC6025, DVC6030 and **DVC6035)**

0 to 50 degrees minimum 0 to 90 degrees maximum

#### Mounting

Designed for direct actuator mounting or remote pipestand or wall mounting. Mounting the instrument vertically, with the vent at the bottom of the assembly, or horizontally, with the vent pointing down, is recommended to allow drainage of moisture that may be introduced via the instrument air supply.

#### Weight

#### **Valve-Mounted Instruments**

Aluminum: 3.5 kg (7.7 lbs) Stainless Steel: 7.7 kg (17 lbs)

#### Remote-Mounted Instruments

DVC6005 Base Unit: 4.1 kg (9 lbs) DVC6015 Feedback Unit: 1.3 kg (2.9 lbs) DVC6025 Feedback Unit: 1.4 kg (3.1 lbs) DVC6035 Feedback Unit: 0.9 kg (2.0 lbs)

#### **Options**

- Supply and output pressure gauges or Tire valves, ■ Integral mounted filter regulator,
- Stainless steel housing, module base and terminal box (valve-mounted instruments only)
- Low Bleed Relay

#### **Declaration of SEP**

Fisher Controls International LLC declares this product to be in compliance with Article 3 paragraph 3 of the Pressure Equipment Directive (PED) 97 / 23 / EC. It was designed and manufactured in accordance with Sound Engineering Practice (SEP) and cannot bear the CE marking related to PED compliance.

However, the product may bear the CE marking to indicate compliance with other applicable EC Directives.

January 2007 1-6

<sup>1. 3-</sup>conductor shielded cable, 22 AWG minimum wire size, is recommended for connection between base unit and feedback unit. Pneumatic tubing between base unit output connection and actuator has been tested to 15 meters (50 feet) maximum without performance degradation.

2. Defined in ISA Standard S51.1.

3. The pressure/lemperature limits in this document and any applicable code or standard should not be exceeded.

4. Values at 1.4 bar (20 psig) based on a single-acting direct relay; values at 5.5 bar (80 psig) based on double-acting relay.

5. Normal m³/hour – Normal cubic meters per hour at 0°C and 1.01325 bar, absolute. Scfh – Standard cubic feet per hour at 60°F and 14.7 psia

6.Not applicable for travels less than 19 mm (0.75 inch) or for shaft rotation less than 60 degrees. Also, not applicable to Type DVC6020 digital valve controllers in long-stroke applications.

7. ATEX/IEC approvals only.

# Introduction

Table 1-3. Immunity Performance

			Performance Criteria <sup>(1)</sup>		
Port	Phenomenon	Basic Standard	Point-to-Point Mode	Multi-drop Mode	
	Electrostatic discharge (ESD)	IEC 61000-4-2	A <sup>(2)</sup>	Α	
Enclosure	Radiated EM field	IEC 61000-4-3	Α	Α	
	Rated power frequency magnetic field	IEC 61000-4-8	Α	Α	
	Burst	IEC 61000-4-4	A <sup>(2)</sup>	Α	
/O signal/control	Surge	IEC 61000-4-5	A <sup>(2)</sup>	Α	
-	Conducted RF	IEC 61000-4-6	Α	Α	

A = No degradation during testing. B = Temporary degradation during testing, but is self-recovering
 Excluding auxiliary switch function, which meets Performance Criteria B.

Table 1-4. Hazardous Area Classifications for Canada (CSA)

CERTIFICATION BODY	TYPE	CERTIFICATION OBTAINED	ENTI	TY RATING	TEMPERATURE CODE	ENCLOSURE RATING
		(Intrinsic Safety) Class/Division Class I,II,III Division 1 GP A,B,C,D,E, F,G per drawing 29B3428	$V_{max} = 30 \text{ Vdc}$ $I_{max} = 226 \text{ mA}$ $C_i = 5 \text{ nF}$ $L_i = 0.55 \text{ mH}$		T5(T <sub>amb</sub> ≤ 80°C)	4X
	DVC60x0 DVC60x0S (x = 1,2,3)	(Explosion Proof) Class/Division Class I Division 1 GP B,C,D			$T6(T_{amb} \le 80^{\circ}C)$	4X
		Class I Division 2 GP A,B,C,D Class II Division 1 GP E,F,G Class III Division 1			$T6(T_{amb} \le 80^{\circ}C)$	4X
	DVC6005	(Intrinsic Safety) Class/Division Class I,II,III Division 1 GP A,B,C,D, E,F,G per drawing 29B3520	$V_{max} = 30 \text{ Vdc}$ $I_{max} = 226 \text{ mA}$ $C_i = 5 \text{ nF}$ $L_i = 0.55 \text{ mH}$	$V_{oc} = 9.6 \text{ Vdc}$ $I_{sc} = 3.5 \text{ mA}$ $C_a = 3.6 \mu\text{F}$ $L_a = 100 \text{ mH}$	$T6(T_{amb} \le 60^{\circ}C)$	4X
CSA		(Explosion Proof) Class/Division Class I Division 1 GP C,D			$T6(T_{amb} \le 60^{\circ}C)$	4X
		Class I Division 2 GP A,B,C,D Class II Division 1 GP E,F,G Class III Division 1			$T6(T_{amb} \le 60^{\circ}C)$	4X
	DVC60x5 (x = 1,2,3)	(Intrinsic Safety) Class/Division Class I,II,III Division 1 GP A,B,C,D, E,F,G per drawing 29B3520	V <sub>max</sub> = 10 Vdc I <sub>max</sub> = 4 mA C <sub>i</sub> = 0 nF L <sub>i</sub> = 0 mH		$\begin{aligned} T4(T_{amb} &\leq 125^{\circ}C) \\ T5(T_{amb} &\leq 95^{\circ}C) \\ T6(T_{amb} &\leq 80^{\circ}C) \end{aligned}$	4X
		(Explosion Proof) Class/Division Class I Division 1 GP B,C,D			$T4(T_{amb} \le 125^{\circ}C)$ $T5(T_{amb} \le 95^{\circ}C)$ $T6(T_{amb} \le 80^{\circ}C)$	4X
		Class I Division 2 GP A,B,C,D Class II Division 1 GP E,F,G Class III Division 1			$\begin{aligned} T4(T_{amb} &\leq 125^{\circ}C) \\ T5(T_{amb} &\leq 95^{\circ}C) \\ T6(T_{amb} &\leq 80^{\circ}C) \end{aligned}$	4X

January 2007 1-7

Table 1-5. Hazardous Area Classifications for United States (FM)

CERTIFICATION BODY	TYPE	CERTIFICATION OBTAINED	ENTITY RATING		TEMPERATURE CODE	ENCLOSURE RATING
	DVC60x0	(Intrinsic Safety) Class/Division Class I,II,III Division 1 GP A,B,C,D, E,F,G per drawing 29B3427	$\begin{aligned} &V_{max} = 30 \text{ Vdc} \\ &I_{max} = 226 \text{ mA} \\ &C_i = 5 \text{ nF} \\ &L_i = 0.55 \text{ mH} \\ &P_i = 1.4 \text{ W} \end{aligned}$		T5(T <sub>amb</sub> ≤ 80°C)	4X
	DVC60x0S (x = 1,2,3)	(Explosion Proof) Class/Division Class I Division 1 GP B,C,D			$T6(T_{amb} \le 80^{\circ}C)$	4X
		Class I Division 2 GP A,B,C,D Class II,III Division 1 GP E,F,G Class II,III Division 2 GP F,G			$T6(T_{amb} \le 80^{\circ}C)$	4X
		(Intrinsic Safety) Class/Division Class I,II,III Division 1 GP A,B,C,D,E, F,G per drawing 29B3521	$\begin{aligned} &V_{max} = 30 \text{ Vdc} \\ &I_{max} = 226 \text{ mA} \\ &C_i = 5 \text{ nF} \\ &L_i = 0.55 \text{ mH} \\ &P_i = 1.4 \text{ W} \end{aligned}$	$V_{oc} = 9.6 \text{ Vdc}$ $I_{sc} = 3.5 \text{ mA}$ $C_a = 3.6 \mu\text{F}$ $L_a = 100 \text{ mH}$ $P_o = 8.4 \text{ mW}$	$T6(T_{amb} \le 60^{\circ}C)$	4X
FM	DVC6005	(Explosion Proof) Class/Division Class I Division 1 GP C,D			$T6(T_{amb} \le 60^{\circ}C)$	4X
		Class I Division 2 GP A,B,C,D Class II,III Division 1 GP E,F,G Class II,III Division 2 GP F,G			$T6(T_{amb} \le 60^{\circ}C)$	4X
		(Intrinsic Safety) Class/Division Class I,II,III Division 1 GP A,B,C,D, E,F,G per drawing 29B3521	$V_{max} = 10 \text{ Vdc}$ $I_{max} = 4 \text{ mA}$ $C_i = 0 \text{ nF}$ $L_i = 0 \text{ mH}$ $P_i = 10 \text{ mW}$		$T4(T_{amb} \le 125 ^{\circ}C)$ $T5(T_{amb} \le 95 ^{\circ}C)$ $T6(T_{amb} \le 80 ^{\circ}C)$	4X
	DVC60x5 (x = 1,2,3)	(Explosion Proof) Class/Division Class I Division 1 GP A,B,C,D			$T4(T_{amb} \le 125^{\circ}C)$ $T5(T_{amb} \le 95^{\circ}C)$ $T6(Tamb \le 80^{\circ}C)$	4X
		Class I Division 2 GP A,B,C,D Class II,III Division 1 GP E,F,G Class II,III Division 2 GP F,G			$T4(T_{amb} \le 125^{\circ}C)$ $T5(T_{amb} \le 95^{\circ}C)$ $T6(T_{amb} \le 80^{\circ}C)$	4X

1-8 January 2007

# Introduction

Table 1-6. Hazardous Area Classifications—ATEX

CERTIFICATE	TYPE	CERTIFICATION OBTAINED	ENTIT	TY RATING	TEMPERATURE CODE	ENCLOSURE RATING
		(b) II 1 G D Gas EEx ia IIC T5/T6—Intrinsic Safety Dust T85°C (Tamb ≤ 80°C)	$\label{eq:continuous} \begin{split} U_i &= 30 \text{ Vdc} \\ I_i &= 226 \text{ mA} \\ C_i &= 5 \text{ nF} \\ L_i &= 0.55 \text{ mH} \\ P_i &= 1.4 \text{ W} \end{split}$		T5(T <sub>amb</sub> ≤ 80°C) T6 (T <sub>amb</sub> ≤ 75°C)	IP66
	DVC60x0 DVC60x0S (x = 1,2,3)	© II 2 G D Gas EEx d IIB+H2 T5/T6 —Flameproof Dust T90°C (Tamb ≤ 85°C)			$T5(T_{amb} \le 85^{\circ}C)$ $T6 (T_{amb} \le 75^{\circ}C)$	IP66
		<ul> <li>II 3 G D</li> <li>Gas</li> <li>EEx nCL IIC T5/T6 —Type n</li> <li>Dust</li> <li>T85°C (Tamb ≤ 80°C)</li> </ul>			$T5(T_{amb} \le 80^{\circ}C)$ $T6 (T_{amb} \le 75^{\circ}C)$	IP66
	DVC6005	© II 1 G D Gas EEx ia IIC T5/T6 —Intrinsic Safety Dust T85°C (Tamb ≤ 80°C)	$\label{eq:Ui} \begin{split} U_i &= 30 \text{ Vdc} \\ I_i &= 226 \text{ mA} \\ C_i &= 5 \text{ nF} \\ L_i &= 0.55 \text{ mH} \\ P_i &= 1.4 \text{ mW} \end{split}$	$\begin{tabular}{l} $U_0 = 9.6 \mbox{ Vdc} \\ $I_0 = 3.5 \mbox{ mA} \\ $C_0 = 3.6 \mbox{ uF} \\ $L_0 = 100 \mbox{ mH} \\ $P_0 = 8.4 \mbox{ mW} \\ \end{tabular}$	$T5(T_{amb} \le 80^{\circ}C)$ $T6(T_{amb} \le 75^{\circ}C)$	IP66
ATEX					$T5(T_{amb} \le 80^{\circ}C)$ $T6 (T_{amb} \le 70^{\circ}C)$	IP66
		<ul> <li>II 3 G D</li> <li>Gas</li> <li>EEx nL IIC T5/T6 —Type n</li> <li>Dust</li> <li>T85°C (Tamb ≤ 80°C)</li> </ul>			$T5(T_{amb} \le 80^{\circ}C)$ $T6 (T_{amb} \le 75^{\circ}C)$	IP66
		© II 1 G D Gas EEx ia IIC T4/T5/T6 —Intrinsic Safety Dust T130°C (Tamb ≤ 125°C)	$\label{eq:controller} \begin{array}{lll} U_i = 10 \text{ Vdc} \\ I_i = 4 \text{ mA} \\ C_i = 0 \text{ nF} \\ L_i = 0 \text{ mH} \\ P_i = 5 \text{ mW} \end{array}$		$T4(T_{amb} \le 125^{\circ}C)$ $T5(T_{amb} \le 95^{\circ}C)$ $T6(T_{amb} \le 80^{\circ}C)$	IP66
	DVC60x5 (x = 1,2,3)	<ul> <li>Il 2 G D</li> <li>Gas</li> <li>EEx d IIC T4/T5/T6 —Flameproof</li> <li>Dust</li> <li>T130°C (Tamb ≤ 125°C)</li> </ul>			$T4(T_{amb} \le 125^{\circ}C)$ $T5(T_{amb} \le 95^{\circ}C)$ $T6(T_{amb} \le 80^{\circ}C)$	IP66
					$T4(T_{amb} \le 125 ^{\circ}C)$ $T5(T_{amb} \le 95 ^{\circ}C)$ $T6(T_{amb} \le 80 ^{\circ}C)$	IP66

January 2007 1-9

Table 1-7. Hazardous Area Classifications—IECEx

CERTIFICATE	TYPE	CERTIFICATION OBTAINED	ENTIT	Y RATING	TEMPERATURE CODE	ENCLOSURE RATING
	DVC60x0 DVC60x0S	Gas Ex ia IIC T5/T6 —Intrinsic Safety	$\label{eq:Ui} \begin{aligned} &U_i = 30 \text{ Vdc} \\ &I_i = 226 \text{ mA} \\ &C_i = 5 \text{ nF} \\ &L_i = 0.55 \text{ mH} \\ &P_i = 1.4 \text{ W} \end{aligned}$	$I_{i} = 226 \text{ mA}$ $C_{i} = 5 \text{ nF}$ $L_{i} = 0.55 \text{ mH}$		IP66
	(x = 1,2,3)	Gas Ex d IIB+H2 T5/T6 —Flameproof			$T5(T_{amb} \le 80^{\circ}C)$ $T6(T_{amb} \le 75^{\circ}C)$	IP66
		Gas Ex nC IIC T5/T6 —Type n			$T5(T_{amb} \le 80^{\circ}C)$ $T6(T_{amb} \le 75^{\circ}C)$	IP66
	DVC6005	Gas Ex ia IIC T5/T6 —Intrinsic Safety	$U_i = 30 \text{ Vdc}$ $I_i = 226 \text{ mA}$ $C_i = 5 \text{ nF}$ $L_i = 0.55 \text{ mH}$ $P_i = 1.4 \text{ W}$	$\begin{array}{l} U_{o} = 9.6 \text{ Vdc} \\ I_{o} = 3.5 \text{ mA} \\ C_{o} = 3.6  \mu\text{F} \\ L_{o} = 100 \text{ mH} \\ P_{o} = 8.4 \text{ mW} \end{array}$	$T5(T_{amb} \le 80^{\circ}C)$ $T6 (T_{amb} \le 75^{\circ}C)$	IP66
IECEx	BV00000	Gas Ex d IIB T5/T6 —Flameproof			$T5(T_{amb} \le 80^{\circ}C)$ $T6 (T_{amb} \le 75^{\circ}C)$	IP66
		Gas Ex nC IIC T5/T6 —Type n			$T5(T_{amb} \le 80^{\circ}C)$ $T6(T_{amb} \le 75^{\circ}C)$	IP66
	DVC60x5 (x = 1,2,3)	Gas Ex ia IIC T4/T5/T6 —Intrinsic Safety	$\label{eq:continuous} \begin{split} U_i &= 10 \text{ Vdc} \\ I_i &= 4 \text{ mA} \\ C_i &= 0 \text{ nF} \\ L_i &= 0 \text{ mH} \\ P_i &= 10 \text{ mW} \end{split}$		$\begin{aligned} T4(T_{amb} &\leq 125^{\circ}C) \\ T5(T_{amb} &\leq 95^{\circ}C) \\ T6(T_{amb} &\leq 80^{\circ}C) \end{aligned}$	IP66
		Gas Ex d IIC T4/T5/T6 —Flameproof			$T4(T_{amb} \le 125^{\circ}C)$ $T5(T_{amb} \le 95^{\circ}C)$ $T6(T_{amb} \le 80^{\circ}C)$	IP66
		Gas Ex nA IIC T4/T5/T6 —Type n			$T4(T_{amb} \le 125^{\circ}C)$ $T5(T_{amb} \le 95^{\circ}C)$ $T6(T_{amb} \le 80^{\circ}C)$	IP66

**1-10** January 2007

# **Section 2 Installation**

Installations in Hazardous Areas	
CSA	2-3
FM	2-3
ATEX Intrinsic Safety, Dust	2-3
ATEX Flameproof, Dust	2-3
ATEX Type n, Dust	2-4
IECEx Intrinsic Safety, Type n, Flameproof	2-4
Mounting	
Type DVC6010 on Sliding-Stem Actuators (up to 4 inches travel)	2-4
Type DVC6020 on Long-Stroke Sliding-Stem Actuators (4 to 24 inches travel) and Rotary Actuators	2-6
Type DVC6030 on Quarter-Turn Actuators	2-9
Guidelines for Mounting Type DVC6005 Base Unit	2-11 2-11 2-11
Type DVC6015 on Sliding-Stem Actuators (up to 4 inches travel)	2-11
Type DVC6025 on Long-Stroke Sliding-Stem Actuators (4 to 24 inches travel) and Rotary Actuators	2-13
Type DVC6035 on Quarter-Turn Actuators	2-14
67CFR Filter Regulator	
Integral-Mounted Regulator	2-15
Yoke-Mounted Regulator	2-15 2-15
Pneumatic Connections	
	0.16
Supply Connections	2-16
Output Connections	2-17 2-17
Double-Acting Actuators	2-17 2-17
Special Construction to Support Solenoid Testing	2-17
Vent	2-18
Electrical Connections	
4 to 20 mA Loop Connections	2-18

January 2007

Remote Travel Sensor Connections	2-19
Test Connections	2-22
Communication Connections	2-23
Wiring Practices	
Control System Requirements	2-23
HART® Filter	2-23
Voltage Available	2-23
Compliance Voltage	2-24
Maximum Cable Capacitance	2-25
Installation in Conjunction with a Rosemount Model 333 HART <sup>®</sup> Tri-Loop <sup>™</sup> HART <sup>®</sup> -to-Analog	
Signal Converter	2-26

#### 9

#### Installation

# **WARNING**

Avoid personal injury or property damage from sudden release of process pressure or bursting of parts. Before proceeding with any Installation procedures:

- Always wear protective clothing, gloves, and eyewear to prevent personal injury.
- Disconnect any operating lines providing air pressure, electric power, or a control signal to the actuator. Be sure the actuator cannot suddenly open or close the valve.
- Use bypass valves or completely shut off the process to isolate the valve from process pressure. Relieve process pressure from both sides of the valve.
- Vent the pneumatic actuator loading pressure and relieve any actuator spring precompression.
- Use lock-out procedures to be sure that the above measures stay in effect while you work on the equipment.
- Check with your process or safety engineer for any additional measures that must be taken to protect against process media.

# **Special Instructions for Safe Use and Installations in Hazardous Locations**

Certain nameplates may carry more than one approval, and each approval may have unique installation requirements and/or conditions of safe use. Special instructions are listed by agency/approval.

After reading and understanding these special conditions of use, proceed with standard installation procedures.

# **WARNING**

Failure to follow these conditions of safe use could result in personal injury or property damage from fire or explosion, or area re-classification.

#### **CSA**

#### **Special Conditions of Safe Use**

No special conditions for safe use.

Refer to table 1-4 for approval information, figures 11-1 and 11-2 for CSA loop schematics, and figure 11-3 for CSA nameplates.

#### FM

#### **Special Conditions of Safe Use**

No special conditions for safe use.

Refer to table 1-5 for approval information, figures 11-4 and 11-5 for FM loop schematics, and figure 11-6 for FM nameplates.

#### ATEX Intrinsic Safety, Dust

#### **Special Conditions for Safe Use**

- 1. This apparatus can only be connected to an intrinsically safe certified equipment and this combination must be compatible as regards the intrinsically safe rules.
- 2. The electrical parameters of this equipment must not exceed any following values:

 $U_O \le 30 \text{ V}; I_O \le 226 \text{ mA}; P_O \le 1.4 \text{ W}$ 

3. Operating ambient temperature: -52°C or -40°C to + 80°C

Refer to table 1-6 for additional approval information, and figure 11-7 for the ATEX Intrinsic Safety, Dust nameplates.

#### ATEX Flameproof, Dust

#### **Special Conditions for Safe Use**

Operating ambient temperature: -52°C or -40°C to + 85°C

Refer to table 1-6 for additional approval information, and figure 11-8 for ATEX Flameproof, Dust nameplates.

January 2007

#### ATEX Type n, Dust

#### **Special Conditions for Safe Use**

Operating ambient temperature:  $-52^{\circ}\text{C}$  or  $-40^{\circ}\text{C}$  to  $+80^{\circ}\text{C}$ 

Refer to table 1-6 for additional approval information, and figure 11-9 for ATEX Type n, Dust nameplates.

# IECEx Intrinsic Safety, Type n, Flameproof Conditions of Certification

Ex ia / Ex d / Ex n

 Warning: Electrostatic charge hazard. Do not rub or clean with solvents. To do so could result in an explosion.

EX d / Ex n

2. Do not open while energized.

Refer to table 1-7 for additional approval information, and figure 11-10 for IECEx nameplates.

### Mounting

Type DVC6010 on Sliding-Stem Actuators Up to 102 mm (4 Inches) of Travel

# **WARNING**

Refer to the Installation WARNING at the beginning of this section.

If ordered as part of a control valve assembly, the factory mounts the digital valve controller on the actuator, makes pneumatic connections to the actuator, sets up, and calibrates the instrument. If you purchased the digital valve controller separately, you will need a mounting kit to mount the digital valve controller on the actuator. See the instructions that come with the mounting kit for detailed information on mounting the digital valve controller to a specific actuator model.

The Type DVC6010 digital valve controller mounts on sliding-stem actuators with up to 102 mm (4-inch)

travel. Figure 2-1 shows a typical mounting on an actuator with up to 51 mm (2-inch) travel. Figure 2-2 shows a typical mounting on actuators with 51 to 102 mm (2- to 4-inch) travel. For actuators with greater than 102 mm (4-inch) travel, see the guidelines for mounting a Type DVC6020 digital valve controller.

Refer to the following guidelines when mounting on sliding-stem actuators with up to 4 inches of travel. Where a key number is referenced, refer to figure 10-1.

- 1. Isolate the control valve from the process line pressure and release pressure from both sides of the valve body. Shut off all pressure lines to the actuator, releasing all pressure from the actuator. Use lock-out procedures to be sure that the above measures stay in effect while you work on the equipment.
- 2. Attach the connector arm to the valve stem connector.
- 3. Attach the mounting bracket to the digital valve controller housing.
- 4. If valve travel exceeds 2 inches, a feedback arm extension is attached to the existing 2-inch feedback arm. Remove the existing bias spring (key 78) from the 2-inch feedback arm (key 79). Attach the feedback arm extension to the feedback arm (key 79) as shown in figure 2-2.
- 5. Mount the digital valve controller on the actuator as described in the mounting kit instructions.
- 6. Set the position of the feedback arm (key 79) on the digital valve controller to the no air position by inserting the alignment pin (key 46) through the hole on the feedback arm as follows:
- For air-to-open actuators (i.e., the actuator stem retracts into the actuator casing or cylinder as air pressure to the casing or lower cylinder increases), insert the alignment pin into the hole marked "A". For this style actuator, the feedback arm rotates counterclockwise, from A to B, as air pressure to the casing or lower cylinder increases.
- For air-to-close actuators (i.e., the actuator stem extends from the actuator casing or cylinder as air pressure to the casing or upper cylinder increases), insert the alignment pin into the hole marked "B". For this style actuator, the feedback arm rotates clockwise, from B to A, as air pressure to the casing or upper cylinder increases.

**2-4** January 2007




Figure 2-1. Type DVC6010 Digital Valve Controller Mounted on Sliding-Stem Actuators with up to 2 Inches Travel




Figure 2-2. Type DVC6010 Digital Valve Controller Mounted on Sliding-Stem Actuators with 2 to 4 Inches Travel

January 2007 **2-5** 




Figure 2-3. Locating Adjustment Arm Pin in Feedback Arm



### Note

When performing the following steps, ensure there is enough clearance between the adjustment arm and the feedback arm to prevent interference with the bias spring.

- 7. Apply lubricant to the pin of the adjustment arm. As shown in figure 2-3, place the pin into the slot of the feedback arm or feedback arm extension so that the bias spring loads the pin against the side of the arm with the valve travel markings.
- 8. Install the external lock washer on the adjustment arm. Position the adjustment arm in the slot of the connector arm and loosely install the flanged hex nut.
- 9. Slide the adjustment arm pin in the slot of the connector arm until the pin is in line with the desired valve travel marking. Tighten the flanged hex nut.
- 10. Remove the alignment pin (key 46) and store it in the module base next to the I/P assembly.
- 11. After calibrating the instrument, attach the shield with two machine screws.

Type DVC6020 on Long-Stroke (4 to 24 Inch Travel) Sliding-Stem Actuators and Rotary Actuators

# **WARNING**

Refer to the Installation WARNING at the beginning of this section.

If ordered as part of a control valve assembly, the factory mounts the digital valve controller on the actuator, makes pneumatic connections to the actuator, sets up, and calibrates the instrument. If you purchased the digital valve controller separately, you will need a mounting kit to mount the digital valve controller on the actuator. See the instructions that come with the mounting kit for detailed information on mounting the digital valve controller to a specific actuator model.



#### Note

All cams supplied with FIELDVUE mounting kits are characterized to provide a linear response.

Type DVC6020 digital valve controllers use a cam (designed for linear response) and roller as the feedback mechanism. Figure 2-4 shows an example of mounting on sliding-stem actuators with travels from 4 inches to 24 inches. Some long-stroke applications will require an actuator with a tapped lower yoke boss. Figures 2-5 and 2-7 show the Type DVC6020 mounted on rotary actuators.

As shown in figure 2-5, two feedback arms are available for the digital valve controller. Most long-stroke sliding-stem and rotary actuator installations use the long feedback arm [62 mm (2.45 inches) from roller to pivot point]. Installations on Fisher Type 1051 size 33 and Type 1052 size 20 and 33 actuators use the short feedback arm [54 mm (2.13 inches) from roller to pivot point]. Make sure the correct feedback arm is installed on the digital valve controller before beginning the mounting procedure.

Refer to figures 2-4, 2-5, and 2-7 for parts locations. Also, where a key number is referenced, refer to figure 10-2. Refer to the following guidelines when mounting on sliding-stem actuators with 4 to 24 inches of travel or on rotary actuators:

**2-6** January 2007




Figure 2-4. Type DVC6020 Digital Valve Controller Mounted on Long-Stroke Sliding-Stem Actuator.




Figure 2-5. Type DVC6020 Digital Valve Controller Mounted on Rotary Actuator

January 2007 **2-7** 




Figure 2-6. Mounting a Type DVC6030 Digital Valve Controller on a Rotary Actuator (Type 1032 Size 425A Shown)




Figure 2-7. Type DVC6020 Digital Valve Controller with Long Feedback Arm and Follower Arm Extension Mounted on a Rotary Actuator

- 1. Isolate the control valve from the process line pressure and release pressure from both sides of the valve body. Shut off all pressure lines to the pneumatic actuator, releasing all pressure from the actuator. Use lock-out procedures to be sure that the above measures stay in effect while working on the equipment.
- 2. If a cam is not already installed on the actuator, install the cam as described in the instructions included with the mounting kit. For sliding-stem actuators, the cam is installed on the stem connector.

- 3. If a mounting plate is required, fasten the mounting plate to the actuator.
- 4. For applications that require remote venting, a pipe-away bracket kit is available. Follow the instructions included with the kit to replace the existing mounting bracket on the digital valve controller with the pipe-away bracket and to transfer the feedback parts from the existing mounting bracket to the pipe-away bracket.
- 5. Larger size actuators may require a follower arm extension, as shown in figure 2-7. If required, the follower arm extension is included in the mounting kit. Follow the instructions included with the mounting kit to install the follower arm extension.
- 6. Mount the Type DVC6020 on the actuator as follows:
- If required, a mounting adaptor is included in the mounting kit. Attach the adaptor to the actuator as shown in figure 2-5. Then attach the digital valve controller assembly to the adaptor. The roller on the digital valve controller feedback arm will contact the actuator cam as it is being attached.
- If no mounting adaptor is required, attach the digital valve controller assembly to the actuator or mounting plate. The roller on the digital valve controller feedback arm will contact the actuator cam as it is being attached.
- 7. For long-stroke sliding-stem actuators, after the mounting is complete, check to be sure the roller aligns with the position mark on the cam (see figure 2-4). If necessary, reposition the cam to attain alignment.

**2-8** January 2007




Figure 2-8. Explanation of Travel Indicator Starting Position and Movement, if **Clockwise** Orientation is Selected for "Travel Sensor Motion" in AMS ValveLink® Software or the 375 Field Communicator

# Type DVC6030 on Quarter-Turn Actuators

# **WARNING**

Refer to the Installation WARNING at the beginning of this section.

If ordered as part of a control valve assembly, the factory mounts the digital valve controller on the actuator, makes pneumatic connections to the actuator, sets up, and calibrates the instrument. If you purchased the digital valve controller separately, you will need a mounting kit to mount the digital valve controller on the actuator. See the instructions that come with the mounting kit for detailed information on mounting the digital valve controller to a specific actuator model.

Figure 2-6 shows the Type DVC6030 digital valve controller mounted on a quarter-turn actuator. Refer to figure 2-6 for parts locations. Refer to the following guidelines when mounting on quarter-turn actuators:




# Note

Due to NAMUR mounting limitations, do not use the heavier stainless steel Type DVC6030S in vibration service.


- 1. Isolate the control valve from the process line pressure and release pressure from both sides of the valve body. Shut off all pressure lines to the pneumatic actuator, releasing all pressure from the actuator. Use lock-out procedures to be sure that the above measures stay in effect while working on the equipment.
- 2. If necessary, remove the existing hub from the actuator shaft.
- 3. If a positioner plate is required, attach the positioner plate to the actuator as described in the mounting kit instructions.
- 4. If required, attach the spacer to the actuator shaft.

Refer to figures 2-8 and 2-9. The travel indicator assembly can have a starting position of 7:30 or 10:30. Determine the desired starting position then proceed with the next step. Considering the top of the digital valve controller as the 12 o'clock position, in the


January 2007 **2-9** 



STARTING POSITION OF TRAVEL INDICATOR ASSEMBLY (DIGITAL VALVE CONTROLLER OUTPUT A AT 0 PSI). IN THIS POSITION, THE "A" HOLE IN THE FEEDBACK ARM WILL BE ALIGNED WITH THE REFERENCE HOLE IN THE DIGITAL VALVE CONTROLLERS HOUSING.



DVC6030 FEEDBAC ARM MOVEMENT



ACTUATOR SHAFT MOVEMENT

STARTING POSITION OF THE TRAVEL INDICATOR ASSEMBLY IF INCREASING PRESSURE FROM OUTPUT A DRIVES THE INDICATOR CLOCKWISE THE POTENTIOMETER SHAFT WILL ROTATE COUNTERCLOCKWISE AS VIEWED FROM THE BACK OF THE FIELDVUE INSTRUMENT.

Figure 2-9. Explanation of Travel Indicator Starting Position and Movement if **Counterclockwise** Orientation is Selected for "Travel Sensor Motion" in AMS ValveLink® Software or the 375 Field Communicator

next step attach the travel indicator, so that the pin is positioned as follows:

- If increasing pressure from the digital valve controller output A rotates the potentiometer shaft clockwise (as viewed from the back of the instrument), mount the travel indicator assembly such that the arrow is in the 10:30 position, as shown in figure 2-8.
- If increasing pressure from the digital valve controller output A rotates the potentiometer shaft counterclockwise (as viewed from the back of the instrument), mount the travel indicator assembly such that the arrow is in the 7:30 position, as shown in figure 2-9.



### **Note**

AMS ValveLink Software and the 375 Field Communicator use the convention of clockwise (figure 2-8) and counterclockwise (figure 2-9) when viewing the potentiometer shaft from the back of the FIELDVUE instrument.




Figure 2-10. Positioning Travel Indicator Pin in the Feedback Arm (Viewed as if Looking from the Type DVC6030 toward the Actuator)

**2-10** January 2007

- 5. Attach the travel indicator, to the shaft connector or spacer as described in the mounting kit instructions.
- Attach the mounting bracket to the digital valve controller.
- 7. Position the digital valve controller so that the pin on the travel indicator engages the slot in the feedback arm and that the bias spring loads the pin as shown in figure 2-10. Attach the digital valve controller to the actuator or positioner plate.
- 8. If a travel indicator scale is included in the mounting kit, attach the scale as described in the mounting kit instructions.

# Guidelines for Mounting the Type DVC6005 Base Unit

For remote-mounted digital valve controllers, the Type DVC6005 base unit ships separately from the control valve and does not include tubing, fittings or wiring. See the instructions that come with the mounting kit for detailed information on mounting the digital valve controller to a specific actuator model.

For remote-mounted instruments, mount the Type DVC6005 base unit on a 50.8 mm (2-inch) pipestand or wall. The included bracket is used for either mounting method.

#### Wall Mounting

Refer to figures 2-11 and 2-12. Drill two holes in the wall using the dimensions shown in figure 2-11. Attach the mounting bracket to the base unit using four spacers and 25.4 mm (1-inch) 1/4-20 hex head screws. Attach the base unit to the wall using suitable screws or bolts.

#### Pipestand Mounting

Refer to figure 2-12. Position a standoff on the back of the base unit. Using two 101.6 mm (4-inch) 1/4-20 hex head screws loosely attach the base unit to the pipestand with the mounting bracket. Position the second standoff, then using the remaining 101.6 mm (4-inch) hex head screws, securely fasten the base unit to the pipe stand.




Figure 2-11. Type DVC6005 Base Unit with Mounting Bracket (Rear View)

#### Type DVC6015 on Sliding-Stem Actuators Up to 102 mm (4 Inches) of Travel

# **WARNING**

Refer to the Installation WARNING at the beginning of this section.

If ordered as part of a control valve assembly, the factory mounts the digital valve controller on the actuator, makes pneumatic connections to the actuator, sets up, and calibrates the instrument. If you purchased the digital valve controller separately, you will need a mounting kit to mount the digital valve controller on the actuator. See the instructions that come with the mounting kit for detailed information on mounting the digital valve controller to a specific actuator model.




# Note

Refer to Type DVC6005 Base Unit Mounting on page 2-11 when installing a Type DVC6015 remote feedback unit.

The Type DVC6015 remote feedback unit mounts on sliding-stem actuators with up to 102 mm (4-inch) travel. Figure 2-1 shows a typical mounting on an actuator with up to 51 mm (2-inch) travel. Figure 2-2

January 2007 **2-11** 






Figure 2-12. Type DVC6005 Base Unit Mounting

shows a typical mounting on actuators with 51 to 102 mm (2- to 4-inch) travel. For actuators with greater than 102 mm (4-inch) travel, see the guidelines for mounting a Type DVC6025 remote feedback unit.



#### Note

While the housing differs on the DVC6015 and the DVC6010, feedback parts are the same.

Refer to the following guidelines when mounting on sliding-stem actuators with up to 4 inches of travel. Where a key number is referenced, figure 10-6.

- 1. Isolate the control valve from the process line pressure and release pressure from both sides of the valve body. Shut off all pressure lines to the actuator, releasing all pressure from the actuator. Use lock-out procedures to be sure that the above measures stay in effect while you work on the equipment.
- 2. Attach the connector arm to the valve stem connector.
- 3. Attach the mounting bracket to the digital valve controller housing.
- 4. If valve travel exceeds 2 inches, a feedback arm extension is attached to the existing 2-inch feedback arm. Remove the existing bias spring (key 78) from the 2-inch feedback arm (key 79). Attach the feedback arm extension to the feedback arm (key 79) as shown in figure 2-2.
- 5. Mount the digital valve controller on the actuator as described in the mounting kit instructions.
- 6. Set the position of the feedback arm (key 79) on the digital valve controller to the no air position by inserting the alignment pin (key 46) through the hole on the feedback arm as follows:
- For air-to-open actuators (i.e., the actuator stem retracts into the actuator casing or cylinder as air pressure to the casing or lower cylinder increases), insert the alignment pin into the hole marked "A". For this style actuator, the feedback arm rotates counterclockwise, from A to B, as air pressure to the casing or lower cylinder increases.
- For air-to-close actuators (i.e., the actuator stem extends from the actuator casing or cylinder as air pressure to the casing or upper cylinder increases), insert the alignment pin into the hole marked "B". For this style actuator, the feedback arm rotates clockwise, from B to A, as air pressure to the casing or upper cylinder increases.



# Note

When performing the following steps, ensure there is enough clearance between the adjustment arm and the feedback arm to prevent interference with the bias spring.

7. Apply lubricant to the pin of the adjustment arm. As shown in figure 2-3, place the pin into the slot of the

**2-12** January 2007

feedback arm or feedback arm extension so that the bias spring loads the pin against the side of the arm with the valve travel markings.

- 8. Install the external lock washer on the adjustment arm. Position the adjustment arm in the slot of the connector arm and loosely install the flanged hex nut.
- 9. Slide the adjustment arm pin in the slot of the connector arm until the pin is in line with the desired valve travel marking. Tighten the flanged hex nut.
- 10. Remove the alignment pin (key 46) and store it in the module base next to the I/P assembly.
- 11. After calibrating the instrument, attach the shield with two machine screws.

Type DVC6025 on Long-Stroke (4 to 24 Inch Travel) Sliding-Stem Actuators and Rotary Actuators



Refer to the Installation WARNING at the beginning of this section.

If ordered as part of a control valve assembly, the factory mounts the digital valve controller on the actuator, makes pneumatic connections to the actuator, sets up, and calibrates the instrument. If you purchased the digital valve controller separately, you will need a mounting kit to mount the digital valve controller on the actuator. See the instructions that come with the mounting kit for detailed information on mounting the digital valve controller to a specific actuator model.



### **Note**

Refer to Type DVC6005 Base Unit Mounting on page 2-11 when installing a Type DVC6025 remote feedback unit.

Type DVC6025 remote feedback units use a cam and roller as the feedback mechanism. Figure 2-4 shows an example of mounting on sliding-stem actuators with travels from 4 inches to 24 inches. Some long-stroke applications will require an actuator with a tapped lower yoke boss. Figures 2-5 and 2-7 show examples of mounting on rotary actuators.



### **Note**

While the housing differs on the DVC6025 and the DVC6020, feedback parts are the same.

As shown in figure 2-5, two feedback arms are available for the digital valve controller. Most long-stroke sliding-stem and rotary actuator installations use the long feedback arm [62 mm (2.45 inches) from roller to pivot point]. Installations on Fisher Type 1051 size 33 and Type 1052 size 20 and 33 actuators use the short feedback arm [54 mm (2.13 inches) from roller to pivot point]. Make sure the correct feedback arm is installed on the digital valve controller before beginning the mounting procedure.

Refer to figures 2-4, 2-5, and 2-7 for parts locations. Refer to the following guidelines when mounting on sliding-stem actuators with 4 to 24 inches of travel or on rotary actuators:

- 1. Isolate the control valve from the process line pressure and release pressure from both sides of the valve body. Shut off all pressure lines to the pneumatic actuator, releasing all pressure from the actuator. Use lock-out procedures to be sure that the above measures stay in effect while working on the equipment.
- 2. If a cam is not already installed on the actuator, install the cam as described in the instructions included with the mounting kit. For sliding-stem actuators, the cam is installed on the stem connector.
- 3. If a mounting plate is required, fasten the mounting plate to the actuator.
- 4. For applications that require remote venting, a pipe-away bracket kit is available. Follow the instructions included with the kit to replace the existing mounting bracket on the digital valve controller with the pipe-away bracket and to transfer the feedback parts from the existing mounting bracket to the pipe-away bracket.
- 5. Larger size actuators may require a follower arm extension, as shown in figure 2-7. If required, the follower arm extension is included in the mounting kit. Follow the instructions included with the mounting kit to install the follower arm extension.
- 6. Mount the Type DVC6025 on the actuator as follows:
- If required, a mounting adaptor is included in the mounting kit. Attach the adaptor to the actuator as shown in figure 2-5. Then attach the digital valve controller assembly to the adaptor. The roller on the

2-13

January 2007

digital valve controller feedback arm will contact the actuator cam as it is being attached.

- If no mounting adaptor is required, attach the digital valve controller assembly to the actuator or mounting plate. The roller on the digital valve controller feedback arm will contact the actuator cam as it is being attached.
- 7. For long-stroke sliding-stem actuators, after the mounting is complete, check to be sure the roller aligns with the position mark on the cam (see figure 2-4). If necessary, reposition the cam to attain alignment.

# Type DVC6035 on Quarter-Turn Actuators

# **WARNING**

Refer to the Installation WARNING at the beginning of this section.


If ordered as part of a control valve assembly, the factory mounts the digital valve controller on the actuator, makes pneumatic connections to the actuator, sets up, and calibrates the instrument. If you purchased the digital valve controller separately, you will need a mounting kit to mount the digital valve controller on the actuator. See the instructions that come with the mounting kit for detailed information on mounting the digital valve controller to a specific actuator model.



### Note

Refer to Type DVC6005 Base Unit Mounting on page 2-11 when installing a Type DVC6035 remote feedback unit.

Figure 2-6 shows an example of mounting on a quarter-turn actuator. Refer to figure 2-6 for parts locations. Refer to the following guidelines when mounting on quarter-turn actuators:



STARTING POSITION OF THE TRAVEL INDICATOR ASSEMBLY IF INCREASING PRESSURE FROM OUTPUT A DRIVES THE INDICATOR CLOCKWISE. THE POTENTIOMETER SHAFT WILL ROTATE COUNTERCLOCKWISE AS VIEWED FROM THE BACK OF THE INSTRUMENT.

STARTING POSITION OF THE TRAVEL INDICATOR ASSEMBLY IF INCREASING PRESSURE FROM OUTPUT A DRIVES THE INDICATOR COUNTERCLOCKWISE. THE POTENTIOMETER SHAFT WILL ROTATE CLOCKWISE AS VIEWED FROM THE BACK OF THE INSTRUMENT

Figure 2-13. Type DVC6035 Travel Indicator Installation



### **Note**

While the housing differs on the DVC6035 and the DVC6030, feedback parts are the same.

- 1. Isolate the control valve from the process line pressure and release pressure from both sides of the valve body. Shut off all pressure lines to the pneumatic actuator, releasing all pressure from the actuator. Use lock-out procedures to be sure that the above measures stay in effect while working on the equipment.
- 2. If necessary, remove the existing hub from the actuator shaft.
- 3. If a positioner plate is required, attach the positioner plate to the actuator as described in the mounting kit instructions.
- 4. If required, attach the spacer to the actuator shaft.

Refer to figure 2-13. The travel indicator assembly can have a starting position of 7:30 or 10:30. Determine the desired starting position then proceed with the next step. Considering the top of the remote travel sensor as the 12 o'clock position, in the next step attach the travel indicator, so that the pin is positioned as follows:

**2-14** January 2007




Figure 2-14. Mounting the Type 67CFR Regulator on a DVC6000 Series Digital Valve Controller

- If increasing pressure from the digital valve controller output A rotates the digital valve controllers potentiometer shaft counterclockwise (as viewed from the back of the instrument), mount the travel indicator assembly such that the arrow is in the 7:30 position, as shown in figures 2-9 and 2-13.
- If increasing pressure from the digital valve controller output A rotates the digital valve controllers potentiometer shaft clockwise (as viewed from the back of the instrument), mount the travel indicator assembly such that the arrow is in the 10:30 position, as shown in figures 2-8 and 2-13.



### Note

AMS ValveLink Software and the 375 Field Communicator use the convention of clockwise (figure 2-8) and counterclockwise (figure 2-9) when viewing the potentiometer shaft from the back of the FIELDVUE instrument.

- 5. Attach the travel indicator, to the shaft connector or spacer as described in the mounting kit instructions.
- 6. Attach the mounting bracket to the digital valve controller.
- 7. Position the digital valve controller so that the pin on the travel indicator, engages the slot in the feedback arm and that the bias spring loads the pin as shown in figure 2-10. Attach the digital valve controller to the actuator or positioner plate.

8. If a travel indicator scale is included in the mounting kit, attach the scale as described in the mounting kit instructions.

# Mounting the Type 67CFR Filter Regulator

A Type 67CFR filter regulator, when used with the DVC6000 Series digital valve controllers, can be mounted three ways.

#### Integral-Mounted Regulator

Refer to figure 2-14. Lubricate an O-ring and insert it in the recess around the SUPPLY connection on the digital valve controller. Attach the Type 67CFR filter regulator to the side of the digital valve controller. Thread a 1/4-inch socket-head pipe plug into the unused outlet on the filter regulator. This is the standard method of mounting the filter regulator.

#### Yoke-Mounted Regulator

Mount the filter regulator with 2 cap screws to the pre-drilled and tapped holes in the actuator yoke.

Thread a 1/4-inch socket-head pipe plug into the unused outlet on the filter regulator. The O-ring is not required.

### Casing-Mounted Regulator

Use the separate Type 67CFR filter regulator casing mounting bracket provided with the filter regulator. Attach the mounting bracket to the Type 67CFR and then attach this assembly to the actuator casing. Thread a 1/4-inch socket-head pipe plug into the unused outlet on the filter regulator. The O-ring is not required.

January 2007 **2-15** 

#### **Pressure Connections**

# **WARNING**

Refer to the Installation WARNING at the beginning of this section.

#### Note

Make pressure connections to the digital valve controller using tubing with at least 3/8-inch diameter.

Pressure connections are shown in figure 2-15. All pressure connections on the digital valve controller are 1/4-inch NPT female connections. Use 10 mm (3/8-inch) tubing for all pneumatic connections. If remote venting is required, refer to the vent subsection.


### **Supply Connections**

# **WARNING**


To avoid personal injury and property damage resulting from bursting of parts, do not exceed maximum supply pressure.

# **WARNING**

Severe personal injury or property damage may occur from an uncontrolled process if the instrument air supply is not clean, dry and oil-free. While use and regular maintenance of a filter that removes particles larger than 40 microns in diameter will suffice in most applications, check with an Emerson Process Management field office and industry instrument air quality standards for use with corrosive air or if you are unsure about the proper amount or method of air filtration or filter maintenance.



**TYPE DVC6005 BASE UNIT** 



NOTE:
PNEUMATIC CONNECTIONS APPLICABLE TO BOTH VALVE-MOUNTED
INSTRUMENTS AND TYPE DVC6005 BASE UNIT.

Figure 2-15. DVC6000 Series Digital Valve Controller Connections

Supply pressure must be clean, dry air that meets the requirements of ISA Standard 7.0.01.

A Fisher Type 67CFR filter regulator, or equivalent, may be used to filter and regulate supply air. A filter regulator can be integrally mounted onto the side of the digital valve controller, casing mounted separate from the digital valve controller, or mounted on the actuator mounting boss. Supply and output pressure gauges may be supplied on the digital valve controller. The output pressure gauges can be used as an aid for calibration.

**2-16** January 2007

2



Figure 2-16. Type DVC6010 Digital Valve Controller Mounted on Type 585C Piston Actuator

Connect the nearest suitable supply source to the 1/4-inch NPT IN connection on the filter regulator (if furnished) or to the 1/4-Inch NPT SUPPLY connection on the digital valve controller housing (if Type 67CFR filter regulator is not attached).

### **Output Connections**

A factory mounted digital valve controller has its output piped to the pneumatic input connection on the actuator. If mounting the digital valve controller in the field, or installing the remote-mounted Type DVC6005 base unit, connect the 1/4-inch NPT digital valve controller output connections to the pneumatic actuator input connections.

#### Single-Acting Actuators

When using a single-acting direct digital valve controller (relay type C) on a single-acting actuator connect OUTPUT A to the actuator pneumatic input.

When using a single-acting reverse digital valve controller (relay type B) on a single-acting actuator connect OUTPUT B to the actuator diaphragm casing.

#### **Double-Acting Actuators**

DVC6000 Series digital valve controllers on double-acting actuators always use relay type A. With no input current, OUTPUT A is at 0 pressure and




Figure 2-17. Pneumatic Hookup for Solenoid Testing

OUTPUT B is at full supply pressure when the relay is properly adjusted.

To have the actuator stem extend from the cylinder with increasing input signal, connect OUTPUT A to the upper actuator cylinder connection. Connect OUTPUT B to the lower cylinder connection. Figure 2-16 shows the digital valve controller connected to a double-acting piston actuator.

To have the actuator stem retract into the cylinder with increasing input signal, connect OUTPUT A to the lower actuator cylinder connection. Connect OUTPUT B to the upper cylinder connection.

# Special Construction to Support Solenoid Valve Testing

In single-acting actuator applications with a solenoid valve installed, the DVC6000 can be configured to test the operation of the solenoid valve. This is accomplished by connecting the "unused" output port from the DVC6000 to the pneumatic line between the solenoid valve and the actuator, as shown in figure 2-17. When single-acting, direct relay C is installed, the "unused" output port is port B. When single-acting, reverse relay B is used, the unused port is port A.



# **Note**

Solenoid valve testing is only available for instrument level PD.

January 2007 **2-17** 



### **Note**

This application is called "special application" in the Setup Wizard relay selection.

This configuration is not possible with a double-acting actuator or when using relay A in single-acting mode.

# **WARNING**

Personal injury or property damage may occur from overpressure of the unit if the unused port is used to sense process pressure. The unused port may only be used for supply-regulated actuator pressure.

#### Vent

# **WARNING**

Personal injury or property damage can occur from cover failure due to overpressure. Ensure that the housing vent opening is open and free of debris to prevent pressure buildup under the cover.

The relay output constantly bleeds supply air into the area under the cover. The vent opening at the back of the housing should be left open to prevent pressure buildup under the cover. If a remote vent is required, the vent line must be as short as possible with a minimum number of bends and elbows.

To connect a remote vent to Type DVC6010 and DVC6030 digital valve controllers and Type DVC6005 base unit— remove the plastic vent (key 52, figures 10-4 and 10-1). The vent connection is 3/8-inch NPT female. At a minimum, 12.7 mm (1/2-inch) tubing should be used when installing a remote vent to prevent excessive pressure from building up under the cover.

To connect a remote vent to Type DVC6020 digital valve controllers—replace the standard mounting bracket (key 74, figures 10-4 and 10-2) with the vent-away bracket (key 74). Install a pipe plug in the

vent-away mounting bracket (key 74). Mount the digital valve controller on the actuator as described in the Installation section of this manual. The vent connection is 3/8-inch NPT female. At a minimum, 12.7 mm (1/2-inch) tubing should be used when installing a remote vent to prevent excessive pressure from building up under the cover.

#### **Electrical Connections**

# **WARNING**

Refer to the Installation WARNING at the beginning of this section.

# **WARNING**

To avoid personal injury resulting from electrical shock, do not exceed the maximum input voltage specified in table 1-2 of this instruction manual, or on the product nameplate. If the input voltage specified differs, do not exceed the lowest specified maximum input voltage.

Select wiring and/or cable glands that are rated for the environment of use (hazardous area, ingress protection and temperature). Failure to use properly rated wiring and/or cable glands can result in personal injury or property damage from fire or explosion.

# **WARNING**

To avoid personal injury or property damage caused by fire or explosion, remove power to the instrument before removing the terminal box cover in an area which contains a potentially explosive atmosphere or has been classified as hazardous.

### 4 to 20 mA Loop Connections

The digital valve controller is normally powered by a control system output card. The use of shielded cable will ensure proper operation in electrically noisy environments.

**2-18** January 2007




Figure 2-18. DVC6000 Series Digital Valve Controller Terminal Box

# **WARNING**

To avoid personal injury or property damage from the sudden release of process pressure, be sure the valve is not controlling the process. The valve may move when the source is applied.

Wire the digital valve controller as follows: (unless indicated otherwise, refer to figures 10-1 through 10-3 for identification of parts).

- 1. Remove the terminal box cap (key 4) from the terminal box (key 3).
- 2. Bring the field wiring into the terminal box. When applicable, install conduit using local and national electrical codes which apply to the application.
- 3. Refer to figure 2-18. Connect the control system output card positive wire "current output" to the LOOP + screw terminal in the terminal box. Connect the control system output card negative (or return) wire to the LOOP screw terminal.

# **WARNING**

Personal injury or property damage, caused by fire or explosion, can result from the discharge of static electricity. Connect a 14 AWG (2.08 mm²) ground strap between the digital valve controller and earth ground when flammable or hazardous gases are present. Refer to national and local codes and standards for grounding requirements.

To avoid static discharge from the plastic cover, do not rub or clean the cover with solvents. Clean with a mild detergent and water only.

- 4. As shown in figure 2-18, two ground terminals are available for connecting a safety ground, earth ground, or drain wire. These ground terminals are electrically identical. Make connections to these terminals following national and local codes and plant standards.
- 5. Replace and hand tighten the terminal box cap. When the loop is ready for startup, apply power to the control system output card.

#### **Remote Travel Sensor Connections**

The DVC6005 base unit is designed to receive travel information via a remote sensor. The remote can be any of the following:

- Emerson Process Management supplied DVC6015, DVC6025 or DVC6035 feedback unit,
- An under-traveled 10 kOhm potentiometer used in conjunction with onboard 30 kOhm resistor, or
- A potentiometer used in conjunction with two fixed resistors (potentiometer travel is the same as actuator travel).

# **MARNING**

Personal injury or property damage, caused by wiring failure, can result if the feedback wiring connecting the base unit with the remote feedback unit shares a conduit with any other power or signal wiring.

Do not place feedback wiring in the same conduit as other power or signal wiring.

January 2007 **2-19** 




Figure 2-19. Terminal Details for Connecting Base Unit and Feedback Units of Remote-Mounted Digital Valve Controllers

# Using the DVC6015, DVC6025 & DVC6035 Feedback Unit as a Remote Travel Sensor

- 1. On the feedback unit, remove the housing cap.
- 2. On the base unit, remove the feedback connections terminal box cap (see figure 2-15).
- 3. If necessary, install conduit between the feedback unit and the base unit following applicable local and national electrical codes. Route the 3-conductor shielded cable between the two units (refer to figure 2-19).
- 4. Connect one wire of the 3-conductor shielded cable between terminal 1 on the feedback unit and terminal 1 on the base unit.
- 5. Connect the second wire of the 3-conductor shielded cable between terminal 2 on the feedback unit and terminal 2 on the base unit.
- 6. Connect the third wire of the 3-conductor shielded cable between terminal 3 on the feedback unit and terminal 3 on the base unit.
- 7. Connect the cable shield or drain wire to the ground screw in the feedback connections terminal box of the base unit. Do not connect the shield or drain wire to any terminal on the feedback unit.
- 8. Replace and hand tighten all covers.

# Using an External 10 kOhm External Potentiometer as a Remote Travel Sensor



# **Note**

Potentiometer travel must be between 1.3 and 1.6 times greater than the actuator travel. For example: if an actuator has a travel of 9 inches, then a linear potentiometer must be selected with a rated travel between 11.7 and 14.4 inches. The resistive element must be tapered from 0 kOhm to 10 kOhm over rated travel of the potentiometer. The actuator will only use 63 to 76 % of the potentiometer rated travel.

**2-20** January 2007




Figure 2-20. Terminal Details for Connecting a DVC60005 Base
Unit and a 10k Ohm External Potentiometer



#### Note

The digital valve controller must be configured using the SStem/Roller selection on the menu of the appropriate setup device.

The base unit (DVC6005) was designed to work with a 40 kOhm potentiometer for travel feedback. However, there are linear potentiometers that are readily available with a rated resistance of 10 kOhm. Therefore, the feedback terminal box of the DVC6005 contains an additional 30 kOhm fixed resistor that may be added to the circuit. This brings the total resistance up to the required 40 kOhm.

- 1. Mount the external 10 kOhm potentiometer to the actuator such that the mid-travel position of the potentiometer (5 kOhm) corresponds to the mid-travel position of the actuator. This will leave an equal amount of unused resistive element on both ends of the travel, which is required by the digital valve controller to function properly.
- 2. On the base unit, remove the feedback connections terminal box cap (see figure 2-15).
- 3. If necessary, install conduit between the potentiometer and the base unit following applicable local and national electrical codes. Route the 3-conductor shielded cable between the two units (refer to figure 2-20).
- 4. Connect one wire of the 3-conductor shielded cable between the Terminal labeled " $30k\Omega$ " on the base unit and one end lead of the potentiometer.
- 5. Connect the second wire of the 3-conductor shielded cable between the middle lead (wiper) of the

- 10 kOhm potentiometer to Terminal 2 on the base unit.
- 6. Connect the third wire of the 3-conductor shielded cable between Terminal 3 on the base unit and the other end-lead of the 10 kOhm potentiometer.
- 7. Connect the cable shield or drain wire to the ground screw in the feedback connections terminal box of the base unit. Do not connect the shield or drain wire to the external potentiometer.
- 8. Replace and tighten the base unit cover.

# Using a Potentiometer with Two Fixed Resistors as a Remote Travel Sensor

Perform the following procedure if a potentiometer is used with the same, or slightly longer travel than the actuator's travel.



#### Note

The potentiometer must be capable of resistance close to 0 Ohms.

#### CAUTION

To prevent damage to the potentiometer, ensure that it is free to travel the entire length of the actuator's travel.



## **Note**

The digital valve controller must be configured using the SStem/Roller selection on the menu of the appropriate setup device.

This procedure uses three resistors connected in series, two fixed resistors and one potentiometer. Three conditions must be met for the resistor combination to correctly operate the digital valve controller:

- The maximum resistance of the potentiometer (R<sub>pot(max)</sub>) must be between 3.9 kOhm and 10 kOhm.
- $\bullet$  The resistance of  $R_1$  is 4.25 times greater than  $R_{\text{pot}(\text{max})}.$

January 2007 **2-21** 

 $\bullet$  The resistance of  $R_2$  is 4 times less than  $R_{\text{pot}(\text{max})}.$ 

# **WARNING**

To avoid personal injury or property damage from an uncontrolled process ensure that the R1 resistor is properly insulated before installing it in the terminal box.

- 1. On the base unit, remove the feedback connections terminal box cap (see figure 2-15).
- 2. If necessary, install conduit between the two-resistor series and the base unit following applicable local and national electrical codes. Route the 3-conductor shielded cable between the two units (refer to figure 2-21).
- 3. Install the fixed resistor ( $R_1$ ) across the unlabeled bottom Terminal and Terminal #1. The bottom terminal does not have a screw. The screw on the 30 kOhm terminal can be used. R1 must be properly insulated when installed in the terminal box to prevent personal injury or property damage.
- 4. Connect one wire of the 3-conductor shielded cable between the unlabeled bottom Terminal on the base unit and an end-lead of the external potentiometer ( $R_{pot}$ ).
- 5. Connect the second wire of the 3-conductor shielded cable between the middle lead (wiper) of the external potentiometer ( $R_{pot}$ ) and Terminal 2 on the base unit.
- 6. Connect the third wire of the 3-conductor shielded cable between between a lead on  $(R_2)$  and terminal #3 of the base unit.
- 7. Connect the available end-lead on the potentiometer ( $R_{pot}$ ) with the available lead on fixed resistor ( $R_2$ ).
- 8. Connect the cable shield or drain wire to the ground screw in the feedback connections terminal box of the base unit. Do not connect the shield or drain wire to the two-resistor series.
- 9. Replace and tighten the base unit cover.

Example: Using a linear potentiometer rated at 400 Ohms/inch on an actuator with 16" of travel.

- R<sub>pot(max)</sub> is 400 Ohms/in x 16" = 6.4 kOhm
- R<sub>1</sub> = 6.4 kOhm x 4.25 = 27.2 kOhm
- R<sub>2</sub> = 6.4 kOhm / 4 = 1.6 kOhm




Figure 2-21. Terminal Details for Connecting a DVC60005 Base Unit and a Three-Resistor Series

#### **Test Connections**

# **WARNING**

Personal injury or property damage caused by fire or explosion may occur if this connection is attempted in a potentially explosive atmosphere, or in an area that has been classified as hazardous. Confirm that area classification and atmosphere conditions permit the safe removal of the terminal box cap before proceeding.

Test connections inside the terminal box can be used to measure loop current across a 1 ohm resistor.

- 1. Remove the terminal box cap.
- 2. Adjust the test meter to measure a range of 0.001 to 0.1 volts.
- 3. Connect the positive lead of the test meter to the TEST + connection and the negative lead to the TEST connection inside the terminal box.
- 4. Measure Loop current as:

Voltage (on test meter)  $\times$  1000 = milliamps example:

Test meter Voltage X 1000 = Loop Milliamps

0.004 X1000 = 4.0 milliamperes

0.020 X 1000 = 20.0 milliamperes

5. Remove test leads and replace the terminal box cover.

**2-22** January 2007

#### **Communication Connections**

# **WARNING**

Personal injury or property damage caused by fire or explosion may occur if this connection is attempted in a potentially explosive atmosphere or in an area that has been classified as hazardous. Confirm that area classification and atmosphere conditions permit the safe removal of the terminal box cap before proceeding.

A HART communicating device, such as a Model 375 Field Communicator or a personal computer running AMS ValveLink Software communicating through a HART modem, interfaces with the DVC6000 Series digital valve controller from any wiring termination point in the 4–20 mA loop. If you choose to connect the HART communicating device directly to the instrument, attach the device to the LOOP + and LOOP - terminals or to the TALK + and TALK - connections inside the terminal box to provide local communications with the instrument.

# **Wiring Practices**

#### **Control System Requirements**

There are several parameters that should be checked to ensure the control system is compatible with the DVC6000 Series digital valve controller.

#### HART® Filter

Depending on the control system you are using, a HART filter may be needed to allow HART communication. The HART filter is an active device that is inserted in field wiring from the HART loop. The filter is normally installed near the field wiring terminals of the control system I/O (see figure 2-22). Its purpose is to effectively isolate the control system output from modulated HART communication signals and raise the impedance of the control system to allow HART communication. For more information on the description and use of the HART filter, refer to the separate HART filter instruction manual.




Figure 2-22. HART® Filter Application

Contact your Emerson Process Management sales office if assistance is needed to determine if your system requires a filter.



# Note

A HART filter is NOT required for any of the Emerson Process Management control systems, including PROVOX<sup>®</sup>, RS3<sup>™</sup>, and DeltaV<sup>™</sup> systems.

#### Voltage Available

The voltage available at the DVC6000 Series digital valve controller must be at least 11 volts dc. The voltage available at the instrument is not the actual voltage measured at the instrument when the instrument is connected. The voltage measured at the instrument is limited by the instrument and is typically less than the voltage available.

As shown in figure 2-23, the voltage available at the instrument depends upon:

- the control system compliance voltage
- if a filter or intrinsic safety barrier is used, and
- the wire type and length.

January 2007 **2-23** 

# **DVC6000 Series**

Calculate Voltage Available at the Instrument as follows:

Control system compliance voltage

- Filter voltage drop (if used)
- Intrinsic safety barrier resistance (if used) x maximum loop current
- Total loop cable resistance x maximum loop current
- = Voltage available at the instrument  $\sqrt{2}$

**Example Calculation** 

18.5 volts (at 21.05 mA)

- 2.3 volts (for HF300 series filter)
- 2.55 volts (121 ohms x 0.02105 amps)
- 1.01 volts (48 ohms x 0.02105 amps for 1000 feet of Belden 9501 cable)
- = 15.19 volts, available

#### NOTES:

- Obtain filter voltage drop. The measured drop will be different than this value. The measured filter voltage drop depends upon control system output voltage, the intrinsic safety barrier (if used), and the instrument. See note 2.
- The voltage available at the instrument is not the voltage measured at the instrument terminals. Once the instrument is connected, the instrument limits the measured voltage to approximately 9.0 to 10.5 volts.

Figure 2-23. Determining Voltage Available at the Instrument

The control system compliance voltage is the maximum voltage at the control system output terminals at which the control system can produce maximum loop current.

The voltage available at the instrument may be calculated from the following equation:

Voltage Available = [Control System Compliance Voltage (at maximum current)] – [filter voltage drop (if a HART filter is used)] – [total cable resistance × maximum current] – [barrier resistance x maximum current].

The calculated voltage available should be greater than or equal to 11 volts dc.

Table 2-1 lists the resistance of some typical cables.

The following example shows how to calculate the voltage available for a Honeywell <sup>™</sup> TDC2000 control system with a Type HF340 HART filter, and 1000 feet of Belden<sup>®</sup> 9501 cable:

Voltage available =  $[18.5 \text{ volts (at } 21.05 \text{ mA})] - [2.3 \text{ volts}] - [48 \text{ ohms} \times 0.02105 \text{ amps}]$ 

Voltage available = [18.5] - [2.3] - [1.01]

Voltage available = 15.19 volts

#### Compliance Voltage

If the compliance voltage of the control system is not known, perform the following compliance voltage test.

- 1. Disconnect the field wiring from the control system and connect equipment as shown in figure 2-24 to the control system terminals.
- 2. Set the control system to provide maximum output current.
- 3. Increase the resistance of the 1 kilohm potentiometer, shown in figure 2-24, until the current observed on the milliammeter begins to drop quickly.
- 4. Record the voltage shown on the voltmeter. This is the control system compliance voltage.

For specific parameter information relating to your control system, contact your Emerson Process Management sales office.

\_\_

Cable Type	Capacitance <sup>(1)</sup> pF/Ft	Capacitance <sup>(1)</sup> pF/M	Resistance <sup>(2)</sup> Ohms/Ft	Resistance <sup>(2)</sup> Ohms/M
BS5308/1, 0.5 sq mm	61.0	200	0.022	0.074
BS5308/1, 1.0 sq mm	61.0	200	0.012	0.037
BS5308/1, 1.5 sq mm	61.0	200	0.008	0.025
BS5308/2, 0.5 sq mm	121.9	400	0.022	0.074
BS5308/2, 0.75 sq mm	121.9	400	0.016	0.053
BS5308/2, 1.5 sq mm	121.9	400	0.008	0.025
BELDEN 8303, 22 awg	63.0	206.7	0.030	0.098
BELDEN 8441, 22 awg	83.2	273	0.030	0.098
BELDEN 8767, 22 awg	76.8	252	0.030	0.098
BELDEN 8777, 22 awg	54.9	180	0.030	0.098
BELDEN 9501, 24 awg	50.0	164	0.048	0.157
BELDEN 9680, 24 awg	27.5	90.2	0.048	0.157
BELDEN 9729, 24 awg	22.1	72.5	0.048	0.157
BELDEN 9773, 18 awg	54.9	180	0.012	0.042
BELDEN 9829, 24 awg	27.1	88.9	0.048	0.157
BELDEN 9873, 20 awg	54.9	180	0.020	0.069

Table 2-1. Cable Characteristics

<sup>2.</sup> The resistance values include both wires of the twisted pair.




Figure 2-24. Voltage Test Schematic

## **Maximum Cable Capacitance**

The maximum cable length for HART communication is limited by the characteristic capacitance of the cable. Maximum length due to capacitance can be calculated using the following formulas:

$$Length(ft) = [160,000 - C_{master}(pF)] \div [C_{cable}(pF/ft)]$$

Length(m) = 
$$[160,000 - C_{master}(pF)] \div [C_{cable}(pF/m)]$$

where:

160,000 = a constant derived for FIELDVUE instruments to ensure that the HART network RC time

constant will be no greater than 0.65  $\mu s$  (per the HART specification).

 $C_{master}$  = the capacitance of the control system or HART filter

 $C_{cable}$  = the capacitance of the cable used (see table 2-1)

The following example shows how to calculate the cable length for a Foxboro  $^{\otimes}$  I/A control system (1988) with a C<sub>master</sub> of 50, 000 pF and a Belden 9501 cable with characteristic capacitance of 50pF/ft.

Length(ft) =  $[160,000 - 50,000pF] \div [50pF/ft]$ Length = 2200 ft.

January 2007 **2-25** 




Figure 2-25. HART® Tri-Loop™ Installation Flowchart

The HART communication cable length is limited by the cable characteristic capacitance. To increase cable length, select a wire with lower capacitance per foot. Contact your Emerson Process Management sales office for specific information relating to your control system.

# Installation in Conjunction with a Rosemount® Model 333 HART® Tri-Loop™ HART-to-Analog Signal Converter

Use the DVC6000 Series digital valve controller in operation with a Rosemount® Model 333 HART Tri-Loop™ HART-to-Analog Signal Converter to acquire an independent 4-20 mA analog output signal for the analog input, travel target, pressure, or travel. The HART Tri-Loop accepts any three of these digital signals and converts them into three separate 4-20 mA analog channels.

Refer to figure 2-25 for basic installation information. Refer to the Model 333 HART Tri-Loop HART-to-Analog Signal Converter Product Manual for complete installation information.

### Commissioning the Digital Valve Controller for use with the HART® Tri-Loop™ Signal Converter

To prepare the digital valve controller for use with a

Model 333 HART Tri-Loop, you must configure the digital valve controller to burst mode, and select Burst Command 3. In burst mode, the digital valve controller provides digital information to the HART Tri-Loop HART-to-Analog Signal Converter. The HART Tri-Loop converts the digital information to a 4 to 20 mA analog signal. Each burst message contains the latest value of the primary (analog input), secondary (travel target), tertiary (configured output pressure), and quaternary (travel) variables.

To commission a DVC6000 Series digital valve controller for use with a HART Tri-Loop, perform the following procedures.

# Set the Burst Operation (1-2-1-4)



- 1. From the Online menu, select Configure / Setup, Detailed Setup, Mode and Protection, and Burst Mode.
- 2. Select Burst Enable. Select Enable then press ENTER and SEND.
- 3. Select Burst Command. Select the desired command (HART Univ Command 3).
- 4. Select Cmd 3 Press. Select the pressure you desire the HART Tri-Loop to use as the tertiary variable.

2-26 January 2007

# **Section 3 Model 375 Field Communicator Basics**

Display	3-2
Using the Keypad	3-2
On/Off Key	3-2
Navigation Keys	3-2
Enter Key	3-2
Tab Key	3-2
Alphanumeric Keys	3-2
Backlight Adjustment Key	3-3
Function Key	3-3
Multifunction LED	3-3
Using the Touch Screen	3-3
Using the Soft Input Panel Keyboard	3-3
Menu Structure	3-4
Offline Operation	3-4
Saving Setup and Calibration Data	3-4
Polling	3-5
System Information	3-5 3-5
Reviewing Instrument Device Descriptions	3-5
Online Operation	3-6
Displaying the Field Communicator	
Device Description Revision	3-6

January 2007 **3-1** 



Figure 3-1. Model 375 Field Communicator

# Note

The Model 375 Field Communicator device description revision (DD) determines how the Field Communicator interfaces with the instrument. For information on displaying the device description revision, see page 3-5.

This section discusses the display, keypad, and menu structure for the Field Communicator, shown in figure 3-1. It includes information for displaying the Field Communicator device description revision number. For information on connecting the Field Communicator to the instrument, see the Installation section. For more information on the Field Communicator, such as specifications and servicing, see the User's Manual for the Field Communicator 00375-0047-0001, included with the Field Communicator. This manual also is available from Rosemount Inc., Measurement Division.

#### Display

The Field Communicator communicates information to you through a 1/4 VGA (240 by 320 pixels) monochrome touch screen. It has a viewing area of approximately 9 cm by 12 cm.

#### Using the Keypad

# On/Off Key



The on/off key is used to turn the Field Communicator on and off.

From the Main Menu, select HART Application to run the HART application. On startup, the HART Application automatically polls for devices.

If a HART-compatible device is found, the Field Communicator displays the Online menu. For more information on Online and Offline operation, see Menu Structure in this section.

The on/off key is disabled while any applications are open, making it necessary for you to exit the 375 Main Menu before using the on/off key. This feature helps to avoid situations where the Field Communicator could be unintentionally turned off while a device's output is fixed or when configuration data has not been sent to a device.

# **Navigation Kevs**

Four arrow navigation keys allow you to move through the menu structure of the application. Press the right arrow ( ) navigation key to navigate further into the menu.

# **Enter Key**



The enter key allows you to perform the highlighted item, or to complete an editing action. For example, if you highlight the Cancel button, and then push the enter key, you will cancel out of that particular window. The enter key does not navigate you through the menu structure.

# Tab Key 🕮



The tab key allows you to move between selectable controls.

#### Alphanumeric Keys

Figure 3-2 shows the alphanumeric keypad. Data entry, and other options, using letters, number and

January 2007 3-2

# 375 Field Communicator Basics



Figure 3-2. Model 375 Field Communicator Alphanumeric and Shift Keys

other characters can be performed using this keypad. The 375 Field Communicator will automatically determine the mode depending upon the input necessary for the particular field.

To enter text when in alphanumeric mode, press the desired keypad button in quick repetition to scroll through the options to attain the appropriate letter or number.

For example, to enter the letter "Z", press the 9 key quickly four times.

The alphameric keys are also used for the Fast Key sequence. The Fast Key sequence is a sequence of numerical button presses, corresponding to the menu options that lead you to a given task. See the Model 375 Field Communicator Menu Structures at the beginning of this manual.

# Backlight Adjustment Key



The backlight adjustment key has four settings allowing you to adjust the intensity of the display. Higher intensities will shorten the battery life.

# **Function Key**



The function key allows you to enable the alternate functionality of select keys. The grey characters on the keys indicate the alternate functionality. When enabled, the orange multifunction LED light will appear and an indication button can be found on the soft input panel (SIP). Press the key again to disable the function key.

#### **Multifunction LED**

The multifunction LED indicates when the 375 Field Communicator is in various states. Green signifies that the Field Communicator is on, while flashing green indicates that it is in power saving mode. Green and orange indicate that the function key is enabled, and a green and orange flash indicates that the on/off button has been pressed long enough for the Field Communicator to power up.

## **Using the Touch Screen**

The touch screen display allows you to select and enter text by touching the window.

Tap the window once to select a menu item or to activate a control. Double-tap to access the various options associated with the menu item.

#### **CAUTION**

The touch screen should be contacted by blunt items only. The preferred item is the stylus that is included with the 375 Field Communicator. The use of a sharp instrument can cause damage to the touch screen interface.

Use the back arrow button(+) to return to the previous menu. Use the terminate key (x) in the upper right corner of the touch screen to end the application.

# Using the Soft Input Panel (SIP) Keyboard

As you move between menus, different dynamic buttons appear on the display. For example, in menus providing access to on-line help, the HELP button may appear on the display. In menus providing access to the Home menu, the HOME button may appear on the display. In many cases the SEND label appears indicating that you must select the button on the display to send the information you have entered on the keypad to the FIELDVUE instrument's memory. Online menu options include:

**3-3** 

# • Hot Key

Tap the Hot Key from any Online window to display the Hot Key menu. This menu allows you to quickly:

- Change the instrument mode
- Change the control mode
- Change the instrument protection
- Change tuning to improve response

The Hot Key can also be accessed by enabling the function key, and pressing the 3 key on the alphanumeric key pad.

For details on instrument mode, control mode, protection, tuning sets, and other configuration parameters, see the Detailed Setup section of this manual.

- SCRATCHPAD is a text editor that allows you to create, open, edit and save simple text (.txt) documents.
- **HELP**—gives you information regarding the display selection.
- **SEND**—sends the information you have entered to the instrument.
  - HOME—takes you back to the Online menu.
- **EXIT**—takes you back to the menu from which you had requested the value of a variable that can only be read.
- ABORT—cancels your entry and takes you back to the menu from which you had selected the current variable or routine. Values are not changed.
- **OK**—takes you to the next menu or instruction screen.
- ENTER—sends the information you have selected to the instrument or flags the value that is to be sent to the instrument. If it is flagged to be sent, the SEND dynamic label appears as a function key selection.
- **ESC**—cancels your entry and takes you back to the menu from which you had selected the current variable or routine. Values are not changed.
- **SAVE**—saves information to the internal flash or the configuration expansion module.

#### **Menu Structure**

The Field Communicator is generally used in two environments: offline (when not connected to an instrument) and online (connected to an instrument).

#### Offline Operation

Selecting HART Application when not connected to a FIELDVUE instrument causes the Field Communicator to display the message "No device found at address 0. Poll?" Selecting "Yes" or "No" will bring you to the HART Application menu. Three choices are available from this screen: *Offline, Online* and *Utility*. The Offline menu allows you to create offline configurations, as well as view and change device configurations stored on the 375 Field Communicator. The Utility menu allows you to set the polling option, change the number of ignored status messages, view the available Device Descriptions, perform a simulation, and view HART diagnostics.

#### Saving Setup and Calibration Data

You can upload setup and calibration data from the DVC6000 Series digital valve controller and save it in the Field Communicator Internal Flash or a Configuration Expansion Module. From the *Offline* menu you can then download this data to multiple devices so that they all contain the same setup and calibration data. You can also edit the saved data.

You upload setup and calibration data from the *Online* menu. This requires that the Field Communicator be connected to a digital valve controller powered by a 4 to 20 mA source. To save data from any *Online* menu select the SAVE key. Follow the prompts on the Field Communicator to save the data to the Internal Flash or the Configuration EM and name the saved data. Once the data is saved, the SAVE key disappears until you change the data in the instrument.

Downloading the saved data requires that you first mark the configurable variables you wish to download (the default is all variables unmarked). To do this, from the *Offline* menu select *Saved Configuration*. Depending on the location of the saved data, select either *Internal Flash Contents* or *Configuration EM Contents*. Select the name for the saved data. From the *Saved Configuration* menu select *Edit*.

From the *Edit* menu you can mark all configurable variables for download, unmark all configurable variables so none are downloaded, edit each variable individually, or save your configuration to the internal flash or the optional configuration expansion module. The following briefly describes each item on the menu. For more information, see the User's Manual for the 375 Field Communicator – 00375-0047-0001.

• *Mark All*—flags all configurable variables to be sent to a HART-compatible device. Configurable

January 2007

# 375 Field Communicator Basics

variables are those that appear when you edit variables in the configuration using the *Edit Individually* option.

- Unmark All—removes flags from all configurable variables in the configuration. Unmarked configurable variables are not sent to a connected HART-compatible device.
- Edit Individually—opens the Edit Individually menu to permit editing configurable variables in the saved data. For information on editing configurable variables, refer to the Field Communicator product manual.
- Save As...—saves your new configuration to the Internal Flash, or the Configuration EM. For more information on the Save As option, see the Field Communicator product manual.

Once the configurable variables are marked for download, return to the Saved Configuration menu and select *Save*. Follow the prompts on the Field Communicator to download the saved data to the instrument.

#### **Polling**

When several devices are connected in the same loop, such as for split ranging, each device must be assigned a unique polling address. Use the Polling options to configure the Field Communicator to automatically search for all or specific connected devices.

To enter a polling option, select *Utility* from the HART Application menu. Select *Configure HART Application*, and then select *Polling*. Tap ENTER to select the highlighted option.

The Polling options are:

- 1. **Never Poll**—connects to a device at address 0, and if not found will not poll for devices at addresses 1 through 15.
- 2. **Ask Before Polling**—connects to a device at address 0, and if not found asks if you want to poll for devices at addresses 1 through 15.
- 3. **Always Poll**—connects to a device at address 0, and if not found will automatically poll for devices at addresses 1 through 15.
- 4. **Digital Poll**—automatically polls for devices at address 0 through 15 and lists devices found by tag.
- 5. **Poll Using Tag**—asks for a device HART tag and then polls for that device.
- 6. **Poll Using Long Tag**—allows you to enter the long tag of the device. (Only supported in HART Universal revision 6 devices.)

To find individual device addresses, use the Digital Poll option to find each connected device in the loop and list them by tag.

For more information on setting the polling address, see the Detailed Setup section.

#### System Information

To access the Field Communicator system information, select *Settings* from the 375 Main Menu.

About 375 includes software information about your 375 Field Communicator.

Licensing can be viewed when you turn on the 375 Field Communicator and in the License settings menu. The license setting allows you to view the license on the System Card.

Memory settings consists of System Card, Internal Flash size, and Ram size, as well as the Expansion Module if installed. It allows you to view the total memory storage and available free space.

# Reviewing Instrument Device Descriptions

The Field Communicator memory module contains device descriptions for specific HART-compatible devices. These descriptions make up the application software that the communicator needs to recognize particular devices.

To review the device descriptions programmed into your Field Communicator, select *Utility* from the HART Application menu, then select *Available Device Descriptions*. The manufacturers with device descriptions installed on the Field Communicator are listed.

Select the desired manufacturer to see the list of the currently installed device models, or types, provided by the selected manufacturer.

Select the desired instrument model or type to see the available device revisions that support that instrument.

#### Simulation

The Field Communicator provides a simulation mode that allows you to simulate an online connection to a HART-compatible device. The simulation mode is a training tool that enables you to become familiar with the various menus associated with a device without having the Field Communicator connected to the device.

To simulate an online connection, select *Utility* from the main menu. Select *Simulation* then select *Fisher Controls*. Select *DVC6000* to see the menu structure for the DVC6000 Series digital valve controller. Refer to the appropriate sections of this manual for information on the various menus.

# **DVC6000 Series**

#### **Online Operation**

The Online menu is the first to be displayed when connecting to a HART compatible device. It contains important information about the connected device.

The figures in the beginning of this manual show the DVC6000 Series digital valve controller menu structures.

# Displaying the Field Communicator Device Description Revision

Device Description (DD) Revision is the revision number of the Fisher Device Description that resides in the Field Communicator. It defines how the Field Communicator is to interact with the user and instrument.

Field Communicators with device description revision 1 are used with DVC6000 Series device revision 2 digital valve controllers with firmware revision 7. You can display the device description revision when the Field Communicator is Offline or Online:

**Offline**—To see the Field Communicator device description revision number, from the main menu, select *Utility*, *Simulation*, *Fisher Controls*, and *DVC6000*.

**Online**—To see the Field Communicator device description revision number, connect the Field Communicator to an instrument connected to a source supplying a 4 to 20 mA signal. From the *Online* menu, select *Device Variables*, *DD Revision*.

**3-6** January 2007

# Section 4 Basic Setup

Instrument Mode	
Configuration Protection	4-2
Basic Setup	4-2
Setup Wizard	4-2
Using the Performance Tuner	4-5
Stabilizing/Optimizing Valve Response	4-5

January 2007 4-1

## **Instrument Mode**



To setup and calibrate the instrument, the instrument mode must be *Out Of Service*.

To view the instrument mode, press the Hot Key and select *Instrument Mode*. If the mode is not *Out Of Service*, select *Out Of Service* from the *Instrument Mode* menu and press ENTER.

#### **Basic Setup**

# **MARNING**

Changes to the instrument setup may cause changes in the output pressure or valve travel. Depending on the application, these changes may upset process control, which may result in personal injury or property damage.

## 4

# **Configuration Protection**



To setup and calibrate the instrument, the protection must be set to *None* with the Field Communicator. If the protection is not *None*, changing the protection requires placing a jumper across the Auxiliary terminals in the terminal box.

To remove protection:

- 1. Connect a 4 to 20 mA source to the instrument.
- 2. Connect the Field Communicator to the instrument and turn it on.
- 3. Press the Hot key on the Field Communicator and select *Protection*.



#### Note

If the Aux Terminal Mode is configured for Auto Travel Calibration, be sure the jumper remains across the auxiliary terminals until the Field Communicator prompts you to remove it. Removing the jumper too soon will cause the instrument to begin auto travel calibration.

4. From the *Protection* menu, select *None*. When prompted by the Field Communicator, temporarily attach the jumper to the AUX + and AUX – terminals in the instrument terminal box.



## Note

To setup and calibrate the instrument, the protection must be None and the Instrument Mode must be Out Of Service. See Configuration Protection and Instrument Mode at the beginning of this section for information on removing instrument protection and changing the instrument mode.

If you are operating in burst mode, we recommend that you disable burst before continuing with calibration. Once calibration is complete, burst mode may then be turned back on.

When the DVC6000 Series digital valve controller is ordered as part of a control valve assembly, the factory mounts the digital valve controller and sets up the instrument as specified on the order. When mounting to a valve in the field, the instrument needs to be setup to match the instrument to the valve and actuator

Before beginning Basic Setup, be sure the instrument is correctly mounted as described in the Installation section.

## Setup Wizard (1-1-1)

To have the Field Communicator automatically setup the instrument using specified actuator information, from the *Online* Menu select *Configure / Setup, Basic Setup,* and *Setup Wizard.* Follow the prompts on the Field Communicator display to setup the instrument. Table 4-2 provides the actuator information required to setup and calibrate the instrument.

- 1. Select travel or pressure control. Travel control is the typical mode of operation.
- 2. Enter the pressure units: psi, bar, kPa, or kg/cm<sup>2</sup>.

**4-2** January 2007

Table 4-1. DVC6000 Series Factory Default Settings

Setup Parameter	Default Setting
Analog Input Units	mA
Analog In Range High	20.0 mA
Analog In Range Low	4.0 mA
Control Mode	Analog
Restart Control Mode	Resume Last
Self-Test Shutdown	All Failures Disabled
Setpoint Filter Time	0 secs
Input Characteristic	Linear
Travel Limit High	125%
Travel Limit Low	-25%
Travel Cutoff High	99.5%
Travel Cutoff Low	0.5%
Minimum Opening Time	0 secs
Minimum Closing Time	0 secs
Polling Address	0
Aux Terminal Mode	Aux Input Alert
Command 3 Pressure	
For double-acting actuators	differential output pressure
For single-acting actuators	actuator pressure

3. Enter the maximum instrument supply pressure.

After entering the maximum instrument supply pressure, the Setup Wizard prompts you for actuator information.

- 4. Enter the manufacturer of the actuator on which the instrument is mounted. If the actuator manufacturer is not listed, select Other.
- 5. Enter the actuator model or type. If the actuator model is not listed, select Other.
- 6. Enter the actuator size.
- 7. Select whether the valve is open or closed under the zero power condition.

# **WARNING**

In the next step, if you answer YES to the prompt for permission to move the valve when the Field Communicator is determining the travel sensor motion, the instrument will move the valve through its full travel range. To avoid personal injury and property damage caused by the release of pressure or process fluid, provide some temporary means of control for the process.

- 8. Specify if a volume booster or quick release is present.
- 9. Specify if factory defaults should be used for basic setup. If you select YES for factory default, the Field Communicator sets the setup parameters to the

values listed in table 4-1. If you select NO for the factory defaults, the setup parameters listed in the table remain at their previous settings.

Typically the Setup Wizard determines the required setup information based upon the actuator manufacturer and model specified. However, if you enter *other* for the actuator manufacturer or the actuator model, then you will be prompted for setup parameters such as:

Actuator style (spring & diaphragm, piston double-acting without spring, piston single-acting with spring, piston double-acting with spring),

Valve style (rotary or sliding stem),

On Loss of Instrument Signal (valve opens or closes), see Zero Power Condition in the Detailed Setup section.

Feedback connection (rotary-all, sstem-roller, or sstem-standard), see Feedback Connection in the Detailed Setup section.

Travel Sensor motion (increasing air pressure causes the travel sensor shaft to rotate clockwise or counterclockwise). The Field Communicator will ask if it can move the valve to determine travel sensor motion. If you answer yes, the instrument may stroke the valve the full travel span to determine travel sensor rotation. If you answer No, then you will have to specify the rotation for increasing air pressure: clockwise or counterclockwise. (see Travel Sensor Motion in the Detailed Setup section).

Volume booster (indicate if volume booster or quick release is present)

Tuning set (see Tuning Set in the Detailed Setup section).

After completing the setup information, travel is automatically calibrated. Follow the prompts on the Field Communicator display. The calibration procedure uses the valve and actuator stops as the 0% and 100% calibration points. For additional information, refer to Auto Calibrate Travel on page 6-2 of the Calibration section.

When travel calibration is complete, you are asked if you wish to adjust the relay (double-acting only). Select yes to adjust the relay. For additional information, refer to Relay Adjustment on page 6-10 of the Calibration section.



# **Note**

Relay Adjustment is only available for the double-acting relay (Relay A).

January 2007 **4-3** 

Table 4-2. Actuator Information for Basic Setup

Actuator	Actuator	ctuator		Starting	Feedback Connection	Travel Sensor Motion	
Manufacturer	Model	Actuator Size	Actuator Style	Tuning Set		Relay A or C	Relay B
	585C & 585CR	25 50, 60 60, 80 100, 130	Piston Dbl w/ or w/o Spring. See actuator instruction manual and nameplate.	F J L M	SStem-Standard for travels up to 4 inches. SStem- Roller for longer travels	Depends upon pnet See description f	or Travel Sensor
	657	30 34, 40 45, 50 46, 60, 70, 76, & 80-100	Spring & Diaphragm	H K L	SStem-Standard	Clockwise	Counterclockwise
	667	30 34, 40 45, 50 46, 60, 70, 76, & 80-100	Spring & Diaphragm	H K L	SStem-Standard	Counterclockwise	Clockwise
Fisher	1051 & 1052	20, 30 33 40 60, 70	Spring & Diaphragm	H I K M	Rotary	Clockwise	Counterclockwise
	1061	30 40 60 68, 80, 100, 130	Piston Dbl w/o Spring	J K L M	Rotary	Depends upon pnet See description f	or Travel Sensor
	1066	20, 27, 75	Piston Dbl w/o Spring	Specify	Rotary	Depends upon pnet See description f Mo	or Travel Sensor
	1066SR	20 27, 75	Piston Sgl w/Spring	G L	Rotary	Depends upon mactuator instruction	manual and table
		225		X <sup>(1)</sup>	SStem-Standard	Air	to
	GX	750	Spring & Diaphragm	K	001 01 1 1	Open	Close
		1200	Diapriragin	М	SStem-Standard	Counterclockwise	Clockwise
	Air to Extend	16		C	SStem-Standard	Clockwise	Counterclockwise
Baumann	Air to Retract	32 570	Spring &	E K	SStem-Standard	Counterclockwise	Clockwise
Daumami	Rotary	10 25 54	Diaphragm	E H J	Rotary	Specify	
Gulde	3024	GA 1.21 GA 1.31 GA 1.41	Spring & Diaphragm	E H K	SStem-Standard	For P <sub>o</sub> operating mode (air opens), Counterclockwise For P <sub>s</sub> operating mode (air closes), Clockwise	For P <sub>o</sub> operating mode (air opens), Clockwise For P <sub>s</sub> operating mode (air closes), Counterclockwise
	3025	P460, P462, P900		М	Rotary	Spe	ecify

Table 4-3. Travel Sensor Motion Selections for Type DVC6030 on Type 1066SR Actuators

Mauntina Chala	Travel Sensor Motion			
Mounting Style	Relay A or C	Relay B		
A	Clockwise	Counterclockwise		
В	Counterclockwise	Clockwise		
С	Counterclockwise	Clockwise		
D	Clockwise	Counterclockwise		

**4-4** January 2007

If after completing the Setup Wizard the valve seems slightly unstable or unresponsive, you can improve operation by selecting either *Performance Tuner* or Stabilize/Optimize from the Basic Setup menu. For additional information on using the performance tuner, refer to Using the Performance Tuner in this section. For additional information on stabilizing or optimizing valve response, refer to Stabilize/Optimize at the end of this section.

#### **Using the Performance Tuner (1-1-2)**



#### Note

The Performance Tuner is not available for instrument level AC or HC.

The Performance Tuner is used to optimize digital valve controller tuning. It can be used with digital valve controllers mounted on most sliding-stem and rotary actuators, including Fisher and other manufacturers' products. Moreover, because the performance tuner can detect internal instabilities before they become apparent in the travel response, it can generally optimize tuning more effectively than manual tuning. Typically, the performance tuner takes 3 to 5 minutes to tune an instrument, although tuning instruments mounted on larger actuators may take longer.

Access Performance Tuner by selecting *Performance* Tuner from the Basic Setup menu. Follow the prompts on the Field Communicator display to optimize digital valve controller tuning.

# Stabilizing/Optimizing or (1-1-2) Valve Response





#### Note

Stabilize/Optimize is only available through the Basic Setup menu for instrument level HC.

If after completing setup and calibration the valve seems slightly unstable or unresponsive, you can improve operation by pressing the Hot Key and selecting Stabilize/Optimize, or select Stabilize/Optimize from the Basic Setup menu.

Stabilize/Optimize permits you to adjust valve response by changing the digital valve controller

If the valve is unstable, select Decrease Response to stabilize valve operation,. This selects the next lower tuning set (e.g., F to E). If the valve response is sluggish, select *Increase Response* to make the valve more responsive. This selects the next higher tuning set (e.g., F to G).

If after selecting Decrease Response or Increase Response the valve travel overshoot is excessive select Decrease Damping to select a damping value that allows more overshoot. Select *Increase Damping* to select a damping value that will decrease the overshoot. When finished, select done.

January 2007

4

**4-6** January 2007

5-1

# Section 5 Detailed Setup

Menu and Quick Key Sequence TablesF	Torit Cover
Detailed Setup	5-4
Mode and Protection	5-4
Mode	5-4
Instrument Mode	
Control Mode	
Restart Control Mode	
Burst Mode	
Protection	5-5
Protection	
Response Control	5-6
Tuning	5-6
Travel Tuning	5-6
Travel Tuning Set	
Travel Tuning Set	
Travel Proportional Gain	
Travel Velocity Gain	
Travel MLFB Gain	
Travel Integral Control Enable	
Travel Integral Gain	
Stabilize/Optimize	
Performance Tuner	
Integral Settings	5-9
Integral Dead Zone	
Integral Limit	
Pressure Tuning	5-9
Pressure Tuning Set	
Pressure Tuning Set	
Pressure Proportional Gain	
Pressure MLFB Gain	
Pressure Integral Control Enable	
Pressure Integral Gain	- 44
Travel/Pressure Control	5-11
Travel/Pressure Select	5-11
Travel/Pressure Cutoffs	5-11
Travel/Pressure Cutoff Hi	
Travel Limits	E 11
Travel Limits	5-11
Travel Limit Hi Travel Limit Lo	
Havei Lilliit LU	

January 2007

Pressure Control	5-11
Pressure Range Hi	
Pressure Range Lo	
End Point Pressure Control	5-12
End Point Control Enable	
PST Start Point	
Pressure Set Point	
Pressure Sat Time	
Input Characterization	5-12
Define Custom Characterization	5-12
Dynamic Response	5-12
SP Rate Open	
SP Rate Close	
Lag Time	
Lead / Lag	
Leau / Lay	
Alerts	5-14
Electronic Alerts	5-14
Drive Current Shutdown	
Drive Signal Alert	
Drive Signal Alert Enable	
Drive Signal	
Processor Impaired Alerts	
Offline/Failed Alert Enable	
Power Starvation Alert Enable	
Non-Critical NVM Alert Enable	
Critical NVM Shutdown	
Flash ROM Shutdown	
No Free Time Shutdown	
Reference Voltage Shutdown	
Sensor Alerts	5-15
Travel Sensor Shutdown	5-15
Temperature Sensor Shutdown	
Pressure Sensor Shutdown	
Environmental Alerts	5-15
Aux Terminal Alert	3-13
Auxiliary Terminal Alert Enable	
Auxiliary Input	
Auxiliary Terminal Mode	
Supply Pressure Lo Alert	
Supply Pressure Lo Alert Enable	
Supply Pressure	
Supply Pressure Lo Alert Point	
Travel Alerts	5-15
Travel	
Travel Set Point	
Travel Alert Dead Band	
Travel Deviation Alert	
Travel Limit Alerts	
Travel Limit Hi/Lo Alerts	
Travel Cutoff Alerts	

**5-2** January 2007

#### 5

# **Detailed Setup**

Travel History Alerts	5-17
Cycle Count/Travel Accumulator Deadband	
Travel Accumulator	
SIS Alerts	5-18
PST Pressure Limit	
Pressure Deviation Alert Enable	
Pressure Deviation Alert Point	
Pressure Deviation Time	
Alert Record	5-18
Alrt Record Not Empty Enab	
Alrt Record Full Enab	
Display Record	
Clear Record	
Alert Groups	
Status	5-18
Instrument Time	
Calibration and Diagnostics	
Operational	
Integrator	
Instrument	5-19
General	
Units	
Analog Input Range	
Relay Type	
Zero Power Condition	
Maximum Supply Pressure	
Auxiliary Terminal Mode	
Instrument Date and Time	
Calibration Status and Location	
Valve & Actuator	5-21
Manufacturer	
Valve Serial Number	
Valve Style	
Actuator Style	
Feedback Connection	
Travel Sensor Motion	
Partial Stroke	5-21
PST Enable	
PST Variables View/Edit	

January 2007 **5-3** 

# **Detailed Setup**





## **Note**

Detailed Setup is not available for instrument level AC.

The *Detailed Setup* selection from the *Configure / Setup* menu allows you to configure the digital valve controller to your application. Table 5-1 lists the default settings for a standard factory configuration. You can adjust actuator response, set the various modes, alerts, ranges, travel cutoffs and limits. You can also restart the instrument and set the protection.

#### **Mode and Protection (1-2-1)**

#### Mode

• Instrument Mode 🔉

You can change the instrument mode by selecting *Mode and Protection, Instrument Mode* from the *Detailed Setup* menu, or press the Hot Key and select *Instrument Mode.* 

Instrument Mode allows you to either take the instrument Out Of Service or place it In Service. Taking the instrument Out Of Service allows you to perform instrument calibration and also allows you to change setup variables that affect control, provided the calibration/configuration protection is properly set. See Setting Protection.



# Note

Some changes that require the instrument to be taken Out Of Service will not take effect until the instrument is placed back In Service or the instrument is restarted.

Table 5-1. Factory Default Detailed Setup Parameters

	. Factory Default Defalled Setu Setup Parameter	Default Setting <sup>(1)</sup>
	Control Mode	Analog
	Restart Control Mode	Resume Last
	Zero Power Condition	Valve Open <sup>(2)</sup>
	Analog In Range Low	4 mA
		20 mA
	Analog In Range High	
	Analog Input Units	mA
	Feedback Connection	Rotary – All <sup>(2)</sup>
Instrument	Travel Sensor Motion	Clockwise <sup>(2)</sup>
Configuration	Auxiliary Terminal Mode	Disabled
	Max Supply Pressure	20 <sup>(2)</sup>
	Pressure Units	PSI
	Temperature Units	F
	Polling Address	0
	Burst Mode Enable	No
	Burst Command	3
	Cmd #3 (Trending) Pressure	A-B
	Tuning Set	F(2)
	Input Characteristic	Linear
	Travel Limit High	125%
	Travel Limit Low	-25%
	Travel/Pressure Cutoff High	99.50%
Dynamic Response and	Travel/Pressure Cutoff Low	0.50%
Tuning	Set Point Rate Open	0%/sec
·g	Set Point Rate Close	0%/sec
	Set Point Rate Close  Set Point Filter Lag Time	•
		0 sec
	Integral Gain	9.4 repeats/minute
	Integral Deadband	0.25%
	Cycle Count Alert Enable	No
	Cycle Count Alert Deadband	1%
Travel History	Cycle Count Alert Point	1,000,000
Alerts	Travel Accumulator Alert	No
	Enable	10/
	Travel Accumulator Deadband	1%
	Travel Accumulator Alert Point	1000000%
	Travel Deviation Alert Enable	Yes
	Travel Deviation Alert Point	5%
	Travel Deviation Time	10 sec
	Pressure Deviation Alert	Yes
Deviation &	Enable	
Other Alerts	Pressure Deviation Alert Point	5 psi
	Pressure Deviation Alert Time	10 sec
	Drive Signal Alert Enable	Yes
	Supply Pressure Alert Enable	Yes
	Supply Pressure Alert Point	19 psi
	Travel Alert Lo Enable	No
	Lo Point	-25%
	Travel Alert Hi Enable	No
	Hi Point	125%
Travel Alerts	Travel Alert Lo Lo Enable	No
	Lo Lo Point	-25%
	Travel Alert Hi Hi Enable	No
	Hi Hi Point	125%
		5%
	Deadband	
	Deadband Shutdown Activated	
Electronic	Shutdown Activated	Yes
Electronic Alerts		

**5-4** January 2007

# **Detailed Setup**

Table 5-1. Factory Default Detailed Setup Parameters (continued)

;	Default Setting <sup>(1)</sup>	
	Instrument Time Invalid Enable	Yes
	Calibration in Progress Enable	No
	Autocalibration in Progress Enable	No
	Diagnostics in Progress Enable	No
Informational Status	Diagnostics Data Available Enable	Yes
	Integrator Saturated Hi Enable	Yes
	Integrator Saturated Lo Enable	Yes
	Pressure Control Active Enable	Yes
	Multi-Drop Alert Enable	No
	Valve Alerts Enable	Yes
	Failure Alerts Enable	Yes
Alert Record	Misc Alerts Enable	No
	Alert Record Not Empty Enable	Yes
	Alert Record Full Enable	Yes

The settings listed are for standard factory configuration. DVC6000 Series instruments can also be ordered with custom configuration settings. For the default custom settings, refer to the order requisition.

 If the instrument is shipped mounted on an actuator, these values depend upon the actuator on which the instrument is mounted.

#### Control Mode >>>



You can change the control mode by selecting *Control* Mode from the Mode and Protection menu, or press the Hot Key and select Control Mode.

Control Mode lets you define where the instrument reads its set point. Follow the prompts on the Field Communicator display to choose one of the following control modes: Analog or Digital.

Choose Analog if the instrument is to receive its set point over the 4-20 mA loop. Normally the instrument control mode is Analog.

Choose Digital if the instrument is to receive its set point digitally, via the HART communications link.

A third mode, Test, is also displayed. Normally the instrument should not be in the Test mode. The Field Communicator automatically switches to this mode whenever it needs to stroke the valve during calibration or stroke valve, for example. However, if you abort from a procedure where the instrument is in the Test mode, it may remain in this mode. To take the instrument out of the Test mode, select Control Mode then select either Analog or Digital.

#### Restart Ctrl Mode

Restart Control Mode lets you choose which operating mode you want the instrument to be in after a restart. Access Restart Control mode by selecting Restart Ctrl Mode from the Mode and Protection menu. Follow the prompts on the Field Communicator display to define the restart control mode as Resume Last, Analog, or Digital.

#### Burst Mode

Enabling burst mode provides continuous communication from the digital valve controller. Burst mode applies only to the transmission of burst mode data (analog input, travel target, pressure, and travel) and does not affect the way other data is accessed.

Access to information in the instrument is normally obtained through the poll/response of HART communication. The Model 375 Field Communicator or the control system may request any of the information that is normally available, even while the instrument is in burst mode. Between each burst mode transmission sent by the instrument, a short pause allows the Field Communicator or control system to initiate a request. The instrument receives the request. processes the response message, and then continues "bursting" the burst mode data.

To enable burst mode, select Burst Mode, and Burst Enable from the Mode and Protection menu.

- Burst Enable—Yes or no. Burst mode must be enabled before you can change the burst mode command.
- Burst Command—There are four burst mode commands. Command 3 is recommended for use with the Rosemount Model 333 HART Tri-Loop HART-to-analog signal converter. The other three are not used at this time.
- Cmd 3(Trending)Press—Command 3 provides the following variables:

Primary variable—analog input in % or ma,

Secondary variable—travel target in % of ranged travel,

**Tertiary variable**—supply or output pressure in psig, bar, kPa, or kg/cm<sup>2</sup>. Select Select Cmd 3 Press from the Burst menu to select if the output A, output B, differential (A-B), or supply pressure is sent.

Quaternary variable—travel in % of ranged travel.

#### **Protection**

#### Protection

Some setup parameters may require changing the protection with the Field Communicator. To remove protection (change protection to None) requires placing a jumper across the Auxiliary terminals in the terminal box in order to change protection.

January 2007

#### **Note**

If the Aux Terminal Mode is configured for Auto Travel Calibration, be sure the jumper remains across the auxiliary terminals until the Field Communicator prompts you to remove it. Removing the jumper too soon will cause the instrument to begin auto travel calibration.

# **WARNING**

If the jumper is removed too soon, and auto travel calibration begins, the valve will move full stroke. To avoid personal injury and property damage caused by the release of pressure or process fluid, provide some temporary means of control for the process.

Two levels of protection are available:

- Config & Calib—Both setup and calibration are protected. Prohibits changing calibration and protected setup parameters.
- None—Neither setup nor calibration is protected.
   Allows changing calibration and setup parameters.

Table 5-3 lists configurable parameters in the instrument and the requirements for modifying these parameters, in terms of instrument mode and protection.

To change an instrument's protection, press the Hot key on the Field Communicator and select *Protection* or from the *Online* menu, select *Configure/Setup*, *Detailed Setup*, *Mode and Protection*, and *Protection*. Select the desired level of protection. Follow the prompts on the Field Communicator display to set the protection level. If necessary, temporarily attach the jumper to the AUX + and AUX – terminals in the instrument terminal box when prompted by the Field Communicator.

Table 5-2. Gain Values for Preselected Travel Tuning Sets

TUNING SET	PROPORTIONAL GAIN	VELOCITY GAIN	MINOR LOOP FEEDBACK GAIN
В	2.0	3.0	35
С	4.4	3.0	35
D	4.8	3.0	35
E	5.5	3.0	35
F	6.2	3.1	35
G	7.2	3.6	34
Н	8.4	4.2	31
I	9.7	4.8	27
J	11.3	5.6	23
K	13.1	6.0	18
L	15.5	6.0	12
M	18.0	6.0	12
X (Expert)	User Adjusted	User Adjusted	User Adjusted

#### **Response Control (1-2-2)**

Select Configure/Setup, Detailed Setup, and Response Control. Follow the prompts on the Field Communicator display to configure the following response control parameters: Tuning, Tvl/Press Control (Travel/Pressure Control), Input Char (Input Characteristic) Define Custom Char (Define Custom Characteristic), and Dynamic Response.

#### **Tuning**

**Travel Tuning (1-2-2-1-1)** 

# **WARNING**

Changes to the tuning set may cause the valve/actuator assembly to stroke. To avoid personal injury and property damage caused by moving parts, keep hands, tools, and other objects away from the valve/actuator assembly.

#### • Tvl Tuning Set (1-2-2-1-1-1)

Tvl Tuning Set— There are twelve tuning sets to choose from. Each tuning set provides a preselected value for the digital valve controller gain settings. Tuning set B provides the slowest response and M provides the fastest response. Table 5-2 lists the proportional gain, velocity gain and minor loop feedback gain values for preselected tuning sets.

5

# **Detailed Setup**

Table 5-3. Conditions for Modifying DVC6000 Series Digital Valve Controller Parameters

Parameters	In Service/ Config Protected	In Service/ Config Unprotected	Out of Service/ Config Protected	Out of Service/ Config Unprotecte
Control Mode			V	~
Restart Ctrl Mode				<b>1</b>
Burst Mode Enable	<i>\\</i>	<b>~</b>		<b>/</b>
Burst Mode Command				<b>1</b>
Protection	<i>\\</i>	<b>✓</b>	<b>/</b>	<b>1</b>
HART Tag		<i>V</i>		~
Message		<i>y</i>		<b>/</b>
Descriptor		<i>y</i>		· ·
Date '		, , , , , , , , , , , , , , , , , , ,		<i>V</i>
Valve Serial Num		<i>y</i>		·
Inst Serial Num				·
Polling Address				·
				·
Relay Type				<b>/</b>
Max Supply Pressure				
Actuator Style				<b>~</b>
Feedback Connection				<b>✓</b>
Travel Sensor Motion				<b>~</b>
/alve Style				<b>✓</b>
Zero Ctrl Signal				<b>✓</b>
Analog In Unita				
Analog In Units				
nput Range High				
nput Range Low				
Pressure Units				<b>✓</b>
Гетр Units	<i>\nu\</i>	<b>✓</b>		<i>V</i>
Tuning Set				<i>V</i>
Prop Gain				<b>✓</b>
/elocity Gain				V
MLFB Gain				V
nput Char				, /
Define Custom Char				1
Set Pt Filter Time				1
				· ·
ΓvI Limit High				<i>\rightarrow</i>
ΓvI Limit Low				<b>1</b>
Γvl Cutoff High				~
Tvl Cutoff Low				<b>✓</b>
Set Point Rate Open				<i>V</i>
Set Point Rate Close				· ·
				· ·
[vl Hi/Lo Enab	$\nu$	<b>✓</b>		<b>✓</b>
「vl HH/LL Enab	$\nu$	<b>✓</b>		<i>\rightarrow</i>
VI Alert Hi Pt	<i>&gt;</i>	~		<i>\rightarrow</i>
[vl Alert Lo Pt	<i>\\</i>	<i>&gt;</i>		<b>✓</b>
Γvl Alert HiHi Pt	<b>/</b>	<b>∠</b>		<b>1</b>
Γvl Alert LoLo Pt	<b>/</b>	<b>∠</b>		<b>/</b>
ΓvI Alrt DB	<b>/</b>	<b>∠</b>	<b>/</b>	<b>1</b>
Tvl Dev Alrt Enab	<u> </u>	<i>V</i>	<i>V</i>	<i>V</i>
vi Dev Airt Eriab Tvl Dev Airt Pt				
		· ·		· ·
vl Dev Time	V	<i>V</i>	<i>V</i>	<i>V</i>
Cycl Cnt Airt Enab	<b>~</b>	<i>\rightarrow</i>	~	<b>~</b>
Cycl Count Airt Pt	<b>~</b>	<b>✓</b>	<b>1</b>	<b>✓</b>
Cycl Count DB	<i>\rightarrow</i>	<b>✓</b>	~	~
Cycl Count	$\nu$	<b>✓</b>	~	~
VI Acum Airt Enab	<u> </u>	<i>V</i>	<i>V</i>	<i>V</i>
TVI Acum Airt Enab	V	<i>y</i>		
TVI Acum Alit Ft		· ·		*
	<u> </u>	<i>y</i>	<i>V</i>	<i>y</i>
Tvl Acum	<i>\(\begin{array}{cccccccccccccccccccccccccccccccccccc</i>	<i>V</i>	<i>V</i>	~
Aux Terminal Mode				~
Aux In Airt Enab				<b>~</b>
Aux In Alrt State				<b>✓</b>
Orive Alrt Enab	<b>~</b>	<b>✓</b>	<b>/</b>	, /
Supply Press Airt	, ,	, V	<i>/</i>	<i>y</i>
11 / 11	,	,	,	· · · · · · · · · · · · · · · · · · ·

-Continued-

January 2007 **5-7** 

Table 5-3. Conditions for Modifying DVC6000 Series Digital Valve Controller Parameters (Continued)

Parameters	In Service/ Config Protected	In Service/ Config Unprotected	Out of Service/ Config Protected	Out of Service/ Config Unprotected	
Flash ROM Fail				V	
No Free Time				$\nu$	
Ref Voltage Fail				<i>V</i>	
Drive Current Fail				<i>V</i>	
Critical NVM Fail				<b>✓</b>	
Temp Sensor Fail				<b>∠</b>	
Press Sensor Fail				<b>∠</b>	
Tvl Sensor Fail				<b>~</b>	
✓—indicates parameter may be modified for instrument mode and protection shown.					



## **Note**

When selecting a tuning set for a DVC6015, DVC6025 or DVC6035 remote mount unit, it may be necessary to reduce the tuning set, due to the effects of the long tubing between the digital valve controller and the actuator.

In addition, you can select User Adjusted or Expert, which allows you to modify tuning of the digital valve controller. With User Adjusted, you specify the proportional gain; an algorithm in the Field Communicator calculates the velocity gain and minor loop feedback gain. With Expert you can specify the proportional gain, velocity gain, and minor loop feedback gain.



### Note

Use Expert tuning only if standard tuning has not achieved the desired results.

Stabilize/Optimize or Performance Tuner may be used to achieve the desired results more rapidly than Expert tuning.

Table 5-5 provides tuning set selection guidelines for Fisher, Baumann, and Gulde actuators. These tuning sets are only recommended starting points. After you finish setting up and calibrating the instrument, you may have to select either a higher or lower tuning set to get the desired response. You can use the Performance Tuner to optimize tuning.

For an actuator not listed in the tables, you can estimate a starting tuning set by calculating the casing or cylinder volume. Then, in the tables, find an actuator with the closest equivalent volume and use the tuning set suggested for that actuator.

Tvl Prop Gain—Travel Proportional Gain is the proportional gain for the travel control tuning set. Changing this parameter will also change the tuning set to Expert.

Tvl Velocity Gain—Travel Velocity Gain is the velocity gain for the travel control tuning set. Changing this parameter will also change the tuning set to Expert.

Tvl MLFB Gain—Travel MLFB Gain is the minor loop feedback gain for the travel control tuning set. Changing this parameter will also change the tuning set to Expert.

- **Tvi Integ Enable**—Yes or No. Enable the integral setting to improve static performance by correcting for error that exists between the travel target and actual travel. Travel Integral Control is disabled by default.
- Tvl Integ Gain—Travel Integral Gain is the ratio of the change in output to the change in input, based on the control action in which the output is proportional to the time integral of the input.
- **Stabilize/Optimize**—Stabilize/Optimize permits you to adjust valve response by changing the digital valve controller tuning.

If the valve is unstable, select *Decrease Response* to stabilize valve operation. This selects the next lower tuning set (e.g., F to E). If the valve response is sluggish, select *Increase Response* to make the valve more responsive. This selects the next higher tuning set (e.g., F to G).

If after selecting *Decrease Response* or *Increase Response* the valve travel overshoot is excessive, select *Decrease Damping* to select a damping value that allows more overshoot. Select *Increase Damping* to select a damping value that will decrease the overshoot. When finished, select *done*.

**5-8** January 2007

#### • Performance Tuner



#### Note

The Performance Tuner is not available for instrument level HC.

The Performance Tuner is used to optimize digital valve controller tuning. It can be used with digital valve controllers mounted on most sliding-stem and rotary actuators, including Fisher and other manufacturers' products. Moreover, because the performance tuner can detect internal instabilities before they become apparent in the travel response, it can generally optimize tuning more effectively than manual tuning. Typically, the performance tuner takes 3 to 5 minutes to tune an instrument, although tuning instruments mounted on larger actuators may take longer.

#### Integral Settings (1-2-2-1-2)

- Integ DeadZ—Integral Dead Zone is a window around the Primary Setpoint in which integral action is disabled. This feature is used to eliminate friction induced limit cycles around the Primary Setpoint when the integrator is active. The Dead Zone is configurable from 0% to 2%, corresponding to a symmetric window from 0% to +/-2% around the Primary Setpoint. Default value is 0.25%.
- Integ Limit—The Integral Limit provides an upper limit to the integrator output. The high limit is configurable from 0 to 100% of the I/P drive signal.

Pressure Tuning (1-2-2-1-3)

# **WARNING**

Changes to the tuning set may cause the valve/actuator assembly to stroke. To avoid personal injury and property damage caused by moving parts, keep hands, tools, and other objects away from the valve/actuator assembly.

#### • Press Tuning Set (1-2-2-1-3-1)

Press Tuning Set—There are twelve Pressure Tuning Sets to choose from. Each tuning set provides a preselected value for the digital valve controller gain settings. Tuning set B provides the

Table 5-4. Gain Values for Preselected Pressure Tuning Sets

TUNING SET	PRESSURE PROPORTIONAL GAIN	PRESSURE INTEGRATOR GAIN	PRESSURE MINOR LOOP FEEDBACK GAIN
В	0.5	0.3	35
С	2.2	0.1	35
D	2.4	0.1	35
E	2.8	0.1	35
F	3.1	0.1	35
G	3.6	0.1	34
Н	4.2	0.1	31
1	4.8	0.1	27
J	5.6	0.1	23
K	6.6	0.1	18
L	7.8	0.1	12
M	9.0	0.1	12
X (Expert)	User Adjusted	User Adjusted	User Adjusted

slowest response and M provides the fastest response.

Tuning set B is appropriate for controlling a pneumatic positioner. Table 5-4 lists the proportional gain, pressure integrator gain and minor loop feedback gain values for preselected tuning sets.



#### Note

When selecting a tuning set for a DVC6015, DVC6025 or DVC6035 remote mount unit, it may be necessary to reduce the tuning set, due to the effects of the long tubing between the digital valve controller and the actuator.

In addition, you can specify Expert tuning and individually set the pressure proportional gain, pressure integrator gain, and pressure minor loop feedback gain. Individually setting or changing any tuning parameter will automatically change the tuning set to X (expert).



# **Note**

Use Expert tuning only if standard tuning has not achieved the desired results.

Stabilize/Optimize and performance tuner may be used to achieve the desired results more rapidly than Expert tuning.

January 2007 **5-9** 

Table 5-5. Actuator Information for Initial Setup

Actuator	Actuator Actuator Size Actuator Style Starting Feedback	Feedback	Travel Sensor	sor Motion			
Manufacturer	Model	Actuator Size	Actuator Style	Tuning Set	Connection	Relay A or C	Relay B
	585C & 585CR	25 50, 60 60, 80 100, 130	Piston Dbl w/ or w/o Spring. See actuator instruction manual and nameplate.	F J L M	SStem-Standard for travels up to 4 inches. SStem- Roller for longer travels	Depends upon pneumatic connections. See description for Travel Sensor Motion	
	657	30 34, 40 45, 50 46, 60, 70, 76, & 80-100	Spring & Diaphragm	H K L	SStem-Standard	Clockwise	Counterclockwise
	667	30 34, 40 45, 50 46, 60, 70, 76, & 80-100	Spring & Diaphragm	H K L	SStem-Standard	Counterclockwise	Clockwise
Fisher	1051 & 1052	20, 30 33 40 60, 70	Spring & Diaphragm	H I K M	Rotary	Clockwise	Counterclockwise
	1061	30 40 60 68, 80, 100, 130	Piston Dbl w/o Spring	J K L M	Rotary	Depends upon pneumatic connections. See description for Travel Sensor Motion	
	1066	20, 27, 75	Piston Dbl w/o Spring	Specify	Rotary	Depends upon pneumatic connections. See description for Travel Sensor Motion	
	1066SR	20 27, 75	Piston Sgl w/Spring	G L	Rotary	Depends upon mounting style, actuator instruction manual and 5-6	
		225		X <sup>(2)</sup>		Air	to
	GX	750	Spring & Diaphragm	K	SStem-Standard	Open	Close
		1200	Diapiliagili	М		Counterclockwise	Clockwise
	Air to Extend	16		C	001 6: : :	Clockwise	Counterclockwise
_	Air to Retract	32 570	Spring &	E SStem-Standard K	Counterclockwise	Clockwise	
Baumann	Rotary	10 25 54	Diaphragm	E H J	Rotary	Spe	ecify
Gulde	3024	GA 1.21 GA 1.31 GA 1.41	Spring & Diaphragm	E H K	SStem-Standard	For P <sub>o</sub> operating mode (air opens), Counterclockwise For P <sub>s</sub> operating mode (air closes), Clockwise	For P <sub>o</sub> operating mode (air opens), Clockwise For P <sub>s</sub> operating mode (air closes), Counterclockwise
	3025	P460, P462, P900		М	Rotary	Spe	ecify

Table 5-6. Travel Sensor Motion Selections for Type DVC6030 on Type 1066SR Actuators

Marintina Chila	Travel Sensor Motion		
Mounting Style	Relay A or C	Relay B	
Α	Clockwise	Counterclockwise	
В	Counterclockwise	Clockwise	
С	Counterclockwise	Clockwise	
D	Clockwise	Counterclockwise	

**5-10** January 2007

# **Detailed Setup**

Press Prop Gain—Pressure Proportional Gain is the proportional gain for the pressure control tuning set. Changing this parameter will also change the tuning set to Expert.

Press MLFB Gain—Pressure MLFB Gain is the minor loop feedback gain for the pressure control tuning set. Changing this parameter will also change the tuning set to Expert.

- Press Integ Enable—Yes or No. Enable the pressure integral setting to improve static performance by correcting for error that exists between the pressure target and actual pressure. Pressure Integral Control is disabled by default.
- Press Integ Gain—Pressure Integral Gain (also called reset) is the ratio of the change in output to the change in input, based on the control action in which the output is proportional to the time integral of the input. Changing this parameter will also change the tuning set to Expert.

#### TvI/Press Control (1-2-2-2)

#### • TvI/Press Select

Travel / Pressure Select determines if the instrument is set up for position or pressure control. Select Travel, Pressure, Travel with Pressure Fallback/Auto recovery or Travel with Pressure Fallback/Manual Recovery. If the travel sensor fails, and Travel with Pressure Fallback/Auto Recovery is selected, it will return to travel control when the travel sensor starts working again. Travel with Pressure Fallback/Manual recovery will stay in pressure control until Travel Pressure Select is changed to Travel or Travel with Pressure Fallback/Auto recovery. It is not necessary to enable the Travel Sensor Alert for Pressure Fallback to occur.

#### TvI/Press Cutoffs (1-2-2-2-2)

• Tvl/Press Cut Hi—Travel Cutoff High defines the high cutoff point for the travel in percent (%) of ranged input current. Above this cutoff, the travel target is set to 123.0% of the ranged input current. When a Travel Cutoff High is set, the Travel Limit High is deactivated, since only one of these parameters can be active. Travel Cutoff Hi is deactivated by setting it to 125.0%.

Pressure Cutoff Hi defines the high cutoff point for the pressure in percent (%) of pre-characterized setpoint. Above this cutoff, the pressure target is set to 123.0%. A Pressure Cutoff Hi of 99.5% is recommended to ensure valve goes fully open. Pressure Cutoff Hi is deactivated by setting it to 125%. ● TvI/Press Cut Lo—Travel Cutoff Low defines the low cutoff point for the travel set point. Travel Cutoff Low can be used to ensure proper seat load is applied to the valve. When below the travel cutoff low, the output is set to zero or to full supply pressure, depending upon the zero power condition. A Travel Cutoff Low of 0.5% is recommended to help ensure maximum shutoff seat loading. When a Travel Cutoff Low is set, the Travel Limit Low is deactivated, since only one of these parameters can be active. Travel Cutoff Low is deactivated by setting it to −25%.

Pressure Cutoff Lo defines the low cutoff point for the pressure in percent (%) of pre-characterized setpoint. Below this cutoff, the pressure target is set to -23%. A Pressure Cutoff Lo of 0.5% is recommended to help ensure maximum shutoff seat loading. Pressure Cutoff Lo is deactivated by setting it to -25.0%

#### **Travel Limits (1-2-2-3)**

- Tvl Limit Hi—Travel Limit High defines the high limit for the travel in percent (%) of ranged travel. If is the maximum allowable travel (in percent of ranged travel) for the valve. During operation, the travel target will not exceed this limit. When a Travel Limit High is set, the Travel Cutoff High is deactivated, since only one of these parameters can be active. Travel Limit High is deactivated by setting it to 125.0%
- Tvl Limit Lo—Travel Limit Low defines the low limit for the travel in percent (%) of ranged travel. It is the minimum allowable travel (in percent of ranged travel) for the valve. During operation, the travel target will not exceed this limit. When a Travel Limit Low is set, the Travel Cutoff Low is deactivated, since only one of these parameters can be active. Travel Limit Low is deactivated by setting it to -25.0%.

#### Pressure Control (1-2-2-2-4)

- Press Range Hi—Pressure Range Hi is the high end of output pressure range. Enter the pressure that corresponds with 100% valve travel when Zero Power Condition is closed, or 0% valve travel when Zero Power Condition is open. This pressure must be greater than the Pressure Range Lo.
- Press Range Lo—Pressure Range Low is the low end of the output pressure range. Enter the pressure that corresponds to 0% valve travel when Zero Power Condition is closed, or 100% valve travel when Zero Power Condition is open. This pressure must be less than the Pressure Range Hi.

January 2007 **5-11** 

End Pt Press Control (1-2-2-2-5)



#### Note

End Point Pressure Control is only available for instrument level ODV.

- End Pt Control Enab— Select Yes or No. End Point Pressure Control allows the digital valve controller to pull back from saturation of the pneumatic output after reaching the travel extreme. Rather than having the instrument provide full supply pressure (saturation) continuously at the travel extreme, the digital valve controller switches to an End Point Pressure Control where the output pressure (pressure controller set point) to the actuator is maintained at a certain value. This value is configured through the Upper Operating Pressure feature. Because the digital valve controller is constantly in control and not allowed to reach a dormant or saturated state, it is constantly testing its own pneumatic system. If there is an output pressure deviation, for example, the instrument will issue an alert. To ensure there is an alert when an output pressure deviation occurs, setup the alert as described under Pressure Deviation Alert.
- PST Start Pt—Defines the travel stop the valve needs to be at before a partial stroke test can be initiated. Also defines the travel stop for end point pressure control. Setting this value to Not Configured will disable partial stroke tests and end point pressure control.
- Press Set Point—Used in conjunction with End Point Pressure Control, Pressure Set Point allows the user to select a pressure to be delivered by the instrument at the travel extreme. For a fail-closed valve, this pressure must be sufficient to maintain the fully open position. For a fail-open valve, this pressure (which is automatically set to supply pressure) must be sufficient to fully close the valve and maintain its rated shutoff classification. For double-acting spring return actuators, this is the differential pressure required to either maintain the fully open or fully closed position, depending on the valve and actuator configuration. For a double-acting actuator without springs with a fail-close valve, this is 95% of the supply pressure. If the valve is fail-open, the upper operating pressure for all actuator is set to the supply pressure.

• Press Sat Time—Pressure Sat Time is the amount of time the digital valve controller stays in hard cutoff before switching to pressure control. Default is 45 seconds.

#### Input Char (1-2-2-3)

Input Characterization defines the relationship between the travel target and ranged set point. Ranged set point is the input to the characterization function. If the zero power condition equals closed, then a set point of 0% corresponds to a ranged input of 0%. If the zero power condition equals open, a set point of 0% corresponds to a ranged input of 100%. Travel target is the output from the characterization function.

To select an input characterization, select *Select Input Char* from the *Input Char* menu. You can select from the three fixed input characteristics shown in figure 5-1 or you can select a custom characteristic. Figure 5-1 shows the relationship between the travel target and ranged set point for the fixed input characteristics, assuming the Zero Power Condition is configured as closed.

You can specify 21 points on a custom characteristic curve. Each point defines a travel target, in % of ranged travel, for a corresponding set point, in % of ranged set point. Set point values range from –6.25% to 106.25%. Before modification, the custom characteristic is linear.

#### **Define Custom Char (1-2-2-4)**


To define a custom input character, from the *Input Char* menu select *Define Custom Char*. Select the point you wish to define (1 to 21), then enter the desired set point value. Press Enter then enter the desired travel target for the corresponding set point. When finished, select point 0 to return to the *Input Char* menu.


With input characterization you can modify the overall characteristic of the valve and instrument combination. Selecting an equal percentage, quick opening, or custom (other than the default of linear) input characteristic modifies the overall valve and instrument characteristic. However, if you select the linear input characteristic, the overall valve and instrument characteristic is the characteristic of the valve, which is determined by the valve trim (i.e., the plug or cage).

#### Dynamic Response (1-2-2-5)

• SP Rate Open—Maximum rate (% of valve travel per second) at which the digital valve controller will move to the open position regardless of the rate of input current change. A value of 0 will deactivate this feature and allow the valve to stroke open as fast as possible.

**5-12** January 2007








Figure 5-1. Travel Target Versus Ranged Set Point, for Various Input Characteristics (Zero Power Condition = Closed)

• SP Rate Close—Maximum rate (% of valve travel per second) at which the digital valve controller will move to the close position regardless of the rate of input current change. A value of 0 will deactivate this feature and allow the valve to stroke close as fast as possible.



# **Note**

Lag Time is only available for instrument level HC, AD, and PD.

• Lag Time—Slows the response of the digital valve controller. A value ranging from 0.2 to 10.0 can be used for noisy or fast processes to improve closed loop process control. Entering a value of 0.0 will deactivate the lag filter.



# **Note**

Lead/Lag is only available for instrument level ODV.

• Lead/Lag—ODV tiered devices have access to a lead-lag input filter that can be used to improve a valve's dynamic response. The lead-lag input filter is part of the set point processing routine that reshapes the input signal before it becomes travel set point. Lead-lag filters are characterized by lead and lag time constants.

When the valve is in its active control region (off the seat), the lead-lag filter improves small amplitude response by momentarily overdriving the travel set point. This is useful when the actuator is large and equipped with accessories. As a result, any volume boosters that are present will be activated. The longer the lag time, the more pronounced the overdrive. Since the lead-lag input filter is used to enhance the dynamic response of a control valve, filter parameters should be set after the tuning parameters have been established.

January 2007

Table 5-7. Typical Lead/Lag Filter Settings

Parameter	Description	Typical Value
Lag Time	First order time constant. A value of 0.0 will disable the lead-lag filter.	0.2 sec
Opening Lead/Lag Ratio	Initial response to the filter in the opening direction.	2.0
Closing Lead/Lag Ratio	Initial response to the filter in the closing direction.	2.0
Lead-Lag Boost	Initial conditions of the lead-lag filter when the lower travel cutoff is active.	Off

When the valve is at its seat, the lead-lag filter also has a boost function that sets the initial conditions of the filter artificially low so that small amplitude signal changes appear to be large signal changes to the filter. The boost function introduces a large spike that momentarily overdrives the instrument and activates any external volume boosters that may be present. The lead-lag boost function is normally disabled except for those cases where the valve must respond to small command signals off the seat. By setting the lead/lag ratio in the opening and closing directions to 1.0, the boost function can be enabled without introducing lead-lag dynamics in the active control region. See table 5-7 for typical lead-lag filter settings.

#### **Alerts (1-2-3)**

The following menus are available for configuring Alerts. Items on the menus may be changed with the instrument In Service. Protection does not need to be removed (no need to set to *None*). Alerts are not processed when a Diagnostic is in progress. Select *Configure / Setup*, *Detailed Setup*, and *Alerts*. Follow the prompts on the Field Communicator display to configure the following Alerts: *Electronic Alerts*, *Sensor Alerts*, *Environmental Alerts*, *Travel Alerts*, *Travel History Alerts*, *SIS Alerts* (instrument level ODV only), and *Alert Record*.

#### • Electronic Alerts (1-2-3-1)

• Drive Current Shutdown— When enabled, the instrument shuts down whenever the drive current does not read as expected.

#### Drive Signal Alert (1-2-3-1-2)

Drive Signal Alert checks the drive signal and calibrated travel. If one of the following conditions exists for more than 20 seconds, the Drive Signal Alert is set.

For the case where Zero Power Condition is defined as closed:

Drive Signal < 10% and Calibrated Travel > 3%

Drive Signal > 90% and Calibrated Travel < 97%

For the case where Zero Power Condition is defined as open:

Drive Signal < 10% and Calibrated Travel < 97%

Drive Signal > 90% and Calibrated Travel > 3%

- *Drive Signal Alert Enable*—Yes or No. Drive Signal Alert Enable activates checking of the relationship between the Drive Signal and the calibrated travel.
- *Drive Signal*—Shows the value of the instrument drive signal in % (percent) of maximum drive.

#### Processor Impaired Alerts (1-2-3-1-3)

- Offline/Failed Alrt Enab—If enabled, set when the device is in a failed state and not controlling the input.
- Power Starvation Alrt Enab—When enabled, the instrument shuts down whenever there is a failure associated with power starvation.
- Non-Critical NVM AIrt Enab—When enabled, the instrument shuts down whenever there is a failure associated with non-critical NVM (non-volatile memory).
- Critical NVM Shutdown—When enabled, the instrument shuts down whenever there is a failure associated with critical NVM (non-volatile memory).
- Flash ROM Shutdown—When enabled, the instrument shuts down whenever there is a failure associated with flash ROM (read only memory).
- No Free Time Shutdown—When enabled, the instrument shuts down whenever there is a failure associated with No Free Time.
- Reference Voltage Shutdown—When enabled, the instrument shuts down whenever there is a failure associated with the internal voltage reference.

**5-14** January 2007

#### • Sensor Alerts (1-2-3-2)

#### • Tvl Sensor Shutdown

When enabled, the instrument shuts down whenever there is a failure associated with the travel sensor.

#### • Temp Sensor Shutdown

When enabled, the instrument shuts down whenever there is a failure associated with the temperature sensor.



# **Note**

The Pressure Sensor Shutdown alert is not available in instrument level HC.

#### Press Sensor Shutdown

When enabled, the instrument shuts down whenever there is a failure associated with the pressure sensor.

#### Environmental Alerts

#### Aux Terminal Alerts (1-2-3-3-1)

- Aux Terminal Alrt Enab—Yes or No. Auxiliary Input Alert Enable activates checking the status of the auxiliary input when the Auxiliary Terminal Mode is Aux Input Alert. When enabled, the Auxiliary Input Alert is set when the auxiliary input terminals are either open or closed, depending upon the selection for the Aux In Alrt State.
- Aux Input—The auxiliary input is a contact or discrete input, which may be open or closed.
- Aux Term Mode—Aux Input Alert or Auto Travel Calib. Selecting Aux Input Alert then Aux In Alrt Enab activates checking the status of the auxiliary input contacts. Selecting Auto Travel Calib permits starting an automatic travel calibration procedure by placing a jumper across the auxiliary input terminals for 3 to 5 seconds.



# **Note**

The Supply Pressure Lo alert is not available in instrument level HC.

#### Supply Press Lo Alert (1-2-3-3-2)

- Supply Press Lo Alrt Enab—When enabled, the instrument shuts down whenever there is a failure associated with the supply pressure.
- Supply Press—Supply Pressure displays the instrument supply pressure in kPa,bar, or psi.
- Supply Press Lo Alrt Pt—Supply Pressure Lo Alert Point. When the supply pressure falls below the supply pressure alert point, the supply pressure alert is active. To disable the supply pressure alert, set Supply Press Alrt Pt to zero.

#### • Travel Alerts (1-2-3-4)

- *Travel*—Travel displays the actual position of the valve in percent (%) of calibrated travel.
- Tvl Set Pt—Travel set point is the input to the characterization function.
- Tvl Airt DB—Travel Alert Deadband is the travel, in percent (%) of ranged travel, required to clear a travel alert, once it has been set. The deadband applies to both Travel Alert Hi/Lo and Travel Alert Hi Hi/Lo Lo. See figure 5-2.

#### Deviation Alert (1-2-3-4-4)


If the difference between the travel target and the actual target exceeds the Travel Deviation Alert Point for more than the Travel Deviation Time, the Travel Deviation Alert is set. It remains set until the difference between the travel target and the actual travel is less than the Travel Deviation Alert Point minus the Travel Alert Deadband.

- Tvl Dev Alrt Enable—Travel Deviation Alert Enable, select Yes or No. When enabled, checks the difference between the travel target and the actual travel.
- Tvl Dev Alrt Pt—Travel Deviation Alert Point is the alert point for the difference, expressed in percent (%), between the travel target and the actual travel. When the difference exceeds the alert point for more than the Travel Deviation Time, the Travel Deviation Alert is set.
- Tvl Dev Time—Travel Deviation Time is the time, in seconds, that the travel deviation must exceed the Travel Deviation Alert Point before the alert is set.

#### Limit Alerts (1-2-3-4-5)

Travel Alert Hi Hi is set if the ranged travel rises above the alert high point. Once the alert is set, the ranged travel must fall below the alert high high

January 2007



66532/IL

Figure 5-2. Travel Alert Deadband

point by the Travel Alert Deadband before the alert is cleared. See figure 5-2.

Travel Alert Lo Lo is set if the ranged travel falls below the alert low low point. Once the alert is set, the ranged travel must rise above the alert low low point by the Travel Alert Deadband before the alert is cleared.

- Tvl Alrt Hi Hi Enab—Yes or No. Travel Alert HiHi Enable activates checking of the ranged travel against the Travel Alert High-High points.
- Tvl Airt Lo Lo Enab—Yes or No. Travel Alert LoLo Enable activates checking of the ranged travel against the Travel Alert Low-Low points.
- Tvl Alrt Hi Hi Pt—Travel Alert High-High Point is the value of the travel, in percent (%) of ranged travel, which, when exceeded, sets the Travel Alert Hi Hi alert.
- Tvl Alrt Lo Lo Pt—Travel Alert Low-Low Point is the value of the travel, in percent (%) of ranged travel, which, when exceeded, sets the Travel Alert Lo Lo alert.

#### Travel Limit Hi/Lo Alerts (1-2-3-4-6)

Travel Alert Hi is set if the ranged travel rises above the alert high point. Once the alert is set, the ranged travel must fall below\_the alert high point by the Travel Alert Deadband before the alert is cleared. See figure 5-2.

Travel Alert Lo is set if the ranged travel falls below the alert low point. Once the alert is set, the ranged travel must rise above the alert low point by the Travel Alert Deadband before the alert is cleared.

• Tvl Alrt Hi Enab—Yes or No. Travel Alert Hi Enable activates checking of the ranged travel against the Travel Alert High Point.

- Tvl Alrt Lo Enab—Yes or No. Travel Alert Lo Enable activates checking of the ranged travel against the Travel Alert Lo Point.
- Tvl Alrt Hi Point—Travel Alert High Point is the value of the travel, in percent (%) of ranged travel, which, when exceeded, sets the Travel Alert High alert.
- Tvl Alrt Lo Point—Travel Alert Low Point is the value of the travel, in percent (%) of ranged travel, which, when exceeded, sets the Travel Alert Low alert.

#### Travel Limit Cutoff Alerts (1-2-3-4-7)

- Tvl Limit/Cutoff Hi Alrt Enab—Yes or No. Travel Limit /Cutoff Hi Alert Enable activates the Travel Limit / Cutoff Hi alert.
- Tvl Limit/Cutoff Lo Alrt Enab—Yes or No. Travel Limit /Cutoff Lo Alert Enable activates the Travel Limit/Cutoff Lo alert.
- Tvl/Press Cut Hi—Travel Cutoff Hi defines the high cutoff point for the travel in percent(%) of pre-characterized set point. Above this cutoff, the travel target is set to 123.0% of the ranged travel. Travel Cutoff Hi is deactivated by setting it to 125.0%.

Pressure Cutoff Hi defines the high cutoff point for the pressure in percent(%) of pre-characterized set point. Above this cutoff,the pressure target is set to 123.0%. A Pressure Cutoff Hi of 99.5% is recommended to ensure valve goes fully open. Pressure Cutoff Hi is deactivated by setting it to 125%

● Tvl/Press Cut Lo—Travel Cutoff Lo defines the low cutoff point for the travel in percent (%)of pre-characterized set point. Below this cutoff, the travel target is set to −23%. A Travel Cutoff Lo of 0.5% is recommended to help ensure maximum shutoff seat loading. Travel Cutoff Lo is deactivated by setting it to−25.0%

Pressure Cutoff Lo defines the low cutoff point for the pressure in percent(%) of pre-characterized set point. Below this cutoff,the pressure target is set to -23%. A Pressure Cutoff Lo of 0.5% is recommended to help ensure maximum shutoff seat loading. Pressure Cutoff Lo is deactivated by setting it to -25.0%

• Tvl Limit High—Travel Limit High defines the high limit for the travel in percent (%) of ranged travel. It is the maximum allowable travel (in percent of ranged travel) for the valve. During operation, the travel target will not exceed this limit.

**5-16** January 2007




Figure 5-3. Travel Accumulator Deadband (set at 10%)

When a Travel Limit High is set, the Travel Cutoff High is deactivated, since only one of these parameters can be active. Travel Limit High is deactivated by setting it to 125.0%.

● Tvl Limit Lo—Travel Limit Low defines the low limit for the travel in percent (%) of ranged travel. It is the minimum allowable travel (in percent of ranged travel) for the valve. During operation, the travel target will not exceed this limit. When a Travel Limit Low is set, the Travel Cutoff Low is deactivated, since only one of these parameters can be active. Travel Limit Low is deactivated by setting it to −25.0%.

#### • Travel History Alerts

#### Cycle Count (1-2-3-5-1)

- Cycle Count Airt Enab—Yes or No. Cycle Counter Alert Enable activates checking of the difference between the Cycle Counter and the Cycle Counter Alert point. The Cycle Counter Alert is set when the value exceeds the Cycle Counter Alert point. It is cleared after you reset the Cycle Counter to a value less than the alert point.
- Cycle Count—Cycle Counter records the number of times the travel changes direction. The change in direction must occur after the deadband has been exceeded before it can be counted as a cycle. See figure 5-4. You can reset the Cycle Counter by configuring it as zero.
- Cycle Count Airt Pt—Cycle Counter Alert Point is the value of the Cycle Counter, in cycles, which, when exceeded, sets the Cycle Counter Alert.




Figure 5-4. Cycle Counter Deadband (set at 10%)

#### Cycle Count/Tvl Accum Deadband (1-2-3-5-2)

Deadband

Cycle Counter Deadband is the area around the travel reference point, in percent (%) of ranged travel, that was established at the last increment of the Cycle Counter. This area must be exceeded before a change in travel direction can be counted as a cycle. See figure 5-4.

Travel Accumulator Deadband is the area around the travel reference point, in percent (%) of ranged travel, that was established at the last increment of the accumulator. This area must be exceeded before a change in travel can be accumulated. See figure 5-3.

#### Tvl Accum (1-2-3-5-3)

- Tvl Accum Alrt Enab—Yes or No. Travel Accumulation Alert Enable activates checking of the difference between the Travel Accumulator value and the Travel Accumulator Alert Point. The Travel Accumulation Alert is set when the Travel Accumulator value exceeds the Travel Accumulator Alert Point. It is cleared after you reset the Travel Accumulation to a value less than the alert point.
- Tvl Accum—Travel Accumulator records the total change in travel, in percent (%) of ranged travel, since the accumulator was last cleared. The value of the Travel Accumulator increments when the magnitude of the change exceeds the Travel Accumulator Deadband. See figure 5-3. You can reset the Travel Accumulator by configuring it to zero.
- Tvl Accum Alrt Pt—Travel Accumulator Alert Point is the value of the Travel Accumulator, in percent (%) of ranged travel, which, when exceeded, sets the Travel Accumulator Alert.

January 2007

• SIS Alerts (1-2-3-6)



## Note

SIS Alerts are only available for instrument level ODV.

- PST Press Limit—Partial Stroke Test
  Pressure Limit defines the output pressure that will
  cause the partial stroke test to stop. For actuators
  that vent from the test starting point, the pressure
  limit will be a minimum value. For actuators that fill
  from the test starting point, the pressure limit will
  be a maximum value.
- Press Dev Alrt Enab—Pressure Deviation Alert Enable, select Yes or No. This alert notifies a monitoring system when a deviation in the actuator pressure has occurred. This is used when the instrument is controlling via pressure (Pressure Control Mode is enabled) to the actuator (rather than valve position) to prevent saturation of the pneumatic output. If the target pressure deviates from the actual pressure within a certain band of time, the alert will activate. The pressure deviation alert point and deviation alert time are configurable and can be disabled altogether. When enabled, this alert checks the difference between the target pressure and the actual pressure. If the difference exceeds the Pressure Deviation Alert Point for more than the Pressure Deviation Time, the Pressure Deviation Alert is set. It remains set until the difference between the target pressure and the actual pressure is less than the Pressure Deviation Alert Point.
- Press Dev Alrt Pt—Pressure Deviation Alert Point is the alert point for the difference between the pressure target and the actual pressure. When the difference exceeds the alert point for more than the Pressure Deviation Time, the Pressure Deviation Alert is set.
- Press Dev Time—Pressure Deviation Time is the time, in seconds, that the pressure deviation must exceed the Pressure Deviation Alert Point before the alarm is set.
- Alert Record (1-2-3-6) HC, AD, and PD (1-2-3-7) ODV

To be recorded, an alert must both be enabled for reporting, and the group in which it resides must be

Table 5-8. Alerts Included in Alert Groups for Alert Record

Alert Group	Alerts Include in Group
	Travel Lo Alert
Valve Alerts	Travel Hi Alert
	Travel Lo Lo Alert
	Travel Hi Hi Alert
	Travel Deviation Alert
	Drive Signal Alert
	Flash ROM Fail
	No Free Time
	Reference Voltage Fail
Failure Alerts	Drive Current Fail
I allule Aleits	Critical NVM Fail
	Temperature Sensor Fail
	Pressure Sensor Fail
	Travel Sensor Fail
Miscellaneous Alerts	Auxiliary input

enabled for recording. Table 5-8 lists the alerts included in each of the groups. When any alert from an enabled group becomes active, active alerts in all enabled groups are stored.

- Alrt Record Not Empty Enab—Yes or No. When enabled indicates when an alert has been recorded.
- Alrt Record Full Enab—Yes or No. When enabled indicates when the Alert Event Record is full.
- *Display Record*—Displays all recorded alerts and the date and time the alerts were recorded.
- Clear Record—Clears the alert record. To clear the alert record, all alerts in enabled groups must be inactive.

Alert Groups (1-2-3-6-5) HC, AD, and PD (1-2-3-7-5) ODV

- Failure Group Enab—Permits enabling the Failure Alert group. Table 5-8 lists the alerts included in each of the groups.
- Valve Group Enab—Permits enabling the Valve Alert group. Table 5-8 lists the alerts included in each of the groups.
- *Misc Group Enab*—Permits enabling the Miscellaneous Alert group. Table 5-8 lists the alerts included in each of the groups.

## **Status (1-2-4)**

Select Configure / Setup, Detailed Setup, and Status. Follow the prompts on the Field Communicator display to configure the following parameters: Instrument Time, Calibration and Diagnostics, Operational, and Integrator.

**5-18** January 2007

#### • Instrument Time (1-2-4-1)

- Inst Time Invalid Enab—Yes or No. When enabled indicates when the Instrument Time Invalid alert is active.
- Inst Date and Time—Permits setting the instrument clock. When alerts are stored in the alert record, the date and time (obtained from the instrument clock) that they were stored is also stored in the record. The instrument clock uses a 24-hour format.

## • Calibration & Diagnostics (1-2-4-2)

- Cal in Progress Enab—Yes or No. When enabled indicates that calibration is in progress.
- AutoCal in Progress Enab—Yes or No. When enabled indicates that auto calibration is in progress.
- *Diag in Progress Enab*—Yes or No. When enabled indicates that a diagnostic test is in progress.
- *Diag Data Avail Enab*—Yes or No. When enabled indicates when there is diagnostic data available.

#### Operational (1-2-4-3)

- Press Cntrl Active Enab—Yes or No. When enabled indicates when Pressure Control is active.
- *Multi-Drop Enab*—Yes or No. When enabled indicates the digital valve controller is operating in a multi-drop loop.

#### • Integrator (1-2-4-4)

- Integrator Sat Hi Enab—Yes or No. When enabled indicates when the Integrator Saturated High alert is active.
- Integrator Sat Lo Enab—Yes or No. When enabled indicates when the Integrator Saturated Lo alert is active.
- Integ Limit—The Integral Limit provides an upper limit to the integrator output. The high limit is configurable from 0 to 100% of the I/P drive signal.
- Integ DeadZ—Integral Dead Zone is a window around the Primary Setpoint in which integral action is disabled. This feature is used to eliminate friction induced limit cycles around the Primary Setpoint when the integrator is active. The Dead

Zone is configurable from 0% to 2%, corresponding to a symmetric window from 0% to  $\pm -2\%$  around the Primary Setpoint. Default value is 0.25%.


## Instrument (1-2-5)

Select Configure / Setup, Detailed Setup, and Instrument. Follow the prompts on the Field Communicator display to configure the following Instrument parameters: General, Units, Analog Input Range, Relay Type, Zero Pwr Condition (Zero Power Condition), Max Supply Press (Maximum Supply Pressure), Aux Term Mode (Auxiliary Terminal Mode) Inst Date and Time (Instrument Date and Time), and Calib Status and Loc (Calibration Status and Location).

## • General (1-2-5-1)

- HART Tag—Enter an up to 8 character HART tag for the instrument. The HART tag is the easiest way to distinguish between instruments in a multi-instrument environment. Use the HART tag to label instruments electronically according to the requirements of your application. The tag you assign is automatically displayed when the Field Communicator establishes contact with the digital valve controller at power-up.
- Message—Enter any message with up to 32 characters. Message provides the most specific user-defined means for identifying individual instruments in multi-instrument environments.
- Descriptor—Enter a descriptor for the application with up to 16 characters. The descriptor provides a longer user-defined electronic label to assist with more specific instrument identification than is available with the HART tag.
- Date—Enter a date with the format MM/DD/YY. Date is a user-defined variable that provides a place to save the date of the last revision of configuration or calibration information.
- Valve Serial Num—Enter the serial number for the valve in the application with up to 12 characters.
- *Inst Serial Num*—Enter the serial number on the instrument nameplate, up to 12 characters.
- Polling Address—If the digital valve controller is used in point-to-point operation, the Polling Address is 0. When several devices are connected in the same loop, such as for split ranging, each device must be assigned a unique polling address. The Polling Address is set to a value between 0 and 15. To change the polling address the instrument must be Out Of Service.

January 2007



NOTE: ZPC = ZERO POWER CONDITION

Figure 5-5. Calibrated Travel to Analog Input Relationship

For the Field Communicator to be able to communicate with a device whose polling address is not 0, it must be configured to automatically search for all or specific connected devices. For information on configuring the Field Communicator for automatic polling, see the Model 375 Field Communicator Basics section.

#### • Units (1-2-5-2)

- Pressure Units—Defines the output and supply pressure units in either psi, bar, kPa, or kg/cm<sup>2</sup>.
- Temp Units—Degrees Fahrenheit or Celsius. The temperature measured is from a sensor mounted on the digital valve controller's printed wiring board.
- Analog In Units—Permits defining the Analog Input Units in mA or percent of 4–20 mA range.

#### Analog Input Range (1-2-5-3)

- Input Range Hi—Permits setting the Input Range High value. Input Range High should correspond to Travel Range High, if the Zero Power Condition is configured as closed. If the Zero Power Condition is configured as open, Input Range High corresponds to Travel Range Low. See figure 5-5.
- Input Range Lo—Permits setting the Input Range Low value. Input Range Low should correspond to Travel Range Low, if the Zero Power




Figure 5-6. Feedback Connection for Typical Sliding-Stem Actuator (Up to 4-inch Travel)

Condition is configured as closed. If the Zero Power Condition is configured as open, Input Range Low corresponds to Travel Range High. See figure 5-5.

## • Relay Type

There are three basic categories of relays that result in various combinations from which to select.

Relay Type: The relay type is printed on the label affixed to the relay body. A = double-acting, B = single-acting, C= single-acting, direct.

Special App: This is used only in single-acting applications where the "unused" output port is configured to read the pressure downstream of a solenoid valve. See page 2-17 for additional information.

Lo Bleed: The label affixed to the relay body indicates whether it is a low bleed version.

#### Zero Pwr Cond

Identifies whether the valve is open or closed when instrument power is lost. If you are unsure how to set this parameter, disconnect the segment loop power to the instrument. The resulting valve travel is the Zero Power Condition.

## Max Supply Press

Enter the maximum supply pressure in psi, bar, kPa, or kg/cm<sup>2</sup>, depending on what was selected for pressure units.

#### Aux Term Mode

Aux Input Alert or Auto Travel Calib. Selecting Aux Input Alert then Aux In Alrt Enab activates checking the status of the auxiliary input contacts. Selecting

**5-20** January 2007

# **Detailed Setup**




Figure 5-7. Feedback Connection for Typical Long-Stroke Sliding-Stem Actuator (4 to 24-Inches Travel)

Auto Travel Calib permits starting an automatic travel calibration procedure by placing a jumper across the auxiliary input terminals for 3 to 5 seconds.

#### Inst Date and Time

Date is a user-defined variable that provides a place to save the date of the last revision of configuration or calibration information.

## • Calib Status and Loc (1-2-5-9)

- Last Calib Status—Indicates the status of the last instrument calibration.
- Calib Loc—Indicates the location of the last instrument calibration.

## Valve & Actuator (1-2-6)

Select Configure / Setup, Detailed Setup, and Valve & Actuator. Follow the prompts on the Field Communicator display to configure the following instrument parameters: Manufacturer, Valve Serial Num (Valve Serial Number), Valve Style, Actuator Style, Feedback Conn (Feedback Connection), and Tvl Sensor Motion (Travel Sensor Motion).

### Manufacturer

Enter the manufacturer of the actuator on which the instrument is mounted. If the actuator manufacturer is not listed, select Other.

#### Valve Serial Num

Enter the serial number for the valve in the application with up to 12 characters.

#### Valve Style

Enter the valve style, rotary or sliding-stem

#### Actuator Style

Enter the actuator style, spring and diaphragm, piston double-acting without spring, piston single-acting with spring, or piston double-acting with spring.

#### • Feedback Conn

Select Rotary All, SStem - Roller or SStem - Standard. For rotary valves, enter Rotary - All, SStem - Roller. For sliding-stem valves, if the feedback linkage consists of a connector arm, adjustment arm, and feedback arm (similar to figure 5-6), enter SStem - Standard. If the feedback linkage consists of a roller that follows a cam (similar to figure 5-7), enter Rotary All, SStem - Roller.

#### • Tvl Sensor Motion

Select Clockwise, or Counterclockwise. Travel Sensor Motion establishes the proper travel sensor rotation. Determine the rotation by viewing the end of the travel sensor shaft from the perspective of the actuator.

## Partial Stroke (1-2-7)



## **Note**

Partial Stroke is only available for instrument level ODV.

Select Configure / Setup, Detailed Setup, and Partial Stroke. Follow the prompts on the Field Communicator display to configure the following partial stroke parameters: PST Enable (Partial Stroke Test Enable), and PST Vars View/Edit (View/Edit Partial Stroke Test Variables).

#### PST Enable

Yes or No. Enables or disables the Partial Stroke Test.

## PST Vars View/Edit

Follow the prompts on the Field Communicator display to enter or view information for the following PST Variables: Partial Stroke Tvl (Partial Stroke Travel), Stroke Speed, Pause Time, PST Press Limit (Partial Stroke Pressure Limit), PST Mode Enable (Partial

January 2007 **5-21** 

## **DVC6000 Series**

Stroke Enable), *Pressure Set Point* (Pressure Set Point), and *End Pt Contrl Enab* (End Point Control Enable).

Partial Stroke TvI—The default value for Max Travel Movement is 10%. It may be set to a value between 1 and 30% in 0.1% increments.

Stroke Speed—The stroke speed can be set for 1%/second, 0.5%/second, 0.25%/second, 0.12%/second, or 0.06%/second. The default value for Partial Stroke Speed is 0.25%/second.

Pause Time—The Setup Wizard sets the Partial Stroke Pause Time to 5 seconds. This is the pause time between the up and down strokes of the test. It can be set for 5, 10, 15, 20 or 30 seconds.

PST Press Limit (single acting actuators)—During the Setup Wizard, or Auto Travel Calibration, the Partial Stroke Pressure Limit value will be set to a positive value. For single acting actuators that vent from the test starting point, the pressure limit will be a minimum value. For those actuators that fill from the test starting point, the pressure limit will be a maximum value. The pressure signal used for this threshold depends on relay type and is summarized below.

Relay Type	Pressure Signal
A or C	Port A – Port B
В	Port B – Port A
B Special App.	Port B
C Special App.	Port A

Min Diff Press (double acting actuators)—During the Setup Wizard, or Auto Travel Calibration, the Minimum Differential Pressure value will be set to a negative value for double acting actuators for normal configuration (i. e. air to open, air Fail Close, Direct acting Relay).

To set the partial stroke pressure limit manually for single acting actuators select *min pressure*. Select *min diff press* for double acting actuators.



## Note

In order to manually set the partial stroke pressure limit with the correct value, you must be able to run a valve signature test using AMS ValveLink Software. It is then possible to set the partial stroke pressure limit with the Field Communicator, using the information generated by the valve signature test.

Table 5-9. Values for Disabling Partial Stroke Pressure Limit

Actuator Type	Relay Type	Zero Power Condition	Partial Stroke Start Point	Partial Stroke Pressure Limit (Disabled)
		Closed	Open	0.0
	A 0* C	Ciosed	Closed	Psupply
	A or C Single	Onon	Open	Psupply
Single		Open	Closed	0.0
Acting		Closed	Open	Psupply
	В		Closed	0.0
		ь	Open	Open
		Open	Closed	Psupply
	•			•
		Closed	Open	-Psupply
Double	А		Closed	Psupply
Acting		Open	Open	Psupply
			Closed	-Psupply

To manually set the partial stroke pressure limit, disable the travel deviation alert by setting Travel Dev Alert Pt to 125%. Also disable "end point pressure control" and disable the partial stroke pressure limit by setting the values shown in table 5-9.

Run the partial stroke test using the 375 Field Communicator. Once the test is completed download the partial stroke test results using AMS ValveLink Software.

Select the press/ time radio button from the pressure time series plot, find the minimum or maximum actuator pressure that occurs during the test. Use table 5-10 to estimate the partial stroke pressure limit

The default value is 0.



## **Note**

The Max Travel Movement is the percentage of total span that the valve moves away from its operating state towards its fail state during a Partial Stroke Test.

For double acting valves, the differential pressure is used.

**5-22** January 2007

# **Detailed Setup**

Table 5-10. Estimates for Partial Stroke Pressure Limits

Actuator Style	Relay Type	Zero Power Condition	PST Starting Point	Partial Stroke Pressure Limit		
		Closed	Open	Pmin - 0.25 * (Bench Set High - Bench Set Low)		
			Closed	Pmax + 0.25 * (Bench Set High – Bench Set Low)		
	A or C		Open	Pmax + 0.25 * (Bench Set High – Bench Set Low)		
Spring and Diaphragm	Open	Closed	Pmin – 0.25 * (Bench Set High – Bench Set Low)			
	Closed	Open	Pmax + 0.25 * (Bench Set High – Bench Set Low)			
		Closed	Pmin – 0.25 * (Bench Set High – Bench Set Low)			
	В		Open	Pmin - 0.25 * (Bench Set High - Bench Set Low)		
		Open	Closed	Pmax + 0.25 * (Bench Set High – Bench Set Low)		
<u> </u>	<u> </u>					
		Closed	Open	0.5 * Pmin		
	• •		Closed	Pmax + 0.5 * (Psupply - Pmax)		
	A or C	A or C	A or C	0	Open	Pmax + 0.5 * (Psupply - Pmax)
0: 1 4 1: 5: 1		Open	Closed	0.5 * Pmin		
Single Acting Piston			01	Open	Pmax + 0.5 * (Psupply - Pmax)	
	Б	Closed	Closed	0.5 * Pmin		
	В	0	Open	0.5 * Pmin		
		Open	Closed	Pmax + 0.5 * (Psupply - Pmax)		
<u>"</u>						
		Closed	Open	Pmin – 0.5 * (Psupply + Pmin)		
Double Acting Piston A			Closed	Pmax + 0.5 * (Psupply - Pmax)		
	А	0	Open	Pmax + 0.5 * (Psupply - Pmax)		
	Open	Open	Closed	Pmin – 0.5 * (Psupply + Pmin)		

January 2007 **5-23** 

5

**5-24** January 2007

# Section 6 Calibration

Calibration Overview	6-2
Travel Calibration	6-2
Auto Calibrate Travel	6-2
Manual Calibrate Travel	6-4
Touch-Up Travel Calibration	6-5
Sensor Calibration	6-6
Pressure Sensor Calibration	6-6
Travel Sensor Adjust	6-7
Analog Input Calibration	6-9
Relay Adjustment	6-10
Double-Acting Relay	6-10
Single-Acting Direct Relay	6-11
Single-Acting Reverse Relay	6-11
Restore Factory Settings	6-11

January 2007 **6-1** 

## **Calibration Overview**

When a DVC6000 Series digital valve controller is ordered as part of a control valve assembly, the factory mounts the digital valve controller on the actuator and connects the necessary tubing, then sets up and calibrates the controller. For remote-mounted digital valve controllers, the Type DVC6005 base unit ships separately from the control valve and does not include tubing, fittings or wiring.

For digital valve controllers that are ordered separately, recalibration of the analog input or pressure sensors generally is unnecessary. However, after mounting on an actuator, perform the initial setup (either auto or manual), then calibrate travel by selecting *Calibrate, Travel Calibration*, and *Auto Tvl Calib* (Auto Travel Calibration) from the *Configure / Setup* menu. For more detailed calibration information, refer to the following calibration procedures, available from the *Calibrate* menu:

#### **Travel Calibration**

- Auto Travel Calibrate This procedure automatically calibrates the travel. The calibration procedure uses the valve and actuator stops as the 0% and 100% calibration points.
- Manual Travel Calibrate —This procedure permits manual calibration of the travel. This calibration procedure allows you to determine the 0% and 100% calibration points and obtain the optimum linearity on a sliding-stem valve.

#### **Sensor Calibration**

- Pressure Sensor Calibration—This procedure permits calibrating the three pressure sensors. Normally the sensors are calibrated at the factory and should not need calibration.
- Travel Sensor Adjust—This procedure permits calibrating the travel sensor. Normally the travel sensor is calibrated at the factory. Calibrating the travel sensor should only be necessary if the travel sensor is replaced.
- Analog In Calibration—This procedure permits calibrating the analog input sensor. Normally the sensor is calibrated at the factory and should not need calibration.

**Relay Adjustment**—This procedure permits adjustment of the pneumatic relay.

**Restore Factory Settings**—This procedure permits you to restore the calibration settings back to the factory settings.

To display the calibrate menu, from the *Online* menu, select *Configure / Setup* and *Calibrate*.



## Note

The Instrument Mode must be Out Of Service and the Protection set to None before the instrument can be calibrated.

If you are operating in burst mode, we recommend that you disable burst before continuing with calibration. Once calibration is complete, burst mode may then be turned back on.

## **WARNING**

During calibration, the valve may move. To avoid personal injury and property damage caused by the release of pressure or process fluid, provide some temporary means of control for the process.

## **Travel Calibration**

There are two procedures available for calibrating travel:

- Automatically (Auto Calibrate Travel)
- Manually (Manual Calibrate Travel)

Once the travel is calibrated by performing either the Auto Calibrate Travel or Manual Calibrate Travel procedures, the travel calibration can be "touched-up" using Touch-Up Travel Calibration.

## **Auto Calibrate Travel (1-3-1-1)**

User interaction is only required with Auto Calibrate Travel when the feedback connection is SStem - Standard (Sliding Stem - Standard). A feedback connection of Rotary - All, SStem - Roller (Sliding Stem - Roller) requires no user interaction and you can start with step 6.

For a SStem - Standard feedback connection, interaction provides a more accurate crossover adjustment. Setting crossover establishes the zero degree point for the geometric correction used to translate the rotary motion observed by the travel sensor into the linear motion of the sliding-stem valve.

**6-2** January 2007

When a double-acting actuator is used, you will be prompted to run the Relay Adjustment when Auto Travel Calibration is selected. Select Yes to adjust the relay. Select No to proceed with Auto Travel Calibration. For additional information, refer to Relay Adjustment in this section.

Select *Auto Tvl Calib* from the *Calibrate* menu, then follow the prompts on the Field Communicator display to automatically calibrate travel.

1. Select the method of crossover adjustment: manual, last value, or default. Manual is the recommended choice. If you select Manual, the Field Communicator will prompt you to adjust the crossover in step 3.

If you select Last Value, the crossover setting currently stored in the instrument is used and there are no further user interactions with the auto-calibration routine (go to step 6). Use this selection if you cannot use manual, such as when you cannot see the valve.

If you select Default, an approximate value for the crossover is written to the instrument and there are no further user interactions with the auto-calibration routine (go to step 6). Use this selection only as a last resort. Default assumes a midrange position on the travel sensor as the crossover point, however, this may not be an appropriate value to use for crossover because of variations in mounting and travel sensor calibration.

- 2. The instrument seeks the high and low drive points and the minor loop feedback (MLFB) and output bias. No user interaction is required in this step. For a description of these actions see step 6.
- 3. If you select Manual in step 1, you are asked to select an adjustment source, either analog or digital. If you use a current source to adjust the crossover, select Analog and go to step 4. If you wish to adjust the current source digitally, select Digital and go to step 5.
- 4. If you selected Analog as the crossover adjustment source, the Field Communicator prompts you to adjust the current source until the feedback arm is 90° to the actuator stem, as shown in figure 6-1. After you have made the adjustment, press OK and go to step 6.
- 5. If you selected Digital as the crossover adjustment source, the Field Communicator displays a menu to allow you to adjust the crossover.

Select the direction and size of change required to set the feedback arm so it is 90° to the actuator stem, as shown in figure 6-1. Selecting large, medium, and small adjustments to the crossover causes changes of




Figure 6-1. Crossover Point

approximately 10.0°, 1.0°, and 0.1°, respectively, to the rotation of the feedback arm.

If another adjustment is required, repeat step 5. Otherwise, select Done and go to step 6.

6. The remainder of the auto calibration procedure is automatic. It is completed when the "Auto Calibration has completed" message appears.

During calibration, the instrument seeks the high and low end points and the minor loop feedback (MLFB) and output bias. By searching for the end points, the instrument establishes the limits of physical travel, i.e., the actual travel 0 and 100% positions. This also determines how far the relay beam swings to calibrate the sensitivity of the beam position sensor.

Adjusting the minor loop feedback bias is done around mid travel. The valve position is briefly moved back and forth to determine the relay beam position at quiescence. Essentially, it establishes the zero point for the Minor Loop Feedback circuit. The back and forth motion is performed to account for hysteresis.

Adjusting the output bias aligns the travel set point with the actual travel by computing the drive signal required to produce 0% error. This is done while the valve is at 50% travel, making very small adjustments.

7. Place the instrument In Service and verify that the travel properly tracks the current source.

If the unit does not calibrate, refer to table 6-1 for error messages and possible remedies.

January 2007

## Manual Calibrate Travel (1-3-1-2)

It is recommended that you adjust the relay before manually calibrating travel. For additional information refer to Relay Adjustment in this section.



## **Note**

Relay Adjustment is only available for the double-acting relay (Relay A).

Two procedures are available to manually calibrate travel:

- Analog Adjust
- Digital Adjust

## **Analog Calibration Adjust**

From the *Calibrate* menu, select *Man Tvl Calib* and *Analog Adjust*. Connect a variable current source to the instrument LOOP + and LOOP – terminals. The current source should be capable of generating 4 to 20 mA. Follow the prompts on the Field Communicator display to calibrate the instrument's travel in percent.



## Note

0% Travel = Valve Closed 100% Travel = Valve Open

- 1. Adjust the input current until the valve is near mid-travel. Press OK.
- 2. If the feedback connection is Rotary All, SStem Roller, go to step 6. If the feedback connection is SStem Standard, you are prompted to set the crossover point. Adjust the current source until the feedback arm is 90° to the actuator stem, as shown in figure 6-1. Then press OK.

Table 6-1. Auto Calibrate Travel Error Messages

Error Message	Possible Problem and Remedy
Input current must exceed 3.8 mA for calibration.	The analog input signal to the instrument must be greater than 3.8 mA. Adjust the current output from the control system or the current source to provide at least 4.0 mA.
Place Out Of Service and ensure Calibrate Protection is disabled before calib.	The Instrument Mode must be <i>Out of Service</i> and the Protection must be <i>None</i> before the instrument can be calibrated. For information on changing instrument protection and mode, see the beginning of this section.
Calibration Aborted. An end point was not reached.	The problem may be one or the other of the following:  1. The tuning set selected is too low and the valve does not reach an end point in the allotted time. Press the Hot Key, select Stabilize/Optimize then Increase Response (selects next higher tuning set).  2. The tuning set selected is too high, valve operation is unstable and does not stay at an end point for the allotted time. Press the Hot Key, select Stabilize/Optimize then Decrease Response (selects next lower tuning set).
Invalid travel value. Check travel sensor	Prior to receiving this message, did the instrument output go from zero to full supply? If not, verify instrument supply pressure by referring to the specifications in the appropriate actuator instruction manual. If supply pressure is correct, check instrument pneumatic components (I/P converter and relay).
and feedback arm adjustments, and inst supply press. Then, repeat Auto Calib.	If the instrument output did go from zero to full supply prior to receiving this message, then verify proper mounting by referring to the appropriate mounting procedure in the Installation section.  Verify travel sensor adjustment by performing the appropriate Travel Sensor Adjust procedure in the Calibration section.  Making the crossover adjustment with the valve positioned at either end of its travel will also cause this message to appear.



## **Note**

In steps 3 through 7, the accuracy of the current source adjustment affects the position accuracy.

- 3. Adjust the current source until the valve is at 0% travel, then press OK.
- 4. Adjust the current source until the valve is at 100% travel, then press OK.
- 5. Adjust the current source until the valve is at 50% travel, then press OK.
- 6. Adjust the current source until the valve is at 0% travel, then press OK.
- 7. Adjust the current source until the valve is at 100% travel, then press OK.

**6-4** January 2007

- 8. Adjust the current source until the valve is near 5% travel, then press OK.
- 9. Adjust the current source until the valve is near 95% travel, then press OK.
- 10. Place the instrument In Service and verify that the travel properly tracks the current source.

## Digital Calibration Adjust

From the *Calibrate* menu, select *Man Tvl Calib* and *Digital Adjust*. Connect a variable current source to the instrument LOOP + and LOOP – terminals. The current source should be set between 4 and 20 mA. Follow the prompts on the Field Communicator display to calibrate the instrument's travel in percent.



## Note

0% Travel = Valve Closed 100% Travel = Valve Open

1. From the adjustment menu, select the direction and size of change required to adjust the output until the valve is near mid-travel. Selecting large, medium, and small adjustments causes changes of approximately 10.0°, 1.0°, and 0.1°, respectively, to the feedback arm rotation.

If another adjustment is required, repeat step 1. Otherwise, select Done and go to step 2.

- 2. If the feedback connection is Rotary All, SStem Roller, go to step 7. If the feedback connection is SStem Standard, adjust the feedback arm to the crossover point by using the adjustment menu.
- 3. From the adjustment menu, select the direction and size of change required to set the feedback arm so it is 90° to the actuator stem, as shown in figure 6-1. Selecting large, medium, and small adjustments to the crossover causes changes of approximately 10.0°, 1.0°, and 0.1°, respectively, to the feedback arm rotation.

If another adjustment is required, repeat step 3. Otherwise, select Done and go to step 4.

4. From the adjustment menu, select the direction and size of change required to set the travel at 0%. Selecting large, medium, and small adjustments causes changes of approximately 10.0°, 1.0°, and 0.1°, respectively, to the feedback arm rotation.

If another adjustment is required, repeat step 4. Otherwise, select Done and go to step 5.

5. From the adjustment menu, select the direction and size of change required to set the travel to 100%. Selecting large, medium, and small adjustments causes changes of approximately 10.0°, 1.0°, and 0.1°, respectively, to the feedback arm rotation.

If another adjustment is required, repeat step 5. Otherwise, select Done and go to step 6.

6. From the adjustment menu, select the direction and size of change required to set the travel to 50%. Selecting large, medium, and small adjustments causes changes of approximately 10.0°, 1.0°, and 0.1°, respectively, to the feedback arm rotation.

If another adjustment is required, repeat step 6. Otherwise, select Done and go to step 7.

7. From the adjustment menu, select the direction and size of change required to set the travel to 0%. Selecting large, medium, and small adjustments causes changes of approximately 10.0°, 1.0°, and 0.1°, respectively, to the feedback arm rotation for a sliding-stem valve or to the travel for a rotary valve.

If another adjustment is required, repeat step 7. Otherwise, select Done and go to step 8.

8. From the adjustment menu, select the direction and size of change required to set the travel to 100%. Selecting large, medium, and small adjustments causes changes of approximately 10.0°, 1.0°, and 0.1°, respectively, to the feedback arm rotation for a sliding-stem valve or to the travel for a rotary valve.

If another adjustment is required, repeat step 8. Otherwise, select Done and go to step 9.

9. From the adjustment menu, select the direction and size of change required to set the travel to near 5%. Selecting large, medium, and small adjustments causes changes of approximately 10.0°, 1.0°, and 0.1°, respectively, to the feedback arm rotation for a sliding-stem valve or to the travel for a rotary valve.

If another adjustment is required, repeat step 9. Otherwise, select Done and go to step 10.

10. From the adjustment menu, select the direction and size of change required to set the travel to near 95%. Selecting large, medium, and small adjustments causes changes of approximately 10.0°, 1.0°, and 0.1°, respectively, to the feedback arm rotation for a sliding-stem valve or to the travel for a rotary valve.

If another adjustment is required, repeat step 10. Otherwise, select Done and go to step 11.

11. Place the instrument In Service and verify that the travel properly tracks the current source.

## Touch-Up Travel Calibration

Once the travel is calibrated by performing either the Auto Calibrate Travel or Manual Calibrate Travel procedures, the travel calibration can be "touched-up"

## **DVC6000 Series**

by shorting the Aux Terminal Connections for 3 to 5 seconds to activate Touch-Up Calibration. Touch-Up Travel Calibration uses Last Value for the crossover adjustment. You can abort the procedure by shorting the auxiliary terminals for 1 second.

To enable Touch-Up Travel Calibration the *Aux Terminal Mode* must be set to *Auto Travel Calib*. The instrument *Operational Status* during calibration is *Calibration in Progress*.

Use Touch-Up Calibration to calibrate the digital valve controller travel whenever the I/P converter or relay is replaced. Do not use Touch-Up calibration for initial calibration when mounting the instrument on an actuator, or if the travel sensor assembly or printed wiring board assembly was replaced.

You can use Touch-Up Travel Calibration to calibrate the digital valve controller if you suspect calibration has changed due to drift. However, prior to initiating Touch-Up Travel Calibration, perform a Valve Signature diagnostic test, using AMS ValveLink Software. This will capture the as-found data for future root cause analysis.

## Sensor Calibration

## **Pressure Sensors (1-3-2-1)**

There are three pressure sensors: output A, output B and supply. Select the appropriate menu depending upon which pressure sensor you are calibrating.



## **Note**

The pressure sensors are calibrated at the factory and should not require calibration.

## **Output Pressure Sensor Calibration**

To calibrate the output pressure sensors, connect an external reference gauge to the output being calibrated. The gauge should be capable of measuring maximum instrument supply pressure. From the Calibrate menu, select Sensor Calibration and Press Sensors (Pressure Sensors). Depending upon the sensor you wish to calibrate, select either Output A Sensor or Output B Sensor. Follow the prompts on the Field Communicator display to calibrate the instrument's output pressure sensor.

- 1. Adjust the supply pressure regulator to the desired supply pressure. Press OK.
- 2. Select a) Zero only, or b) Zero and Span (gauge required) sensor calibration.
  - a. If Zero only calibration is selected, wait until output x pressure has completely exhausted, then continue. Once calibration is completed, go to step 6. The output x pressure corresponds to A or B, depending on which output you are calibrating.
  - b. If Zero and Span calibration is selected, wait until output x pressure has completely exhausted, then continue. You will then be asked to wait until output x pressure has reached full supply, then continue. The output x pressure corresponds to A or B, depending on which output you are calibrating. Proceed with step 3.
- 3. The instrument sets the output pressure to full supply. The following message appears:

Use the Increase and Decrease selections until the displayed pressure matches the output x pressure.

The output x pressure corresponds to A or B, depending on which output you are calibrating. Press OK when you have read the message.

- 4. The value of the output pressure appears on the display.
- 5. From the adjustment menu, select the direction and size of adjustment to the displayed value. Selecting large, medium, and small adjustments causes changes of approximately 3.0 psi/0.207 bar/20.7 kPa, 0.30 psi/0.0207 bar/2.07 kPa, and 0.03 psi/0.00207 bar/0.207 kPa, respectively. Adjust the displayed value until it matches the output pressure, select Done and go to step 6.
- 6. Place the instrument In Service and verify that the displayed pressure matches the measured output pressure.

## Supply Pressure Sensor Calibration



## Note

Supply Pressure Sensor Calibration is not available for instrument level HC.

**6-6** January 2007

To calibrate the supply pressure sensor, connect an external reference gauge to the output side of the supply regulator. The gauge should be capable of measuring maximum instrument supply pressure. From the *Calibrate* menu, select *Sensor Calibration*, *Press Sensors* (Pressure Sensors), and *Supply Sensor*. Follow the prompts on the Field Communicator display to calibrate the instrument's supply pressure sensor.

- 1. Select a) Zero Only, or b) Zero and Span (gauge required).
  - a. If Zero Only calibration is selected, adjust the supply pressure regulator to remove supply pressure from the instrument. Press OK. Once calibration is complete, go to step 5.
  - b. If Zero and Span calibration is selected, adjust the supply pressure regulator to remove supply pressure from the instrument. Press OK. Adjust the supply regulator to the maximum instrument supply pressure. Press OK. Proceed with step 2.
- 2. The following message appears:

Use the Increase and Decrease selections until the displayed pressure matches the instrument supply pressure.

Press OK when you have read this message.

- 3. The value of the pressure appears on the display.
- 4. From the adjustment menu, select the direction and size of adjustment to the displayed value. Selecting large, medium, and small adjustments causes changes of approximately 3.0 psi/0.207 bar/20.7 kPa, 0.30 psi/0.0207 bar/2.07 kPa, and 0.03 psi/0.00207 bar/0.207 kPa, respectively. Adjust the displayed value until it matches the supply pressure, select Done and go to step 5.
- 5. Place the instrument In Service and verify that the displayed pressure matches the measured supply pressure.

## Travel Sensor Adjust (1-3-2-2)

The travel sensor is normally adjusted at the factory and should not require adjustment. However, if the travel sensor has been replaced, adjust the travel sensor by performing the appropriate procedure. See the Maintenance section for travel sensor replacement procedures.




Figure 6-2. Type DVC6010 Digital Valve Controller Showing Feedback Arm in Position for Travel Sensor Adjustment

# DVC6010, DVC6015, DVC6030 and DVC6035 Digital Valve Controllers

1. Remove supply air and remove the instrument from the actuator.

## **WARNING**

Failure to remove air pressure may cause personal injury or property damage from bursting parts.

2. As shown in figure 6-2, align the feedback arm (key 79) with the housing by inserting the alignment pin (key 46) through the hole marked "A" on the feedback arm. Fully engage the alignment pin into the tapped hole in the housing.



## **Note**

The alignment pin (key 46) is stored inside the digital valve controller housing.

January 2007 6-7




Figure 6-3. Type DVC6020 Travel Sensor Arm/Housing Back Plane Alignment

Table 6-2. DVC6000 Series Digital Valve Controller Travel Sensor Counts

Digital Valve Controller	Travel Sensor Counts
Type DVC6010 / DVC6015	600 ±150
Type DVC6020 / DVC6025	1950 ±150
Type DVC6030 / DVC6035	600 ±150

- 3. Loosen the screw that secures the feedback arm to the travel sensor shaft. Position the feedback arm so that the surface of the feedback arm is flush with the end of the travel sensor shaft.
- 4. Connect a current source to the instrument LOOP
   and LOOP + terminals. Set the current source to any value between 4 and 20 mA. Connect the Field Communicator to the TALK terminals.
- 5. Before beginning the travel sensor adjustment, set the instrument mode to Out Of Service and the protection to None.
- 6. From the *Calibrate* menu select *Sensor Calibration*,and *Tvl Sensor Adjust* (Travel Sensor Adjust). Follow the prompts on the Field Communicator display to adjust the travel sensor counts to the value listed in table 6-2.



## **Note**

In the next step, be sure the feedback arm surface remains flush with the end of the travel sensor shaft.

- 7. While observing the travel sensor counts, tighten the screw that secures the feedback arm to the travel sensor shaft. Be sure the travel sensor counts remain within the tolerances listed in table 6-2. Paint the screw to discourage tampering with the connection.
- 8. Disconnect the Field Communicator and current source from the instrument.
- 9. Remove the alignment pin and store it in the instrument housing.
- 10. Install the digital valve controller on the actuator.

# DVC6020 and DVC6025 Digital Valve Controllers

1. Remove supply air and remove the instrument from the actuator.

## **WARNING**

Failure to remove air pressure may cause personal injury or property damage from bursting parts.

- 2. See figure 6-4 for parts identification. Disconnect the bias spring (key 82) from the feedback arm assembly (key 84) and the arm assembly (key 91). Remove the mounting bracket (key 74) from the back of the digital controller. Hold the arm assembly (key 91) so that the arm assembly points toward the terminal box and the arm is parallel to the back of the housing, as shown in figure 6-3.
- Loosen the screw that secures the arm assembly to the travel sensor shaft. Position the arm assembly so that the outer surface is flush with the end of the travel sensor shaft.
- 4. Connect a current source to the instrument LOOP and LOOP + terminals. Set the current source to any value between 4 and 20 mA. Connect the Field Communicator to the TALK terminals.
- 5. Before beginning the travel sensor adjustment, set the instrument mode to Out Of Service and the protection to None.

**6-8** January 2007




Figure 6-4. Type DVC6020 Digital Valve Controller Mounted on Type 1052, Size 33 Actuator

6. From the *Calibrate* menu, select *Sensor Calibration* and *Tvl Sensor Adjust* (Travel Sensor Adjust). Follow the prompts on the Field Communicator display to adjust the travel sensor counts to the value listed in table 6-2.



## Note

In the next step, be sure the arm assembly outer surface remains flush with the end of the travel sensor shaft.

7. While observing the travel sensor counts, tighten the screw that secures the arm assembly to the travel sensor shaft. Be sure the travel sensor counts remain within the tolerances listed in table 6-2. Paint the screw to discourage tampering with the connection.

- 8. Disconnect the Field Communicator and current source from the instrument.
- 9. Apply lubricant (key 63) to the pin portion of the arm assembly (key 91).
- 10. Replace the mounting bracket on the back of the instrument and reconnect the bias spring between the feedback arm assembly and the arm assembly on the travel sensor shaft.
- 11. Install the digital valve controller on the actuator.

## **Analog Input Calibration (1-3-2-3)**

To calibrate the analog input sensor, connect a variable current source to the instrument LOOP+ and LOOP- terminals. The current source should be capable of generating an output of 4 to 20 mA. From the Configure / Setup menu select Calibrate, Sensor Calibration, and Analog In Calib (Analog Input Calibration). Follow the prompts on the Field

January 2007

Communicator display to calibrate the analog input sensor.

- 1. Set the current source to the target value shown on the display. The target value is the Input Range Low value. Press OK.
- 2. The following message appears:

Use Increase and Decrease selections until the displayed current matches the current source.

Press OK when you have read this message.

- 3. The value of the Analog Input appears on the display.
- 4. From the adjustment menu, select the direction and size of adjustment to the displayed value. Selecting large, medium, and small adjustments causes changes of approximately 0.4 mA, 0.04 mA, and 0.004 mA, respectively. Adjust the displayed value until it matches the current source, select Done and go to step 5.
- 5. Set the current source to the target value shown on the display. The target value is the Input Range High value. Press OK.
- 6. The following message appears:

Use Increase and Decrease selections until the displayed current matches the current source.

Press OK when you have read this message.

- 7. The value of the Analog Input appears on the display.
- 8. From the adjustment menu, select the direction and size of adjustment to the displayed value. Selecting large, medium, and small adjustments causes changes of approximately 0.4 mA, 0.04 mA, and 0.004 mA, respectively. Adjust the displayed value until it matches the current source, select Done and go to step 9.
- 9. Place the instrument In Service and verify that the analog input displayed matches the current source.




Figure 6-5. Location of Relay Adjustment (Shroud Removed for Clarity)

## Relay Adjustment (1-3-3)

Before beginning travel calibration, check the relay adjustment. To check relay adjustment, select *Relay Adjust* from the *Calibrate* menu, then follow the prompts on the Field Communicator display. Replace the digital valve controller cover when finished.



## Note

Relay B and C are not user-adjustable.

## **Double-Acting Relay**

The double-acting relay is designated by "Relay A" on a label affixed to the relay itself. For double-acting actuators, the valve must be near mid-travel to properly adjust the relay. The Field Communicator will automatically position the valve when *Relay Adjust* is selected.

Rotate the adjustment disc, shown in figure 6-5, until the output pressure displayed on the Field Communicator is between 50 and 70% of supply pressure. This adjustment is very sensitive. Be sure to allow the pressure reading to stabilize before making

6

**6-10** January 2007

another adjustment (stabilization may take up to 30 seconds or more for large actuators).

If the low bleed relay option has been ordered stabilization may take approximately two minutes longer than the standard relay.

## Single-Acting Direct Relay

The single-acting direct relay is designated by "Relay C" on a label affixed to the relay itself. Relay C requires no adjustment.



## Note

If the unused port (Port B) is being used to monitor pressure, the pressure in to Port B cannot exceed the instrument supply pressure. Exceeding the instrument supply will create a back flow through the relay, resulting in leakage.

## Single-Acting Reverse Relay

The single-acting reverse relay is designated by "Relay B" on a label affixed to the relay itself. Relay B is calibrated at the factory and requires no further adjustment.

## **Restoring Factory Settings (1-3-4)**

From the *Online* menu, select *Configure / Setup*, then select *Calibrate*, and *Restore Factory Settings*. Follow the prompts on the Field Communicator display to restore calibration to the factory settings. You should only restore the calibration if it is not possible to calibrate an individual sensor. Restoring calibration returns the calibration of all of the sensors and the tuning set to their factory settings. Following restoration of the factory calibration, the individual sensors should be recalibrated.

January 2007 6-11

6

**6-12** January 2007

# **Section 7 Viewing Device Information**

Alert Conditions  Electronic Alerts Sensor Alerts Environmental Alerts Travel Alerts Travel History Alerts SIS Alerts	7-3
Status	7-5
Device Record  Temp Max  Temp Min  Run Time  Number of Power Ups	7-5
Stroke Valve	7-5
Partial Stroke Test  Device (Digital Valve Controller) Remote Push Button Model 375 Field Communicator	7-6
Device Variables	7-7
Analog Input	7-7
	7-7
Travel Set Point	77
Travel Set Point	7-7
	7-7 7-7
Travel	

January 2007

# **DVC6000 Series**

Raw Travel Input Run Time Number of Power Ups	
Device Information	7-8
HART Tag	
Device ID	
Manufacturer	
Model	
Device Revision	
Firmware Revision	
Hardware Revision	
Instrument Level	
HART® Universal Revision	
DD Information	7-9

7

**7-2** January 2007

# **Viewing Device Information**

## **Device Diagnostics**



## Note

Device Diagnostics are not available for instrument level AC.

## Alert Conditions (2-1)

Instrument Alert Conditions, when enabled, detect many operational and performance issues that may be of interest. To view these alerts, from the *Online* menu select *Device Diagnostics*, and *Alert Conditions*. The alert conditions for each group of alerts are listed below. If there are no alerts active for a particular group the group will not be displayed on the Field Communicator.

• **Electronics**— If an electronics alert is active it will appear under ELECT ALERTS.

#### **Drive Current**

Drive Current Alert—This alert is indicated when the drive current does not read as expected. If this alert occurs, check the connection between the I/P converter and the printed wiring board assembly. Try removing the I/P converter and re-installing it. If the failure does not clear, replace the I/P converter or the printed wiring board assembly.

#### Drive Signal

Drive Signal Alert—This alert is indicated when the Drive Signal is greater or less than the expected maximum or minimum.

#### Processor Impaired

Offline/Failed Alert—This alert is indicated if a failure, enabled from the Self Test Shutdown menu, caused an instrument shutdown. Press Enter to see which of the specific failures caused the Offline/Failed indication.

Power Starvation Alert—This alert is indicated if the instrument does not have enough power to function properly.

Non-Critical NVM Alert—This alert is indicated if the checksum for data, which are not critical for instrument operation, has failed.

Critical NVM Alert—This alert is indicated when the Non-Volatile Memory integrity test fails. Configuration data is stored in NVM. If this failure is indicated,

restart the instrument and see if it clears. If it does not clear, replace the PWB Assembly.

Flash ROM Alert—This alert indicates that the Read Only Memory integrity test failed. If this alert is indicated, restart the instrument and see if it clears. If it does not clear, replace the printed wiring board assembly.

No Free Time Alert—This alert is indicated if the instrument is unable to complete all of the configured tasks. This will not occur with a properly functioning instrument.

Reference Voltage Alert—This failure is indicated whenever there is a failure associated with the internal voltage reference. If this alert is indicated, restart the instrument and see if it clears. If it does not clear, replace the printed wiring board assembly.

Internal Sensor Out of Limits—This alert is indicated if there is a possible problem with either the pressure sensor or the printed wiring board assembly submodule.

Variable Out of Range—This alert is indicated if there is a possible problem with one or more of the following: the Analog Input Signal, the I/P converter submodule, the pneumatic relay submodule, or the printed wiring board.

Field device malfunction—The alert is indicated if the pressure, position, or temperature sensors are providing invalid readings.

• Sensor— If a sensor alert is active it will appear under SENSOR ALERTS.

#### Travel Sensor

Travel Sensor Alert—This alert is indicated if the sensed travel is outside the range of -25.0 to 125.0% of calibrated travel. If this alert is indicated, check the instrument mounting and the travel sensor adjustment. Also, check that the electrical connection from the travel sensor is properly plugged into the printed wiring board assembly. After restarting the instrument, if the alert does not clear, troubleshoot the printed wiring board assembly or travel sensor.

#### **Pressure Sensors**

Pressure Sensor Alert—This alert is indicated if the actuator pressure is outside the range of -24.0 to 125.0% of the calibrated pressure for more than 60 seconds. If this alert is indicated, check the instrument supply pressure. If the failure persists, ensure the printed wiring board assembly is properly mounted onto the Module Base Assembly, and the pressure sensor O-rings are properly installed. If the alert does not clear after restarting the instrument, replace the printed wiring board assembly.

January 2007 **7-3** 



## **Note**

The pressure sensor alert is used for output A, output B, and the supply pressure sensor. Check the pressure values to see which sensor is causing the alert.

## Temperature Sensor

Temperature Sensor Alert—This alert is indicated when the instrument temperature sensor fails, or the sensor reading is outside of the range of –40 to 85°C (–40 to 185°F). The temperature reading is used internally for temperature compensation of inputs. If this alert is indicated, restart the instrument and see if it clears. If it does not clear, replace the printed wiring board assembly.

• **Environment**— If an environment alert is active it will appear under ENVIRO ALERTS.

#### Supply Pressure

Supply Pressure Lo Alert—This alert is indicated when supply pressure is lower than the configured limit.

#### Aux Terminal Alert

Aux Terminal Alert—This alert is set when the auxiliary input terminals are either open or closed, depending upon the selection for the Aux In Alrt State.

• Travel— If a travel alert is active it will appear under TRAVEL ALERTS.

#### **Travel Deviation**

Travel Deviation Alert—The difference between Setpoint and Travel is greater than the configured limits.

#### Travel Limit

*Travel Alert Hi Hi*—This alert is indicated if the Travel is greater than the configured limit.

Travel Alert Lo Lo—This alert is indicated if the Travel is lower than the configured limit.

#### Travel Limit Hi/Lo

Travel Alert Hi—This alert is indicated if the Travel is greater than the configured limit.

*Travel Alert Lo*—This alert is indicated if the Travel is lower than the configured limit.

## Travel Limit / Cutoff

*Travel Limit/Cutoff Hi*—This alert is indicated if the Travel is limited high or the high cutoff is in effect.

Travel Limit/Cutoff Lo—This alert is indicated if the Travel is limited low or the low cutoff is in effect.

Table 7-1. Alerts Included in Alert Groups for Alert Record

Alert Group	Alerts Include in Group
	Travel Alert Lo
	Travel Alert Hi
Valve Alerts	Travel Alert Lo Lo
	Travel Alert Hi Hi
	Travel deviation
	Drive signal
	No free time
	Flash ROM fail
	Drive current fail
Failure Alerts	Ref Voltage fail
Failure Alerts	NVM fail
	Temperature sensor fail
	Pressure sensor fail
	Travel sensor fail
Miscellaneous Alerts	Auxiliary input

• Travel History— If a travel history alert is active it will appear under TVL HIST ALERTS.

#### Cycle Count

Cycle Count Alert—This alert is indicated if the Cycle Counter exceeds the Cycle Count Alert Point.

#### Travel Accumulator

Travel Accumulator Alert—This alert is indicated if the Travel Accum exceeds the Travel Accumulator Alert Point.

• SIS (ODV tier only)— If an SIS alert is active it will appear under SIS ALERTS.

#### Partial Stroke Test (PST)

Valve Stuck or Pressure/Travel Path
Obstructed—This alert is indicated if the valve is stuck
or the pressure/travel path is obstructed.

#### **End Point Pressure Deviation**

Pressure Deviation Alert—The alert is indicated if the difference between the target pressure and the actual pressure exceeds the Pressure Deviation Alert Point for a period of time greater than the Pressure Deviation Time.

Locked in Safety Alert—This alert is indicated if the ODV unit is locked in the safety position.

#### Alert Record

Alert Record not Empty—This alert indicates that an alert has been saved to the alert record.

Alrt Record Full—This alert indicates that the alert record is full.

## 7

# **Viewing Device Information**

## **Viewing Instrument Status (2-2)**



## Note

Status is not available for instrument level AC.

To view the instrument status, from the *Device Diagnostics* menu select *Status*. This menu item indicates the status of the Operational items listed below. The status of more than one operational item may be indicated.

#### **Instrument Time**

Inst Time Invalid

## **Calibration and Diagnostics**

Cal in Progress

Autocal in Progress

Diag in Progress

Diag Data Avail

## Operational

Press Ctrl Active

Multi-Drop

#### Integrator

Integrator Sat Hi

Integrator Sat Lo

## **Device Record (2-3)**



## **Note**

Device Record is not available for instrument level AC.

From the *Online* menu, select *Device Diagnostics* and *Device Record*. Follow the prompts on the Field Communicator display to view the following Device Record parameters: *Temp Max* (Maximum Temperature), *Temp Min* (Minimum Temperature), *Run Time*, and *Num of Power Ups* (Number of Power Ups).

• Temp Max—Maximum Recorded Temperature shows the maximum temperature the instrument has experienced since installation.

- *Temp Min*—Minimum Recorded Temperature shows the minimum temperature the instrument has experienced since installation.
- Run Time—Indicates in hours or days the total elapsed time the instrument has been powered up.
- Num of Power Ups—Number of Power Ups indicates how many times the instrument has cycled power.

# Stroking the Digital Valve Controller Output (2-4)



## Note

Stroke Valve is not available with instrument level AC.

From the *Online* menu, select *Device Diagnostics* and *Stroke Valve*. Follow the prompts on the Field Communicator display to select from the following: *Done, Ramp Open, Ramp Closed, Ramp to Target, Step to Target,* and *Stop.* 

- Done—Select this if you are done. All ramping is stopped when DONE is selected.
- Ramp Open—ramps the travel toward open at the rate of 1.0% per second of the ranged travel.
- Ramp Closed—ramps the travel toward closed at the rate of 1.0% per second of the ranged travel.
- Ramp to Target—ramps the travel to the specified target at the rate of 1.0% per second of the ranged travel.
- Step to Target—steps the travel to the specified target.

January 2007

## **Partial Stroke Test (2-5)**



## Note

Partial Stroke Test is only available for instrument level ODV.

## **WARNING**

During the partial stroke test the valve will move. To avoid personal injury and property damage caused by the release of pressure or process fluid, provide some temporary means of control for the process.

The Partial Stroke Test allows the DVC6000 Series digital valve controllers with instrument level ODV to perform a Valve Signature type of test while the instrument is in service and operational. In some applications, it is important to be able to exercise and test the valve to verify that it will operate when commanded. This feature allows the user to partially stroke the valve while continually monitoring the input signal. If a demand arises, the test is aborted and the valve moves to its commanded position. The partial stroke valve travel is configurable between 1 and 30% maximum travel, in 0.1% increments. Data from the last partial stroke test is stored in the instrument memory for retrieval by AMS ValveLink Software.

The Partial Stroke Test allows you to perform a partial, 10%, stroke test (standard) or a custom stroke test. With the custom stroke test, the stroke may be extended up to 30%. Be sure to check plant guidelines before performing a custom stroke test. The purpose of this test is to ensure that the valve assembly moves upon demand.

A partial stroke test can be initiated when the valve is operating at either 4 or 20 mA (point-to-point mode). In applications where a spurious trip is to be minimized, 4 mA is the normal operating position.

When enabled, a partial stroke test may be initiated by the device (as a scheduled, auto partial stroke test), a remote push button located in the field or at the valve, the Model 375 Field Communicator, or AMS ValveLink Software.

## Device (Digital Valve Controller)

The Auto Partial Stroke Test allows the partial stroke test to be scheduled by the DVC6000. The test is scheduled in number of hours between tests. Any power cycle will reset the test clock timer.

#### Remote Push Button

The remote push button can be used for different applications. Refer to the note on the facing page for guidelines for auxiliary terminal wiring length.

#### Local Push Button

A partial stroke test command may be sent to the DVC6000 Series digital valve controller using a set of contacts wired to the auxiliary +/- terminals. To perform a test, the contacts must be closed for 3 to 5 seconds and then opened. To abort the test, close the contacts for 1 second. The last set of diagnostic data is stored in the instrument memory for later retrieval via AMS ValveLink Software.

#### Local DI

When configured by the user interface, the Auxiliary Terminal can be used as a discrete input from a pressure switch, temperature switch etc., to provide an alert.

#### Model 375 Field Communicator

- 1. Connect the Model 375 Field Communicator to the LOOP terminals on the digital valve controller.
- 2. Turn on the Field Communicator.
- 3. From the *Online* menu, select *Device Diagnostics* and *Partial Stroke Test*.
- 4. Select either *Standard (10%)* or *Custom*. With the Custom Stroke Test, the stroke may be entered up to 30% with configurable stroking speed and pause time.
- 5. The currently configured Stroke, Stroking Speed, and Pause Time is displayed. Choose "Yes" to run the test using these values. Choose "No" to modify the values.
- 6. The valve begins to move and the actual travel reported by the digital valve controller is displayed on the Field Communicator.
- 7. Once the valve has reached the endpoint, check that the valve has reached the desired set point. The valve should return to its original position.

For information on configuring the Partial Stroke Test, see Partial Stroke Variables in the Detailed Setup section.

# **Viewing Device Information**



## **Note**

#### **Auxiliary Terminal Wiring Length Guidelines**

The Auxiliary Input Terminals of a DVC6000 with instrument level ODV can be used with a locally-mounted switch for initiating a partial stroke test. Some applications require that the partial stroke test be initiated from a remote location.

The length for wiring connected to the Auxiliary Input Terminals is limited by capacitance. For proper operation of the Auxiliary Input Terminals capacitance should not exceed 18000 pF. As with all control signal wiring, good wiring practices should be observed to minimize adverse effect of electrical noise on the Aux Switch function.

Example Calculation: Capacitance per foot or per meter is required to calculate the length of wire that may be connected to the Aux switch input. The wire should not exceed the capacitance limit of 18000 pF. Typically the wire manufacturer supplies a data sheet which provides all of the electrical properties of the wire. The pertinent parameter is the highest possible capacitance. If shielded wire is used, the appropriate number is the "Conductor to Other Conductor & Shield" value

Example — 18 AWG Unshielded Audio, Control and Instrumentation Cable

#### Manufacturer's specifications include:

Nom. Capacitance Conductor to Conductor @ 1 KHz: 26 pF/ft

Nom. Conductor DC Resistance @ 20 Deg. C: 5.96 Ohms/1000 ft

Max. Operating Voltage – UL 200 V RMS (PLTC, CMG),150 V RMS (ITC)

Allowable Length with this cable = 18000pF/(26pF/ft) = 692 ft

## Example — 18 AWG Shielded Audio, Control and Instrumentation Cable

Manufacturer's specifications include:

Nom. Characteristic Impedance: 29 Ohms

Nom. Inductance: .15 µH/ft

Nom. Capacitance Conductor to Conductor @ 1 KHz: 51 pF/ft

Nom. Cap. Cond. to other Cond. & Shield @ 1 KHz 97 pF/ft

Allowable Length with this cable = 18000pF /(97pF/ft) = 185 ft

The AUX switch input passes less than 1 mA through the switch contacts, and uses less than 5V, therefore, neither the resistance nor the voltage rating of the cable are critical. Ensure that switch contact corrosion is prevented. It is generally advisable that the switch have gold-plated or sealed contacts.

## **Device Variables**

The following menus are available to define and/or view information about the instrument. From the Online menu select *Device Variables*.



## Note

These variables are not available for instrument level AC. Supply Pressure alert is not available for instrument level HC.

#### Analog In (3-1)

Analog Input shows the value of the instrument analog input in mA (milliamperes) or % (percent) of ranged input.

#### Travel Set Point (3-2)

Travel Set Point shows the requested valve position in % of ranged travel.

#### **Travel (3-3)**

Travel shows the value of the DVC6000 Series digital valve controller travel in % (percent) of ranged travel. Travel always represents how far the valve is open.

#### Drive Signal (3-4)

Drive Signal shows the value of the instrument drive signal in % (percent) of maximum drive.

## Pressures (3-5)

Shows the value of the instrument supply and output pressures in psi, bar, kPa, or kg/cm<sup>2</sup>. Also shows the output pressure differential. To display pressures may require selecting the variable; a detail display of that variable with its values will appear.

- Pressure A— Pressure A shows the value of Output Pressure A in psi, bar, kPa, or kg/cm<sup>2</sup>.
- *Pressure B* Pressure B shows the value of Output Pressure A in psi, bar, kPa, or kg/cm<sup>2</sup>.
- Pressure Diff—Pressure Differential shows the value of the output pressure differential in psi, bar, kPa, or kg/cm<sup>2</sup>.
- Supply Pressure—Supply Pressure displays the instrument supply pressure in psi, bar, kPa, or kg/cm<sup>2</sup>.



## Note

Supply Pressure is not available for instrument level HC.

January 2007 7-7

## Note

These variables are not available for instrument level AC.

The Variables menu is available to view additional variables, including; Aux Input (Auxiliary Input), Temperature, Temp Max (Maximum Temperature), Temp Min (Minimum Temperature), Cycle Count, Tvl Accum (Travel Accumulator), Raw Tvl Input (Raw Travel Input), Run Time, and Num of Power Ups (Number of Power Ups).

To view one of these variables, from the *Online* menu select *Device Variables* and *Variables*. If a value for a variable does not appear on the display, select the variable and a detailed display of that variable with its value will appear. A variable's value does not appear on the menu if the value becomes too large to fit in the allocated space on the display, or if the variable requires special processing, such as Aux Input.

- Aux Input—The Auxiliary Input is a discrete input that can be used with an independent limit or pressure switch. Its value is either open or closed.
- Temp—The internal temperature of the instrument is displayed in either degrees Fahrenheit or Celsius.
- Temp Max—Maximum Recorded Temperature shows the maximum temperature the instrument has experienced since installation.
- *Temp Min*—Minimum Recorded Temperature shows the minimum temperature the instrument has experienced since installation.
- Cycle Count—Cycle Counter displays the number of times the valve travel has cycled. Only changes in direction of the travel after the travel has exceeded the deadband are counted as a cycle. Once a new cycle has occurred, a new deadband around the last travel is set. The value of the Cycle Counter can be reset from the Cycle Count Alert menu. See page 5-17 of the Detailed Setup section for additional information.
- Tvl Accum—Travel Accumulator contains the total change in travel, in percent of ranged travel. The accumulator only increments when travel exceeds the deadband. Then the greatest amount of change in one direction from the original reference point (after the

deadband has been exceeded) will be added to the Travel Accumulator. The value of the Travel Accumulator can be reset from the *Travel Accum* menu. See page 5-17 of the Detailed Setup section for additional information.



## Note

Do not use the following raw travel input indication for calibrating the travel sensor. The following should only be used for a relative indication to be sure the travel sensor is working and that it is moving in the correct direction. Perform the Travel Sensor Adjust procedure in the Calibration section to calibrate the travel sensor.

- Raw Tvl Input—Raw travel input indicates the travel sensor position in analog-to-digital converter counts. When the travel sensor is operating correctly, this number changes as the valve strokes.
- Run Time—Indicates in hours or days the total elapsed time the instrument has been powered up.
- Num of Power Ups—Number of Power Ups Indicates how many times the instrument has cycled power.

#### **Device Information (3-7)**

The Device Information menu is available to view information about the instrument. From the Online menu, select Device Variables and Device Information. Follow the prompts on the Field Communicator display to view information in the following fields: HART Tag, Device ID, Manufacturer, Model, Device Rev (Device Revision), Firmware Rev (Firmware Revision), Hardware Rev (Hardware Revision), Inst Level (Instrument Level), and HART Univ Rev (HART Universal Revision).

7

January 2007

# **Viewing Device Information**

Table 7-2. Functions Available for Instrument Level

Instrument Level	Functions Available
AC	Communicates with Model 375 Field Communicator Provides basic setup and calibration.
НС	Communicates with Model 375 Field Communicator and AMS ValveLink Software. In addition to above, provides: travel cutoffs and limits, minimum opening and closing times, input characterization (linear, equal percentage, quick opening, and custom), trending with ValveLink Solo, and the following alerts: travel deviation; travel alert high, low, high high, and low low; drive signal; auxiliary terminal; cycle counter; and travel accumulation.
AD	Includes all functions listed above plus (with ValveLink software) all offline diagnostic tests (dynamic error band, drive signal, step response, and valve signature) plus online trending
PD	Includes all functions listed above plus online valve signature test (friction analysis)
ODV	Includes all functions listed above plus partial stroke test and lead/lag input filter.

- Hart Tag—A HART tag is a unique name (up to eight characters) that identifies the physical instrument.
- Device ID—Each instrument has a unique Device Identifier. The device ID provides additional security to prevent this instrument from accepting commands meant for other instruments.
- Manufacturer—Identifies the manufacturer of the instrument.

- Model—Identifies the instrument model.
- Device Rev—Device Revision is the revision number of the software for communication between the Field Communicator and the instrument.
- Firmware Rev—Firmware Revision is the revision number of the firmware in the instrument.
- Hardware Rev—Hardware Revision is the revision number of the electrical circuitry within the instrument printed wiring board.
  - Inst Level—Indicates the instrument level

AC—Auto Calibrate

**HC—HART** Communicating

AD—Advanced Diagnostics

PD—Performance Diagnostics

ODV—Optimized Digital Valve

Table 7-2 lists the functions available for each instrument level.

• HART Univ Rev—HART Universal Revision is the revision number of the HART Universal Commands which are used as the communications protocol for the instrument.

## • DD Information (3-8)

DD Information contains the device description in the Field Communicator. To access DD Information from the Online menu, select *Device Variables* and *DD Information*.

January 2007 **7-9** 

7

**7-10** January 2007


# **Section 8 Principle of Operation**

HART <sup>®</sup> Communication	8-2
Digital Valve Controller Operation	8-2

R

January 2007 **8-1** 

## **DVC6000** Series



AVERAGE CURRENT CHANGE DURING COMMUNICATION = 0

Figure 8-1. HART Frequency Shift Keying Technique

## HART® Communication

The HART (Highway Addressable Remote Transducer) protocol gives field devices the capability of communicating instrument and process data digitally. This digital communication occurs over the same two-wire loop that provides the 4–20 mA process control signal, without disrupting the process signal. In this way, the analog process signal, with its faster update rate, can be used for control. At the same time, the HART protocol allows access to digital diagnostic, maintenance, and additional process data. The protocol provides total system integration via a host device.

The HART protocol uses frequency shift keying (FSK). Two individual frequencies of 1200 and 2200 Hz are superimposed over the 4–20 mA current signal. These frequencies represent the digits 1 and 0 (see figure 8-1). By superimposing a frequency signal over the 4–20 mA current, digital communication is attained. The average value of the HART signal is zero, therefore no dc value is added to the 4–20 mA signal. Thus, true simultaneous communication is achieved without interrupting the process signal.

The HART protocol allows the capability of multidropping, i.e., networking several devices to a single communications line. This process is well suited for monitoring remote applications such as pipelines, custody transfer sites, and tank farms. See table 9-3 for instructions on changing the printed wiring board DIP switch configuration to multidrop.

## **Digital Valve Controller Operation**

The DVC6000 Series digital valve controller housing contains the travel sensor, terminal box, pneumatic input and output connections and a module base that may be easily replaced in the field without disconnecting field wiring or tubing. This master module contains the following submodules: I/P




Figure 8-2. Typical FIELDVUE<sup>®</sup> Instrument to Personal Computer Connections for AMS™ ValveLink<sup>®</sup> Software

converter, printed wiring board (pwb) assembly, and pneumatic relay. The module base can be rebuilt by replacing the submodules. See figures 8-3 and 8-4.

DVC6000 Series digital valve controllers are loop-powered instruments that provide a control valve position proportional to an input signal from the control room. The following describes a double-acting Type DVC6010 digital valve controller mounted on a piston actuator.

The input signal is routed into the terminal box through a single twisted pair of wires and then to the printed wiring board assembly submodule where it is read by the microprocessor, processed by a digital algorithm, and converted into an analog I/P drive signal.

As the input signal increases, the drive signal to the I/P converter increases, increasing the I/P output pressure. The I/P output pressure is routed to the pneumatic relay submodule. The relay is also connected to supply pressure and amplifies the small pneumatic signal from the I/P converter. The relay accepts the amplified pneumatic signal and provides two output pressures. With increasing input (4 to 20 mA signal), the output A pressure always increases and the output B pressure decreases. The output A pressure is used for double-acting and single-acting direct applications. The output B pressure is used for double-acting and single-acting reverse applications. As shown in figure 8-3 the increased output A pressure causes the actuator stem to move

**8-2** January 2007

# **Principle of Operation**




Figure 8-3. DVC6000 Series Digital Valve Controller Block Diagram

downward. Stem position is sensed through the feedback linkage by the travel sensor which is electrically connected to the printed wiring board assembly submodule. The stem continues to move downward until the correct stem position is attained. At this point the printed wiring board assembly stabilizes the I/P drive signal. This positions the flapper to prevent any further increase in nozzle pressure.

As the input signal decreases, the drive signal to the I/P converter submodule decreases, decreasing the I/P output pressure. The pneumatic relay decreases the output A pressure and increases the output B pressure. The stem moves upward until the correct position is attained. At this point the printed wiring board assembly stabilizes the I/P drive signal. This positions the flapper to prevent any further decrease in nozzle pressure.

January 2007 **8-3** 




Figure 8-4. DVC6000 Series Digital Valve Controller Assembly

**8-4** January 2007

## 9

# **Section 9 Maintenance**

Instrument Troubleshooting	9-3
Checking Voltage Available	9-5
Module Base Maintenance	
Removing the Module Base	9-6
Replacing the Module Base	9-7
Submodule Maintenance	
I/P Converter	
Removing the I/P Converter	9-8
Replacing the I/P Converter	9-8
Printed Wiring Board (PWB) Assembly	
Removing the Printed Wiring Board Assembly	9-9
Replacing the Printed Wiring Board Assembly	9-9 9-9
	9-9
Pneumatic Relay  Removing the Pneumatic Relay	9-10
Replacing the Pneumatic Relay	9-10
Gauges, Pipe Plugs or Tire Valves	9-10
clauges, ripe riage or rice valves recommended	0 .0
Terminal Box	
Removing the Terminal Box	9-11
Replacing the Terminal Box	9-11
Travel Sensor	
Disassembly	
DVC6010 Digital Valve Controller and DVC6015 Remote Feedback Unit (Sliding-Stem)	9-12
DVC6020 Digital Valve Controller and DVC6025 Remote Feedback Unit (Rotary)	9-12
DVC6030 Digital Valve Controller and DVC6035 Remote Feedback Unit (Rotary)	9-12

January 2007 9-1

# **DVC6000 Series**

Assembly	
DVC6010 Digital Valve Controller and DVC6015 Remote	
Feedback Unit (Sliding-Stem)	9-12
DVC6020 Digital Valve Controller and DVC6025 Remote	
Feedback Unit (Rotary)	9-13
DVC6030 Digital Valve Controller and DVC6035 Remote	
Feedback Unit (Rotary)	9-15

**9-2** January 2007

ع

The DVC6000 Series digital valve controller enclosure is rated NEMA 4X and IP66, therefore periodic cleaning of internal components is not required. If the DVC6000 is installed in an area where the exterior surfaces tend to get heavily coated or layered with industrial or atmospheric contaminants, however, it is recommended that the vent (key 52) be periodically inspected to ensure it is fully open. If the vent appears to be clogged, the vent can be removed, cleaned and replaced. Lightly brush the exterior of the vent to remove contaminant and run a mild water/detergent solution through the vent to ensure it is fully open.

## **WARNING**

Personal injury or property damage can occur from cover failure due to overpressure. Ensure that the housing vent opening is open and free of debris to prevent pressure buildup under the cover.  Check with your process or safety engineer for any additional measures that must be taken to protect against process media.

### CAUTION

When replacing components, use only components specified by the factory. Always use proper component replacement techniques, as presented in this manual. Improper techniques or component selection may invalidate the approvals and the product specifications, as indicated in table 1-2. It may also impair operations and the intended function of the device.

## **WARNING**

Avoid personal injury or property damage from sudden release of process pressure or bursting of parts. Before performing any maintenance procedures on the DVC6000 Series digital valve controller:

- Always wear protective clothing, gloves, and eyewear to prevent personal injury.
- Disconnect any operating lines providing air pressure, electric power, or a control signal to the actuator. Be sure the actuator cannot suddenly open or close the valve.
- Use bypass valves or completely shut off the process to isolate the valve from process pressure. Relieve process pressure from both sides of the valve.
- Vent the pneumatic actuator loading pressure and relieve any actuator spring precompression.
- Use lock-out procedures to be sure that the above measures stay in effect while you work on the equipment.



## **Note**

If the feedback arm (key 79) or feedback arm assembly (key 84) is removed from the digital valve controller, the travel sensor (key 77) must be recalibrated.

Because of the diagnostic capability of the DVC6000 Series digital valve controllers, predictive maintenance is available through the use of AMS ValveLink Software. Using the digital valve controller, valve and instrument maintenance can be enhanced, thus avoiding unnecessary maintenance. For information on using the ValveLink Software, refer to the AMS ValveLink Software online help.

## **Instrument Troubleshooting**

If communication or output difficulties are experienced with the instrument, refer to the troubleshooting chart in table 9-1.

# **DVC6000 Series**

Table 9-1. Instrument Troubleshooting

Symptom	Possible Cause	Action
Analog input reading at instrument does not match actual current provided.	1a. Control mode not Analog.	1a. Check the control mode using the Field Communicator. If in the Digital or Test mode, the instrument receives its set point as a digital signal. Control is not based on input current. Change Control Mode to Analog.
	1b. Low control system compliance voltage.	<ol> <li>Check system compliance voltage (see Wiring Practices in the Installation section.</li> </ol>
	1c. Instrument shutdown due to self test failure.	Check instrument status using the Field Communicator (see Viewing Instrument Status in the Viewing Device Information section).
	1d. Analog input sensor not calibrated.	1d. Calibrate the analog input sensor (see Analog Input Calibration in the Calibration section).
	1e. Current leakage.	1e. Excessive moisture in the terminal box can cause current leakage. Typically the current will vary randomly if this is the case. Allow the inside of the terminal box to dry, then retest.
Instrument will not communicate.	2a. Insufficient Voltage Available.	<ol> <li>Calculate Voltage Available (see Wiring Practices in the Installation section). Voltage Available should be greater than or equal to 11 Vdc.</li> </ol>
	2b. Controller output Impedance too low.	2b. Install a HART filter after reviewing Control System Compliance Voltage requirements (see Wiring Practices in the Installation section).
	2c. Cable capacitance too high.	2c. Review maximum cable capacitance limits (see Wiring Practices in the Installation section).
	2d. HART filter improperly adjusted.	2d. Check filter adjustment (see the appropriate HART filter instruction manual).
	2e. Improper field wiring.	2e. Check polarity of wiring and integrity of connections. Make sure cable shield is grounded only at the control system.
	2f. Controller output providing less than 4 mA to loop.	2f. Check control system minimum output setting, which should not be less than 3.8 mA.
	2g. Disconnected loop wiring cable at PWB.	2g. Verify connectors are plugged in correctly.
	2h. PWB DIP switch not set properly.	2h. Check for incorrect setting or broken DIP switch on the back of the PWB. Reset switch or replace PWB, if switch is broken. See table 9-3 for switch setting information
	2j. PWB failure.	2j. Use a 4–20 mA current source to apply power to the instrument. Terminal voltage across the LOOP+ and LOOP- terminals should be 9 to 10.5 Vdc. If the terminal voltage is not 9 to 10.5 Vdc, replace the PWB.
	2k. Polling address incorrect.	2k. Use the Field Communicator to set the polling address (refer to the Detailed Setup section). From the <i>Utilities</i> menu, select <i>Configure Communicator</i> and <i>Polling</i> . Select <i>Always Poll</i> . Set the instrument polling address to 0.
	2l. Defective terminal box.	2l. Check continuity from each screw terminal to the corresponding PWB connector pin. If necessary, replace the terminal box assembly.
	2m. Defective Field Communicator or ValveLink modem cable.	2m. If necessary, repair or replace cable.
	2n. ValveLink modem defective or not compatible with PC.	2n. Replace ValveLink modem.
	2p. ValveLink hardlock defective or not programmed.	2p. Replace if defective or return to factory for programming.
3. Instrument will not calibrate, has sluggish	3a. Travel sensor seized, will not turn.	3a. Rotate feedback arm to ensure it moves freely. If not, replace the pot/bushing assy.
performance or oscillates.	3b. Broken travel sensor wire(s).	3b. Inspect wires for broken solder joint at pot or broken wire. Replace pot/bushing assy.
	3c. Travel sensor misadjusted.	3c. Perform Travel Sensor Adjust procedure in the Calibration section.
	3d. Open travel sensor.	3d. Check for continuity in electrical travel range. If necessary, replace pot/bushing assy.
	3e. Cables not plugged into PWB correctly.	3e. Inspect connections and correct.
	3f. Feedback arm loose on pot.	3f. Perform Travel Sensor Adjust procedure in the Calibration section.
	3g. Feedback arm bent/damaged or bias spring missing/damaged.	3g. Replace feedback arm and bias spring.

**9-4** January 2007

## **Maintenance**

Table 9-1. Instrument Troubleshooting (Continued)

Symptom	Possible Cause	Action
Instrument will not calibrate, has sluggish performance or oscillates.	3h. Configuration errors.	3h. Verify configuration: If necessary, set protection to None. If Out of Service, place In Service. Check: Travel Sensor Motion Tuning set Zero control signal Feedback Connection Control mode (should be Analog) Restart control mode (should be Analog)
	3j. Restricted pneumatic passages in I/P converter.	3j. Check screen in I/P converter supply port of the module base. Replace if necessary. If passages in I/P converter restricted, replace I/P converter.
	3k. O-ring(s) between I/P converter ass'y missing or hard and flattened losing seal.	3k. Replace O-ring(s).
	3I. I/P converter ass'y damaged/corroded/clogged.	3I. Check for bent flapper, open coil (continuity), contamination, staining, or dirty air supply. Coil resistance should be between 1680 - 1860 ohms. Replace I/P assy if damaged, corroded, clogged, or open coil.
	3m. I/P converter ass'y out of spec.	3m. I/P converter ass'y nozzle may have been adjusted. Verify drive signal (55 to 80% for double-acting; 60 to 85% for single-acting) with the valve off the stops. Replace I/P converter ass'y if drive signal is continuously high or low.
	3n. Defective module base seal.	3n. Check module base seal for condition and position. If necessary, replace seal.
	3p. Defective relay.	3p. Depress relay beam at adjustment location in shroud, look for increase in output pressure. Remove relay, inspect relay seal. Replace relay seal or relay if I/P converter ass'y good and air passages not blocked. Check relay adjustment.
	3q. Defective 67CFR regulator, supply pressure gauge jumps around.	3q. Replace 67CFR regulator.
	4a. Bent or defective pressure sensor.	4a. Replace PWB.
provide erroneous results.	4b. Pressure sensor O-ring missing.	4b. Replace O-ring.
5. Cannot perform advanced diagnostics.	5a. Variable not available in printed wiring board.	5a. Instrument does not have AD instrument level.
6. Field Communicator does not turn on.	6a. Battery pack not charged.	6a. Charge battery pack.  Note: Battery pack can be charged while attached to the Field communicator or separately. The 375 Field Communicator is fully operable while the battery pack is charging. Do not attempt to charge the battery pack in a hazardous area.

## **Checking Voltage Available**



Personal injury or property damage caused by fire or explosion may occur if this test is attempted in an area which contains a potentially explosive atmosphere or has been classified as hazardous.

To check the Voltage Available at the instrument, perform the following:

1. Connect the equipment in figure 2-24 to the field wiring in place of the FIELDVUE instrument.

- 2. Set the control system to provide maximum output current.
- 3. Set the resistance of the 1 kilohm potentiometer shown in figure 2-24 to zero.
- 4. Record the current shown on the milliammeter.
- 5. Adjust the resistance of the 1 kilohm potentiometer until the voltage read on the voltmeter is 11.0 volts.
- 6. Record the current shown on the milliammeter.
- 7. If the current recorded in step 6 is the same as that recorded in step 4 ( $\pm$  0.08 mA), the voltage available is adequate.
- 8. If the voltage available is inadequate, refer to Wiring Practices in the Installation section.

January 2007 **9-5** 

		•
Tool	Size	Component
Phillips Screwdriver		Relay, printed wiring board
		assembly, and cover screws
Hex key	5 mm	Terminal box screw
Hex key	1.5 mm	Terminal box cover screw
Hex key	2.5 mm	I/P converter screws
Hex key	5 mm	Travel sensor screws
Hex key	6 mm	Module base screws
Open-end wrench	1/2-inch	Connector Arm screw (DVC6010)
Hex key	9/64-inch	Feedback arm screw
Open-end wrench	7/16-inch	DVC6010 mounting bolts
Hex key	3/16-inch	DVC6020 mounting bolts



The digital valve controller contains a module base consisting of the I/P converter, printed wiring board assembly, and pneumatic relay. The module base may be easily replaced in the field without disconnecting field wiring or tubing.

## **Tools Required**

Table 9-2 lists the tools required for maintaining the DVC6000 Series digital valve controller.

## **Removing the Module Base**

To remove the module base for DVC6010, DVC6020 and DVC6030 digital valve controllers, perform the following steps. Refer to figures 10-1, 10-2 and 10-3, respectively, for key number locations.

## **WARNING**

To avoid personal injury or equipment damage from bursting of parts, turn off the supply pressure to the digital valve controller and bleed off any excess supply pressure before attempting to remove the module base assembly from the housing.

1. For sliding-stem applications only, a protective shield for the feedback linkage is attached to the side of the module base assembly (see figures 2-1 and 2-2). Remove this shield and keep for reuse on the replacement module. The replacement module will not have this protective shield.




Figure 9-1. Printed Wiring Board Cable Connections

- 2. Unscrew the four captive screws in the cover (key 43) and remove the cover from the module base (key 2).
- 3. Using a 6 mm hex socket wrench, loosen the three-socket head screws (key 38). These screws are captive in the module base by retaining rings (key 154).



## **Note**

The module base is linked to the housing by two cable assemblies. Disconnect these cable assemblies after you pull the module base out of the housing.

- 4. Pull the module base straight out of the housing (key 1). Once clear of the housing, swing the module base to the side of the housing to gain access to the cable assemblies.
- 5. The digital valve controller has two cable assemblies, shown in figure 9-1, which connect the module base, via the printed wiring board assembly, to the travel sensor and the terminal box. Disconnect these cable assemblies from the printed wiring board assembly on the back of the module base.

**9-6** January 2007

9

### CAUTION

To avoid affecting performance of the instrument, take care not to damage the module base seal or guide surface. Do not bump or damage the bare connector pins on the PWB assembly. Damaging either the module base or guide surface may result in material damage, which could compromise the instruments ability to maintain a pressure seal.

### Replacing the Module Base

To replace the module base, for DVC6010, DVC6020 and DVC6030 digital valve controllers, perform the following steps. Refer to figures 10-1, 10-2 and 10-3, respectively, for key number locations.



## **Note**

To avoid affecting performance of the instrument, inspect the guide surface on the module and the corresponding seating area in the housing before installing the module base assembly. These surfaces must be free of dust, dirt, scratches, and contamination.

Ensure the module base seal is in good condition. Do not reuse a damaged or worn seal.

- 1. Ensure the module base seal (key 237) is properly installed in the housing (key 1). Ensure the O-ring (key 12) is in place on the module base assembly.
- 2. Connect the terminal box connector to the PWB assembly (key 50). Orientation of the connector is required.
- 3. Connect the travel sensor connector to the PWB assembly (key 50). Orientation of the connector is required.
- 4. Insert the module base (key 2) into the housing (key 1).
- 5. Install three socket head screws (key 38) in the module base into the housing. If not already installed, press three retaining rings (key 154) into the module base. Evenly tighten the screws in a crisscross pattern to a final torque of 16 N•m (138 lbf•in).

- 6. Attach the cover (key 43) to the module base assembly.
- 7. For sliding-stem applications only, install the protective shield onto the side of the replacement module base assembly (see figures 2-1 and 2-2).

### **Submodule Maintenance**

The digital valve controller's module base contains the following submodules: I/P converter, PWB assembly, and pneumatic relay. If problems occur, these submodules may be removed from the module base and replaced with new submodules. After replacing a submodule, the module base may be put back into service.

### **CAUTION**

Exercise care when performing maintenance on the module base. Reinstall the cover to protect the I/P converter and gauges when servicing other submodules.

In order to maintain accuracy specifications, do not strike or drop the I/P converter during submodule maintenance.

### I/P Converter

Refer to figures 10-4 through 10-5 for key number locations. The I/P converter (key 41) is located on the front of the module base.



## **Note**

After I/P converter submodule replacement, calibrate the digital valve controller to maintain accuracy specifications.

### Replacing the I/P Filter

A screen in the supply port beneath the I/P converter serves as a secondary filter for the supply medium. To replace this filter, perform the following procedure:

1. Remove the I/P converter (key 41) and shroud (key 169) as described in the Removing the I/P Converter procedure.

January 2007




Figure 9-2. I/P Filter Location

- 2. Remove the screen (key 231) from the supply port.
- 3. Install a new screen in the supply port as shown in figure 9-2.
- 4. Inspect the O-ring (key 39) in the I/P output port. if necessary, replace it.
- 5. Reinstall the I/P converter (key 41) and shroud (key 169) as described in the Replacing the I/P Converter procedure.

### Removing the I/P Converter

- 1. Remove the front cover (key 43), if not already removed.
- 2. Refer to figure 9-3. Using a 2.5 mm hex socket wrench, remove the four socket-head screws (key 23) that attach the shroud (key 169) and I/P converter (key 41) to the module base (key 2).
- 3. Remove the shroud (key 169); then pull the I/P converter (key 41) straight out of the module base (key 2). Be careful not to damage the two electrical leads that come out of the base of the I/P converter.
- 4. Ensure that the O-ring (key 39) and screen (key 231) stay in the module base and do not come out with the I/P converter (key 41).

## Replacing the I/P Converter

- 1. Refer to figure 9-2. Inspect the condition of the O-ring (key 39) and screen (key 231) in the module base (key 2). Replace them, if necessary. Apply silicone lubricant to the O-rings.
- 2. Ensure the two boots (key 210) shown in figure 9-3 are properly installed on the electrical leads.
- 3. Install the I/P converter (key 41) straight into the module base (key 2), taking care that the two electrical leads feed into the guides in the module base. These guides route the leads to the printed wiring board assembly submodule.
- 4. Install the shroud (key 169) over the I/P converter (key 41).
- 5. Install the four socket-head screws (key 23) and evenly tighten them in a crisscross pattern to a final torque of 1.6 N•m (14 lbf•in).
- 6. After replacing the I/P converter, calibrate travel or perform touch-up calibration to maintain accuracy specifications.

**9-8** January 2007




Figure 9-3. I/P Converter

### **PWB (Printed Wiring Board) Assembly**

Refer to figures 10-4 through 10-5 for key number locations. The PWB assembly (key 50) is located on the back of the module base assembly (key 2).



## **Note**

If the PWB assembly submodule is replaced, calibrate and configure the digital valve controller to maintain accuracy specifications.

# Removing the Printed Wiring Board Assembly

- 1. Separate the module base from the housing by performing the Removing the Module Base procedure.
- 2. Remove three screws (key 33).
- 3. Lift the PWB assembly (key 50) straight out of the module base (key 2).
- 4. Ensure that the O-rings (key 40) remain in the pressure sensor bosses on the module base assembly (key 2) after the PWB assembly (key 50) has been removed.




Figure 9-4. DVC6000 Series Digital Valve Controller DIP Switch Location

Table 9-3. DIP Switch Configuration<sup>(1)</sup>

OPERATIONAL MODE	SWI	TCH PC	OSITION
Multidrop Loop	UP		<b>↑</b>
Point-to-Point Loop	DOWN		<b>+</b>
Refer to figure 9-4 for switch location.			

# Replacing the PWB Assembly and Setting the DIP Switch

- 1. Apply silicone lubricant to the pressure sensor O-rings (key 40) and install them on the pressure sensor bosses in the module base assembly.
- 2. Properly orient the PWB assembly (key 50) as you install it into the module base. The two electrical leads from the I/P converter (key 41) must guide into their receptacles in the PWB assembly and the pressure sensor bosses on the module base must fit into their receptacles in the PWB assembly.
- 3. Push the PWB assembly (key 50) into its cavity in the module base.
- 4. Install and tighten three screws (key 33) to a torque of 1 N•m (10.1 lbf•in).
- 5. Set the DIP switch on the PWB assembly according to table 9-3.

January 2007

## Note

For the digital valve controller to operate with a 4 to 20 mA control signal, be sure the DIP switch is in the point-to-point loop position, i.e., switch in down position.

- 6. Reassemble the module base to the housing by performing the Replacing the Module Base procedure.
- 7. Setup and calibrate the digital valve controller.

## **Pneumatic Relay**

Refer to figures 10-4 through 10-5 for key number locations. The pneumatic relay (key 24) is located on the front of the module base.



## **Note**

After relay submodule replacement, calibrate the digital valve controller to maintain accuracy specifications.

## Removing the Pneumatic Relay

- 1. Loosen the four screws that attach the relay (key 24) to the module base. These screws are captive in the relay.
- 2. Remove the relay.

## Replacing the Pneumatic Relay

- 1. Visually inspect the holes in the module base to ensure they are clean and free of obstructions. If cleaning is necessary, do not enlarge the holes.
- 2. Apply silicone lubricant to the relay seal and position it in the grooves on the bottom of the relay as shown in figure 9-5. Press small seal retaining tabs into retaining slots to hold relay seal in place.
- 3. Position the relay (with shroud) on the module base. Tighten the four screws, in a crisscross pattern, to a final torque of 2 N•m (20.7 lbf•in).
- 4. Using the Field Communicator, verify that the value for Relay Type parameter matches the relay type installed.



Figure 9-5. Pneumatic Relay Assembly

5. After replacing the relay and verifying the relay type, calibrate travel or perform touch-up calibration to maintain accuracy specifications

## Gauges, Pipe Plugs, or Tire Valves

Depending on the options ordered, the DVC6000 Series digital valve controller will be equipped with either gauges (key 47), pipe plugs (key 66), or tire valves (key 67). Single-acting direct instruments will also have a screen (key 236, figure 10-5). These are located on the top of the module base next to the relay.

Perform the following procedure to replace the gauges, tire valves, or pipe plugs. Refer to figures 10-4 through 10-5 for key number locations.

- 1. Remove the front cover (key 43).
- 2. Remove the gauge, pipe plug, or tire valve as follows:

For gauges (key 47), the flats are on the gauge case. Use a wrench on the flats of the gauge to remove the gauge from the module base. For double-acting instruments, to remove the supply gauge remove one of the output gauges.

For pipe plugs (key 66) and tire valves (key 67), use a wrench to remove these from the module base.

- 3. Apply sealant (key 64) to the threads of the replacement gauges, pipe plugs, or tire valves.
- 4. Using a wrench, screw the gauges, pipe plugs, or tire valves into the module base.

### **Terminal Box**

Refer to figures 10-4 through 10-5 for key number locations.

The terminal box is located on the housing and contains the terminal strip assembly for field wiring connections.

9



## **Note**

This procedure also applies to the DVC6005 remote terminal box.

## **Removing the Terminal Box**



To avoid personal injury or property damage caused by fire or explosion, remove power to the instrument before removing the terminal box cover in an area which contains a potentially explosive atmosphere or has been classified as hazardous.

- 1. Loosen the set screw (key 58) in the cap (key 4) so that the cap can be unscrewed from the terminal box.
- 2. After removing the cap (key 4), note the location of field wiring connections and disconnect the field wiring from the terminal box.
- 3. Separate the module base from the housing by performing the Removing the Module Base procedure.
- 4. Remove the screw (key 72). Pull the terminal box assembly straight out of the housing.
- 5. Remove two wire retainers (key 44), internal and external to the terminal box.

## **Replacing the Terminal Box**



## Note

Inspect all O-rings for wear and replace as necessary.

1. Install two wire retainers (key 44), internal and external to the terminal box.

- 2. Apply silicone lubricant to the O-ring (key 35) and install the O-ring over the stem of the terminal box.
- 3. Insert the terminal box assembly stem into the housing until it bottoms out. Position the terminal box assembly so that the hole for the screw (key 72) in the terminal box aligns with the threaded hole in the housing. Install the screw (key 72).
- 4. Connect the terminal box connector to the PWB assembly (key 50). Orientation of the connector is required.
- 5. Reassemble the module base to the housing by performing the Replacing the Module Base procedure.
- 6. Reconnect the field wiring as noted in step 2 in the Removing the Terminal Box procedure.
- 7. Apply silicone lubricant to the O-ring (key 36) and install the O-ring over the 2-5/8 inch threads of the terminal box. Use of a tool is recommended to prevent cutting the O-ring while installing it over the threads.
- 8. Apply lubricant (key 63) to the 2-5/8 inch threads on the terminal box to prevent seizing or galling when the cap is installed.
- 9. Screw the cap (key 4) onto the terminal box.
- 10. Install a set screw (key 58) into the cap (key 4). Loosen the cap (not more than 1 turn) to align the set screw over one of the recesses in the terminal box. Tighten the set screw (key 58).
- 11. Apply sealant (key 64) to the conduit entrance plug (key 62) and install it into the unused conduit entry of the terminal box.

### **Travel Sensor**

Replacing the travel sensor requires removing the digital valve controller from the actuator.



To avoid personal injury or property damage caused by fire or explosion, remove power to the instrument before removing the potentiometer in an area which contains a potentially explosive atmosphere or has been classified as hazardous.

January 2007

Disassembly

## Note

If the feedback arm (key 79) or feedback arm assembly (key 84) is removed from the digital valve controller, the travel sensor (key 77) must be recalibrated.

# Type DVC6010 Digital Valve Controller and Type DVC6015 Remote Feedback Unit

Refer to figure 10-1 for Type DVC6010 and 10-6 for Type DVC6015 key number locations.

- 1. Remove piping and fittings from the instrument.
- 2. Disconnect the adjustment arm from the connector arm and the feedback arm (see figures 2-1 and 2-2).
- 3. Remove the instrument from the actuator.
- 4. Loosen the screw (key 80) that secures the feedback arm (key 79) to the travel sensor shaft.
- 5. Remove the feedback arm (key 79) from the travel sensor shaft.

If disassembling a DVC6010 digital valve controller, use step 6a. If disassembling a DVC6015 remote feedback unit, use step 6b.

- 6. a. Separate the module base from the housing by performing the Removing the Module Base procedure.
- b. Disconnect the three potentiometer assembly wires from the terminals.
- 7. Remove the screw (key 72) that fastens the travel sensor assembly to the housing.
- 8. Pull the travel sensor assembly (key 223) straight out of the housing.

# Type DVC6020 Digital Valve Controller and Type DVC6025 Remote Feedback Unit

Refer to figure 10-2 for Type DVC6020 and 10-7 for Type DVC6025 key number locations.

- 1. Remove piping and fittings from the instrument.
- Remove the digital valve controller from the actuator.
- 3. Disconnect the bias spring (key 82) from the feedback arm assembly (key 84) and the arm assembly (key 91). Remove the mounting bracket (key 74) from the back of the digital controller.

- 4. Loosen the screw (key 80) that secures the arm assembly to the travel sensor shaft.
- 5. Remove the arm assembly (key 91) from the travel sensor assembly (key 77) shaft.

If disassembling a DVC6020 digital valve controller, use step 6a. If disassembling a DVC6025 remote feedback unit use step 6b.

- 6. a. Separate the module base from the housing by performing the Removing the Module Base procedure.
- b. Disconnect the three potentiometer assembly wires from the terminals.
- 7. Remove the screw (key 72) that fastens the travel sensor assembly to the housing.
- 8. Pull the travel sensor assembly (key 223) straight out of the housing.

# Type DVC6030 Digital Valve Controller and Type DVC6035 Remote Feedback Unit

Refer to figure 10-3 for Type DVC6030 and 10-8 for Type DVC6035 key number locations.

- 1. Remove piping and fittings from the instrument.
- 2. Remove the digital valve controller from the actuator. Loosen the screw (key 80) that secures the feedback arm (key 79) to the travel sensor shaft. Remove the feedback arm from the travel sensor shaft.

If disassembling a DVC6030 digital valve controller use step 3a. If disassembling a DVC6035 remote feedback unit use step 3b.

- 3. a. Separate the module base from the housing by performing the Removing the Module Base procedure.
- b. Disconnect the three potentiometer assembly wires from the terminals.
- 4. From within the housing, unscrew the travel sensor assembly (key 223) from the housing.

## **Assembly**



## **Note**

If the feedback arm (key 79) or feedback arm assembly (key 84) is removed from the digital valve controller, the travel sensor (key 77) must be recalibrated.

# Type DVC6010 Digital Valve Controller and Type DVC6015 Remote Feedback Unit

Refer to figure 10-1 for Type DVC6010 and 10-6 for Type DVC6015 key number locations.

9

ع

1. Insert the travel sensor assembly (key 223) into the housing (key 1). Secure the travel sensor assembly with screw (key 72).

If assembling a DVC6010 digital valve controller, use step 2a. If assembling a DVC6015 remote feedback unit, use step 2b.

- 2. a. Connect the travel sensor connector to the PWB as described in the Replacing the Module Base procedure.
- b. Connect the three travel sensor wires to the terminals.



## Note

For the Type DVC6015 feedback unit, connect the potentiometer assembly (key 223) wires to the terminals as follows:

red → terminal 1 white → terminal 2 black → terminal 3

- 3. Loosely assemble the bias spring (key 78), screw (key 80), plain washer (key 163), and nut (key 81) to the feedback arm (key 79), if not already installed.
- 4. Attach the feedback arm (key 79) to the travel sensor shaft.

Two methods are available for adjusting the travel sensor. You can use a multimeter to measure the potentiometer resistance, or if you have a Field Communicator, you can use the procedure in the Calibration section. To use the multimeter, perform steps 5 through 11. To use the Field Communicator, skip to step 12.

### **Travel Sensor Adjustment with a Multimeter**

- 5. Align the feedback arm (key 79) to the housing (key 1) by inserting the alignment pin (key 46) through the hole marked "A" on the feedback arm. Fully engage the alignment pin into the tapped hole in the side of the housing. Position the feedback arm so that the surface is flush with the end of the travel sensor shaft.
- 6. Connect a multimeter set to a resistance range of 3000 ohms to pins 2 and 3 of the travel sensor connector. Refer to figure 9-6 for pin location.
- 7. Adjust the travel sensor shaft to obtain a measured resistance of 1950 to 2050 ohms.



## **Note**

In the next step, be sure the feedback arm surface remains flush with the end of the travel sensor shaft.

- 8. While observing the resistance, tighten the screw (key 80) to secure the feedback arm to the travel sensor shaft. Be sure the resistance reading remains within the range listed in step 7. Paint the screw to discourage tampering with the connection.
- 9. Disconnect the multimeter from the travel sensor connector.
- 10. For the DVC6010, connect the travel sensor connector to the PWB as described in Replacing the Module Base.
- 11. Travel sensor replacement is complete. Install the digital valve controller on the actuator.

## Travel Sensor Adjustment with the Field Communicator

The next two steps do not apply if you used a multimeter to adjust the travel sensor. Perform these steps only if you elected to adjust the travel sensor using the Field Communicator.

- 12. For the DVC6010, connect the travel sensor connector to the PWB as described in Replacing the Module Base.
- 13. For both the DVC6010 and the DVC6015, perform the appropriate Travel Sensor Adjust procedure in the Calibration section.

# Type DVC6020 Digital Valve Controller and Type DVC6025 Remote Feedback Unit


Refer to figure 10-2 for Type DVC6020 and 10-7 for Type DVC6025 key number locations.

1. Insert the travel sensor assembly (key 223) into the housing. Secure the travel sensor assembly with screw (key 72).

If assembling a DVC6020 digital valve controller, use step 2a. If assembling a DVC6025 remote feedback unit, use step 2b.

- 2. a. Connect the travel sensor connector to the PWB as described in Replacing the Module Base.
- b. Connect the three travel sensor wires to the terminals.

January 2007



NOTE:

1 THE POTENTIOMETER RESISTANCE BETWEEN PINS 2 AND 3 CAN BE MEASURED AT THE CONNECTOR. INSERT TWO SHORT LENGTHS OF 22 AWG WIRE INTO THE PIN 2 AND 3 RECEPTACLES IN THE CONNECTOR. CLIP ON LEADS FROM A DVM (DIGITAL VOLTMETER) TO MEASURE THE RESISTANCE.

Figure 9-6. Potentiometer Resistance Measurement



## **Note**

For the Type DVC6025 feedback unit, connect the potentiometer assembly (key 223) wires to the terminals as follows:

red → terminal 1 white → terminal 2 black → terminal 3

3. Loosely assemble the screw (key 80), plain washer (key 163), and nut (key 81) to the arm assembly (key 91), if not already installed.

4. Attach the arm assembly (key 91) to the travel sensor assembly (key 223) shaft.

Two methods are available for adjusting the travel sensor. You can use a multimeter to measure the potentiometer resistance, or if you have a Field Communicator, you can use the procedure in the Calibration section. To use the multimeter, perform steps 5 through 15. To use the Field Communicator, skip to step 16.

### Travel Sensor Adjustment with a Multimeter

- 5. Connect a multimeter set to a resistance range of 7000 ohms to pins 2 and 3 of the travel sensor connector. Refer to figure 9-6 for pin location.
- 6. Hold the arm assembly (key 91) in a fixed position so that the arm is parallel to the housing back plane and pointing toward the terminal box. Position the arm

**9-14** January 2007

assembly so that the outer surface is flush with the end of the travel sensor shaft.

7. Adjust the travel sensor shaft to obtain a measured resistance of 6250 to 6350 ohms.



## Note


In the next step, be sure the arm assembly outer surface remains flush with the end of the travel sensor shaft.

- 8. While observing the resistance, tighten the screw (key 80) to secure the feedback arm to the travel sensor shaft. Be sure the resistance reading remains within the range listed in step 7. Paint the screw to discourage tampering with the connection.
- 9. Disconnect the multimeter from the travel sensor connector.
- 10. Apply lubricant (key 63) to the pin portion of the arm assembly (key 91).
- 11. Position the mounting bracket over the back of the digital valve controller. Push the feedback arm assembly (key 84) toward the housing and engage the pin of the arm assembly into the slot in the feedback arm.
- 12. Install the mounting bracket (key 74).
- 13. Install the bias spring (key 82) as shown in figure 9-7.
- 14. For the DVC6020 only, connect the travel sensor connector to the PWB as described in Replacing the Module Base.
- 15. Travel sensor replacement is complete. Install the digital valve controller on the actuator.

## Travel Sensor Adjustment with the Field Communicator

The next two steps do not apply if you used a multimeter to adjust the travel sensor. Perform these steps only if you elected to adjust the travel sensor using the Field Communicator.

- 16. For the DVC6020 only, connect the travel sensor connector to the PWB as described in Replacing the Module Base.
- 17. For both the DVC6020 and the DVC6025, perform the appropriate Travel Sensor Adjust procedure in the Calibration section.



NOTE: INSTALL BIAS SPRING WITH SMALLER DIAMETER HOOK CONNECTED TO ARM ASSEMBLY (KEY 91) AND WITH BOTH HOOK OPENINGS TOWARD CENTER OF BRACKET.

Figure 9-7. Type DVC6020 digital Valve Controller, Bias Spring (key 82) Installation

# Type DVC6030 Digital Valve Controller and Type DVC6035 Remote Feedback Unit

Refer to figure 10-3 for Type DVC6030 and 10-8 for Type DVC6035 key number locations.

- 1. Apply lubricant (key 63) to the travel sensor assembly threads.
- 2. Screw the travel sensor assembly (key 223) into the housing until it is tight.

If assembling a DVC6030 digital valve controller, use step 3a. If assembling a DVC6035 remote feedback unit, use step 3b.

- a. Connect the travel sensor connector to the PWB as described in the Replacing the Module Base procedure.
- b. Connect the three travel sensor wires to the terminals.

January 2007 9-15



## Note

For the Type DVC6035 feedback unit, connect the potentiometer assembly (key 223) wires to the terminals as follows:

red → terminal 1 white → terminal 2 black → terminal 3

- 4. Loosely assemble the bias spring (key 78), screw (key 80), plain washer (key 163), and nut (key 81) to the feedback arm (key 79), if not already installed.
- 5. Attach the feedback arm (key 79) to the travel sensor shaft.

Two methods are available for adjusting the travel sensor. You can use a multimeter to measure the potentiometer resistance, or if you have a Field Communicator, you can use the procedure in the Calibration section. To use the multimeter, perform steps 6 through 12. To use the Field Communicator, skip to step 13.

### Travel Sensor Adjustment with a Multimeter

- 6. Align the feedback arm (key 79) to the housing (key 1) by inserting the alignment pin (key 46) through the hole marked "A" on the feedback arm. Fully engage the alignment pin into the tapped hole in the housing. Position the feedback arm so that the outer surface is flush with the end of the travel sensor shaft.
- 7. Connect a multimeter set to a resistance range of 3000 ohms to pins 2 and 3 of the travel sensor connector. Refer to figure 9-6 for pin location.
- 8. Adjust the travel sensor shaft to obtain a measured resistance of 1950 to 2050 ohms.



## **Note**

In the next step, be sure the feedback arm outer surface remains flush with the end of the travel sensor shaft.

- 9. While observing the resistance, tighten the screw (key 80) to secure the feedback arm to the travel sensor shaft. Be sure the resistance reading remains within the range listed in step 7. Paint the screw to discourage tampering with the connection.
- 10. Disconnect the multimeter from the travel sensor connector.
- 11. For the DVC6030 only, connect the travel sensor connector to the PWB as described in Replacing the Module Base.
- 12. Travel sensor replacement is complete. Install the digital valve controller on the actuator as described in the Installation section.

## Travel Sensor Adjustment with the Field Communicator

The next two steps do not apply if you used a multimeter to adjust the travel sensor. Perform these steps only if you elected to adjust the travel sensor using the Field Communicator.

- 13. For the DVC6030 only, connect the travel sensor connector to the PWB as described in Replacing the Module Base.
- 14. For both the DVC6030 and the DVC6035, perform the appropriate Travel Sensor Adjust procedure in the Calibration section.

9

10-1

# **Section 10 Parts**

Parts Ordering	10-2
Parts Kits	10-2
Parts List	10-3
Housing	10-3
Common Parts	10-3
Module Base	10-3
I/P Converter Assembly	10-4
Relay	10-4
Terminal Box	10-4
Remote Terminal Box	10-4
PWB Assembly	10-4
Pressure Gauges, Pipe Plugs, or Tire Valve Assemblies	10-4
Feedback / Remote Travel Sensor Parts	10-5
HART® Filters	10-5

January 2007

## **Parts Ordering**

Whenever corresponding with your Emerson Process Management sales office about this equipment, always mention the controller serial number. When ordering replacement parts, refer to the 11-character part number of each required part as found in the following parts list. Parts which do not show part numbers are not orderable.

## **WARNING**

Use only genuine Fisher replacement parts. Components that are not supplied by Emerson Process Management should not, under any circumstances, be used in any Fisher instrument. Use of components not supplied by Emerson Process Management will void your warranty, might adversely affect the performance of the valve, and could give rise to personal injury and property damage.



## Note

Neither Emerson, Emerson Process Management, nor any of their affiliated entities assumes responsibility for the selection, use, and maintenance of any product. Responsibility for the selection, use, and maintenance of any product remains with the purchaser and end-user.



## **Note**

All part numbers are for both aluminum and stainless steel constructions, unless otherwise indicated.

### **Parts Kits**

Conversion kit 3 listed below provides the parts required to convert a DVC6010 to a DVC6020 or a DVC6015 to a DVC6025. Conversion kit 4 provides the parts required to convert a DVC6020 to a DVC6010 or a DVC6025 to a DVC6015.

Kit	Description	Part Number
1*	Elastomer Spare Parts Kit (kit contains parts to	
	service one digital valve controller)	
	Standard	19B5402X012
	Extreme Temperature option	
	(fluorosilicone elastomers)	19B5402X022
2*	Small Hardware Spare Parts Kit (kit contains parts	
	to service one digital valve controller)	19B5403X012
3	Conversion Kit (DVC6010 to DVC6020 or	
	DVC6015 to DVC6025)	
	Also see note below	19B5405X012

#### Note

When converting a DVC6010 to a DVC6020 for pipe-away construction, also order pipe-away bracket kit, item 6.

4	Conversion Kit (DVC6020 to DVC6010 or	
	DVC6015 to DVC6025)	14B5072X112
5	Alignment Pin Kit	
	[kit contains 15 alignment pins (key 46)]	14B5072X092
6	Pipe-Away Bracket Kit (DVC6020) [kit contains	
	mounting bracket (key 74) and O-ring (key 75)]	
	Standard	19B5404X012
	Extreme Temperature option	
	(fluorosilicone elastomers)	19B5404X022
7*	Seal Screen Kit	
	[kit contains 25 seal screens (key 231)	
	and 25 O-rings (key 39)]	
	Standard and Extreme Temperature option	14B5072X182
	(fluorosilicone elastomers)	
8	Terminal Box Kit, aluminum	
	Standard	19B5401X012
	Extreme Temperature option	
	(fluorosilicone elastomers)	19B5401X022
9*	I/P Converter Kit	
	Standard	38B6041X052
	For Extreme Temperature option	
	(fluorosilicone elastomers)	38B6041X062
10	Vent with extension	
	For a DVC6020 replacing a DVC5020	
	on an existing mounting	19B3407X012
11	Adjustment Arm Kit	
	(includes washer, nut and adjustment arm	14B5072X132
12*	PTFE Sleeve Kit	
	[For pot bushing assembly (kit includes 10 sleev	ves and
	Lubricant)]	
	DVC6010 and DVC6020	GE08726X012
	DVC6030	GE08727X012

**10-2** January 2007

<sup>\*</sup>Recommended spare

#### Kit Description **Part Number** Spare Module Base Assembly Kit, aluminum [kit contains module base (key 2); drive screws, qty. 2, (key 11); shield/label (key 19); hex socket cap screw, qty. 3, (key 38); self tapping screw, qty. 2 (key 49); pipe plug, qty. 3 (key 61); retaining ring, qty. 3 (key 154); screen (key 236); and flame arrestors, qty. 3 (key 243)] GE18654X012 14\* Spare Housing Assembly Kit, aluminum [kit contains housing (key 1); drive screw, qty. 2 (key 11); shield (key 20); and screen (key 271)] DVC6010/DVC6020 GF18652X012 GE18653X012 DVC6030 DVC6020 Cam Adjustment Tool GE12742X012 **Remote Mount Kits** Remote Terminal Box Kit 16 Standard GE00418X012 17 Feedback Unit DVC6015 49B7986X012 DVC6025 long arm 49B7987X012 DVC6025 Short Arm 49B7987X022 DVC6035 49B7988X012 Remote Mount Retrofit Kit

This kit converts an existing DVC6000 in the remote mounted version. Note that the DVC6030 cannot be converted to the DVC6035.

DVC6010 to DVC6005/DVC6015

Note

	DVC6010 to DVC6005/DVC6035 DVC6020 to DVC6005/DVC6025 (short arm DVC6020 to DVC6005/DVC6025 (long arm)	DVC6035RMTR DVC6025RMSA DVC6025RLMA
19 20	Feedback Unit Termination Strip Kit Pipestand/Wall Mounting Kit	GE00419X012 GE00420X012

### **Parts List**

Parts which do not show part numbers are not orderable as individual parts. In most cases, they are available in one of the parts kits listed under Parts Kits.



## **Note**

Parts with footnote numbers shown are available in parts kits. Also see footnote information at the bottom of the page.

Key Description Part Number

### Housing

# DVC6010, DVC6020, DVC6030, DVC6005 (see figures 10-1, 10-2, 10-3, and 10-4)

- 1 Housing<sup>(14)</sup>
- 11 Drive Screw<sup>(14)</sup> (2 req'd)
- 20 Shield<sup>(14)</sup>
- 52 Vent, plastic<sup>(2)</sup> DVC6010, DVC6030, and DVC6005 only
- 74 Mounting Bracket
  - DVC6020 Std<sup>(3)</sup> or pipe-away<sup>(6)</sup>, and DVC6005<sup>(20)</sup>
- 75\* O-Ring<sup>(6)</sup>, DVC6020 only
- 245 Pipe Plug, pl stl<sup>(6)</sup>, DVC6020 Vent-away only
- 248 Screw, hex head<sup>(20)</sup> (4 req'd), (DVC6005 only)
- 249 Screw, hex head<sup>(20)</sup> (4 req'd), (DVC6005 only)
- 250 Spacer<sup>(20)</sup> (4 req'd), (DVC6005 only)
- 267 Standoff<sup>(20)</sup> (2 req'd), ( (DVC6005 only)
- 271 Screen<sup>(14)</sup>

### **Common Parts**

# DVC6010, DVC6020, DVC6030, DVC6005 (see figures 10-1, 10-2, 10-3, and 10-4)

- 16\* O-ring<sup>(1)</sup> (3 req'd)
- 23 Cap Screw, hex socket, SST<sup>(2)</sup> (4 req'd)
- 29 Warning label, for use only with LCIE hazardous area classifications
- 33 Mach Screw, pan hd, SST<sup>(2)</sup> (3 req'd)
- 38 Cap Screw, hex socket, SST<sup>(2,13)</sup> (3 req'd)
- 43\* Cover Assembly (includes cover screws)

**Aluminum Construction** 

Standard 38B9580X012

Extreme temperature option

(fluorosilicone elastomers) 38B9580X032

Stainless Steel Construction

Standard 38B9580X022

Extreme temperature option
(fluorosilicone elastomers) 38B9580X042

48 Nameplate

DVC6015RMTR

- 49 Screw, self tapping (2 req'd)<sup>(13)</sup>
- 63 Lithium grease (not furnished with the instrument)
- 64 Anti-seize compound (not furnished with the instrument)
- 65 Lubricant, silicone sealant (not furnished with the instrument)
- 154 Retaining Ring<sup>(2)</sup> (3 req'd)
- 237 Module Base Seal<sup>(1)</sup>

### **Module Base**

# DVC6010, DVC6020, DVC6030, DVC6005 (see figures 10-1, 10-2, 10-3, 10-4, and 10-5)

- 2 Module Base<sup>(13)</sup>
- 11 Drive Screw<sup>(13)</sup> (2 req'd)
- 12 O-ring<sup>(1)</sup>
- 19 Label, Shield Assembly<sup>(13)</sup>
- 61 Pipe Plug, hex socket<sup>(13)</sup> (3 req'd)
- 236 Screen, for single-acting direct units only<sup>(13)</sup>
- 243 Flame Arrestor Assy<sup>(13)</sup> (3 req'd)

#### \*Recommended spare

- Available in the Elastomer Spare Parts Kit
- 2. Available in the Small Hardware Spare Parts Kit
- 3. Available in the DVC6010 to DVC6020 Conversion Kit
- 6. Available in the Pipe-Away Bracket Kit
- 13. Available in the Spare Module Base Assembly Kit
- 14. Available in the Spare Housing Assembly Kit
- 20. Available in the Pipestand/Wall Mounting Kit

**Key Description Part Number Key Description Part Number** I/P Converter Assembly **PWB Assembly** DVC6010, DVC6020, DVC6030, DVC6005 DVC6010, DVC6020, DVC6030, DVC6005 (see figures 10-1, 10-2, 10-3, and 10-4)

39\* O-ring (1,9) I/P Converter(9) 41 169 Shroud<sup>(9)</sup>

Boot, nitrile<sup>(1,9)</sup> (2 req'd) (also see figure 9-3) 210\*

Seal Screen(1,7,9)

### Relay

### DVC6010, DVC6020, DVC6030, DVC6005 (see figures 10-1, 10-2, 10-3, and 10-4)

24\* Relay Assembly, (includes shroud, relay seal, mounting screws) Standard

Single-acting direct (relay C) 38B5786X132 Double-acting (relay A) 38B5786X052 Single-acting reverse (relay B) 38B5786X092

Low Bleed

Single-acting direct (relay C) 38B5786X152 Double-acting (relay A) 38B5786X072 Single-acting reverse (relay B) 38B5786X112

Extreme Temperature option (fluorosilicone elastomers)

Standard Bleed

Single-acting direct (relay C) 38B5786X142 Double-acting (relay A) 38B5786X032 Single-acting reverse (relay B) 38B5786X102

Low Bleed

Single-acting direct (relay C) 38B5786X162 Double-acting (relay A) 38B5786X082 Single-acting reverse (relay B) 38B5786X122

### **Terminal Box**

### DVC6010, DVC6020, DVC6030, DVC6005 (see figures 10-1, 10-2, 10-3, and 10-4)

Terminal Box Cap(16)

34\* O-ring<sup>(1,8,16)</sup>

O-ring<sup>(1,8,16)</sup> 36\*

Wire Retainer, pl stl<sup>(2)</sup> (6 req'd) (not shown) 44

58 Set Screw, hex socket, SST(2,16)

Cap Screw, hex socket, SST(2,16) 72

Terminal Box Assembly<sup>(8)</sup>

### **Remote Terminal Box**

### **DVC6005** (see figure 10-4)

Terminal Box Cap(16) 4

O-ring<sup>(1,8,16)</sup> 34\*

O-ring<sup>(1,8,16)</sup> 36\*

Wire Retainer, pl stl<sup>(2,17)</sup> (5 reg'd) (not shown) 44

58 Set Screw, hex socket, SST(2,16)

Pipe Plug, hex hd, SST<sup>(16)</sup> 62

Cap Screw, hex socket, SST(2,16) (3 reg'd) 72

Adapter(16) 262

O-ring(16) 263\*

Standard 1F463606992 Extreme temperature option, (fluorosilicone) 1F4636X0092

Terminal Box Assembly, remote(16)

(see figures 10-1, 10-2, 10-3, and 10-4)

Note

**Contact your Emerson Process Management sales** office for PWB Assembly FS numbers.

PWB Assembly

Standard

For instrument level AC For instrument level HC For instrument level AD For instrument level PD For instrument level ODV

Extreme Temperature option (fluorosilicone elastomers)

For instrument level AC For instrument level HC For instrument level AD For instrument level PD For instrument level ODV

## Pressure Gauges, Pipe Plugs, or Tire Valve Assemblies (see figure 10-5)

Pressure Gauge, nickel-plated brass case, brass connection

Double-acting (3 req'd); Single-acting (2 req'd)

PSI/MPA Gauge Scale

18B7713X042 To 60 PSI, 0.4 MPa To 160 PSI, 1.1 MPa 18B7713X022

PSI/bar Gauge Scale

To 60 PSI, 4 bar 18B7713X032 To 160 PSI, 11 bar 18B7713X012

Pipe Plug, hex hd

For double-acting and single acting direct w/gauges

For Single-acting reverse w/gauges (1 req'd)

For all units w/o gauges (3 req'd)

Tire Valve Assembly (3 reg'd)

Stainless Steel Construction

DVC6010 (oversized) (4 reg'd)

Not for mounting on 1250 and 1250R actuators.

\*Recommended spare

1. Available in the Elastomer Spare Parts Kit

2. Available in the Small Hardware Spare Parts Kit

7. Available in the Seal Screen Kit

8. Available in the Terminal Box Kit

9. Available in the I/P Converter Kit

17. Available in Feedback Unit Kit16. Available in the Remote Terminal Box Kit

**Key Description Part Number** Key Description **Part Number** Feedback / Remote Travel Sensor Parts 88 Roller, SST/PTFE(3) Spring Lock Washer, pl stl(3) 89 Common Feedback Parts 90 Hex Nut, pl stl(3) DVC6010, DVC6020, DVC6030, DVC6015, DVC6025, Arm Assy, SST and DVC6035 (see figures 10-1, 10-2, 10-3, 10-6, Cap Screw, hex socket(3) (4 req'd) 92 10-7, and 10-8) Torsion Spring, Feedback Arm(3) Alignment Pin(5,17) 46 for Type DVC6010, DVC6030, DVC6015 and DVC6035 DVC6015, DVC6025, and DVC6035 64 Anti-seize compound (not furnished with the instrument) (see figures 10-6, 10-7, and 10-8) 65 Lubricant, silicone sealant (not furnished with the instrument) Cap Screw, hex socket(17,19) (2 reg'd) Cap Screw, hex socket<sup>(2,17)</sup> (2 req'd) Wire Retainer, pl stl<sup>(17,19)</sup> (9 reg'd) for Type DVC6010, DVC6020, DVC6015, and DVC6025 49 Screw, self tapping (2 req'd) 78 Bias Spring, SST(2,17) Set Screw, hex socket(17) for Type DVC6010, DVC6030, DVC6015 and DVC6035 Pipe Plug, hex hd, SST<sup>(17)</sup> 62 Feedback Arm 79 131 Retainer Wire for Type DVC6010, DVC6015, DVC6030 and DVC6035 Feedback housing<sup>(17)</sup> 251 Cap Screw, hex socket, SST<sup>(2,17)</sup> 80 Assembly Plate Shield<sup>(17)</sup> (DVC6015 only) 252 Square Nut, SST(2,17) 253 Terminal bracket<sup>(17,19)</sup> Cap Screw, hex hd<sup>(17)</sup> (4 req'd) 104 Terminal Strip<sup>(17,19)</sup> 254 Aluminum Construction 255 Terminal Cap(17) DVC6010 and DVC6015 O-ring, fluorosilicone<sup>(17)</sup> 256 Not for mounting on 1250 and 1250R actuators. Machine Screw, pan head<sup>(17)</sup> (2 req'd) (DVC6015 only) 257 Mounting parts for 1250 and 1250R actuators are Label, cover(17) 258 included in the mounting kit for these actuators. Hex Nut, SST (2 req'd) 260

### HART® Filters

Nameplate

Plug<sup>(17)</sup> (DVC6015 and DVC6035 only)

261

265

HF340, DIN rail mount 39B5411X012 HF341, DIN rail Mount, pass through (no filter) 39B5412X012

10

### 223\* Potentiometer/Bushing Assy<sup>(17)</sup>

Plain Washer, SST(2,17)

163

Up to 50.4 mm (2-inch) travel

Standard Elastomers

DVC6010, DVC6020 18B9576X012 DVC6030 17B4030X032 DVC6015 and DVC6025 19B6834X012 DVC6035 19B6835X012

Type 585C size 60, 19 mm (0.75 inch) to 104mm (4-inch) travel

Mounting Bracket<sup>(4,17)</sup>, DVC6010 and DVC6015 only

Not for mounting on 1250 and 1250R actuators.

Mounting parts for 1250 and 1250R actuators are included in the mounting kit for these actuators.

Feedback Linkage Shield, see figures 2-1 and 2-2

All sliding-stem actuators except 585C size 60 50.4 mm (2-inch) to 104mm (4-inch) travel All sliding-stem actuators except 585C size 60

Extreme Temperature option (fluorosilicone elastomers)

DVC6010 and DVC6020 GE01028X012 DVC6030 GE01027X012

# DVC6020 and DVC6025 (see figures 10-2 and 10-7)

74 Mounting Bracket, DVC6025 only (also in Housing parts for DVC6020)

82 Bias Spring, SST(3)

83 Bearing Flange, PTFE-based<sup>(3)</sup> (2 req'd)

84 Feedback Arm Assy, SST(3)

85 E-ring, pl stl<sup>(3)</sup> (2 req'd)

86 Plain Washer, pl stl<sup>(3)</sup> (2 req'd)

87 Follower Post, SST(3)

#### \*Recommended spare

- 2. Available in the Small Hardware Spare Parts Kit
- 3. Available in the DVC6010 to DVC6020 Conversion Kit
- 4. Available in the DVC6020 to DVC6010 Conversion Kit
- 5. Available in Alignment Pin Kit
- 17. Available in Feedback Unit Kit
- 19. Available in Feedback Unit Termination Strip Kit




Figure 10-1. Type DVC6010 Digital Valve Controller Assembly

SEE FIGURE 10-5 FOR GAUGE CONFIGURATIONS
 APPLY LUBRICANT KEY 65 TO ALL O-RINGS UNLESS OTHERWISE SPECIFIED

48B7710-K SHT 1 & 2 / DOC

**10-6** January 2007






Figure 10-2. Type DVC6020 Digital Valve Controller Assembly

January 2007 10-7



□ APPLY LUB, SEALANT
NOTES:
□ SEE FIGURE 10-5 FOR GAUGE CONFIGURATIONS
2. APPLY LUBRICANT KEY 65 TO ALL O-RINGS UNLESS OTHERWISE SPECIFIED

Figure 10-2. Type DVC6020 Digital Valve Controller Assembly (continued)




 $\hfill \square$  APPLY LUB, SEALANT, THREAD LOCK NOTES:


SEE FIGURE 10-5 FOR GAUGE CONFIGURATIONS
 APPLY LUBRICANT KEY 65 TO ALL O-RINGS UNLESS OTHERWISE SPECIFIED


48B9597-K SHT 1 & 2 / DOC


Figure 10-3. Type DVC6030 Digital Valve Controller Assembly


January 2007 10-9












**SECTION B-B** 


 $\hfill \Box$  Apply Lub, sealant notes: 
1. Apply Lubricant Key 65 to all 0-rings unless otherwise specified

49B3261-C SHT 1 & 2

Figure 10-4. Type DVC6005 Base Unit

10-10 January 2007





☐ APPLY LUB, SEALANT
NOTES:

1 SEE FIGURE 10-5 FOR GAUGE CONFIGURE

NOTES:


 SEE FIGURE 10-5 FOR GAUGE CONFIGURATIONS
 APPLY LUBRICANT KEY 65 TO ALL O-RINGS UNLESS OTHERWISE SPECIFIED

49B3261-C SHT 2 & 3 / DOC

Figure 10-4. Type DVC6005 Base Unit (continued)

January 2007 10-11

## **DVC6000 Series**



☐ APPLY LUB, SEALANT

1) FOR SINGLE-ACTING DIRECT, OUTPUT B IS PLUGGED.
2) FOR SINGLE-ACTING REVERSE, OUTPUT A IS PLUGGED.

48B7710-K SHT 2 / DOC

Figure 10-5. Typical DVC6000 Series Digital Valve Controller Gauge Configuration





Figure 10-6. Type DVC6015 Digital Valve Controller Assembly

10

10-12 January 2007



 $\hfill \square$  APPLY LUB, SEALANT, THREAD LOCK

NOTE:

1. APPLY LUBRICANT KEY 65 TO ALL O-RINGS UNLESS OTHERWISE SPECIFIED

49B7987-A/IL

Figure 10-7. Type DVC6025 Digital Valve Controller Assembly

10-13 January 2007

Figure 10-8. Type DVC6035 Digital Valve Controller Assembly

10

# **Loop Schematics/Nameplates**

# **Section 11 Loop Schematics/Nameplates**

CSA Schematics	11-2
CSA Nameplates	11-3
FM Schematics	11-4
FM Nameplates	11-5
ATEX Nameplates; Intrinsic Safety, Dust-Tight	11-6
ATEX Nameplates; Flameproof, Dust-Tight	11-7
ATEX Nameplates; Type n, Dust-Tight	11-8
IFCEx Namenlates	11-9

ii

January 2007 11-1

## **DVC6000 Series**

This section includes loop schematics required for wiring of intrinsically safe installations. It also contains the approvals nameplates. If you have any questions, contact your Emerson Process Management sales office.




Figure 11-1. CSA Schematic for Type DVC6000 and Type DVC6000S




Figure 11-2. CSA Schematic for Type DVC6005


**11-2** January 2007

### 7


## **Loop Schematics/Nameplates**

\ NO     DC ===     U	SERIAL		CL I, DIV 2, GP ABCD, T6:  EX IB INTRINSICALLY SAFE/SECURITE INTRINSEQUE; CL I,I,III, DIV 1, GROUPS PER DWG 2983428, T5: WARNING: SUBSTITUTION OF COMPONENTS MAY IMPAIR INTRINSIC SAFETY/AVERTISSEMENT: LA SUBSTITUTION DE COMPOSANTS PEUT COMPROMETTRE LA SECURITE INTRINSEQUE. TYPE 4X, IP66, SEAL NOT REQUIRED; REFER TO MANUAL FOR MAX SUPPLY PRESSURE.	FISHER*	GE 05621
-----------------------	--------	--	---	---------	----------

### TYPES DVC6010, DVC6020, DVC6030, DVC6010S, DVC6020S, DVC6030S



#### **TYPE DVC6005**



TYPES DVC6015, DVC6025, DVC6035

Figure 11-3. CSA Nameplates

January 2007 11-3




Figure 11-4. FM Schematic for Type DVC6000 and Type DVC6000S





Figure 11-5. FM Schematic for Type DVC6005

**11-4** January 2007


## **Loop Schematics/Nameplates**

	AMB TEMP: TO 80°C  MAX VOLTAGE: 30 VDC ——  NEMA 4X, FACTORY SEALED  USE FIELD WIRING SUITABLE FOR  AT LEAST 90°C. REFER TO INSTRUCTION  MANUAL FOR MAX SUPPLY PRESSURE.	XP CL I, DIV 1, GP BCD, T6; DI CL II, DIV 1, GP EFG, S CL II, DIV 2, GP FG, T6; CAUTION: KEEP COVER TI WHILE CIRCUITS ARE ALIVE.  NI CL 1, DIV 2, GP ABCD, T6; IS CL I,II,III, DIV 1, GROUPS PER DWG 29B3427, T5; WARNING: SUBSTITUTION OF COMPONENTS MAY IMPAIR INTRINSIC SAFETY.	GHT	HART	5622
SERIAL NO	INPUT DC ==		ГҮРЕ		

TYPES DVC6010, DVC6020, DVC6030, DVC6010S, DVC6020S, DVC6030S



### **TYPE DVC6005**




TYPES DVC6015, DVC6025, DVC6035


Figure 11-6. FM Nameplates

January 2007 11-5

#### TYPES DVC6010, DVC6020, DVC6030, DVC6010S, DVC6020S, DVC6030S



#### **TYPE DVC6005**




TYPES DVC6015, DVC6025, DVC6035


Figure 11-7. ATEX Nameplates; Intrinsic Safety, Dust-Tight

76


## **Loop Schematics/Nameplates**



TYPES DVC6010, DVC6020, DVC6030, DVC6010S, DVC6020S, DVC6030S



**TYPE DVC6005** 




TYPE DVC6015, DVC6025, DVC6035


Figure 11-8. ATEX Nameplates; Flameproof, Dust-Tight

January 2007 11-7

TYPES DVC6010, DVC6020, DVC6030, DVC6010S, DVC6020S, DVC6030S



**TYPE DVC6005** 



TYPES DVC6015, DVC6025, DVC6035

Figure 11-9. ATEX Nameplates; Type n, Dust-Tight

# **Loop Schematics/Nameplates**

TYPE

AMB TEMP: TO 8 MAX VOLTAGE: 30 VDC NEMA 4X, IP66 REFER TO MANUAL FOR MA  SERIAL NO	FIELDBUS: Ui=24VI FISCO: Ui=17.5VDC  Ex d IIB+H2 T5(Ta   Fx nC IIC T5(Ta	00°C),T6(Ta ≤ 75°C) li=226mA, Pi=1.4W, Ci=5nF, Li=0.55mH DC, li=226mA, Pi=1.4W, Ci=5nF, Li=0mH C, li=380mA, Pi=5.32W, Ci=5nF, Li=0mH ≤ 80°C),T6(Ta ≤ 75°C)	MARSHALITOWN, IOWA, USA MAG LOCATION  FOUNDATION  HART  FELD COMMISSELTIONS PRINCIPLES  GUID
ТҮ	PES DVC6010, DVC6020, DVC6030, I	DVC6010S, DVC6020S, DVC6030S	
AMB TEMP: -40°C TO 80 MAX VOLTAGE: 30 VDC : NEMA 4X, IP66 REFER TO MANUAL FOR SUPPLY PRESSURE  SERIAL NO	Uo=9.6VDC, lo=3  "C FIELDBUS: Ui=24VDC, li  FISCO: Ui=17.5VDC, li=2  Uo=8.6VDC, lo=3	T6(Ta ≤ 75°C) 6mA, Pi=1.4W, Ci=5nF, Li=0.55mH .5mA, Po=8.4mW, Co=3.6uF, Lo=100mH =226mA, Pi=1.4W, Ci=5nF, Li=0mH 880mA, Pi=5.32W, Ci=5nF, Li=0mH =2.3mA, Po=5mW, Co=6.2uF, Lo=100mH 6(Ta ≤ 75°C)	FISHER CONTROLS INTL LLC MARSHALLTOWN, IOWA, USA MFG LOCATION  FOUNDATION  HART  GET TEMPLES AND MARGENEE  GET TOWNS AND MARGE
	TYPE DVC	C6005	
AMB TEMP: -60°C NEMA 4X, IP66 MAX VOLTAGE: 10N MAX CURRENT: 5 N FISHER CONTROLS	Ui=10VDC, li=5mA    DC ===	SA 04.0004X 25°C),T5(Ta \(\preceq\) 95°C),T6(Ta \(\preceq\) 80°C) 3, Pi=10mW, Ci=0uF, Li=0mH 5°C),T5(Ta \(\preceq\) 95°C),T6(Ta \(\preceq\) 80°C) 125°C),T5(Ta \(\preceq\) 95°C),T6(Ta \(\preceq\) 80°C)	FISHER'

TYPES DVC6015, DVC6025, DVC6035

SN

MARSHALLTOWN, IOWA, USA

MFG LOCATION

Figure 11-10. IECEx Nameplates; Intrinsic Safety, Type n, Flameproof

January 2007 11-9

11

11-10 January 2007

# **Glossary**

#### Alert Point

An adjustable value that, when exceeded, activates an alert.

## **Algorithm**

A set of logical steps to solve a problem or accomplish a task. A computer program contains one or more algorithms.

## **Alphanumeric**

Consisting of letters and numbers.

## **Analog Input Units**

Units in which the analog input is displayed and maintained in the instrument.

## ANSI (acronym)

The acronym ANSI stands for the American National Standards Institute

## **ANSI Class**

Valve pressure/temperature rating.

## **Auxiliary Input Alert**

Checks the status of the auxiliary input; a discrete input. When enabled, the Auxiliary Input Alert is active when the auxiliary input terminals are open or closed (shorted), depending upon the selection for Auxiliary Input Alert State.

## **Auxiliary Terminal (Indicator)**

Indicates whether auxiliary wiring terminals are open or closed (such as by an external switch contact).

#### **Bench Set**

Pressure, supplied to an actuator, required to drive the actuator through rated valve travel. Expressed in pounds per square inch.

## **Byte**

A unit of binary digits (bits). A byte consists of eight bits.

## Calibration Location

Where the instrument was last calibrated; either in the factory or in the field.

## Configuration

Stored instructions and operating parameters for a FIELDVUE Instrument.

## **Control Loop**

An arrangement of physical and electronic components for process control. The electronic components of the loop continuously measure one or more aspects of the process, then alter those aspects as necessary to achieve a desired process condition. A simple control loop measures only one variable. More sophisticated control loops measure many variables and maintain specified relationships among those variables.

## Control Mode

Defines where the instrument reads its set point. The following control modes are available for a FIELDVUE Instrument:

**Analog** The instrument receives its travel set point over the 4–20 mA loop.

**Digital** The instrument receives its set point digitally, via the HART communications link. **Test** This is not a user-selectable mode. The Field Communicator or AMS ValveLink Software places the instrument in this mode whenever it needs to move the valve, such as for calibration or diagnostic tests.

## Control Mode, Restart

Determines the instrument control mode after a restart. See Control Mode for the available restart control modes.

Glossary

January 2007 Glossary-1

#### Controller

A device that operates automatically to regulate a controlled variable.

## **Crossover Point**

The point at which the feedback pin is closest to the axis of rotation of the travel sensor. A visual indication of the crossover point is found when the slot in the instrument feedback arm forms a 90-degree angle with the valve stem.

## Current-to-Pressure (I/P) Converter

An electronic component or device that converts a milliamp signal to a proportional pneumatic pressure output signal.

## **Cycle Counter**

The capability of a FIELDVUE instrument to record the number of times the travel changes direction. The change in direction must occur after the deadband has been exceeded before it can be counted as a cycle.

## **Cycle Counter Alert**

Checks the difference between the Cycle Counter and the Cycle Counter Alert Point. Cycle Counter Alert is active when the cycle counter value exceeds the Cycle Counter Alert Point. It clears after you reset the Cycle Counter to a value less than the alert point.

## Cycle Counter Alert Point

An adjustable value which, when exceeded, activates the Cycle Counter Alert. Valid entries are 0 to 4 billion cycles.

## **Cycle Counter Deadband**

Region around the travel reference point, in percent of ranged travel, established at the last increment of the Cycle Counter. The deadband must be exceeded before a change in travel can be counted as a cycle. Valid entries are 0% to 100%. Typical value is between 2% and 5%.

#### Deviation

Usually, the difference between set point and process variable. More generally, any departure from a desired or expected value or pattern.

#### Device ID

Unique identifier embedded in the instrument at the factory.

#### Device Revision

Revision number of the interface software that permits communication between the Field Communicator and the instrument.

## Drive Signal

The signal to the I/P converter from the printed wiring board. It is the percentage of the total microprocessor effort needed to drive the valve fully open.

## **Drive Signal Alert**

Checks the drive signal and calibrated travel. If one of the following conditions exists for more than 20 seconds, the Drive Signal Alert is active. If none of the conditions exist, the alert is cleared.

## If Zero Control Signal = Closed

The alert is active when:

drive signal <10% and calibrated travel >3% drive signal >90% and calibrated travel <97%

## If Zero Control Signal = Open

The alert is active when:

drive signal <10% and calibrated travel <97% drive signal >90% and calibrated travel >3%

## Equal Percentage

A valve flow characteristic where equal increments of valve stem travel produce equal percentage changes in existing flow. One of the input characteristics available for a FIELDVUE Instrument. See also, Linear and Quick Opening.

#### Feedback Arm

The mechanical connection between the valve stem linkage and the FIELDVUE Instrument travel sensor.

## Feedback Connection

Identifies the type of feedback linkage: rotary, sliding-stem roller or sliding-stem standard.

## Feedback Signal

Indicates to the instrument the actual position of the valve. The travel sensor provides the feedback signal to the instrument printed wiring board assembly. A mechanical linkage connects the travel sensor to the valve stem or shaft.

Glossary

Glossary-2 January 2007

#### Firmware Revision

The revision number of the instrument firmware. Firmware is a program that is entered into the instrument at time of manufacture and cannot be changed by the user.

## Free Time

Percent of time that the microprocessor is idle. A typical value is 25%. The actual value depends on the number of functions in the instrument that are enabled and on the amount of communication currently in progress.

## **Full Ranged Travel**

Current, in mA, that corresponds with the point where ranged travel is maximum, i.e., limited by the mechanical travel stops.

#### Gain

The ratio of output change to input change.

## **Hardware Revision**

Revision number of the Fisher Controls instrument hardware. The physical components of the instrument are defined as the hardware.

# HART® (acronym)

The acronym HART stands for Highway Addressable Remote Transducer.

# HART® Tag

An eight-character name that identifies the physical instrument.

## HART® Universal Revision

Revision number of the HART Universal Commands which are the communications protocol for the instrument.

## Input Characteristic

The relationship between the ranged travel and ranged input. Possible values include: linear, equal percentage, and quick opening.

## **Input Current**

The current signal from the control system that serves as the analog input to the instrument. See also Input Signal.

## Input Range

The analog input signal range that corresponds to the travel range.

## Input Signal

The current signal from the control system. The input signal can be displayed in milliamperes or in percent of ranged input.

## **Instrument Level**

Determines the functions available for the instrument. See table 7-2, page 7-9.

#### Instrument Mode

Determines if the instrument responds to its analog input signal. There are two instrument modes:

**In Service:** For a fully functioning instrument, the instrument output changes in response to analog input changes. Typically changes to setup or calibration cannot be made when the instrument mode is In Service.

**Out of Service:** The instrument output does not change in response to analog input changes when the instrument mode is Out of Service. Some setup parameters can be changed only when the instrument mode is Out of Service.

## Instrument Protection

Determines if commands from a HART device can calibrate and/or configure certain parameters in the instrument. There are two types of instrument protection:

**Configuration and Calibration:** Prohibits changing protected setup parameters; prohibits calibration.

**None**: Permits both configuration and calibration. The instrument is "unprotected."

## Instrument Serial Number

The serial number assigned to the printed wiring board by the factory but can be changed during setup. The instrument serial number should match the serial number on the instrument nameplate.

#### Leak Class

Defines the allowable leakage by a valve when it is closed. Leak class numbers are listed in two standards: ANSI/FCI 70-2 and IEC 534-4.

Glossary

January 2007

#### Linear

A valve flow characteristic where changes in flow rate are directly proportional to changes in valve stem travel. One of the input characteristics available for a FIELDVUE Instrument. See also, Equal Percentage and Quick Opening.

## Linearity, dynamic

Linearity (independent) is the maximum deviation from a straight line best fit to the opening and closing curves and a line representing the average value of those curves.

## Memory

A type of semiconductor used for storing programs or data. FIELDVUE instruments use three types of memory: Random Access Memory (RAM), Read Only Memory (ROM), and Non-Volatile Memory (NVM). See also these listings in this glossary.

## Menu

A list of programs, commands, or other activities that you select by using the arrow keys to highlight the item then pressing ENTER, or by entering the numeric value of the menu item.

## **Minimum Closing Time**

Minimum time, in seconds, for the travel to decrease through the entire ranged travel. This rate is applied to any travel decrease. Valid entries are 0 to 400 seconds. Deactivate by entering a value of 0 seconds.

## **Minimum Opening Time**

Minimum time, in seconds, for the travel to increase through the entire ranged travel. This rate is applied to any travel increase. Because of friction, actual valve travel may not respond in exactly the same time frame. Valid entries are 0 to 400 seconds. Deactivate by entering a value of 0 seconds.

## Non-Volatile Memory (NVM)

A type of semiconductor memory that retains its contents even though power is disconnected. NVM contents can be changed during configuration unlike ROM which can be changed only at time of instrument manufacture. NVM stores configuration restart data.

## **Parallel**

Simultaneous: said of data transmission on two or more channels at the same time.

## **Polling Address**

Address of the instrument. If the digital valve controller is used in a point-to-point configuration, set the polling address to 0. If it is used in a multidrop configuration, or split range application, set the polling address to a value from 0 to 15.

## **Pressure Sensor**

A FIELDVUE instrument internal device that senses pneumatic pressure. DVC6000 Series digital valve controllers have three pressure sensors: one to sense supply pressure and two to sense the output pressures.

## **Primary Master**

Masters are communicating devices. A primary master is a communicating device permanently wired to a field instrument. Typically, a HART-compatible control system or a computer running ValveLink VL2000 Series Software is the primary master.

In contrast, a secondary master is not often permanently wired to a field instrument. The Model 375 Field Communicator or a computer running ValveLink software communicating through a HART modem could be considered a secondary master.

**Note:** If one type of master takes an instrument Out Of Service, the same type must put it In Service. For example, if a device set up as a primary master takes an instrument Out Of Service, a device set up as a primary master must be used to place the instrument In Service.

Glossary

Glossary-4 January 2007

## **Quick Opening**

A valve flow characteristic where most of the change in flow rate takes place for small amounts of stem travel from the closed position. The flow characteristic curve is basically linear through the first 40 percent of stem travel. One of the input characteristics available for a FIELDVUE Instrument. See also, Equal Percentage and Linear.

## Random Access Memory (RAM)

A type of semiconductor memory that is normally used by the microprocessor during normal operation that permits rapid retrieval and storage of programs and data. See also Read Only Memory (ROM) and Non-Volatile Memory (NVM).

#### Rate

Amount of change in output proportional to the rate of change in input.

## Read-Only Memory (ROM)

A memory in which information is stored at the time of instrument manufacture. You can examine but not change ROM contents.

## **Seat Load**

Force exerted on the valve seat, typically expressed in pounds force per lineal inch of port circumference. Seat load is determined by shutoff requirements.

## **Set Point Filter Time**

The time constant, in seconds, for the first-order input filter.

#### Software

Microprocessor or computer programs and routines that reside in alterable memory (usually RAM), as opposed to firmware, which consists of programs and routines that are programmed into memory (usually ROM) when the instrument is manufactured. Software can be manipulated during normal operation, firmware cannot.

## Stroking Time

The time, in seconds, required to move the valve from its fully open position to fully closed, or vice versa.

## **Temperature Sensor**

A device within the FIELDVUE instrument that measures the instrument's internal temperature.

#### Travel

Movement of the valve stem or shaft which changes the amount the valve is open or closed.

## **Travel Accumulator**

The capability of a FIELDVUE instrument to record total change in travel. The value of the Travel Accumulator increments when the magnitude of the change exceeds the Travel Accumulator Deadband. To reset the Travel Accumulator, set it to zero.

#### **Travel Accumulator Alert**

Checks the difference between the Travel Accumulator value and the Travel Accumulator Alert Point. The Travel Accumulator Alert is active when the Travel Accumulator value exceeds the Travel Accumulator Alert Point. It clears after you reset the Travel Accumulator to a value less than the alert point.

## Travel Accumulator Alert Point

An adjustable value which, when exceeded, activates the Travel Accumulator Alert. Valid entries are 0% to 4 billion %.

## **Travel Accumulator Deadband**

Region around the travel reference point established at the last increment of the accumulator. This region must be exceeded before a change in travel can be accumulated. Valid entries are 0% to 100%.

## Travel Alert

Checks the ranged travel against the travel high and low alert points. The travel alert is active if either the high or low point is exceeded. Once a high or low point is exceeded, the ranged travel must clear that point by the Travel Alert Deadband before the alert clears. Four travel alerts are available: Travel Alert Hi, Travel Alert Lo, Travel Alert Hi, and Travel Alert Lo.

## Travel Alert Deadband

Travel, in percent of ranged travel, required to clear a travel alert, once it is active. Valid entries are –25% to 125%.

## **Travel Alert High Point**

Value of the travel, in percent of ranged travel, which, when exceeded, sets the Travel Alert Hi alert. Valid entries are -25% to 125%.

Glossary

January 2007 Glossary-5

## Travel Alert High High Point

Value of the travel, in percent of ranged travel, which, when exceeded, sets the Travel Alert Hi Hi alert. Valid entries are -25% to 125%.

## **Travel Alert Low Point**

Value of the travel, in percent of ranged travel, which, when exceeded, sets the Travel Alert Lo alert. Valid entries are -25% to 125%.

## **Travel Alert Low Low Point**

Value of the travel, in percent of ranged travel, which, when exceeded, sets the Travel Alert Lo Lo alert. Valid entries are –25% to 125%.

## Travel Cutoff

Defines the cutoff point for the travel, in percent of ranged travel. There are two travel cutoffs: high and low. Once travel exceeds the cutoff, the drive signal is set to either maximum or minimum, depending on the Zero Control Signal and if the cutoff is high or low. Minimum opening time or minimum closing time are not in effect while the travel is beyond the cutoff. Use the travel cutoff to obtain the desired seat load or to be sure the valve is fully open.

## **Travel Deviation**

The difference between the analog input signal (in percent of ranged input), the "target" travel, and the actual "ranged" travel.

## **Travel Deviation Alert**

Checks the difference between the target and the ranged travel. If the difference exceeds the Travel Deviation Alert Point for more than the Travel Deviation Time, the Travel Deviation Alert is active. It remains active until the difference is less than the Travel Deviation Alert Point.

## **Travel Deviation Alert Point**

An adjustable value for the target travel and the ranged travel difference, expressed in percent, When this value is exceeded by the travel deviation for more than the Travel Deviation Time, the Travel Deviation Alert is active. Valid entries are 0% to 100%. Typically this is set to 5%.

## Travel Deviation Time

The time, in seconds. that the travel deviation must exceed the Travel Deviation Alert Point before the alert is active. Valid entries are 1 to 60 seconds.

## **Travel Limit**

A setup parameter that defines the maximum allowable travel (in percent of ranged travel) for the valve. During operation, the travel target will not exceed this limit. There are two travel limits: high and low. Typically the travel limit low will be used to keep the valve from going completely closed.

## **Travel Range**

Travel, in percent of calibrated travel, that corresponds to the input range.

## **Travel Sensor**

A device within the FIELDVUE instrument that senses valve stem or shaft movement. The travel sensor is mechanically connected to the valve stem or shaft.

## **Travel Sensor Motion**

Establishes motion of the travel sensor. While viewing the end of the travel sensor shaft, if increasing air pressure to the actuator causes the shaft to rotate clockwise, travel sensor motion is CW. If increasing air pressure causes the shaft to rotate counterclockwise, travel sensor motion is CCW.

## Tuning

The adjustment of control terms or parameter values to produce a desired control effect.

## Tuning Set

Preset values that identify gain settings for a FIELDVUE instrument. The tuning set and supply pressure together determine an instrument's response to input signal changes.

## Watch Dog Timer

A timer that the microprocessor must rearm periodically. If the microprocessor is unable to rearm the timer, the instrument goes through reset.

## **Zero Control Signal**

A setup parameter that determines whether the valve is fully open or fully closed when the input signal is 0%.

Glossary

Glossary-6 January 2007

A	Electronic, 5-14 Drive Signal Alert, 5-14
AC, (Auto Calibrate), 7-9	Processor Impaired Alerts, 5-14
Actuator Style, 5-21	Environmental, 5-15  Aux Terminal Alerts, 5-15
AD, (Advanced Diagnostics), 7-9	Supply Press Lo Alert, 5-15
Advanced Diagnostics, (AD), 7-9	Sensor, 5-15 SIS, 5-18
Alert Conditions, 7-3 Alert Record, 7-4 Electronics, 7-3 Environment, 7-4 Sensor, 7-3 SIS, 7-4 Travel, 7-4 Travel History, 7-4	Travel, 5-15 Deviation Alert, 5-15 Limit Alerts, 5-15 Travel Limit Cutoff Alerts, 5-16 Travel Limit Hi/Lo Alerts, 5-16 Travel History, 5-17 Cycle Count, 5-17 Cycle Count/Tvl Accum Deadband, 5-17 Tvl Accum, 5-17
Alert Groups, 5-18	Analog Calibration Adjust, 6-4
Failure Alerts, 5-18 Miscellaneous, 5-18 Valve Alerts, 5-18	Analog Input Displaying Value, 7-7 Units, 5-20
Alert Record, 5-18	Analog Input Calibration, 6-9
Alerts, 5-14 Alert Record, 5-18	Analog Input Range, 5-20
Alert Groups, 5-18 Enabling Alert Groups, 5-18	ATEX Hazardous Area Classifications, 1-6, 1-9
Nameplates, 11-6, 11-7, 11-8 Special Conditions for Safe Use, 2-3, 2-4	C
·	Calibration Analog Input, 6-9
Special Conditions for Safe Use, 2-3, 2-4	Calibration
Special Conditions for Safe Use, 2-3, 2-4  Audio, Control and Instrumentation Cable, 7-7	Calibration Analog Input, 6-9 Auto Calibrate Travel, 6-2
Special Conditions for Safe Use, 2-3, 2-4  Audio, Control and Instrumentation Cable, 7-7  Auto Calibrate, (AC), 7-9  Auto Calibrate Travel, 6-2	Calibration Analog Input, 6-9 Auto Calibrate Travel, 6-2 Error Messages, 6-4 Manual Calibrate Travel, 6-4 Pressure Sensors, 6-6 Relay Adjustment, 6-10 Sensor Calibration, 6-6
Special Conditions for Safe Use, 2-3, 2-4  Audio, Control and Instrumentation Cable, 7-7  Auto Calibrate, (AC), 7-9  Auto Calibrate Travel, 6-2  Error Messages, 6-3, 6-4	Calibration Analog Input, 6-9 Auto Calibrate Travel, 6-2 Error Messages, 6-4 Manual Calibrate Travel, 6-4 Pressure Sensors, 6-6 Relay Adjustment, 6-10
Special Conditions for Safe Use, 2-3, 2-4  Audio, Control and Instrumentation Cable, 7-7  Auto Calibrate, (AC), 7-9  Auto Calibrate Travel, 6-2  Error Messages, 6-3, 6-4  Aux Term Mode, 5-20	Calibration Analog Input, 6-9 Auto Calibrate Travel, 6-2 Error Messages, 6-4 Manual Calibrate Travel, 6-4 Pressure Sensors, 6-6 Relay Adjustment, 6-10 Sensor Calibration, 6-6 Pressure Sensors, 6-6 Touch-Up Travel, 6-5 Travel Auto, 6-2 Manual, 6-4 Analog Calibration Adjust, 6-4
Special Conditions for Safe Use, 2-3, 2-4  Audio, Control and Instrumentation Cable, 7-7  Auto Calibrate, (AC), 7-9  Auto Calibrate Travel, 6-2  Error Messages, 6-3, 6-4  Aux Term Mode, 5-20  Aux Terminal Mode, 5-6	Calibration Analog Input, 6-9 Auto Calibrate Travel, 6-2 Error Messages, 6-4 Manual Calibrate Travel, 6-4 Pressure Sensors, 6-6 Relay Adjustment, 6-10 Sensor Calibration, 6-6 Pressure Sensors, 6-6 Touch-Up Travel, 6-5 Travel Auto, 6-2 Manual, 6-4 Analog Calibration Adjust, 6-4 Digital Calibration Adjust, 6-5 Travel Sensor, 6-7 Travel Sensor Adjust, 6-7
Special Conditions for Safe Use, 2-3, 2-4  Audio, Control and Instrumentation Cable, 7-7  Auto Calibrate, (AC), 7-9  Auto Calibrate Travel, 6-2  Error Messages, 6-3, 6-4  Aux Term Mode, 5-20  Aux Terminal Mode, 5-6  Auxiliary Input, Displaying Status, 7-8	Calibration Analog Input, 6-9 Auto Calibrate Travel, 6-2 Error Messages, 6-4 Manual Calibrate Travel, 6-4 Pressure Sensors, 6-6 Relay Adjustment, 6-10 Sensor Calibration, 6-6 Pressure Sensors, 6-6 Touch-Up Travel, 6-5 Travel Auto, 6-2 Manual, 6-4 Analog Calibration Adjust, 6-4 Digital Calibration Adjust, 6-5 Travel Sensor, 6-7 Travel Sensor Adjust, 6-7 Calibration, Travel, 6-2
Special Conditions for Safe Use, 2-3, 2-4  Audio, Control and Instrumentation Cable, 7-7  Auto Calibrate, (AC), 7-9  Auto Calibrate Travel, 6-2  Error Messages, 6-3, 6-4  Aux Term Mode, 5-20  Aux Terminal Mode, 5-6  Auxiliary Input, Displaying Status, 7-8	Calibration Analog Input, 6-9 Auto Calibrate Travel, 6-2 Error Messages, 6-4 Manual Calibrate Travel, 6-4 Pressure Sensors, 6-6 Relay Adjustment, 6-10 Sensor Calibration, 6-6 Pressure Sensors, 6-6 Touch-Up Travel, 6-5 Travel Auto, 6-2 Manual, 6-4 Analog Calibration Adjust, 6-4 Digital Calibration Adjust, 6-5 Travel Sensor, 6-7 Travel Sensor Adjust, 6-7 Calibration, Travel, 6-2 Calibration & Diagnostics, 5-19
Special Conditions for Safe Use, 2-3, 2-4  Audio, Control and Instrumentation Cable, 7-7  Auto Calibrate, (AC), 7-9  Auto Calibrate Travel, 6-2 Error Messages, 6-3, 6-4  Aux Term Mode, 5-20  Aux Terminal Mode, 5-6  Auxiliary Input, Displaying Status, 7-8  B  bias spring, 2-12  Burst Mode, 5-5	Calibration Analog Input, 6-9 Auto Calibrate Travel, 6-2 Error Messages, 6-4 Manual Calibrate Travel, 6-4 Pressure Sensors, 6-6 Relay Adjustment, 6-10 Sensor Calibration, 6-6 Pressure Sensors, 6-6 Touch-Up Travel, 6-5 Travel Auto, 6-2 Manual, 6-4 Analog Calibration Adjust, 6-4 Digital Calibration Adjust, 6-5 Travel Sensor, 6-7 Travel Sensor Adjust, 6-7 Calibration, Travel, 6-2 Calibration Status and Location, 5-21
Special Conditions for Safe Use, 2-3, 2-4  Audio, Control and Instrumentation Cable, 7-7  Auto Calibrate, (AC), 7-9  Auto Calibrate Travel, 6-2  Error Messages, 6-3, 6-4  Aux Term Mode, 5-20  Aux Terminal Mode, 5-6  Auxiliary Input, Displaying Status, 7-8	Calibration Analog Input, 6-9 Auto Calibrate Travel, 6-2 Error Messages, 6-4 Manual Calibrate Travel, 6-4 Pressure Sensors, 6-6 Relay Adjustment, 6-10 Sensor Calibration, 6-6 Pressure Sensors, 6-6 Touch-Up Travel, 6-5 Travel Auto, 6-2 Manual, 6-4 Analog Calibration Adjust, 6-4 Digital Calibration Adjust, 6-5 Travel Sensor, 6-7 Travel Sensor Adjust, 6-7 Calibration, Travel, 6-2 Calibration & Diagnostics, 5-19

January 2007 Index-1

Communication, 2-23 Test, 2-22	E		
Pneumatic	Educational Services, 1-4		
Output, 2-17 to support solenoid testing, 2-17 Supply, 2-16	Electromagnetic Interference, 1-5		
	End Point Pressure Control, 5-12 Error Messages, Auto Calibrate Travel, 6-4		
Vent, 2-18			
Control Mode, 5-5	<u>_</u>		
Control System Requirements Compliance Voltage, 2-24	F		
HART Filter, 2-23	Factory Default Settings, Initial Setup, 4-3		
Voltage Available, 2-23	Factory Settings, Restoring, 6-11		
CSA Hazardous Area Classifications, 1-6, 1-7	Feedback Connection, 5-21		
Loop Schematics DVC6000 and DVC6000S, 11-2 DVC6005, 11-2 Nameplates, 11-3 Special Conditions of Safe Use, 2-3	Field Communicator Device Description Revision, 3-6 Display, 3-2 Hot Key, 3-4 Multifunction LED, 3-3 Offline Operation, 3-4		
Cycle Count, 5-17	Online Menu, 3-6		
Cycle Counter Displaying Value, 7-8 Enabling Alert, 5-17 Resetting, 5-17	Online Simulation, 3-5 Polling, 3-5 Reviewing Instrument Device Descript 3-5 Soft Input Panel Keyboard (SIP), 3-3 Specifications, 3-2 System Information, 3-5 Using the Keypad, 3-2 Using the Touch Screen, 3-3		
Data 5 10 5 01	Firmware Revision, 7-9		
Date, 5-19, 5-21	FM		
DD Information, 7-9	Hazardous Area Classifications, 1-6, 1-8 Loop Schematics		
Define Custom Characteristic, 5-12	DVC6000 and DVC6000S, 11-4		
Description, DVC6000 Series, 1-3	DVC6005, 11-4 Nameplates, 11-5		
Descriptor, 5-19	Special Conditions of Safe Use, 2-3		
Detailed Setup, 5-4	Free Time, Self Test Failure, enabling to cause instrument shutdown, 5-14		
Device Information, 7-8	oddoo monament enatuerni, e		
Device Record, 7-5	G		
Device Revision, 7-9			
Device Variables, 7-7	Gauges, Tire Valves, & Pipe Plugs Parts List, 10-4 Replacing, 9-10		
Digital Calibration Adjust, 6-5			
DIP Switch, Setting, 9-9			
Drive Signal, Displaying Value, 7-7	Н		
Dynamic Response, 5-12	Hardware Revision, 7-9		

Index-2 January 2007

HART Communicating, (HC), 7-9	Lead/Lag, 5-13		
HART Filter, Part Numbers, 10-5	typical filter settings, 5-14		
HART Tag, 5-19	Loop Schematics DVC6000 and DVC6000S		
HART Tri-Loop, Configuring DVC6000 for use with, 2-26	CSA, 11-2 FM, 11-4		
Hazardous Area Approvals, 2-3	DVC6005 CSA, 11-2		
HC, (HART Communicating), 7-9	FM, 11-4		
Hot Key, Field Communicator, 3-4			
	M		
I	Manual Calibrate Travel, 6-4		
I/P Converter	Manual Conventions, 1-2		
Parts List, 10-4	Manufacturer, 5-21		
Removing, 9-8 Replacing, 9-8	Maximum Output Capacity, 1-5		
Replacing Filter, 9-7	Maximum Supply Pressure, 5-20		
IECEx	maximum supply pressure, 5-20		
Conditions of Certification, 2-4	Message, 5-19		
Hazardous Area Classifications, 1-6, 1-10 Nameplates, 11-9	Minimum Differential Pressure, 5-22 setting manually, 5-22		
Initial Setup, 4-2	Minimum Partial Stroke Pressure, setting		
Input Characterization, 5-12	manually, 5-22		
Input Range, 5-20	Module Base Removal, 9-6		
Installation, 2-3	Replacing, 9-7		
Instrument Clock, Setting, 5-19	Module Base, Parts List, 10-3		
Instrument Date and Time, 5-21	Module Base Maintenance, 9-6		
Instrument Level, 7-9 capabilities, 1-2	Mounting, 2-4 67CFR, 2-15		
Instrument Mode, 4-2, 5-4	DVC6005 base unit, 2-11		
Instrument Serial Number, 5-19	Pipestand, 2-11 Wall, 2-11		
Instrument Status, 7-5 Viewing, 7-5	DVC6010, 2-4 DVC6015, 2-11		
Integral Action, Enable Integral Settings, 5-8	DVC6020, 2-6 DVC6025, 2-13		
Integral Dead Zone, 5-19	DVC6030, 2-9		
Integral Limit, 5-9	DVC6035, 2-14		
Integral Settings, 5-9			
Internal Temperature, Displaying Value, 7-8	N		
	Nameplates ATEX		
L	Flameproof, Dust-Tight, 11-7 Intrinsic Safety, Dust-Tight, 11-6		
Lag Time, 5-13	Type n, Dust-Tight, 11-8		

CSA, 11-3 FM, 11-5 IECEx, Intrinsic Safety, Type n, Flameproof,	Parts List, 10-4 Removing, 9-10 Replacing, 9-10
11-9	Polling Address, 5-19
Number of Power Ups, Displaying Status, 7-8	Pressure Control, 5-11
	Pressure Sensor Calibration, 6-6
0	Pressure Set Point, 5-12
ODV (Optimized Digital Valva) 7.0	Pressure Tuning Sets, Gain Values, 5-9
ODV, (Optimized Digital Valve), 7-9	Pressure Units, 5-20
Optimized Digital Valve, (ODV), 7-9	Principle of Operation
Output Pressure, Displaying Value, 7-7	DVC6000, 8-2 HART Communication, 8-2
P	Printed Wiring Board Assembly Parts List, 10-4
Parameters, Factory Default, Detailed Setup, 5-4	Removing, 9-9 Replacing, 9-9 Setting DIP Switch, 9-9
Partial Stroke, 5-21	Protection, 4-2, 5-5
Partial Stroke Test, 7-6	1 1010011011, 4 2, 0 0
Configuring Minimum Differential Pressure, 5-22 Partial Stroke Pressure Limit, 5-22	R
Partial Stroke TvI, 5-22 Pause Time, 5-22	Raw Travel Input, Displaying Status, 7-8
Stroke Speed, 5-22	Related Documents, 1-4
Initiating Device (Digital Valve Controller), 7-6 Model 375 Field Communicator, 7-6 Remote Push Button, 7-6	Relay Double-Acting, 6-10 Single-Acting Direct, 6-11 Single-Acting Reverse, 6-11
Local DI, 7-6 Local Push Button, 7-6	Relay A, 6-10
initiating, 7-6	Relay Adjustment, 6-10
Parts	Double-Acting, 6-10
Common Parts, 10-3	Relay B, 6-11
Feedback Parts, 10-5 Gauges, Tire Valves, & Pipe Plugs, 10-4	Relay C, 6-11
HART Filters, 10-5	Relay Type, 5-20
I/P Converter Assembly, 10-4 Kits, 10-2 Module Base, 10-3	Remote Travel Sensor Connections, 2-19 Using a 10 kOhm External Potentiometer as, 2-20
Ordering, 10-2 Printed Wiring Board Assembly, 10-4 Relay, 10-4 Terminal Box, 10-4	Using a Two-Resistor Series as, 2-21 Using the DVC6015, DVC6025 and DVC6035 Feedback unit as, 2-20
PD, (Performance Diagnostics), 7-9	reset, 5-11
Performance Diagnostics, (PD), 7-9	Restart Control Mode, 5-5
Performance Tuner, 4-5, 5-9	Revision Information
Pneumatic Relay Adjusting, 6-10	DVC6000 Device, 7-9 Firmware, 7-9

Index-4 January 2007

Index

Hardware, 7-9 HART Universal, 7-9	Minimum Recorded, Displaying Value, 7-8 Units, 5-20		
Field Communicator, Device Description, 3-6	Terminal Box Parts List, 10-4		
Run Time, Displaying Status, 7-8	Removing, 9-11 Replacing, 9-11		
	Third-Party Approvals, 2-3		
S	Touch-Up Travel Calibration, 6-5		
Serial Number	Travel, Displaying Value, 7-7		
Instrument, 5-19 Valve, 5-19, 5-21	Travel / Pressure Control, 5-11 Cutoffs, 5-11		
Set Point Rate Close, 5-13	End Point Pressure Control, 5-12		
Set Point Rate Open, 5-12	Limits, 5-11 Pressure Control, 5-11		
Setup Wizard, 4-2	Travel Accumulation Alert Enable, 5-17		
SIS, Pressure Mode Enable, 5-12	Travel Accumulator		
SIS Alerts, 5-18	Displaying Value, 7-8		
Solenoid Valve Testing, 2-17	Enabling Alert, 5-17		
special application, 2-18	Resetting, 5-17 Travel Accumulator Alerts, 5-17		
Special Instructions for Safe Use and	Travel Cutoff Alerts, 5-16		
Installations in Hazardous Locations, 2-3	Travel Cutoffs, 5-11		
ATEX Flameproof, Dust, 2-3			
ATEX Intrinsic Safety, Dust, 2-3 ATEX Type n, Dust, 2-4	Travel Uses and Alerty 5-15		
CSA, 2-3	Travel History Alerts, 5-17		
FM, 2-3	travel indicator, 2-9		
IECEx Intrinsic Safety, Type n, Flameproof, 2-4	Travel Limits, 5-17		
Specifications, 1-3	Travel Sensor		
·	Adjusting DVC6010, 6-7		
Stabilize/Optimize, 4-5, 5-8	DVC6015, 6-7		
Status, 5-18	DVC6020, 6-8		
Calibration & Diagnostics, 5-19	DVC6025, 6-8		
Instrument Time, 5-19	DVC6030, 6-7		
Integrator, 5-19	DVC6035, 6-7		
Operational, 5-19	Parts List, 10-5		
Steady-State Air Consumption, 1-5	Removing DVC6010, 9-12		
Stroke Valve, 7-5	DVC6015, 9-12		
	DVC6020, 9-12		
Stroking the Output, with Field Communicator, 7-5	DVC6025, 9-12		
	DVC6030, 9-12		
Supply Pressure, 1-5	DVC6035, 9-12		
Displaying Value, 7-7	Replacing		
	DVC6010, 9-12		
<b>-</b>	DVC6015, 9-12		
Т	DVC6020, 9-13		
T	DVC6025, 9-13		
Temperature	DVC6030, 9-15		
Maximum Recorded, Displaying Value, 7-8	DVC6035, 9-15		

Index

Travel Sensor Adjust, 6-7
Travel Sensor Motion, 5-21
Travel Target, Displaying Value, 7-7
Travel Tuning Sets, Gain Values, 5-6
Troubleshooting, Instrument, 9-3
Tuning, 5-6
Pressure, 5-9
Travel, 5-6
Tuning Sets
Pressure, 5-9
Gain Values, 5-9
Travel, 5-6
Gain Values, 5-6

# U

Upper Operating Pressure, 5-12

# V

Valve Serial Number, 5-19, 5-21

Valve Style, 5-21 Voltage Available Calculating, 2-23

Checking, 9-5

## W

Wiring Length Guidelines, Auxiliary Terminal , 7-7

Wiring Practices
Communication Cable Capacitance, 2-25
Control System Requirements, 2-23
Compliance Voltage, 2-24
HART Filter, 2-23
Voltage Available, 2-23

# Z

Zero Power Condition, 5-20

Index-6 January 2007

Index

# CE

FIELDVUE, ValveLink, PlantWeb and Fisher are marks owned by Fisher Controls International LLC, a member of the Emerson Process Management business division of Emerson Electric Co. Emerson Process Management, Emerson, and the Emerson logo are trademarks and service marks of Emerson Electric Co. PROVOX, Rosemount, Tri-Loop, DeltaV, RS3, and AMS are marks owned by one of the Emerson Process Management group of companies. HART is a mark owned by the HART Comunication Foundation. All other marks are the property of their respective owners. This product may be covered under one or more of the following patents (5,163, 463; 5,265,637; 5,381,817; 5,434,774; 5,439,021; 5,451,923; 5,502,999; 5,532,925; 5,533,544; 5,549,137; 5,558,115; 5,573,032; 5,687,098) or under pending patents.

The contents of this publication are presented for informational purposes only, and while every effort has been made to ensure their accuracy, they are not to be construed as warranties or guarantees, express or implied, regarding the products or services described herein or their use or applicability. We reserve the right to modify or improve the designs or specifications of such products at any time without notice.

Neither Emerson, Emerson Process Management, nor any of their affiliated entities assumes responsibility for the selection, use and maintenance of any product. Responsibility for the selection, use and maintenance of any product remains with the purchaser and end-user.

## **Emerson Process Management**

Marshalltown, Iowa 50158 USA Cernay 68700 France Sao Paulo 05424 Brazil Singapore 128461

www.Fisher.com

