Instruction MI 611-262
August 2010

# Model 876PH Intelligent Transmitter for pH, ORP, and ISE Measurement with HART® Communications



# **Contents**

Contents	. iii
Figures	. vii
Tables	ix
1. Introduction	. 1
Reference Documents	1
Factory Default Passcode	1
2. Quick Start	. 3
Wiring	3
Checking Factory Configuration	4
Calibration	5
Basic Operation in Measure Mode	5
Looking for More Information?	
3. Specifications	. 7
Functional and Physical Specifications	7
Product Safety Specifications	8
4. Installation	11
Unpacking	11
Identification	11
Mounting Panel Mounting Surface Mounting Pipe Mounting	11
WiringVoltage Load Requirements	16
Write Protection Jumper	16
5. Operation Via Local Display	17
Controls and Indicators  Controls  Indicators	. 17
Passcode Access	19

Timeout	20
Viewing and Changing Data	20
Measure Mode	
Status Mode	23
Hold Mode	
Calibration Mode	
mA Cal	
Measurement Calibration	
Temperature Calibration	
ORP Calibration	
ORP Restore	31
Configuration Mode	33
Sensor	
pH	
pH and ORP	
ISE Concentration	
ORP Measurement Configuration	
pH	
pH and ORP	
ISE Concentration	
Temperature Configuration	
Temp Unit	
Temp Mode	
Temperature Compensation	
Analog Out (PV)	
Display Format	
AO Failsafe	
HART Digital	
Diagnostics	
Leakage	
ATC Short, ATC Open	
Comp Range	
Low Slope	
Preamp	
Reference Coating	
Broken Glass	
Aging	
Auto Hold	
Config Timeout	41
Transmitter Tags	
Passcode Access	
Calibration Parameters	
Buffer Set	
Stability	
Restore Configuration	
Diagnostic Mode	
View Faults	45

History Log	
Suspend Faults and Resume Faults	
Save Osei Comiguration	4/
6. Operation Via HART Communicator	49
Entering Modes	49
Saving Changes	49
HART Online Menu	50
Explanation of Parameters	52
7. Maintenance	57
Replacing the Bezel/Keypad Assembly (Item 10)	58
Replacing the Loop Power (MAU) PWA (Item 13)	58
Replacing the Processor PWA (Item 12)	58
Replacing the Display PWA (Item 11)	59
Appendix A. Configuration Structure Diagrams	61
Appendix B. Configuration Table	71
Appendix C. Auto Calibration	77
Calibration Parameters	77
Command Sequence	78
Cmd 148 (0x94): Start Cal	
Request: 22 (0x16) bytes (plus preambles)	
Cmd 149 (0x95): Read Cal Status	
Request: 10 (0x0A) bytes (plus preambles)	
Response: 18 (0x12) bytes (plus preambles)	
Cmd 150 (0x96): Finish Cal	
Request: 15 (0x0F) bytes (plus preambles)	
Response: 17 (0x11) bytes (plus preambles)	
Cmd 142 (0x8E): Write Entity Byte Base	
Response: 15 (0x0F) bytes (plus preambles)	
Cmd 143 (0x8F): Read Entity Byte User Attributes	83
Request: 11 (0x0B) bytes (plus preambles)	
Response: 20 (0x14) bytes (plus preambles)	
Cmd 146 (0x92): Activate Output Hold	
Response: 32 (0x20) bytes (plus preambles)	
Cmd 147 (0x93): Release Output Hold	
Request: 9 (0x09) bytes (plus preambles)	86

_					
C	O	nt	9	n	t٩

Response: 11 (0x0B) bytes (plus preambles)	86
Index	89

# **Figures**

1	Wiring Connections for 876PH Transmitter	4
2	Sample 3-Line Measurement Display	5
3	Sample Data Label	11
4	Panel Mounting	12
5	Surface Mounting	13
6	Pipe Mounting	13
7	Wiring Connections for 876PH Transmitter	15
8	Supply Power and Loop Load	16
9	Indicators and Controls	17
10	Sample 3-Line Measurement Display	19
11	Example of Structure Diagram	21
12	Measure Mode Structure Diagram	22
13	Status Mode Structure Diagram	25
14	Hold Mode Structure Diagram	28
15	Calibration Menu Structure	32
16	Measurement Display	38
17	Sample View Faults Display	45
18	Diagnostic Mode Structure	47
19	876PH Transmitter Online Menu Tree (1 of 2)	50
20	876PH Transmitter Online Menu Tree (2 of 2)	51
21	Exploded View of 876PH Transmitter	57

# **Tables**

1	Reference Documents	1
2	Product Safety Specifications	8
3	Recommended Conduit and Fittings	14
4	Control Keys	17
5	Status Parameters	23
6	Status Messages	26
7	RTD Type for Foxboro Sensors	33
8	Minimum Output Span for ISE Measurement	37
9	Transmitter Tags	42
10	pH Value of Common Buffer Solutions	43
11	List of Possible Faults	46

# 1. Introduction

The 876PH Intelligent Transmitter converts pH, ORP, or ISE measurements to a 4 to 20 mA output signal with a superimposed HART digital signal for remote configuration and monitoring. A human machine interface is integral to the device and provides simplified menu-driven configuration, calibration, status, and diagnostic procedures.

A unique feature of this transmitter is that you can save up to two complete configuration programs and restore them at any time to facilitate a quick and easy change of the transmitter to a presaved configuration.

## Reference Documents

Table 1. Reference Documents

Document Number	Document Description
DP 611-260	Dimensional Print – 876PH, 876EC, and 876CR Transmitters
MI 611-206 <sup>(b)</sup>	Instruction – Intrinsic Safety Connection Diagrams and Nonincendive Circuits
MI 611-208 <sup>(a)(b)</sup>	Instruction – Electrochemical Products Safety Information
PL 611-260	Parts List – 876PH, 876EC, and 876CR Transmitters

<sup>(</sup>a) Available in many languages via our website. For help downloading this document contact our Global Cuastomer Support Center.

# Factory Default Passcode

The factory default passcode for both Administrator and User is 0800.

<sup>(</sup>b) Not available with 876PH Transmitter information at this time.

# 2. Quick Start

#### — NOTE -

This Quick Start chapter only applies to pH measurements. For ORP or ISE measurements, see other chapters of this manual.

The purpose of this section is to:

- Help you wire your transmitter
- Familiarize you with the instrument configuration as received from the factory
- Assist you in verifying that your transmitter is in calibration
- Explain normal operation in Measure mode.

## Wiring



— A WARNING —

Wiring installation must comply with existing local regulations.



— WARNING -

For agency requirements, also see MI 611-206 (FM, CSA) or MI 611-208 (ATEX, IECEx).


Your 876PH Transmitter is a 2-wire transmitter. As such, it transmits output over the same two wires through which it receives power. Connect this power/output signal to the power terminals at the left of the printed wiring board inside the faceplate of your transmitter and the signal from your measurement sensor to the corresponding numbered terminals at the top of the terminal board. See Figure 1.

To access these terminals, remove the four screws in the corners of the bezel/keypad and open the hinged bezel/keypad downward.



-! CAUTION -

The bezel/keypad does not open a full 180°. Do not press on it while wiring.



(a) Use case ground instead of this board ground

Figure 1. Wiring Connections for 876PH Transmitter

#### — NOTE

When using non-Foxboro sensors for simultaneous pH and ORP measurement, connect the pH electrode to 3, reference electrode to 5, and ORP electrode to 4.

# **Checking Factory Configuration**

In Configuration mode, following the structure diagrams in Appendix A and using the arrow keys, you can step through the product structure as configured in the factory. The factory default values are listed in Appendix B. The values in your transmitter may differ from these because your transmitter may have been configured at the factory to your specific requirements. In the table that comprises Appendix B, there is a column provided to make any notations you wish about your specific configuration.

When viewing these values, be sure to check that the Buffer Set parameter configured in your transmitter matches the buffer you intend to use in calibrating your device.

To enter the Configuration mode, press the **Function** key and then the **Config** key. At the prompt, enter the passcode and press **ENTER**.

#### — NOTE

The factory default passcode for both the Administrator and User is 0800.

## Calibration

After wiring your transmitter and checking/changing the configuration, you should perform a 2-Point calibration. To enter the Calibration mode, press the **Function** key and then the **Cal** key. At the prompt, enter the passcode and press **ENTER**. Next, enter the calibrator's name, calibration day, month, and year, pressing **ENTER** after each. Then select **Measurement** from the Calibrate screen and follow the prompts for a 2-point calibration to calibrate your transmitter. At the end of a successful calibration, there should be no faults in the transmitter.

# Basic Operation in Measure Mode

Measure is the normal operating mode of your transmitter. One, two, or three measurements can be displayed depending on the configuration. When the display is configured for single line measurements, the value and unit are usually displayed. Any measurement can be temporarily scrolled onto the display by using the **Up** and **Down** arrow keys. The display returns to the configured values when you press the **Function** key and then the **Measure** key or when the configured timeout period expires. When the transmitter is in Hold mode, a **Hold** indication appears in the upper right of the title bar. If there is a fault, a flashing fault symbol is displayed. If in Measure, Status, or Diagnostic mode, the word **FAULT** also flashes in the lower left of the display. When you press the **Function** key, the function indicator is displayed.




Figure 2. Sample 3-Line Measurement Display

# Looking for More Information?

For more detailed information, refer to the following sections of this manual:

- For detailed installation information, refer to "Installation" on page 11.
- For detailed explanation of the controls and indicators, refer to "Operation Via Local Display" on page 17.
- For detailed configuration instructions, refer to "Configuration Mode" on page 33.
- For detailed calibration instructions, refer to "Calibration Mode" on page 29.

◆ For detailed operation from a HART Communicator, refer to "Operation Via HART Communicator" on page 49.

For dimensional information, refer to DP 611-260.

If you need additional help, contact our Global Customer Support Center at 1-866-746-6477 (within U.S.), 1-508-549-2424 (outside U.S.), or contact your local Invensys representative.

# 3. Specifications

# Functional and Physical Specifications

Sensors: Virtually any glass or antimony pH, ORP, or ISE sensor including the following:

PH12 Series Sensor

PH10 DolpHin<sup>TM</sup> Series pH Sensor

ORP10 DolpHin<sup>TM</sup> Series ORP Sensor

871PH Series pH/ORP Sensor

871A Series pH/ORP Sensor

EP460 pH/ORP Sensor

EP462 pH Sensor

EP466 pH Sensor

EP459A Fluoride Sensor Assembly

Non-Foxboro sensors without integral preamplifiers and with compatible temperature compensation elements

#### Maximum Distance Between Sensor and Transmitter:

With preamplified sensor: 152 m (500 ft)

With non-preamplified sensor that utilizes a driven shield (PH12, PH10-.N, 871A-1, -3; 871PH-5, -6): 15.2 m (50 ft)

#### Temperature Compensation Inputs:

100 ohm platinum RTD, 2- and 3-wire

1000 ohm platinum RTD, 2- and 3-wire

3000 ohm Balco 2-wire RTD

#### Solution Temperature

-30 to +200°C (-22 to +392°F)

#### **Ambient Temperature:**

Electronics:  $-30 \text{ to } +70^{\circ}\text{C} (-22 \text{ to } +158^{\circ}\text{F})$ 

Display:  $-20 \text{ to } +70^{\circ}\text{C} (-4 \text{ to } +158^{\circ}\text{F})$ 

Relative Humidity: 0 to 90% noncondensing

Environmental and Corrosion Resistant Protection: The enclosure is dusttight and weatherproof as defined by IEC IP66, and provides the environmental and corrosion resistant protection of NEMA Type 4X.

Electromagnetic Compatibility (EMC): The 876PH Transmitter complies with the requirements of the European EMC Directive 2004/108/EC by conforming to EN 61326-1:2006.

Power Supply Requirements (for 4 to 20 mA output): 12.8 to 42 V dc (see Figure 8)

Load Limitations (for 4 to 20 mA output): 0 to 1300 ohms (see Figure 8)

### Measurement Range (selectable):

pH: -2 to +16 pH

ORP: -2000 to +2000 mV

ISE: 0 to 9999 ppm

Solution Temperature: -30 to +200 °C (-22 to +392°F)

### Temperature Compensation Range:

-30 to +200°C (-22 to +392°F) for pH or ISE

0 to 100°C (32 to 212°F) for ammonia

### Approximate Weight:

Panel Mounted: 3.1 kg (6.8 lb)

Surface or pipe Mounted: 3.7 kg (8.1 lb) including mounting bracket

# **Product Safety Specifications**

#### — NOTE

The 876PH Transmitters have been designed to meet electrical safety descriptions listed in Table 2. For detailed information, or status of testing laboratory approvals/certifications, contact Invensys.

Table 2. Product Safety Specifications

Testing Laboratory, Types of Protection and Area Classification	Application Conditions	Electrical Safety Design Code
<b>ATEX</b> II 1 G, Ex ia IIC, intrinsically safe for Zone 0.	Temperature Class T4. Ta = -20 to 60°C.	AA
<b>ATEX</b> II 3 G, Ex ic IIC, intrinsically safe for Zone 2.	Temperature Class T4. Ta = -20 to 60°C.	AN
CSA Ex ia IIC; intrinsically safe for Zone 0; and CSA intrinsically safe, Class I, II, III, Division 1, Gas Groups A, B, C, D, E, F, G.	Temperature Class T4. Ta = -20 to 60°C.	CA
CSA Ex nL IIC; energy limited for Zone 2; and CSA for Class I, II, III, Division 2, Gas Groups A, B, C, D, E, F, G.	Temperature Class T4. Ta = -20 to 60°C.	CN
<ul><li>FM AEx ia IIC; intrinsically safe for Zone 0; and</li><li>FM intrinsically safe, Class I, II, III,</li><li>Division 1, Gas Groups A, B, C, D, E, F, G.</li></ul>	Temperature Class T4. Ta = -20 to 60°C.	FA

Table 2. Product Safety Specifications

Testing Laboratory, Types of Protection and Area Classification	Application Conditions	Electrical Safety Design Code
FM AEx nC IIC; energy limited for Zone 2; and FM nonincendive, Class I, II, III, Division 2, Gas Groups A, B, C, D, E, F, G.	Temperature Class T4. Ta = -20 to 60°C.	FN
<b>IECEx</b> II 1 G, Ex ia IIC; intrinsically safe for Zone 0.	Temperature Class T4. Ta = -20 to 60°C.	DA
<b>IECEx</b> II 3 G, Ex ic IIC; intrinsically safe for Zone 2.	Temperature Class T4. Ta = -20 to 60°C.	DN
No Certifications	N/A	ZZ

# 4. Installation

# Unpacking

- 1. Remove the transmitter from the shipping container and check for visible damage.
- 2. Save the container until you determine that no shipping damage has occurred.
  - a. If no damage is observed, proceed to the mounting procedure.
  - **b.** If transmitter has been damaged, notify the carrier immediately and request an inspection report. Obtain a signed copy of the report from the carrier and contact our Global Client Support Center at 1-866-746-6477 or contact your local Invensys representative.

## Identification

A data label is fastened to the left side surface of the enclosure. This label provides the model number and other information pertinent to your particular transmitter.




Figure 3. Sample Data Label

# Mounting

## Panel Mounting

Panel mounting of the transmitter is shown in Figure 4.

- 1. Cut panel to receive instrument.
- 2. Insert screws in back of instrument.

3. Place instrument into panel and add bracket, washers and nuts from back side. For panel cutout size, space requirements, and other dimensional data, see DP 611-260.




Figure 4. Panel Mounting

## **Surface Mounting**

Surface mounting of the transmitter is shown in Figure 5.

- 1. Fasten mounting bracket to transmitter using screws, washers, and lockwashers provided.
- 2. Fasten mounting plate to surface using appropriate hardware.

For space requirements and other dimensional data, see DP 611-260.




Figure 5. Surface Mounting

## Pipe Mounting

Pipe mounting of the transmitter is shown in Figure 6.

- 1. Fasten mounting bracket to instrument using hardware provided.
- 2. Securely fasten mounting bracket to a DN50 or 2-in pipe with U-bolts supplied.

For space requirements and other dimensional data, see DP 611-260.




Figure 6. Pipe Mounting

# Wiring

	WARNING

Wiring installation must comply with existing local regulations.



The bezel/keypad does not open a full 180°. Do not press on it while wiring.

Your 876PH Transmitter is a 2-wire transmitter. As such, it transmits output over the same two wires through which it receives power. Connect this power/output signal and the signal from your measurement sensor as follows:

1. Remove the four screws on the corners of the faceplate and open the hinged door downward. install proper fittings in the left and right ports in the bottom of the case.

Table 3. Recommended Conduit and Fittings

Material	Conduit	Fitting
Rigid Metal	1/2 inch Electrical Trade Size	T&B* #370
Semi-Rigid Plastic	T&B #LTC 050	T&B #LT 50P or T&B #5362
Semi-Rigid Plastic Metal Core	Anaconda Type HV, 1/2 inch	T&B #LT 50P or T&B #5362
Flexible Plastic	T&B #EFC 050	T&B #LT 50P or T&B #5362

<sup>\*</sup>T&B = Thomas & Betts Corp., 1001 Frontier Road, Bridgewater, NJ 08807

- 2. Bring your power wires in the left opening in the bottom of the case and attach to the power terminals at the left of the printed wiring board. See Figure 7.
- 3. Bring the sensor wires in the right opening in the bottom of the case and attach to the appropriate terminals at the top of the printed wiring board. See Figure 7.

#### - NOTE

To maintain NEMA Type 4X and IEC IP66 protection, plug any unused openings with the plug, gasket, and locknut shown in PL 611-260.

4. Set the Write Protect jumper as shown in Figure 7.





Figure 7. Wiring Connections for 876PH Transmitter

### - NOTE -

When using non-Foxboro sensors for simultaneous pH and ORP measurement, connect the pH electrode to 3, reference electrode to 5, and ORP electrode to 4.

## Voltage Load Requirements

The voltage load requirements are given in Figure 8.



NOTE
THE TRANSMITTER CAN FUNCTION WITH AN OUTPUT LOAD LESS THAN 250 OHMS
PROVIDED THAT A REMOTE CONFIGURATOR OR HART COMMUNICATOR IS NOT
CONNECTED TO IT. CONNECTING A REMOTE CONFIGURATOR OR HART COMMUNICTOR WHILE OPERATING IN THIS AREA COULD CAUSE OUTPUT DISTURBANCES AND/OR COMMUNICATION PROBLEMS.

Figure 8. Supply Power and Loop Load

#### Examples:

- 1. For a loop load of 800 ohms, the supply voltage can be any value from 31 to 42 V dc.
- 2. For a supply voltage of 24 V dc, the loop load resistance can be any value from 0 to 517 ohms (250 to 517 ohms with a PC-Based configurator or a HART Communicator connected to the transmitter).

## Sensor Cable Length

The length of the cable between the sensor and the transmitter can be 152 m (500 ft) maximum if using a sensor with an integral preamplifier or used with a remote preamplifier. Without a preamplifier, the length can be 15 m (50 ft) maximum.

## Write Protection Jumper

Your transmitter has write protection capability which meets the security requirements of ISA-S84.01-1986 for use in safety shutdown systems. This means that the local display and remote electronics can be prevented from writing to the electronics. Write protection is set by moving a jumper that is located on the printed wiring board behind the front panel. To activate write protection, open the front panel and place it in the 'protect' position. See Figure 7. In the 'Not Protected' position, writing to certain functions can be limited by passcode protection.

# 5. Operation Via Local Display

## Controls and Indicators

Operator controls and indicators are located on the front panel. Figure 9 shows the panel arrangement. Table 4 identifies the function of each element.




Figure 9. Indicators and Controls


## Controls

Table 4. Control Keys

Control Key	Function
FUNCTION Key	Gives you access to the blue function keys.
INFO Key	Describes the present parameter.
CALibration Key	Places the transmitter in Calibration mode. This enables you to calibrate the transmitter automatically to your buffer solutions or manually to values entered.
CONFIGuration Key	Places the transmitter in Configuration mode. This enables you to configure the value or status of each parameter required for your application.

Table 4. Control Keys (Continued)

Control Key	Function	
HOLD Key	Places the transmitter in Hold mode. This enables you to hold the output at a determined value while configuring or calibrating the transmitter or performing sensor maintenance.	
MEASUREment Key	Places the transmitter in Measurement (normal operation) mode.	
STATUS Key	Places the transmitter in Status mode. This enables you to view the measurement and system parameters and thus assess the performance of the loop.	
DIAGnostics Key	Places the transmitter in Diagnostic mode. This enables you to further identify specific errors and possible solutions to an error flagged in Measurement mode. Also a means to access the history log.	
HELP Key	Describes how to use the keypad to do the present operation.	
+/- Key	Changes a + value to a – value and vice versa.	
Alpha/Numeric Keys	See explanation below.	
Direction (Arrow) Keys	Moves you through the structure diagram and subsequent menus and values.	
ENTER Key	Enters the menu item or value selected. This is the only key that actually enacts a change.	
BACK Key	Used with the Function key, moves you back one level in the menu structure.	
SAVE/EXIT Key	Used with the Function key, asks you if you want to save your entries and then moves you to Measure mode.	
YES Key	Used to answer Yes to a Yes/No question.	
NO Key	Used to answer No to a Yes/No question.	



The alpha/numeric keys have several functions as follows:

- Access the function shown with a blue background
- Enter numeric values
- Enter alpha characters (for example, a HART tag, description, or message).

To enter an alpha character, use the key as you would on a cell phone. For example, to enter the word "Acid", use the following sequence"

1. Press the "2" key once to enter the "A" and use the Right arrow key to advance to the next character

- 2. Press the "2" key three times to enter the letter "C" and press the Down arrow key to change it to lower case. Use the Right arrow key to advance to the next character.
- 3. Press the "4" key three times to enter the letter "I" and press the Down arrow key to change it to lower case. Use the Right arrow key to advance to the next character.
- 4. Press the "3" key once to enter the letter "D" and press the Down arrow key to change it to lower case.

### **Indicators**

The display can be configured to display one, two, or three measurements. However, any measurement can be temporarily scrolled onto the display by using the **Up** and **Down** arrow keys. The display returns to the configured values when you press the **Function** key and then the **Measure** key or when the configured timeout period expires. When the transmitter is in Hold mode, a **Hold** indication appears in the upper right of the title bar. When you press the **Function** key, the function indicator is displayed. If there is a fault, a flashing fault symbol is displayed. If in Measure, Status, or Diagnostic mode, the word **FAULT** also flashes in the lower left of the display.

#### — NOTE

- 1. If **FAULT** is displayed, details of the fault are shown in the Diagnostic mode.
- 2. If **CHECK STATUS** is displayed (in the Fault Indictor location), go to Status mode to check the status.




Figure 10. Sample 3-Line Measurement Display

### Passcode Access

Two levels of protection are available. Administrator (**Admin Code**) access permits changing all parameters in Configuration as well as specifying what parameters are accessible by those having User Code access. User (**User Code**) access permits change and viewing access to those areas specified by the administrator. Both are 4-digit passcodes. The passcodes may or may not be the same. They are set as part of configuring the instrument.

Upon entering the Configuration, Calibration, or Hold mode, you may be prompted to enter a passcode. To exit, select another mode.

#### - NOTE -

Every passcode entry is added to the history log.

If entering Calibration or Configuration mode and you enter the correct passcode, the transmitter responds in one of three ways depending on how **Automatic Hold** is configured. If **Automatic Hold** is configured **Off**, the display cautions you that the transmitter is not in Hold mode. Press **ENTER** to continue. If **Automatic Hold** is configured **Present**, the display cautions that hold is engaged but that outputs are held at the present level. It then unlocks the mode. If **Automatic Hold** is configured **Manual**, the display briefly displays **Hold Engaged** and then unlocks the mode.

The initial factory default value for both Administrator and User passcodes is 0800.

To bypass the passcode, the administrator must configure a passcode of 0000.

### **Timeout**

If there are no key presses within the configured timeout period, the transmitter reverts to Measure mode. You can also return to Measure mode by pressing the **FUNCTION** key and then the **MEASURE** key. If in Configuration or Calibration mode and the automatic hold feature was employed, the output becomes live when the transmitter times out. The timeout feature can be turned off in Configuration mode.

# Viewing and Changing Data

In the Configuration, Calibration, Hold, and Diagnostic modes, you need to move through a structure of parameters (using the arrow keys and **ENTER** key) to view and/or change the value or status of a particular parameter. Structure diagrams, located in Appendix A, will aid you in doing this.

#### - NOTE -

- 1. The Up and Down arrow keys scroll through a menu in either direction.
- 2. Using the Function key with the Up and Down arrow keys takes you to the top and bottom of a menu respectively.
- 3. If a menu selection is invalid, you will see a selection in inverted text (white letters on black background). This choice is not selectable. It will disappear after you make your choice. To keep the selection, use the **Back** key.

The following example will show you how to use the keys in moving through the structure. The example used is that of configuring temperature features. For the example, assume Fahrenheit temperature units, an automatic temperature mode, and a fail temp value of 77°F. Refer to Figure 11.

- 1. To enter the Configuration mode, press the **FUNCTION** key and then the **CONFIG** key. Press **ENTER**.
- 2. Press the Down arrow key twice to move from **Sensor** to **Temp Config**. Press **ENTER**.
- 3. The **Temp Config** screen is displayed. **Temp Units** is highlighted. Press **ENTER**.

- 4. Use the Up or Down arrow key to move to **degF** and press **ENTER**. This enters your Fahrenheit selection and moves the display back to the **Temp Units** screen.
- 5. Use the Down arrow key to move to **Temp Mode**. Press **ENTER**.
- 6. The **Temp Mode** screen is displayed. Use the Up or Down arrow key to move to **Auto** and press **ENTER**. This enters your Auto Mode election and moves the display back to the **Temp Mode** screen.
- 7. Use the Down arrow key to move to **Fail Temp**. Press **ENTER**.
- 8. The **Fail Temp** screen is displayed.
- 9. Press the "7" key twice. Press **ENTER**. This enters your selection of 77 and moves the display back one level.
- 10. Press the **FUNCTION** and **SAVE/EXIT** keys to save your configuration.




Figure 11. Example of Structure Diagram

## Measure Mode

Measure is the normal operating mode of your transmitter. Depending on your configuration, the display can show 1, 2, or 3 measured values. In Configure mode, you can also configure what to display on each line. The choices are the (pH, ORP, or ISE) measurement, the absolute value of the measurement in millivolts, the temperature, and the analog output (4 to 20 mA). The units are always shown with the measured values.

Any measured values can be temporarily scrolled onto the display by using the Up and Down arrow keys. See Figure 12. The display returns to the configured values when you press the **FUNCTION** key and then the **MEASURE** key or when the timeout period expires. When the transmitter is in Hold, a hold indication appears in the upper right of the display. If there is a fault, a fault symbol is displayed in the title bar and, if in Measure, Status, or Diagnostic mode, the word **FAULT** flashes in the lower left of the display. See Figure 2.




Figure 12. Measure Mode Structure Diagram

## Status Mode

Refer to Figure 13 on page 25.

The Status mode enables you to view the measurement and system parameters and thus assess the performance of the loop. You can not edit them in this mode. All measurements and outputs continue while you are in the Status mode.

To enter the Status mode, press the **FUNCTION** key and then the **STATUS** key. Move through the menu by using the Up and Down arrow keys. See Figure 13 on page 25. The Status menu contains the following parameters:

Table 5. Status Parameters

Parameter	Description	Units	Notes
Temperature	Process temperature measurement	degC, degF	
Temp Status	Status of process temperature		See Table 6
Absolute	Uncompensated measurement signal from sensor	mV	
Absolute Status	Status of absolute measurement		See Table 6
Temperature Sensor	Temperature sensor resistance	Ohms	
T Sensor Status	Status of temperature sensor		See Table 6
Measurement	Compensated measurement	pH: pH ORP: mV, ISE: ppm, ppb, %	
Meas Status	Status of measurement		See Table 6
Glass	Resistance of glass electrode	kΩ	If Broken Glass diagnostic enabled
Glass Status	Status of glass electrode resistance		See Table 6
Reference	Reference junction resistance	kΩ	If Reference Coating diagnostic enabled
Ref Status	Status of reference junction resistance		See Table 6
Calibrated By	Name of last operator		
Calibration Date	Date of last calibration (dd/mm/yyyy)		
Slope (mV) <sup>(a)</sup>	Change in mV/pH or mV/decade of the most recent calibration	mV/pH, mV/decade	If pH or ISE
Slope (%) <sup>(a)</sup>	Deviation in percent of the slope of the most recent calibration compared to the standard	%	

Table 5. Status Parameters (Continued)

Parameter	Description	Units	Notes
Asymmetry	Asymmetry potential (mV difference between the theoretical isopotential point and the actual point due to the most recent calibration)	mV	If not ORP
Lo Cal Point <sup>(b)</sup>	Values at Calibration Point One	mV, pH, conc, ORPmV	
Hi Cal Point <sup>(b)</sup>	Values at Calibration Point Two	mV, pH, conc, ORPmV	
Analog Output	Analog Output	mA	
Analog Output Status	Status of analog output		See Table 6
HART PV	PV measurement		
PV Status	Status of PV		See Table 6
HART SV	SV measurement		
SV Status	Status of SV		See Table 6
HART TV	TV measurement		
TV Status	Status of TV		See Table 6
HART QV	QV measurement		
QV Status	Status of QV		See Table 6
Model Code	Model code		
Sales Order	Sales order number		
Xmtr Serial Number	Transmitter serial number		
Firmware Revision	Firmware revision level.		
Front End Revision	Front end revision level		For Foxboro use only
Boot Revision	Boot revision level		For Foxboro use only
Transmitter Type	Transmitter type (876PH)		
In Service	Time in service	Days	
HART Tag	HART Tag		
HART Long Tag	HART Long Tag		HART Versions 6 & 7
Tag Name	Tag name		
Location	Location of measurement		
Device Name	Device name		
HART Descriptor	HART Descriptor		
HART Message	HART Message		

<sup>(</sup>a) In multiple point calibrations, this is the slope closest to the isopotential point.

<sup>(</sup>b) In multiple point calibrations, this is the point closest to the isopotential point.




Figure 13. Status Mode Structure Diagram

Table 6. Status Messages

Displayed Message	Meaning	Information on That Error <sup>(a)</sup>
Meas OK	Measurement OK	OK. All inputs and calculations for the measurement are OK.
1 InputFixed	Input is fixed	OK. Calculation based upon an input is fixed at its manually set value.
Overridden	Measurement is overridden	Measurement has been put into hold mode.
Default	Meas is fixed	OK. Measurement is fixed at the manually set value.
LimitSoftLow	The measurement is approaching the lower limit.	Warning. The measurement is approaching the lower limit.
LimitSoftHi	The measurement is approaching the upper limit.	Warning. The measurement is approaching the upper limit.
InputWarning	Input to meas has a warning	Warning. Measurement input has a warning status.
LimitHardLow	Meas below low limit	Bad. The measurement has dropped below hard lower limit.
LimitHardHi	Meas above upper limit	Bad. The measurement has risen above hard upper limit.
1 Input Bad	Input to meas is bad	Bad. An input to the measurement has a bad status.
MeasStarting	Inputs to meas are not ready	Bad. A to D converter has not yet measured everything for this individual measurement.
InputStarting	Inputs to meas are not ready	Bad. A to D converter has not yet measured everything for this individual measurement.

<sup>(</sup>a) Displayed when the Function and Info keys are pressed for that fault

## Hold Mode

Refer to Figure 14.

#### — NOTE

Hold mode may be protected. See "Passcode Access" on page 19.

The Hold mode enables you to manually hold the output at a determined value, thus allowing you to configure or calibrate the transmitter or perform sensor maintenance without disturbing the control system. Outputs are driven to a preconfigured state or held at their current values. During calibration, the transmitter continues performing live measurements.

## ─▲ WARNING -

When entering hold, you may want to take your loop out of auto control.

To enter the Hold mode, press the **FUNCTION** key and then the **HOLD** key. In the Hold mode menu, select **On Present** to hold all values and states at their current level, **On Manual** to set all values and states at desired levels, or **Off** to release a hold.

If you select **On Present** and press the **ENTER** key, the display briefly reads **Hold Engaged** and proceeds to Measure mode and the outputs are held.

If you select **On Manual** and press the **ENTER** key, the display proceeds to **AO Hold**, the first of a series of parameters to set values and states to desired levels during hold.

#### — NOTE

Additionally, in Configuration mode, you can use the **Automatic Hold** parameter to automatically activate the Hold feature each time you enter Calibration or Configuration mode. In this Configuration mode parameter, you can select **Off**, **Present**, or **Manual**. However, if you select **Manual**, you must go to Hold mode to set the values.

To set the output for the analog output, enter a value from 3.6 to 22 mA.

You can also fix the value for PV, SV, TV, and QV individually. When you have finished making the manual selections, the display briefly reads **Hold Engaged** and returns to the Hold mode menu.

To release Hold, press the **FUNCTION** key and then the **HOLD** key. At the Enter Passcode prompt, enter the correct passcode and press the **ENTER** key. If you enter the incorrect passcode, the display repeats the prompt. If you enter the correct passcode, the display opens the Hold mode. Use the Up or Down arrow key to select **Off** and press **ENTER**. The display briefly reads **Hold Released** and returns to the Hold mode menu.




Figure 14. Hold Mode Structure Diagram

## Calibration Mode

Refer to Figure 15

#### — NOTE

- 1. Calibration mode may be protected. See "Passcode Access" on page 19.
- 2. If using the **Automatic Hold** feature, the outputs are held at the present level or a predetermined level. Returning to Measure mode releases the hold.

Five calibration selections are available; mA Cal, Measurement, Temperature, ORP, and ORP Restore. See Figure 15.

To enter the Calibration mode, press the **FUNCTION** key and then the **CAL** key. Press **ENTER**. The display moves to the first parameter in Calibration mode. At the prompts, enter the name of the person doing the calibration and the calibration day, month, and year.

### mA Cal

#### — NOTE

It is not necessary to do a mA Cal (commonly known as mA Trim) unless there is a plant requirement to make the 4 and 20 mA output values exactly match readings on certain plant calibration equipment and the calibration operations done result in a small but unacceptable difference between the transmitter mA output and the test equipment mA readout values.

To perform a mA calibration, select **mA Cal** and press **ENTER**.

- 1. Connect a digital current meter in the loop.
- 2. At the prompt **4 mA**, press **ENTER**.
- 3. At the prompt **Known x.xxx**, enter the value measured and press **ENTER**.
- 4. At the prompt, **20 mA**, press **ENTER**.
- 5. At the prompt **Known x.xxx**, enter the value measured and press **ENTER**.
- 6. When calibration is done, the display reads **Cal Complete**. Press **ENTER**.

## Measurement Calibration

Measurement Calibration is used when you selected '**pH**' '**ISE**' or '**ORP**' as your Measurement. See "Sensor" on page 33.

To perform a measurement calibration, select **Measurement** and press **ENTER**.

- 1. At the prompt, enter the number of calibration points from 1 to 5.
- 2. At the next prompt, select the standard as **Manual**, **Smart**, or **Process**.

**Manual** presumes no knowledge by the transmitter of the calibration solution being used. You must enter the exact known value at the calibration temperature. No temperature compensation is applied in the firmware.

**Smart** presumes any of the configurable calibration standards. Solutions are recognized automatically so there is no need for you to enter a known value. The temperature response for the recognized solution is used in the calibration. If none of

the solutions provide a unique match (±0.5 pH of nominal buffer value), the calibration reverts to a **Manual** calibration.

**Process** presumes a grab sample of the process. You must enter a known value at the reference temperature (usually 25°C) from laboratory measurements. The configured application temperature compensation is applied.

#### — NOTE

Process only appears in the menu if you selected **Ammonia** or **Custom** as your type of temperature compensation (See "Temperature Compensation" on page 36).

- 3. At the prompt, put the sensor in the first solution and press **ENTER**.
- 4. If you selected **Manual** in Step 2:
  - a. Measurement/Temperature is temporarily displayed while process is stabilizing.
  - **b.** At the prompt, enter the known measurement value at the current temperature and press **ENTER**.
- 5. If you selected **Smart** in Step 2,
  - **a.** Measurement/Temperature is temporarily displayed while process is stabilizing.
  - b. You do not need to enter the known pH values as you did in Manual.
- **6.** If you selected **Process** in Step 2:
  - a. Measurement/Temperature is temporarily displayed while process is stabilizing.
  - **b.** At the prompt, enter the known measurement value at the reference temperature (25°C) and press **ENTER**.
- 7. Repeat Steps 3 and 4, 3 and 5, or 3 and 6 as applicable for each calibration point.
- 8. When calibration is done, the display reads **Cal Complete**. Press **ENTER**.

## Temperature Calibration

To perform a Temperature calibration, select **Temperature** and press **ENTER**.

- 1. At the prompt, enter the number of calibration points as 1 or 2.
- 2. At the prompt, place the sensor in solution at the low temperature and press **ENTER**.
- 3. Temperature is temporarily displayed while process is stabilizing.
- 4. At the prompt, enter the known low temperature and press **ENTER**.
- **5.** If a 2-point calibration, at the prompt, place the sensor in solution at the high temperature and press **ENTER**.
- **6.** At the prompt, enter the known high temperature and press **ENTER**.
- 7. Temperature is temporarily displayed while process is stabilizing.
- 8. When calibration is done, the display reads **Cal Complete**. Press **ENTER**.

## **ORP** Calibration

ORP Calibration is only used when you selected 'pH and ORP' as your Measurement. See "Sensor" on page 33.

To perform an ORP calibration, select **ORP** and press **ENTER**.

- 1. At the prompt, apply the solution and press **ENTER**.
- 2. ORP is temporarily displayed while process is stabilizing.
- 3. At the prompt, enter the known measurement value and press **ENTER**.
- 4. When calibration is done, the display reads **Cal Complete**. Press **ENTER**.

## **ORP** Restore

ORP Restore enables you to erase an ORP calibration.

To perform an ORP Restore, select **ORP Restore** and press **ENTER**. At the prompt **Erase Calibrations?**, respond **Yes** to erase the calibration and restore the ideal mV calibration performed at the factory; respond **No** to keep the present calibration.




Figure 15. Calibration Menu Structure

# Configuration Mode

#### — NOTE

- 1. Configuration mode may be protected. See "Passcode Access" on page 19.
- 2. If using the **Automatic Hold** feature, the outputs are held at the present level or a predetermined level. Returning to Measure mode releases the hold.

Configuration is the process of establishing functional capability in the transmitter firmware for your application. This section helps you to systematically determine and configure the value or status of each parameter required for your application. Invensys recommends that you make configuration changes from the beginning of the menu structure forward. This is because menus are forward referencing meaning that if you start at the beginning and work to the end, you achieve a valid configuration. Also, the transmitter validates the configuration when attempting to exit configuration and directs you to any invalid parameters.

To enter the Configuration mode, press the **FUNCTION** key and then the **CONFIG** key. After gaining access to Configuration, the first category in the top level configuration structure, **Sensor**, is displayed. To view or change another configuration category, press the Up or Down arrow key. When you have located the desired category, press the **ENTER** key. Each category of parameters is shown in subsequent structure diagrams.



#### -! CAUTION -

If there are no key presses within the configured Timeout period, the transmitter reverts to Measure mode and all changes are lost.

## Sensor

Refer to Figure A-2 on page 62.

This section of the configuration structure begins by asking you to specify your type of measurement as pH, pH and ORP, ISE Concentration, or ORP.

#### — NOTE

Whenever the Measurement type or Electrode is entered and saved, any user calibration is erased and the transmitter reverts to an ideal sensor calibration.

### рΗ

If you selected **pH**, you must specify the electrode as **Glass**, **Antimony**, or **Other**. **Glass** sets the isopotential point at 7 pH. **Antimony** sets it at 1 pH. **Other** allows the isopotential point to be set manually from -2.0 through +16.0 pH. If you selected **Other**, you must also enter the **Slope**.

Next specify the temperature (RTD) type as **2-Wire Pt 100**  $\Omega$  **2-Wire Pt 1000**  $\Omega$  **3-Wire** Pt 100  $\Omega$  3-Wire Pt 1000  $\Omega$  or Balco 3 k $\Omega$ 

Table 7. RTD Type for Foxboro Sensors

Foxboro Sensor	RTD Type
PH12	3-Wire Pt 100 Ω, 3-Wire Pt 1000 Ω

Foxboro Sensor	RTD Type
PH10 pH Sensor	2-Wire Pt 100 Ω 3-Wire Pt 1000 Ω 2-Wire 3 kΩ Balco
ORP10 ORP Sensor	2-Wire Pt 100 Ω 3-Wire Pt 1000 Ω 2-Wire 3 kΩ Balco
871A pH/ORP Sensor	2-Wire Pt 100 Ω 2-Wire Pt 1000 Ω 3-Wire Pt 1000 Ω
EP460 pH/ORP Sensor	3-Wire Pt 100 Ω
EP462 pH Sensor	3-Wire Pt 100 Ω
EP466 pH Sensor	3-Wire Pt 100 Ω
EP459 Fluoride Sensor	2-Wire Pt 100 Ω

Table 7. RTD Type for Foxboro Sensors

## pH and ORP

This allows simultaneous measurement of both pH and ORP using a single reference electrode. Ideally, this would use a single sensor having all three required electrodes, but could use two distinct sensors. Connect the pH electrode to terminal 3, the ORP electrode to terminal 4, and one reference electrode to terminal 5.

When using this configuration, the ±2000 mV range applies independently to both terminals 3 and 5 relative to terminal 4. In other words, pH mV – ORP mV must remain within the ±2000 mV range.

If you selected **pH and ORP**, you must specify the pH electrode as **Glass**, **Antimony**, or **Other**. **Glass** sets the isopotential point at 7 pH. **Antimony** sets it at 1 pH. **Other** allows the isopotential point to be set manually from -2.0 through +16.0 pH. If you selected **Other**, you must also enter the **Slope**.

Next specify the temperature (RTD) type as **Balco 3** k $\Omega$  **2-Wire Pt 100**  $\Omega$  **2-Wire Pt 1000**  $\Omega$  **3-Wire Pt 1000**  $\Omega$  See Table 7.

#### — NOTE

When using non-Foxboro sensors for pH and ORP measurement, see wiring note on page 15.

#### ISE Concentration

If you selected ISE Concentration, you must configure the following:

- 1. Specify the ion polarity (Electrode) as **Positive** or **Negative**. A positive ion selective mV value gets more positive as the concentration increases (for example, Na<sup>+</sup>, K<sup>+</sup>). A negative ion selective mV value gets more negative as the concentration increases (for example, F<sup>-</sup>, S<sup>-2</sup>). For fluoride measurements, this parameter should be set to negative.
- 2. Enter the **Isopotential** point from 0.0001 to 9999.9 in concentration units selected in "ISE Concentration" on page 35.
- 3. Specify the **Valence** as **Monovalent** (for example,  $F^-$ ) or **Divalent** (for example,  $S^{-2}$ )

<sup>(</sup>a) In order to select a 3-wire RTD type, the RTD third wire must be connected to Terminal 2A.

4. Specify the temperature (RTD) type as 2-Wire Pt 100  $\Omega$  2-Wire Pt 1000  $\Omega$  3-Wire Pt 100  $\Omega$  3-Wire Pt 1000  $\Omega$  or Balco 3  $\Omega$  See Table 7.

#### **ORP**

If you selected ORP, you only have to specify the temperature (RTD) type. The choices are **Balco** 3 k $\Omega$  2-Wire Pt 100  $\Omega$  3-Wire Pt 1000  $\Omega$  or 3-Wire Pt 1000  $\Omega$  See Table 7.

# Measurement Configuration

Refer to Figure A-3 on page 63.

As in the previous parameter, the structure of Meas Config is dependent on the type of measurement you selected.

#### рΗ

If your Measurement selection was pH, specify your pH Resolution as 0.1 pH or 0.01 pH.

Then enter the **Damping** response time (for 90% recovery from a step change). You can enter a time up to 300 seconds expressed in seconds. To increase damping, use a higher response time. Damping applies only to compensated measurement data, not to temperature or absolute data.

## pH and ORP

If your Measurement selection was pH and ORP, specify your **Resolution** as **0.1 pH** or **0.01 pH**.

Then enter the **Damping** response time (for 90% recovery from a step change). You can enter a time up to 300 seconds expressed in seconds. To increase damping, use a higher response time. Damping applies only to compensated measurement data, not to temperature or absolute data.

#### ISE Concentration

If your Measurement selection was ISE Concentration, specify the **ISE Units** as **ppb**, **ppm**, %, or **Custom**.

Next, specify the ISE Scale as 0.9999, 9.999, 99.99, 999.9, or 9999.

If you selected **Custom** as your **ISE Unit**, you must name (text) that unit in **Custom Units**.

Then enter the **Damping** response time (for 90% recovery from a step change). You can enter a time up to 300 seconds expressed in seconds. To increase damping, use a higher response time. Damping applies only to compensated measurement data, not to temperature or absolute data.

# Temperature Configuration

Refer to Figure A-4 on page 63.

## Temp Unit

Specify **Temp Unit** as **degC** or **degF**. All references to temperature appear in the specified units within the transmitter software.

## Temp Mode

Specify the **Temp Mode** as **Auto** or **Manual**.

In **Auto** mode, the temperature follows the temperature input RTD and you can set a temperature fail signal value (**Fail Temp**), in case the RTD fails, at the temperature at which you expect the process to be operating.

In **Manual** mode, the temperature can be set at a fixed temperature value (**Manual Temp**) and resistance inputs on the temperature terminal are ignored.

## **Temperature Compensation**

Refer to Figure A-5 on page 64.

This section of the structure asks you to specify the temperature compensation if you are measuring pH or ISE.

#### — NOTE

This section does not appear if you selected **ORP** as your **Measurement**.

If **pH** or **pH** and **ORP** was chosen as your **Measurement**, specify **Standard**, **Ammonia**, or **Custom**. **Standard** assumes a glass or antimony electrode and applies the Nernst equation. The nominal temperature compensation range is -30 to +200° C (-22 to +392° F). **Ammonia** compensates for traces of ammonia in addition to the standard compensation. **Custom** allows you to specify particular solution characteristics into the transmitter's memory. When using Ammonia or Custom compensation, all measurements are corrected back to a reference temperature measurement value. Therefore, you are asked to specify a reference temperature. The reference temperature (**Reference Temp**) can be set within the temperature compensation range. For Custom, a number of points needs to be specified. The number of points (**Points**) can be specified from 2 to 21 points. Each point specifies a value at a certain temperature. The temperatures can be set from -30 through + 200°C (-22 through +392°F). The temperature units were specified in the previous section. The values can be specified within the current scale.

#### — NOTE

The temperature values must be entered in increasing or decreasing order or the display will read **Slope Error**.

If **ISE Concentration** was chosen as your **Measurement**, you must specify **Standard** or **Custom**. **Custom** causes you to specify a reference temperature and a number of points to plot a compensation curve. The procedure is described immediately above.

## Analog Out (PV)

Refer to Figure A-6 on page 64.

This section of the structure enables you to specify what measurement the analog output reflects and the minimum and maximum range values for the output just specified. It also enables you to specify the measurement for the HART secondary, tertiary, and fourth measurements.

First, specify AO Source Measurement as Measurement, Temperature, ORP, Absolute, Glass Resistance, Reference Res (reference junction resistance), or ATC Resistance.

- NOTE

AO Source Measurement selections are limited by your configuration of sensor and diagnostics.

Next, in **Lower Value** enter the value of that measurement that produces an output of 4 mA and in **Upper Value**, the value of the measurement that produces an output of 20 mA. The lower and upper values must differ by a minimum amount. That minimum span amount is 0.5 pH for pH measurement, 32 mV for ORP measurement, and the amount shown in Table 8 for ISE measurement.

Scale	Minimum Span
9999	80 ppm
999.9	8 ppm
99.99	0.8 ppm
9.999	0.08 ppm
0.9999	0.008 ppm

Table 8. Minimum Output Span for ISE Measurement

Then specify the measurements of HART SV, HART TV, and HART QV as Measurement, Temperature, ORP, Absolute, Glass Resistance, Reference Res, or ATC Resistance. The secondary measurement is frequently configured to temperature, the tertiary measurement to Absolute, and the fourth measurement (if used) to ATC Resistance.

# Display Format


Refer to Figure A-7 on page 65.

The Display Format section of the structure enables you to display one, two, or three measurements. Then you can specify what measurement you want on each line of the display.

In **Display Format**, first specify the number of measurements to be displayed by selecting **Single Line**, **Double Line**, or **Triple Line**. Then specify what measurement you want displayed on **Line 1**, **Line 2** (if Double or Triple), and **Line 3** (if Triple).

# 1-Line Display Measurements 7.0

#### 2-Line Display



#### 3-Line Display




Figure 16. Measurement Display

## **AO** Failsafe

Refer to Figure A-8 on page 65.

#### — NOTE

The AO Failsafe parameter is not available with multidrop communication.

A fail-safe output is delivered for those diagnostic failures that have been configured **On** as well as other failures. The AO Failsafe section of the structure enables you to specify the analog output under these fault conditions.

In AO Failsafe, select **Fail Low** to drive the analog output to 3.6 mA; select **Fail High** to drive the analog output to 22 mA; select **Off** to omit this feature (continues to follow the measurement). If **Off** is selected, you can continue to monitor failures using the HART protocol.



Invensys recommends that this feature be configured to protect your process in case of a fault.

## **HART** Digital

Refer to Figure A-9 on page 65.

The HART Digital section of the structure enables you to set parameters for HART communication.

#### In Poll Address:

Enter a number from 0 through 15 if using HART Version 5.

- NOTE -

In HART Version 5, address 1 through 15 is reserved for multidrop.

Enter a number from 0 through 63 if using HART Version 6 or 7.

If using HART Version 6 and 7, enter the **mA Loop Mode** as **Active** or **Multi-Drop**.

**Preambles**, the number of preambles to be sent in a response message from the transmitter to the host, are read only.

In **HART Version**, enter the version of the firmware being used.

— NOTE

The Device Description (DD) must match the HART firmware version.

HART 5 - - - DD  $\leq$  14053F HART 6 - - - DD  $\geq$  140540 HART 7 - - - DD  $\geq$  140580

## **Diagnostics**

Refer to Figure A-10 on page 66.

This section of the structure allows you to configure fault messages that can appear on your display. In **Diagnostics**, you can elect to enable (**On**) or disable (**Off**) all of the diagnostics or each of the following individually: **Leakage**, **ATC Short**, **ATC Open**, **Comp Range**, **Meas Range**, **Low Slope**, **Preamp**, **Reference Coating**, **Broken Glass**, and **Aging**. Each of these is discussed below. A typical approach is to initially disable all of the messages and to enable selected messages later when you find out that you require them. A fault symbol is displayed if a particular diagnostic is enabled and the fault occurs. If the diagnostics detects a failure, the analog output goes to the failsafe value if **AO Failsafe** was configured **On**.

## Leakage

This diagnostic reports a problem of severe liquid leakage into the sensor which causes an ATC short to solution ground. The diagnostic can be enabled or disabled.

## ATC Short, ATC Open

This diagnostic reports a problem if the resistance of the temperature compensator is greater or less than the expected resistance of the device configured. The diagnostic for each can be enabled or disabled.

## Comp Range

This diagnostic reports that the measurement or temperature is outside the range configured. The diagnostic can be enabled or disabled.

## Meas Range

This diagnostic reports that the measurement is over or under the analog output range that is configured. The diagnostic can be enabled or disabled.

## Low Slope

This diagnostic reports a problem usually associated with an aging glass electrode. It appears after a multipoint calibration in buffer solutions when the Nernst slope of the sensor becomes less than the user set limit. The limit can be set from 0 through 100 percent. It applies to the slope between any two points. The diagnostic can be enabled or disabled.

#### — NOTE -

- 1. This message does not appear for ORP measurement.
- 2. In Diagnostics, Low Slope applies to the slope between any two points. In Status mode, the slope is that closest to the isopotential point. Therefore it is possible to show a fault in Diagnostics mode but not in Status mode.

## Preamp

This diagnostic reports a failed preamplifier (in the sensor or junction box). It appears if the preamplifier draws too much power. A shorted preamplifier causes the transmitter to cease functioning.

#### — NOTE

If the transmitter is unresponsive, disconnect terminal 6. If the transmitter begins to function, it is a confirmation that the problem is in the preamplifier.

## Reference Coating

This diagnostic reports an increase in reference junction resistance possibly resulting from a fouled reference junction. The diagnostics check the resistance against solution ground. The message appears if the resistance is greater than the user set limit. The limit can be set from 0 through  $200~\mathrm{k}\Omega$  The diagnostic can be enabled or disabled.

#### Broken Glass

This diagnostic reports a problem in the resistance of a glass electrode in the probe. Resistance of a glass electrode is checked versus solution ground. An error message appears if the resistance is less than user set limit. Besides clearing, enabling, and disabling the message, you can limit the message to resistances below a set value. The **Glass Lo Limit** value may be entered between 0.10 and 1.10 M $\Omega$  You can also specify a **Cutoff** temperature above which this feature is disabled. **Cutoff** can be set between -30 and +200. The resistance of a glass bulb decreases (roughly is halved) for every 10 °C increase in temperature.

#### — NOTE

The diagnostic is disabled for ORP and ISE measurement.

### Aging

This diagnostic reports an aging glass electrode. The message appears after a multipoint calibration in pH buffer solutions when the Nernst slope of the sensor closest to the isopotential point has decreased sequentially five times. The diagnostic can be enabled or disabled.

## Auto Hold

Refer to Figure A-11 on page 66.

The Auto Hold section of the structure enables you to use the automatic hold parameter to automatically activate the Hold feature each time you enter Calibration or Configuration mode. In Auto Hold, select **On Present** to hold all values and states at their current level; **On Manual** to set all values and states at desired levels; or **Off** to omit this feature.

#### — NOTE -

If you select **On Manual**, go to Hold mode to change the values.

## **Config Timeout**

Refer to Figure A-12 on page 67.

The Config Timeout section of the structure enables you to specify the time in which the instrument brings you back to the Measure mode from another mode when no keyboard input has occurred. In Measure mode, **Timeout** also limits the time to view a display other than that configured in "Display Format" on page 37 that has been temporarily scrolled into view. Timeout can be configured to **Always Timeout**, timeout in online modes only (**Online Only**) or **Never Timeout**. The **Always Timeout** selection is recommended.

The timeout can be configured separately for front panel (**Front Panel**) and (**HART Communications**) operation. The time can be specified from 30 through 999 seconds.

## **Transmitter Tags**

Refer to "Transmitter Tags Structure" on page 67.

The Transmitter Tags section of the structure enables you to enter tags to identify your transmitter. Each can have a maximum number of characters as described below. When you have

finished entering a tag, press **ENTER**. These identifications appear in Status mode. For details on entering various characters, see page 18.

Tag Name Characters HART Message 32 8 HART Tag HART Long Tag 32 HART Descriptor 16 Tag Name 14 14 Location 6 Device Name

Table 9. Transmitter Tags

## Passcode Access

Refer to "Passcode Access Structure" on page 68.

The Passcode Access section of the structure enables you to limit access to change and/or view various parameters in the firmware. There are two Passcodes; Administrator Code and User Code. A person possessing the Administrator Code can change and view all parameters as well as establish what a person with User Code can access. A person with a User Code can only change and view what the administrator has allowed. Both codes are four digit codes.

#### NOTE

- 1. The initial factory default value for both Administrator and User passcodes is 0800
- 2. To bypass the passcode, the administrator must configure a passcode of 0000.

The configuration of this section is done in four steps.

- 1. In Admin Code, enter the four digit administrator code from 0 through 9999.
- 2. In User Code, enter the four digit user code from 0 through 9999.
- **3.** In User Change, you can elect to enable (**On**) or disable (**Off**) user access to each of the following parameters.

Calibrate	Temp Comp	HART Cfg
Cal Buffers	Sensor Cfg	Auto Hold
Hold	PV Cfg	Tags Config
Suspend Fault	Meas Cfg	Timeouts
Resume Fault	Display Cfg	Default Cfg
Clear History	Diag Cfg	

#### — NOTE

You can also make one selection to configure access to all the User Change parameters On or Off.

4. In User View, you can elect to enable (**On**) or disable (**Off**) user access to each of the following parameters.

Cal Buffers	Diags	Xmtr Tags
Temp Comp	HART	Timeouts
Temp Table	Auto Hold	Default

Display

#### NOTE

You can also make one selection to configure access to all the User View parameters On or Off.

## Calibration Parameters

Refer to "Calibration Parameters Structure" on page 69.

The Cal Parameters section of the structure enables you to specify:

- The calibration standard buffer solutions to be used if you are measuring pH and using the **Smart** solution calibration feature.
- The measurement and temperature stability for all calibrations.

## **Buffer Set**

You can select between American, NIST, European, DIN, MERCK, JIS 8802, or User Selectable as standard buffer set choices.

The pH values of common buffer solutions are shown in Table 10.

Buffer Solution	pH Values
American	1.68, 4.01, 7.00, 10,01, 12.45
NIST	1.68, 4.01, 6.87, 10,01, 12.45
European	4.61, 7.00, 9.18
DIN	1.68, 4.01, 6.86, 9.18, 12.45
MERCK	4.01, 7.00, 10.00
JIS 8802	1.68, 4.01, 6.86, 9.18, 12.45

Table 10. pH Value of Common Buffer Solutions

If you select **User Selectable**, you can select up to seven buffers from either standard buffer values from Table 10 or you can pick **Custom** and create a buffer with your own pH values. The pH values of the buffers you select must be a minimum of 2 pH apart. If you create a custom buffer, you must enter a nominal pH value for the buffer and then establish a curve of temperature values vs pH values. See Figure A-15 on page 69.

# Stability

The **Stability** parameter sets the measurement and temperature stability. It can be set from 25 through 1000%. 25% produces the most accurate measurement and temperature calibration. Therefore it causes the longest calibration time. Invensys recommends 100% for new installations.

# **Restore Configuration**

Refer to "Restore Config Structure" on page 69.

Configuring your transmitter involves the setting of many parameters specific for the application. In some cases, you may wish to employ the transmitter for more than one application (at different times). Rather than having to change several parameters, the 876PH allows you to save up to two unique and complete configuration profiles including the calibrations associated with these profiles. Either of these two profiles can be restored at any time to facilitate a quick and easy change of the transmitter to a presaved configuration. In addition to the two user profiles, the transmitter also includes a "factory default" configuration which allows you to return the transmitter to its original factory configuration at any time.

In Restore Config, select Restore User 1, Restore User 2, or Restore Factory and at the question Restore User 1 Configuration?, Restore User 2 Configuration?, or Restore Factory Configuration?, answer Yes or No.

NOTE		
— NOTE ————		
The two user profiles are saved in	"Save User Configuration"	on page 47.

# Diagnostic Mode

Refer to Figure 18.

The Diagnostic mode enables you to:

- View active faults
- Suspend those faults for one hour
- Resume any suspended faults
- View the diagnostic history log
- Save two user configurations

To enter the Diagnostic mode, press the **FUNCTION** key and then the **DIAG** key. Press **ENTER**. The display returns to Measure mode when you press the **FUNCTION** key and then the **MEASURE** key or when the timeout period expires. If there are no key presses within the configured Timeout period, the transmitter reverts to Measure mode and the outputs remain on hold.

## **View Faults**

Select **View Faults** to view the most severe fault. Use the Up and Down arrow keys to view other faults. Four pieces of information are given for each fault: The type of fault, the severity of the fault, the fault itself, and a factory code (used only to help our Golobal Client Service Center identify the cause if you call for help). See Figure 17. If there are no faults, the display reads **No Active Faults**.




Figure 17. Sample View Faults Display

Table 11. List of Possible Faults

Type	Fault	Severity	Corrective Action
	Analog Calibration Lost	Failed	
	Front End Communications	Service Now	
	Meas Calibration Lost	Failed	
	Memory Failure	Most Severe	
	Memory Write Failure	Most Severe	
Electronics	Operating System	Most Severe	Contact our
Liectionics	Processor Registers	Most Severe	Global Customer Support Center
	RAM Failure	Most Severe	
	Software Failure	Most Severe	
	Solution Ground Potential	Failed	
	Temp Calibration Lost	Failed	
	Watchdog Failure	Most Severe	
Config	Temp Comp Table	Failed	Reconfigure Temp Comp Table Settings. See page 36.
	Analog Overrange	Failed	Reconfigure analog output settings.
	ATC Open Circuit	Failed	<ol> <li>Check ATC wiring and configuration.</li> <li>Replace sensor</li> </ol>
	ATC Short Circuit	Failed	1.Check ATC wiring and configuration.     2. Replace sensor
	Measurement Overflow	Failed	Contact our Global Customer Support Center
	Sensor Coating	Service Soon	Clean sensor     Replace sensor.
	Sensor Glass Aging	Service Soon	<ol> <li>Perform 2-point calibration.</li> <li>Replace sensor.</li> </ol>
Sensor	Sensor Glass Broke	Failed	<ol> <li>Check cutoff temperature.</li> <li>Inspect electrode.</li> <li>Replace sensor.</li> </ol>
	Sensor Leaking	Failed	Replace sensor.
	Sensor Low Slope	Service Soon	<ol> <li>Check configuration.</li> <li>Repeat calibration.</li> <li>Replace sensor.</li> </ol>
	Temperature Overflow	Failed	<ol> <li>Check ATC wiring and configuration.</li> <li>Replace sensor.</li> </ol>
	Temp Comp Overrange	Service Now	
	Temp Sensor 3rd Wire	Service Now	<ol> <li>Check ATC configuration</li> <li>Connect 3rd wire of temp sensor</li> </ol>
Calib	Calibration Required	Service Now	Perform measurement calibration.

# History Log

Select **History** Log and press **ENTER** to view or erase the diagnostic history logs. Use the Up and Down arrow keys to select All History Logs, Calibration Log, Error Log, Operation Log. You can also select Clear History. however clearing the history log requires entering your passcode.

# Suspend Faults and Resume Faults

Select **Suspend Faults** to suspend the present faults for one hour. The display asks for your passcode. An incorrect passcode returns you to the start of the Diagnostic menu. A correct passcode causes the prompt **Suspend Fault?** to be displayed. If you answer **Yes**, the message **Faults Suspended** is displayed. After either a **Yes** or **No** reply, the Diagnostic menu is displayed. Each suspended fault is inhibited from reoccurring for one hour from the time the Diagnostic mode is entered.

Select **Resume Faults** to resume all suspended faults.

# Save User Configuration

Configuring your transmitter involves the setting of many parameters specific for the application. In some cases, you may wish to employ the transmitter for more than one application (at different times). Rather than having to change several parameters, the 876PH allows you to save up to two unique and complete configuration profiles including the calibrations associated with these profiles.

Either of these two profiles can be restored at any time to facilitate a quick and easy change of the transmitter to a presaved configuration. See "Restore Configuration" on page 44.

Select **Save Config 1** or **Save Config 2** to save your configuration. The display asks for your passcode. An incorrect passcode returns you to the start of the Diagnostic menu. A correct passcode causes the prompt **Save Config #?** to be displayed. If you answer **Yes**, the message **Configuration Saved** is displayed. If you answer **No**, the message displayed is **Action Cancelled**.




Figure 18. Diagnostic Mode Structure

# 6. Operation Via HART Communicator

#### — NOTE -

- 1. For HART communications, a 250  $\Omega$  load resistor must be present in the power supply loop.
- 2. For proper communication with a HART Communicator, the communicator must contain the proper DD for the 876PH Transmitter. This DD is available from Foxboro or any other authorized HART Foundation source.
- 3. If the DD shows "access restricted", start over and re-enter the passcode.

# **Entering Modes**

From the home menu, select the mode to be entered. If **Save to Xmtr** appears, it must be handled before entering a different mode. If a passcode is required, select **Enter Passcode** before accessing a new mode.

# Saving Changes

Changes must be saved before going to another mode.

If the **Send** soft key appears on the screen, it must be pressed before saving changes.

Press **Home**, select **Save to Xmtr**. Answer the **Save changes?** question by selecting **Yes** or **No**, and pressing **ENTER**. If errors exist, the **Fix Errors?** question appears. **No** discards all changes; **Yes** provides the title of the first parameter with a problem which must then be resolved.

#### — NOTE

The **Save** soft key refers to a local communicator copy of the parameters, not the transmitter's **Save changes**.

## HART Online Menu




Figure 19. 876PH Transmitter Online Menu Tree (1 of 2)

#### CONFIGURATION (If pH or pH and ORP) 1 Measurement 1 Sensor 7 AO Failsafe Off 2 Electrode Fail Low 3 Slope Fail High 4 Isopotential 5 Temp Type 8 HART Digital 1 Poll Address (If ISE) 2 Preambles 3 HART Version 1 Electrode 2 Isopotential 9 Diagnostics 3 Valence 1 Enable/Disable Diag 4 Temp Type 2 Glass Lo Limit 3 Glass Cutoff 4 Slope Limit (If ORP) 5 Coat limit 1 Temp Type Auto Hold Off (If pH or pH and ORP) On Present 2 Meas Config 1 pH Resolution On Manual 2 Damping Timeout 1. Timeout (If ISE) 1 ISE Units Transmitter Tags 1 HART Message 2 Damping 2 HART Tag 3 HART Descriptor (If ORP) 4 Tag Name 1 Damping 5 Location 6 Device name 3 Temp Config 1 Temp units 2 Temp Mode Passcode Access 1 Admin Code 3 Manual Temp 2 User Code or Fail Temp 3 User Change 4 User view 4 Temp Comp Standard Ammonia Cal parameters 1 Buffer Set Custom 2 Stability 5 Analog Out 1 AO Source Restore Config 1 Restore User 1 2 Lower Value 2 Restore User 2 3 Upper Value 3 Restore Factory 4 HART SV 5 HART TV 6 HART QV 6 Meas Display 1 Display Format 2 Line 1 3 Line 2 4 Line 3

Figure 20. 876PH Transmitter Online Menu Tree (2 of 2)

# **Explanation of Parameters**

#### - NOTE -

- 1. The fast-key path shown is based on a frequently used configuration. If certain parameters are configured off or infrequently used parameters configured on, the fast-key path may be different.
- 2. For more detailed explanation of parameters, see "Operation Via Local Display" on page 17.

Parameter	Fast-Key Path	Explanation
Measurement Mode		
Absolute	1,3	Displays the absolute (uncompensated) measurement value.
Analog Output	1,4	Displays the analog output in mA.
HART PV	1,5	Displays the HART primary value.
HART QV	1,8	Displays the HART fourth value.
HART SV	1,6	Displays the HART secondary value.
HART TV	1,7	Displays the HART tertiary value.
Measurement	1,1	Displays the measurement (PV) value.
Temperature	1,2	Displays the temperature value in specified engineering units.
Diagnostic Mode		
History Log	2,2	Used to view or erase one or more diagnostic history logs.
Resume Faults	2,4	Used to resume suspended faults.
Save Config 1	2,5	Used to save your configuration.
Save Config 2	2,5	Used to save your configuration.
Suspend Faults	2,3	Used to suspend faults for one hour.
View Faults	2,1	Displays the most severe fault and other faults if desired.
Configure Mode	<u> </u>	
Sensor	3,1	Path to sensor related parameters.
Measure Config	3,2	Path to measure related parameters.
Temp Config	3,3	Path to temperature related parameters.
Temp Comp	3,4	If measuring pH or ISE, used to specify temperature compensation as Standard, Ammonia, or Custom.
Analog Out (PV)	3,5	Path to analog output related parameters.
Meas Display	3,6	Path to display related parameters.
AO Failsafe	3,7	Used to specify the analog output under fault conditions.
HART Digital	3,8	Path to HART related parameters.
Diagnostics	3,9	Path to diagnostic related parameters.
Auto Hold		Used to configure all values and states to be held at their
		current level (On Present), at a desired level (On Manual)
		when triggered by a digital signal or when going into
		Calibration or Configuration mode. Select Off to omit
		this feature.

Parameter	Fast-Key Path	Explanation
Config Timeout		Used to specify the time in which you are returned to
		Measure mode when no keyboard input has occurred.
Transmitter Tags		Path to tag related parameters.
Passcode Access		Path to passcode related parameters.
Cal Parameters		Path to calibration related parameters.
Restore Config		Path to restoring the transmitter to a user stored or the
		factory configuration.
Measurement	3,1,1	Select the type of measurement (pH, pH and ORP, ISE
		Concentration, or ORP).
Electrode	3,1,2 (for pH)	If Measurement is pH or pH and ORP: select Electrode as
	3,1,1 (for ISE)	Glass, Antimony, or Other.
		If Measurement is ISE: select Electrode (polarity) as
		Positive or Negative.
Scope	3,1,3	If Electrode is Other: Enter the slope.
Isopotential	3,1,4 (for pH)	If Measurement is pH, pH and ORP, or ISE: Enter the
	3,1,2 (for ISE)	Isopotential point.
Temp Type	3,1,5 (for pH)	Select the Temp Type (RTD) from the picklist provided.
	3,1,4 (for ISE)	
	3,1,1 (for ORP)	
Valence	3,1,3	If Measurement is ISE: Select the Valence as monovalent
	(2)	or Divalent.
pH Resolution	3,2,1 (for pH)	If measurement is pH: Select pH Resolution as 0.1 or 0.01 pH.
Damping	3,2,2 (for pH)	Enter the damping response time.
	3,2,2 (for ISE)	
	3,2,1 (for ORP)	
ISE Units	3,2,1 (for ISE)	If Measurement is ISE: Select the ISE Unit as ppb, ppm,
		%, or Custom.
Temp Units	3,3,1	Select Temp Units as DegC or DegF.
Temp Mode	3,3,2	Select the Temp Mode as Auto or Manual.
Manual Temp	3,3,3	If Temp Mode is Manual: Enter a fixed temperature.
Fail Temp	3,3,3	If Temp Mode is Auto: Enter a temperature fail signal
		value.
AO Source	3,5,1	Select the AO Source from the picklist provided.
Lower Value	3,5,2	Enter the measurement value that is to produce 4 mA.
Upper Value	3,5,3	Enter the measurement value that is to produce 20 mA.
HART SV	3,5,4	Select the SV measurement from the picklist provided.
HART TV	3,5,5	Select the TV measurement from the picklist provided.
HART QV	3,5,6	Select the QV measurement from the picklist provided.
Display Format	3,6,1	Select the Display Format as Single, Double, or Triple.
Line 1	3,6,2	Select the measurement to be displayed on Line 1.
Line 2	3,6,3	Select the measurement to be displayed on Line 2.
Line 3	3,6,4	Select the measurement to be displayed on Line 3.

A nonzero number specifies multidrop applications.	Parameter	Fast-Key Path	Explanation
Preambles  3,8,2  Displays the number of preambles to be sent in a response message from the transmitter to the host.  HART Version  3,8,3  Used to specify the HART version.  Finable/Disable Diag  3,9,1  Turn On or Off the various diagnostics.  Glass Lo Limit  3,9,2  If the Glass diagnostic is On: Enter a low resistance limit.  Glass Cutoff  3,9,3  If the Glass diagnostic is On: Enter a Cutoff temperature.  Slope Limit  3,9,5  If the Reference Coating diagnostic is On: Enter a Cutoff temperature.  Coat Limit  3,9,5  If the Reference Coating diagnostic is On: Enter a Coat (resistance) Limit.  HART Message  HART Tag  Enter a HART Message (32 characters maximum).  Enter a HART Descriptor (16 characters maximum).  Enter a HART Descriptor (16 characters maximum).  Enter a HART Descriptor (16 characters maximum).  Enter a Location (14 characters maximum).  Enter a Device Name  Admin Code  User Code  User Code  User Code  User Code  User Change  Turn On or Off the various parameters the user is allowed to change.  User View  Turn On or Off the various parameters the user is allowed to view.  Buffer Set  Seability  Enter a value (%) for measurement/temperature stability.  Restore User 1  Enables you to restore a saved user configuration.  Restore Factory  Enables you to restore a saved user configuration.  Restore Factory  Enables you to restore a saved user configuration.  Restore Factory  Enables you to restore a saved user configuration.  Enter a Value (%) for measurement temperature measurement  Displays the absolute measurement  Absolute  4,1,1  Displays the temperature measurement  Temp Status  4,1,2  Displays the status of the temperature measurement  Temp Status  4,1,5  Displays the status of the temperature sensor  Measurement  4,1,7  Displays the temperature sensor resistance  T Sensor Status  4,1,6  Displays the temperature sensor fesistance  Displays the reference junction resistance  Displays the reference junction resistance  Preference  Displays the resistance of the glass electrode  Displays the resista	Poll Address	3,8,1	Enter the polling address to a number from 0 through 15.
message from the transmitter to the host.  HART Version 3.8,3 Used to specify the HART version.  Enable/Disable Diag 3.9,1 Turn On or Off the various diagnostics.  Glass Lo Limit 3.9,2 If the Glass diagnostic is On: Enter a low resistance limit.  Glass Cutoff 3.9,3 If the Glass diagnostic is On: Enter a Cutoff temperature.  Slope Limit 3.9,4 If the Low Slope diagnostic is On: Enter the Slope Limit.  Coat Limit 3.9,5 If the Reference Coating diagnostic is On: Enter a Coat (resistance) Limit.  HART Message Enter a HART Message (32 characters maximum).  HART Message Enter a HART Message (32 characters maximum).  HART Tag Enter a HART Tag (8 characters maximum).  HART Descriptor Enter a HART Descriptor (16 characters maximum).  Enter a Tag Name (14 characters maximum).  Enter a Location (14 characters maximum).  Enter a Device name (6 characters maximum).  Enter a Device name (6 characters maximum).  Admin Code Enter a 4-digit Administrator Code.  User Code User Code  User Change Turn On or Off the various parameters the user is allowed to change.  User Wiew Turn On or Off the various parameters the user is allowed to view.  Buffer Set Sclect the Buffer from the picklist provided.  Scability Enter a value (%) for measurement/temperature stability.  Restore User 1 Enables you to restore a saved user configuration.  Restore User 2 Enables you to restore a saved user configuration.  Restore Ver 2 Enables you to restore a saved user configuration.  Restore Wode  Temperature 4,1,1 Displays the temperature measurement  Temp Status 4,1,2 Displays the status of the temperature measurement  Absolute Status 4,1,4 Displays the status of the absolute measurement  Temp Sensor 4,1,5 Displays the status of the desorter measurement  Temp Sensor 4,1,5 Displays the temperature sensor resistance  T Sensor Status 4,1,6 Displays the temperature sensor resistance  T Sensor Status 4,1,8 Displays the status of the desurement  Displays the status of the glass electrode  Displays the resistance of the glass electrode  Displays the reference			
HART Version 3,8,3 Used to specify the HART version.  Enable/Disable Diag 3,9,1 Turn On or Off the various diagnostics.  Glass Lo Limit 3,9,2 If the Glass diagnostic is On: Enter a low resistance limit.  Glass Cutoff 3,9,3 If the Glass diagnostic is On: Enter the Slope Limit 3,9,4 If the Low Slope diagnostic is On: Enter the Slope Limit.  Coat Limit 3,9,5 If the Reference Coating diagnostic is On: Enter a Coat (resistance) Limit.  HART Message Enter a HART Message (32 characters maximum).  HART Tag Enter a HART Descriptor (16 characters maximum).  Enter a HART Descriptor (16 characters maximum).  Enter a Tag Name (14 characters maximum).  Enter a Tag Name (14 characters maximum).  Enter a Device name (6 characters maximum).  Device Name Enter a Device name (6 characters maximum).  Enter a Device name (6 characters maximum).  Enter a 4-digit User Code.  User Code Enter a 4-digit User Code.  User Change Turn On or Off the various parameters the user is allowed to change.  User View Turn On or Off the various parameters the user is allowed to view.  Buffer Set Select the Buffer from the picklist provided.  Enter a value (%) for measurement/temperature stability.  Restore User 1 Enables you to restore a saved user configuration.  Restore Factory Enables you to restore a saved user configuration.  Restore Factory Enables you to restore the factory configuration.  Finally the factory configuration of the temperature measurement of the plays the estatus of the emperat	Preambles	3,8,2	
Enable/Disable Diag 3,9,1   Turn On or Off the various diagnostics.  Glass Lo Limit 3,9,2   If the Glass diagnostic is On: Enter a low resistance limit.  3,9,3   If the Glass diagnostic is On: Enter a Cutoff temperature.  Slope Limit 3,9,4   If the Low Slope diagnostic is On: Enter the Slope Limit.  Coat Limit 3,9,5   If the Reference Coating diagnostic is On: Enter a Coat (resistance) Limit.  HART Message   Enter a HART Message (32 characters maximum).  Enter a HART Message (32 characters maximum).  HART Tag   Enter a HART Descriptor (16 characters maximum).  Enter a Tag Name (14 characters maximum).  Enter a Location (14 characters maximum).  Enter a Device name (6 characters maximum).  Enter a Device name (6 characters maximum).  Enter a 4-digit Administrator Code.  User Code   Enter a 4-digit User Code.  User Change   Turn On or Off the various parameters the user is allowed to change.  User View   Turn On or Off the various parameters the user is allowed to view.  Buffer Set   Select the Buffer from the picklist provided.  Stability   Enter a value (%) for measurement/remperature stability.  Ensetore User 2   Enables you to restore a saved user configuration.  Restore User 2   Enables you to restore a saved user configuration.  Enables you to restore a factory configuration.  Enables you to restore the factory configuration.  Enables you to restore the factory configuration.  Enables you to restore a saved user configuration.  Displays the temperature measurement  Displays the status of the temperature measurement  Temp Status 4,1,2 Displays the status of the temperature sensor resistance  Temp Sensor Status 4,1,6 Displays the status of the measurem			
Glass Lo Limit 3,9,2 If the Glass diagnostic is On: Enter a low resistance limit. Glass Cutoff 3,9,3 If the Glass diagnostic is On: Enter a Cutoff temperature. Slope Limit 3,9,4 If the Low Slope diagnostic is On: Enter the Slope Limit. Coat Limit 3,9,5 If the Reference Coating diagnostic is On: Enter a Coat (resistance) Limit.  HART Message Enter a HART Message (32 characters maximum). Enter a HART Descriptor [16 characters maximum]. Enter a HART Descriptor (16 characters maximum). Enter a HART Descriptor (16 characters maximum). Enter a Location (14 characters maximum). Enter a 4-digit Administrator Code. User Code Enter a 4-digit User Code. User Code Enter a 4-digit User Code.  User Change Turn On or Off the various parameters the user is allowed to change.  User View Turn On or Off the various parameters the user is allowed to change.  User View Enter a value (%) for measurement/temperature stability. Enter a value (%) for measurement/temperature stability. Enables you to restore a saved user configuration. Restore User 2 Enables you to restore a saved user configuration. Enables you to restore a saved user configuration. Enables you to restore the factory configuration. Enables you to restore the factory configuration. Enables you to restore the factory configuration.  Emporature 4,1,1 Displays the temperature measurement Displays the status of the temperature measurement Absolute 4,1,3 Displays the status of the temperature sensor Displays the status of the temperature sensor Displays the status of the temperature sensor Displays the resistance of the glass electrode Displays the reference junction resistance Reference Enter Displays the status of the leasurement Displays the reference junction Testance Reference Enter Displays the status of the leasurement Displays the reference junction Testance Reference Enter Displays the status of the leasurement Displays the reference junction	HART Version	3,8,3	Used to specify the HART version.
Glass Cutoff  3,9,3  If the Glass diagnostic is On: Enter a Cutoff temperature. Slope Limit  3,9,4  If the Low Slope diagnostic is On: Enter the Slope Limit. The Reference Coating diagnostic is On: Enter a Coat (resistance) Limit. The Reference Coating diagnostic is On: Enter a Coat (resistance) Limit. The Reference Coating diagnostic is On: Enter a Coat (resistance) Limit. The Reference Coating diagnostic is On: Enter a Coat (resistance) Limit. The Reference Coating diagnostic is On: Enter a Coat (resistance) Limit. The Reference Coating diagnostic is On: Enter a Coat (resistance) Limit. The Reference Coating diagnostic is On: Enter a Coat (resistance) Limit. The Reference Coating diagnostic is On: Enter a Coat (resistance) Limit. The Reference Coating diagnostic is On: Enter a Coat (resistance) Limit. The Reference Coating diagnostic is On: Enter a Coat (resistance) Limit. The Reference Coating diagnostic is On: Enter a Coat (resistance) Limit. The Reference Coating diagnostic is On: Enter a Coating diagnostic is On: Enter a Coat (resistance) Limit. The Reference Coating diagnostic is On: Enter a Coating diag	Enable/Disable Diag	3,9,1	Turn On or Off the various diagnostics.
Slope Limit   3,9,4   If the Low Slope diagnostic is On: Enter the Slope Limit.   Coat Limit   3,9,5   If the Reference Coating diagnostic is On: Enter a Coat (resistance) Limit.   HART Message   Enter a HART Message (32 characters maximum).   Enter a HART Tag (8 characters maximum).   HART Descriptor   Enter a HART Descriptor (16 characters maximum).   Enter a HART Descriptor (16 characters maximum).   Enter a Tag Name (14 characters maximum).   Enter a Device Name   Enter a Device name (6 characters maximum).   Enter a Device name (6 characters maximum).   Enter a 4-digit Administrator Code.   Enter a 4-digit User Code.   User Code   Enter a 4-digit User Code.   Enter a 4-digit User Code.   User Change   Turn On or Off the various parameters the user is allowed to change.   User View   Turn On or Off the various parameters the user is allowed to view.   Enter a value (%) for measurement/temperature stability.   Entables you to restore a saved user configuration.   Entables you to restore a saved user configuration.   Enables you to restore a saved user configuration.   Enables you to restore the factory configuration.   Enter A 1,1,1	Glass Lo Limit	3,9,2	If the Glass diagnostic is On: Enter a low resistance limit.
Coat Limit   3,9,5   If the Reference Coating diagnostic is On: Enter a Coat (resistance) Limit.	Glass Cutoff	3,9,3	If the Glass diagnostic is On: Enter a Cutoff temperature.
(resistance) Limit.  HART Message  Enter a HART Message (32 characters maximum).  HART Descriptor  Enter a HART Descriptor (16 characters maximum).  Enter a Tag Name (14 characters maximum).  Location  Enter a Location (14 characters maximum).  Device Name  Enter a Device name (6 characters maximum).  Enter a 4-digit Administrator Code.  User Code  User Code  User Change  User Change  User View  Turn On or Off the various parameters the user is allowed to change.  User View  Turn On off the various parameters the user is allowed to view.  Buffer Set  Select the Buffer from the picklist provided.  Stability  Enter a value (%) for measurement/temperature stability.  Restore User 1  Enables you to restore a saved user configuration.  Restore User 2  Enables you to restore a saved user configuration.  Restore Factory  Status Mode  Temperature  4,1,1  Displays the temperature measurement  Temp Status  4,1,2  Displays the status of the temperature measurement  Temp Status  4,1,4  Displays the status of the temperature measurement  Temp Sensor  4,1,5  Displays the status of the temperature sensor resistance  T Sensor Status  4,1,6  Displays the status of the temperature sensor resistance  T Sensor Status  4,1,6  Displays the status of the measurement  Displays the measurement  Displays the measurement  Meas Status  A,1,6  Displays the reference junction resistance  Displays the reference junction resistance  Displays the reference junction  Displays the name of the last operator	Slope Limit	3,9,4	If the Low Slope diagnostic is On: Enter the Slope Limit.
HART Message HART Tag Enter a HART Tag (8 characters maximum).  HART Tag Enter a HART Tag (8 characters maximum).  Enter a HART Descriptor (16 characters maximum).  Enter a Tag Name (14 characters maximum).  Location Enter a Location (14 characters maximum).  Device Name Enter a Device name (6 characters maximum).  Enter a dedigit Administrator Code.  User Code User Code User Change User View User User I Enter a value (%) for measurement/temperature stability.  Enter a value (%) for measurement/temperature stability.  Enables you to restore a saved user configuration.  Enables you to restore a saved user configuration.  Enables you to restore the factory configuration.  Enables you to restore the factory configuration.  Enables you to restore the factory configuration.  Enables the temperature measurement  Temp Status 4,1,1 Displays the temperature measurement  Temp Status 4,1,2 Displays the status of the temperature measurement  Absolute Status 4,1,4 Displays the status of the temperature sensor  Enables you to restore the factory configuration.  Displays the status of the absolute measurement  Displays the status of the temperature sensor  Measurement 4,1,7 Displays the status of the temperature sensor  Measurement 4,1,7 Displays the status of the temperature sensor  Measurement 4,1,7 Displays the status of the measurement  Displays the status of the temperature sensor  Measurement 4,1,7 Displays the measurement  Displays the status of the glass electrode  Displays the reference junction resistance	Coat Limit	3,9,5	
HART Tag   Enter a HART Tag (8 characters maximum).  HART Descriptor   Enter a HART Descriptor (16 characters maximum).  Tag Name   Enter a Tag Name (14 characters maximum).  Location   Enter a Device name (6 characters maximum).  Device Name   Enter a 4-digit Administrator Code.  User Code   Enter a 4-digit User Code.  User Change   Turn On or Off the various parameters the user is allowed to change.  User View   Turn On or Off the various parameters the user is allowed to view.  Buffer Set   Select the Buffer from the picklist provided.  Stability   Enter a value (%) for measurement/temperature stability.  Restore User 1   Enables you to restore a saved user configuration.  Restore User 2   Enables you to restore a saved user configuration.  Restore Factory   Enables you to restore the factory configuration.  Status Mode  Temp Status   4,1,1   Displays the temperature measurement  Temp Status   4,1,2   Displays the status of the temperature measurement  Absolute   4,1,3   Displays the status of the absolute measurement  Temp Sensor   4,1,5   Displays the status of the absolute measurement  Temp Sensor   4,1,6   Displays the status of the temperature sensor  Measurement   4,1,7   Displays the status of the temperature sensor  Measurement   4,1,8   Displays the status of the desounce of the glass electrode  Blass   4,1,9   Displays the status of the glass electrode  Displays the status of the resistance  Displays the resistance of the glass electrode  Displays the status of the reference junction  Calibrated By   Displays the status of the reference junction			(resistance) Limit.
Enter a HART Descriptor (16 characters maximum). Tag Name Enter a Tag Name (14 characters maximum). Location Enter a Location (14 characters maximum). Device Name Enter a Device name (6 characters maximum).  Enter a 4-digit Administrator Code. User Code Enter a 4-digit User Code. User Change Turn On or Off the various parameters the user is allowed to change. User View Turn On or Off the various parameters the user is allowed to view.  Buffer Set Select the Buffer from the picklist provided. Stability Enter a value (%) for measurement/temperature stability. Restore User 1 Enables you to restore a saved user configuration. Restore User 2 Enables you to restore a saved user configuration. Status Mode Temperature 4,1,1 Displays the temperature measurement Temp Status 4,1,2 Displays the status of the temperature measurement Absolute 4,1,3 Displays the status of the absolute measurement Temp Sensor 4,1,5 Displays the status of the absolute measurement Temp Sensor 4,1,6 Displays the temperature sensor resistance T Sensor Status 4,1,8 Displays the status of the temperature sensor Measurement 4,1,7 Displays the status of the measurement Glass 4,1,9 Displays the status of the glass electrode Displays the status of the glass electrode Displays the status of the glass electrode Displays the status of the reference junction Displays the status of the reference junction Displays the status of the ference junction Displays the status of the reference junction	HART Message		
Enter a Tag Name   Enter a Tag Name (14 characters maximum).   Location   Enter a Location (14 characters maximum).   Device Name   Enter a Device name (6 characters maximum).   Admin Code   Enter a 4-digit Administrator Code.   User Code   User Code   User Code.   User Change   Turn On or Off the various parameters the user is allowed to change.   User View   Turn On or Off the various parameters the user is allowed to view.   Buffer Set   Select the Buffer from the picklist provided.   Stability   Enter a value (%) for measurement/temperature stability.   Restore User 1   Enables you to restore a saved user configuration.   Restore User 2   Enables you to restore a saved user configuration.   Restore Factory   Enables you to restore the factory configuration.   Status Mode	HART Tag		Enter a HART Tag (8 characters maximum).
Enter a Location   Enter a Location (14 characters maximum).	HART Descriptor		Enter a HART Descriptor (16 characters maximum).
Enter a Device Name   Enter a Device name (6 characters maximum).	Tag Name		Enter a Tag Name (14 characters maximum).
Admin Code User Code User Code User Change  User Change  User Change  User View  Turn On or Off the various parameters the user is allowed to change.  User View  Turn On or Off the various parameters the user is allowed to view.  Buffer Set Select the Buffer from the picklist provided.  Stability Enter a value (%) for measurement/temperature stability.  Restore User 1 Enables you to restore a saved user configuration.  Restore Factory Enables you to restore a saved user configuration.  Enables you to restore the factory configuration.  Status Mode  Temperature  4,1,1 Displays the temperature measurement Temp Status 4,1,2 Displays the status of the temperature measurement Absolute 4,1,3 Displays the absolute measurement  Temp Sensor 4,1,4 Displays the status of the absolute measurement  Temp Sensor 4,1,5 Displays the status of the temperature sensor resistance  T Sensor Status 4,1,6 Displays the status of the temperature sensor  Measurement 4,1,7 Displays the measurement  Meas Status 4,1,8 Displays the status of the measurement  Displays the measurement  Meas Status Displays the resistance of the glass electrode  Displays the reference junction resistance  Displays the reference junction resistance  Displays the reference junction  Displays the status of the reference junction  Displays the reference junction  Displays the reference junction  Displays the status of the reference junction	Location		Enter a Location (14 characters maximum).
User Code User Change User Change  User View  Turn On or Off the various parameters the user is allowed to change.  User View  Turn On or Off the various parameters the user is allowed to view.  Buffer Set  Select the Buffer from the picklist provided.  Stability  Enter a value (%) for measurement/temperature stability.  Enables you to restore a saved user configuration.  Restore User 1  Enables you to restore a saved user configuration.  Restore Factory  Status Mode  Temperature  4,1,1  Displays the temperature measurement  Temp Status  4,1,2  Displays the status of the temperature measurement  Absolute  4,1,3  Displays the status of the absolute measurement  Temp Sensor  4,1,5  Displays the status of the absolute measurement  Temp Sensor Status  4,1,6  Displays the status of the temperature sensor resistance  T Sensor Status  4,1,7  Displays the status of the temperature sensor  Measurement  4,1,7  Displays the status of the measurement  Meas Status  4,1,8  Displays the status of the measurement  Displays the status of the measurement  Displays the status of the glass electrode  Displays the status of the glass electrode  Displays the reference junction resistance  Reference  Reference  Reference Status  Displays the statue of the reference junction	Device Name		Enter a Device name (6 characters maximum).
User Change  Turn On or Off the various parameters the user is allowed to change.  Turn On or Off the various parameters the user is allowed to view.  Buffer Set  Select the Buffer from the picklist provided.  Stability  Enter a value (%) for measurement/temperature stability.  Restore User 1  Enables you to restore a saved user configuration.  Restore Factory  Enables you to restore the factory configuration.  Status Mode  Temperature  4,1,1  Displays the temperature measurement  Temp Status  4,1,2  Displays the status of the temperature measurement  Absolute Status  4,1,4  Displays the status of the absolute measurement  Temp Sensor  4,1,5  Displays the status of the temperature sensor resistance  T Sensor Status  4,1,6  Displays the status of the temperature sensor  Measurement  4,1,7  Displays the status of the temperature sensor  Measurement  4,1,7  Displays the status of the measurement  Displays the status of the measurement  Displays the measurement  Meas Status  4,1,8  Displays the status of the measurement  Displays the status of the glass electrode  Glass  Glass  4,1,9  Displays the resistance of the glass electrode  Displays the reference junction resistance  Reference  Reference  Reference Status  Displays the statu of the reference junction  Displays the reference junction	Admin Code		Enter a 4-digit Administrator Code.
to change.  Turn On or Off the various parameters the user is allowed to view.  Buffer Set Select the Buffer from the picklist provided.  Stability Enter a value (%) for measurement/temperature stability.  Restore User 1 Enables you to restore a saved user configuration.  Restore Factory Enables you to restore the factory configuration.  Status Mode  Temperature 4,1,1 Displays the temperature measurement  Temp Status 4,1,2 Displays the status of the temperature measurement  Absolute 4,1,3 Displays the absolute measurement  Temp Sensor 4,1,5 Displays the status of the absolute measurement  Temp Sensor 4,1,5 Displays the temperature sensor resistance  T Sensor Status 4,1,6 Displays the status of the temperature sensor  Measurement 4,1,7 Displays the status of the temperature sensor  Measurement 4,1,7 Displays the status of the temperature sensor  Measurement 4,1,7 Displays the status of the measurement  Meas Status 4,1,8 Displays the status of the measurement  Displays the status of the glass electrode  Glass Glass 4,1,9 Displays the resistance of the glass electrode  Displays the reference junction resistance  Reference  Reference  Displays the statu of the reference junction  Displays the reference junction  Displays the reference junction	User Code		Enter a 4-digit User Code.
Turn On or Off the various parameters the user is allowed to view.  Buffer Set Select the Buffer from the picklist provided.  Enablity Enter a value (%) for measurement/temperature stability.  Enables you to restore a saved user configuration.  Restore User 2 Enables you to restore a saved user configuration.  Restore Factory Enables you to restore the factory configuration.  Status Mode  Temperature 4,1,1 Displays the temperature measurement  Temp Status 4,1,2 Displays the status of the temperature measurement  Absolute Status 4,1,4 Displays the status of the absolute measurement  Temp Sensor 4,1,5 Displays the temperature sensor resistance  T Sensor Status 4,1,6 Displays the status of the temperature sensor  Measurement 4,1,7 Displays the status of the temperature sensor  Measurement 4,1,7 Displays the status of the measurement  Meas Status 4,1,8 Displays the measurement  Glass 4,1,9 Displays the status of the glass electrode  Glass Status Displays the status of the glass electrode  Displays the status of the reference junction resistance  Displays the status of the reference junction	User Change		Turn On or Off the various parameters the user is allowed
to view.  Buffer Set Select the Buffer from the picklist provided. Stability Enter a value (%) for measurement/temperature stability.  Restore User 1 Enables you to restore a saved user configuration. Restore Factory Enables you to restore the factory configuration.  Status Mode Temperature 4,1,1 Displays the temperature measurement Temp Status 4,1,2 Displays the status of the temperature measurement Absolute Absolute Status 4,1,4 Displays the status of the absolute measurement Temp Sensor 4,1,5 Displays the temperature sensor resistance T Sensor Status 4,1,6 Displays the temperature sensor resistance T Sensor Status 4,1,7 Displays the status of the temperature sensor Measurement 4,1,7 Displays the status of the temperature sensor Measurement A,1,7 Displays the status of the measurement Displays the status of the measurement Displays the status of the measurement Displays the status of the glass electrode Displays the resistance Displays the reference junction resistance Displays the reference junction Displays the name of the last operator	_		to change.
Select the Buffer from the picklist provided.  Stability Enter a value (%) for measurement/temperature stability.  Enables you to restore a saved user configuration.  Restore User 2 Enables you to restore a saved user configuration.  Enables you to restore a saved user configuration.  Enables you to restore the factory configuration.  Status Mode  Temperature  4,1,1 Displays the temperature measurement  Temp Status 4,1,2 Displays the status of the temperature measurement  Absolute Absolute A1,3 Displays the status of the absolute measurement  Temp Sensor 4,1,5 Displays the temperature sensor resistance  T Sensor Status 4,1,6 Displays the status of the temperature sensor  Measurement 4,1,7 Displays the measurement  Meas Status 4,1,8 Displays the status of the measurement  Glass 4,1,9 Displays the status of the glass electrode  Glass Status Displays the status of the glass electrode  Displays the reference junction resistance  Displays the reference junction  Displays the name of the last operator	User View		Turn On or Off the various parameters the user is allowed
Enter a value (%) for measurement/temperature stability.  Restore User 1  Restore User 2  Enables you to restore a saved user configuration.  Restore Factory  Enables you to restore a saved user configuration.  Enables you to restore the factory configuration.  Status Mode  Temperature  4,1,1  Displays the temperature measurement  Temp Status  4,1,2  Displays the status of the temperature measurement  Absolute  4,1,3  Displays the status of the absolute measurement  Temp Sensor  4,1,5  Displays the status of the absolute measurement  Temp Sensor Status  4,1,6  Displays the status of the temperature sensor resistance  T Sensor Status  4,1,6  Displays the measurement  Measurement  Measurement  4,1,7  Displays the measurement  Measurement  Glass  4,1,8  Displays the status of the measurement  Glass  4,1,9  Displays the resistance of the glass electrode  Glass Status  Displays the status of the reference junction resistance  Reference  Reference Status  Displays the statue of the reference junction  Displays the statue of the reference junction  Displays the statue of the reference junction  Displays the name of the last operator			to view.
Restore User 1  Restore User 2  Enables you to restore a saved user configuration.  Restore Factory  Enables you to restore a saved user configuration.  Enables you to restore the factory configuration.  Status Mode  Temperature  4,1,1  Displays the temperature measurement  Temp Status  4,1,2  Displays the status of the temperature measurement  Absolute  4,1,3  Displays the absolute measurement  Temp Sensor  4,1,4  Displays the status of the absolute measurement  Temp Sensor  4,1,5  Displays the temperature sensor resistance  T Sensor Status  4,1,6  Displays the status of the temperature sensor  Measurement  4,1,7  Displays the status of the temperature sensor  Measurement  4,1,7  Displays the measurement  Meas Status  4,1,8  Displays the status of the measurement  Glass  4,1,9  Displays the status of the glass electrode  Displays the status of the glass electrode  Displays the reference junction resistance  Reference  Displays the statue of the reference junction  Displays the statue of the reference junction  Displays the name of the last operator	Buffer Set		Select the Buffer from the picklist provided.
Restore User 2 Restore Factory  Enables you to restore a saved user configuration.  Enables you to restore the factory configuration.  Status Mode  Temperature  4,1,1 Displays the temperature measurement  Temp Status  4,1,2 Displays the status of the temperature measurement  Absolute  4,1,3 Displays the absolute measurement  Temp Sensor  4,1,4 Displays the status of the absolute measurement  Temp Sensor  4,1,5 Displays the temperature sensor resistance  T Sensor Status  4,1,6 Displays the status of the temperature sensor  Measurement  4,1,7 Displays the measurement  Meas Status  4,1,8 Displays the status of the measurement  Glass  4,1,9 Displays the status of the glass electrode  Glass Status  Displays the resistance of the glass electrode  Displays the reference junction resistance  Reference  Displays the statue of the reference junction  Displays the statue of the reference junction  Displays the name of the last operator	Stability		Enter a value (%) for measurement/temperature stability.
Restore Factory  Status Mode  Temperature 4,1,1 Displays the temperature measurement Temp Status 4,1,2 Displays the status of the temperature measurement Absolute 4,1,3 Displays the absolute measurement Temp Sensor 4,1,5 Displays the status of the absolute measurement Temp Sensor 4,1,5 Displays the temperature sensor resistance T Sensor Status 4,1,6 Displays the status of the temperature sensor Measurement 4,1,7 Displays the measurement Meas Status 4,1,8 Displays the status of the measurement Glass 4,1,9 Displays the resistance of the glass electrode Glass Status Displays the status of the glass electrode Displays the reference junction resistance Reference Displays the statue of the reference junction Calibrated By Displays the name of the last operator	Restore User 1		Enables you to restore a saved user configuration.
Status Mode Temperature	Restore User 2		Enables you to restore a saved user configuration.
Temp Status 4,1,2 Displays the status of the temperature measurement Absolute 4,1,3 Displays the absolute measurement Absolute Status 4,1,4 Displays the status of the absolute measurement Temp Sensor 4,1,5 Displays the temperature sensor resistance T Sensor Status 4,1,6 Displays the status of the temperature sensor Measurement 4,1,7 Displays the measurement Meas Status 4,1,8 Displays the status of the measurement Glass 4,1,9 Displays the resistance of the glass electrode Glass Status Displays the status of the glass electrode Displays the reference junction resistance Displays the statue of the reference junction Calibrated By Displays the name of the last operator	Restore Factory		Enables you to restore the factory configuration.
Temp Status 4,1,2 Displays the status of the temperature measurement Absolute 4,1,3 Displays the absolute measurement Absolute Status 4,1,4 Displays the status of the absolute measurement Temp Sensor 4,1,5 Displays the temperature sensor resistance T Sensor Status 4,1,6 Displays the status of the temperature sensor Measurement 4,1,7 Displays the measurement Meas Status 4,1,8 Displays the status of the measurement Glass 4,1,9 Displays the resistance of the glass electrode Glass Status Displays the status of the glass electrode Displays the reference junction resistance Displays the statue of the reference junction Calibrated By Displays the name of the last operator	Status Mode	•	
Absolute 4,1,3 Displays the absolute measurement Absolute Status 4,1,4 Displays the status of the absolute measurement Temp Sensor 4,1,5 Displays the temperature sensor resistance T Sensor Status 4,1,6 Displays the status of the temperature sensor Measurement 4,1,7 Displays the measurement Meas Status 4,1,8 Displays the status of the measurement Glass 4,1,9 Displays the resistance of the glass electrode Displays the status of the glass electrode Displays the reference junction resistance Displays the statue of the reference junction Displays the name of the last operator	Temperature	4,1,1	Displays the temperature measurement
Absolute 4,1,3 Displays the absolute measurement Absolute Status 4,1,4 Displays the status of the absolute measurement Temp Sensor 4,1,5 Displays the temperature sensor resistance T Sensor Status 4,1,6 Displays the status of the temperature sensor Measurement 4,1,7 Displays the measurement Meas Status 4,1,8 Displays the status of the measurement Glass 4,1,9 Displays the resistance of the glass electrode Displays the status of the glass electrode Displays the reference junction resistance Displays the statue of the reference junction Displays the name of the last operator	Temp Status	4,1,2	Displays the status of the temperature measurement
Absolute Status 4,1,4 Displays the status of the absolute measurement Temp Sensor 4,1,5 Displays the temperature sensor resistance T Sensor Status 4,1,6 Displays the status of the temperature sensor Measurement 4,1,7 Displays the measurement Meas Status 4,1,8 Displays the status of the measurement Glass 4,1,9 Displays the resistance of the glass electrode Displays the status of the glass electrode Displays the reference junction resistance Displays the statue of the reference junction Calibrated By Displays the name of the last operator	Absolute	4,1,3	Displays the absolute measurement
Temp Sensor 4,1,5 Displays the temperature sensor resistance T Sensor Status 4,1,6 Displays the status of the temperature sensor Measurement 4,1,7 Displays the measurement Meas Status 4,1,8 Displays the status of the measurement Glass 4,1,9 Displays the resistance of the glass electrode Glass Status Displays the status of the glass electrode Displays the status of the glass electrode Displays the reference junction resistance Displays the statue of the reference junction Calibrated By Displays the name of the last operator	Absolute Status	4,1,4	
T Sensor Status  4,1,6 Displays the status of the temperature sensor  Measurement 4,1,7 Displays the measurement  Meas Status 4,1,8 Displays the status of the measurement  Glass 4,1,9 Displays the resistance of the glass electrode  Displays the status of the glass electrode  Displays the reference junction resistance  Displays the statue of the reference junction  Calibrated By Displays the name of the last operator	Temp Sensor	4,1,5	
Measurement4,1,7Displays the measurementMeas Status4,1,8Displays the status of the measurementGlass4,1,9Displays the resistance of the glass electrodeGlass StatusDisplays the status of the glass electrodeReferenceDisplays the reference junction resistanceReference StatusDisplays the statue of the reference junctionCalibrated ByDisplays the name of the last operator	T Sensor Status	4,1,6	Displays the status of the temperature sensor
Meas Status  4,1,8 Displays the status of the measurement Glass 4,1,9 Displays the resistance of the glass electrode Displays the status of the glass electrode Displays the reference junction resistance Displays the statue of the reference junction Calibrated By Displays the name of the last operator	Measurement	4,1,7	Displays the measurement
Glass 4,1,9 Displays the resistance of the glass electrode Glass Status Displays the status of the glass electrode Reference Displays the reference junction resistance Reference Status Displays the statue of the reference junction Calibrated By Displays the name of the last operator	Meas Status	4,1,8	
Glass Status  Displays the status of the glass electrode  Displays the reference junction resistance  Displays the statue of the reference junction  Calibrated By  Displays the name of the last operator	Glass	4,1,9	Displays the resistance of the glass electrode
Reference Displays the reference junction resistance Reference Status Displays the statue of the reference junction Calibrated By Displays the name of the last operator	Glass Status		Displays the status of the glass electrode
Reference Status  Displays the statue of the reference junction  Displays the name of the last operator	Reference		Displays the reference junction resistance
Calibrated By Displays the name of the last operator	Reference Status		
Calib Date Displays the date of last calibration (dd/mm/yyyyy)			
Displays the date of last canonation (dd/min/yyyy)	Calib Date		Displays the date of last calibration (dd/mm/yyyy)

Parameter	Fast-Key Path	Explanation
Slope (mV)		Displays the change in mV/pH or mV/decade of the most
		recent calibration
Slope (%)		Displays the deviation in percent of the slope of the most
		recent calibration compared to the standard
Asymmetry		Displays the asymmetry potential (mV difference between
		the theoretical isopotential point and the actual point due
		to the most recent calibration
Lo Cal Point		Displays values at the lower calibration point
Hi Cal Point		Displays values at higher calibration point
Analog Output		Displays the value of the analog output
Analog Output Status		Displays the status of the analog output
HART PV		Displays the HART primary value
PV Status		Displays the status of the HART primary value
HART SV		Displays the HART secondary value
SV Status		Displays the status of the HART secondary value
HART TV		Displays the HART tertiary value
TV Status		Displays the status of the HART tertiary value
HART QV		Displays the HART fourth value
QV Status		Displays the status of the HART fourth value
Model Code		Displays the transmitter model code
Sales Order		Displays the transmitter sales order number
Xmtr Serial Number		Displays the analyzer serial number
Firmware Revision		Displays the firmware revision level
Front End Revision		Displays the front end revision level
Boot Revision		Displays the boot revision level
Transmitter Type		Displays the transmitter type (876PH)
In Service		Displays the time in service in days
HART Tag		Displays the HART Tag name
HART Long Tag		Displays the HART Long Tag name (versions 6 and 7)
Tag Name		Displays the tag name
Location		Displays the location of the measurement
Device Name		Displays the device name
HART Descriptor		Displays the HART descriptor
HART Message		Displays the HART message
Calibrate Mode		
Calibrated By	5,1	Enter the name of the person calibrating the device and
,		the date of calibration.
Calibrate	5,2	Path to calibrating parameters.
mA Cal		Used to perform a mA Cal calibration.
Measurement		Used to perform a measurement calibration.
Temperature		Used to perform a temperature calibration.
ORP		Used to perform an ORP calibration.
ORP Restore		Used to restore an uncompensated ORP output.

Parameter	Fast-Key Path	Explanation
Hold Xmtr Output		
Off		Used to release the transmitter from Hold state.
On Present		Used to hold all values and states at their current level.
On Manual		Used to hold all values and states at desired levels.
DD Revision		Displays the DD Revision level.

# 7. Maintenance

## - warning -

This product contains components that have critical safety characteristics. **Do not** substitute components. Replace components only with identical factory supplied components. Component substitution may impair the electrical safety of this equipment and its suitability for use in hazardous locations.

The maintenance of the 876PH Transmitter is limited to replacement of the bezel/keypad assembly, the display printed wiring assembly (PWA), the processor PWA and the loop power (MAU) PWA. Attempts to repair printed wiring assemblies could result in damage and voiding of the warranty. The recommended repair procedure is return of the transmitter to the factory for repair.

To replace parts, refer to Figure 21.




Figure 21. Exploded View of 876PH Transmitter



Before replacing parts, be sure to turn power off.



#### CAUTION

This unit uses printed wiring assemblies with components that are highly susceptible to damage from electrostatic discharge (ESD). Relatively low static potential can rupture sensitive components resulting in degraded device characteristics or failure.

All printed wiring assemblies **must** be handled with the user grounded via a conductive wrist strap (between 100  $\Omega$  minimum and 1 M $\Omega$  maximum).

# Replacing the Bezel/Keypad Assembly (Item 10)

1. Unscrew the four screws (Item 1) on the corners of the bezel/keypad assembly and open the assembly (Item 10) downward.



#### -! CAUTION

The assembly does not open a full 180°. Do not press on it.

- 2. Remove four Screws (Item 9) and remove the Safety Cover (Item 14).
- 3. Remove four Standoffs (Item 7), disconnect the ribbon cable, and carefully lift off stack of boards.
- 4. Remove ground wire from the bezel/keypad assembly.
- 5. Remove one of the two door Hinges (Item 15 or 16) by removing the two Screws (Item 17) that secure it. Remove the door.
- **6.** Install the new door by reversing Steps 1 though 5.



#### -! CAUTION

When positioning stack of boards on the bezel/keypad assembly bosses, carefully fold the flex ground strap over the lower left boss.

# Replacing the Loop Power (MAU) PWA (Item 13)

1. Unscrew the four screws (Item 1) on the corners of the bezel/keypad assembly and open the assembly (Item 10) downward.



#### -! CAUTION

The assembly does not open a full 180°. Do not press on it.

- 2. Disconnect wires from power terminals.
- 3. Remove four Screws (Item 9) and remove the Safety Cover (Item 14).
- 4. Remove the four Screws (Item 8) that secures the MAU PWA (Item 13) to the Standoffs (Item 6).
- 5. Grasping the MAU PWA on both sides, carefully lift it straight up and off.
- **6.** Install the new MAU PWA by reversing Steps 1 though 5.

# Replacing the Processor PWA (Item 12)

- 1. Remove the MAU PWA as described immediately above.
- 2. Disconnect wires from sensor terminals.

- 3. Remove the four Screws (Item 5) that secures the Processor PWA (Item 12) to the Standoffs (Item 3).
- 4. Remove four Standoffs (Item 7) and save them.
- 5. Carefully separate the Processor PWA (Item 12) and Display PWA (Item 11).
- 6. Remove the four Screws (Item 4) and Standoffs (Item 6) from the Processor PWA (Item 12) and save them.
- 7. Install the new Processor PWA by reversing Steps 1 though 6.

# Replacing the Display PWA (Item 11)

1. Unscrew the four screws (Item 1) on the corners of the bezel/keypad assembly and open the assembly (Item 10) downward.




#### -! CAUTION

The assembly does not open a full 180°. Do not press on it.

- 2. Disconnect wires from power terminals.
- 3. Remove four Screws (Item 9) and remove the Safety Cover (Item 14).
- 4. Remove four Standoffs (Item 7), disconnect the ribbon cable, and carefully lift off stack of boards.
- 5. Remove the four screws (Item 2) that secures the Display PWA to Standoffs (Item 3).
- 6. Carefully separate the Processor PWA (Item 12) and Display PWA (Item 11).
- 7. Install the new Display PWA by reversing Steps 1 though 6.

# Appendix A. Configuration Structure Diagrams



- NOTE

Before entering Configuration mode, you must first enter a proper passcode. The factory default passcode is **0800**.

Figure A-1. Configuration Top Level Structure




Figure A-2. Sensor Configuration Structure




Figure A-3. Measurement Configuration Structure




Figure A-4. Temperature Configuration Structure




Figure A-5. Temperature Compensation Structure




Figure A-6. Analog Output Structure




Figure A-7. Measurement Display Structure



Figure A-8. AO Failsafe Structure





Figure A-9. HART Digital Structure



- (a) If Broken Glass Configured On
- (b) If Slope configured On
- (c) If Reference Coating configured On
- (d) Selections are limited by your configuration of measurement

Figure A-10. Diagnostics Structure



Figure A-11. Auto Hold Structure




Figure A-12. Timeout Structure




Figure A-13. Transmitter Tags Structure




Figure A-14. Passcode Access Structure




Figure A-15. Calibration Parameters Structure




Figure A-16. Restore Config Structure

# Appendix B. Configuration Table

This appendix contains information that helps you configure your transmitter. The information is presented in the form of a table containing each prompt/parameter, its limits, and its factory default value. It also provides space for you to record your specific configuration and notations.

— **NOTE**Bold print in the Factory Configuration column indicates the configuration resulting from the Configure Factory Defaults menu.




Figure	Prompt/Parameter	Parameter Limits	Factory Configuration	User Configuration	Remarks and Notes
A-1	Config	Sensor			
		Meas Config			
		Temp Config			
		Temp Comp			
		Analog Out (PV)			
		Meas Display			
		AO Fail Safe			
		HART Digital			
		Diagnostics			
		Auto Hold			
		Config Timeout			
		Transmitter Tags			
		Passcode Access			
		Cal Parameters			
		Restore Config			

Figure	Prompt/Parameter	Parameter Limits	Factory Configuration	User Configuration	Remarks and Notes					
A-2	Sensor									
	Measurement	pH, pH and ORP, ISE Concentration, ORP	рH							
	If Measurement = pH or pH and ORP									
	Electrode	Glass, Antimony, Other	Glass							
	Slope	-100 to +100 mV/pH	-59.16		If Electrode = Other					
	Isopotential	pH: -2 through +16 pH ISE: 1.0 through 999.00	7		If Electrode = Other					
	Temp Type	2-Wire Pt 100 $\Omega$ , 2-Wire Pt 1000 $\Omega$ 3-Wire Pt 1000 $\Omega$ 3-Wire Pt 1000 $\Omega$ 3 k $\Omega$ Balco	3-Wire Pt 1000 $\Omega$							
	If Measurement = ISE C	Concentration								
	Electrode	Positive, Negative	Glass							
	Isopotential	-2000 to +2000 ppm	100							
	Valence	Monovalent, Divalent	Monovalent							
	Temp Type 2-Wire Pt $100~\Omega_{\rm c}$ 2-Wire Pt $1000~\Omega$ 3-Wire Pt $100~\Omega$ 3-Wire Pt $1000~\Omega$ 3 $k\Omega$ Balco		3-Wire Pt 1000 $\Omega$							
	If Measurement = mV (ORP)									
	Temp Type	2-Wire Pt 100 $\Omega$ , 2-Wire Pt 1000 $\Omega$ 3-Wire Pt 100 $\Omega$ 3-Wire Pt 1000 $\Omega$ 3 $k\Omega$ Balco	3-Wire Pt 1000 $\Omega$							
A-3	Meas Config									
	If Measurement = pH or	PH and ORP			•					
	pH Resolution	0.1 pH, 0.01 pH	0.01 pH							
	Damping	0 to 300 seconds	0		In minutes and seconds					
	If Measurement = ISE C	Concentration	ı	•	•					
	ISE Units	ppb, ppm, %, Custom	ppm							
	ISE Scale	0.9999. 9.999, 99.99, 999.9, 9999	99.99							
	Custom Units		(blank)		If ISE Units = Custom					
	Damping	0 to 300 seconds	0		In minutes and seconds					
	If Measurement = mV (0	ORP)	L							
	Damping	0 to 300 seconds	0		In minutes and seconds					
A-4	Temp Config									
	Temp Units	Celsius, Fahrenheit	Celsius							
	Temp Mode	Auto, Manual	Auto							
	Manual Temp		25°C		If Temp Mode = Manual					
	Fail Temp		25°C		If Temp Mode = Auto					

Figure	Prompt/Parameter Parameter Limits		Factory Configuration	User Configuration	Remarks and Notes
A-5	Temp Comp				
	Temp Comp	Standard, Ammonia, Custom	Standard		Not if Measurement = mV(ORP
	Ref Temp	-30 through +200 by 0.1°C -4 through +392 by 0.1°F	25°C		If Temp Comp = Custom
	Temp Table				1
	Num of Points	2 through 21	2		
	Point n				
	Temperature		-30°C, +200°C		
	Value		7.1, 7.0		
A-6	Analog Out (PV)				
	AO Source Meas	Measurement, Temperature, ORP, Absolute, Glass Resistance, Reference Res, ATC Resistance	Measurement		
	Lower Value		0 pH		At 4 mA
	Upper Value		14 pH		At 20 mA
	HART SV	Measurement, Temperature,	Temperature		
	HART TV	ORP, Absolute, Glass	Absolute		
	HART QV	Resistance, Reference Res, ATC Resistance	ATC Resistance		
A-7	Meas Display				
	Display Format	Single Line, Double Line, Triple Line	Double		
	Line 1	Measurement, ORP,	Measurement		ORP only if
	Line 2	Temperature, Absolute,	Temperature		Measurement = pH and
	Line 3	Analog Out	Absolute		ORP
A-8	AO Failsafe				
	AO Failsafe	Off, Fail Low, Fail High	Off		
A-9	HART Digital				
	Poll Address	0 - 15 (HART Version 5) 0 - 63 (HART Version 6, 7)	0		in HART Version 5, use 1-15 for multi-drop
	mA Loop Mode	Active, Multi-Drop			HART Version 6 and 7
	Preambles		7		
	HART Version	5, 6, or 7	5		
A-10	Diagnostics				
	Leakage	On, Off	Off		
	ATC Short	On, Off	Off		
	ATC Open	On, Off	Off		
	Comp Rng	On, Off	Off		
	Meas Rng	On, Off	Off		
	Low Slope	On, Off	Off		
	Preamp	On, Off	Off		
	Reference Coating	On, Off	Off		
	Broken Glass	On, Off	Off		
	Aging	On, Off	Off		
	Slope Limit	0 through 100%	80.0		If Low Slope enabled
	Coat Limit	0 through 200 k $\Omega$	40		If Coated Ref enabled
	Glass Lo Limit	0.10 and 1.10 M $\Omega$	1.0		If Broken Glass enabled.
	Glass Cutoff	-30 through +200°C	50°C		If Broken Glass enabled.
A-11	Auto Hold				
	Auto Hold	Off, On Present, On Manual	On Manual		See end of this table

Figure	Prompt/Parameter	Parameter Limits	Factory Configuration	User Configuration	Remarks and Notes
A-12	Config Timeout	Never Timeout Online Only Always Timeout	Always Timeout		
	Front Panel	30 to 999	600		
	HART Communications	30 to 999	999		
A-13	Transmitter Tags				
	HART Message	32 characters	(blank)		
	HART Tag	8 characters	(blank)		
	HART Long Tag	32 characters	(blank)		
	HART Descriptor	16 characters	(blank)		
	Tag Name	14 characters	(blank)		
	Location	14 characters	(blank)		
	Device Name	6 characters	(blank)		
A-14	Passcode Access				
	Admin Code	0000 to 9999	0800		
	User Code	0000 to 9999	0800		
	User Change				
	Calibrate	On, Off	On		
	Cal Buffers	On, Off	Off		
	Hold	On, Off	On		
	Suspend Fault	On, Off	Off		
	Resume Fault	On, Off	Off		
	Clear History	On, Off	Off		
	Temp Comp	On, Off	On		
	Sensor Cfg	On, Off	On		
	PV Cfg	On, Off	On		
	Meas Cfg	On, Off	On		
	Display Cfg	On, Off	On		
	Diag Cfg	On, Off	Off		
	HART Cfg	On, Off	Off		
	Auto Hold	On, Off	Off		
	Tags Cfg	On, Off	Off		
	Timeouts	On, Off	Off		
	Default Cfg	On, Off	Off		
	User View				
	Cal Buffers	On, Off	On		
	Temp Comp	On, Off	On		
	Temp Table	On, Off	On		
	Display	On, Off	On		
	Diags	On, Off	On		
	HART	On, Off	On		
	Auto Hold	On, Off	On		
	Xmtr Tags	On, Off	On		
	Timeouts	On, Off	On		
	Default	On, Off	On		

Figure	Prompt/Parameter	Parameter Limits	Factory Configuration	User Configuration	Remarks and Notes
A-15	Cal Parameters				
	Buffer Set	American, NIST, European, DIN, MERK, JIS 8802, User Select	American		
	Stability	25% through 1000%	100		рН
	User Select	Standard 1, 2, 3, 4, 5, 6, 7			
	# Standard	# Standard 1.68, 4.01, 4.61, 6.87, 7.00, 9.18, 10:00, 10.01, 12.45, Custom, not used			
	# Nominal				
	# Num Points	1 through 21			
	# Point n				
	# Temp Value n				
	# Value n				
A-16	Restore Config				
	Restore User 1	Yes, No	No		
	Restore User 2	Yes, No	No		
	Restore Factory	Yes, No	No		

If Auto Hold is set to On Manual, the transmitter hold output value limits and factory configuration is as follows:								
14	Manual Hold							
	AO Hold	3.6 to 22 mA	3.6 mA					
	PV Hold	(per source)	7 pH					
	SV Hold	(per source)	25°C					
	TV Hold	(per source)	0 mV					
	QV Hold	(per source)	1097.3 Ω					

# Appendix C. Auto Calibration

Auto calibration is provided for advanced users with automated systems for cleaning and recalibrating the probe. These systems require and external control system to orchestrate the process. The transmitter activates its output hold feature, and performs solution calibrations. Auto-service is initiated by the external control system. There is no scheduling nor time delays in the transmitter.

A typical calibration includes:

Activate output hold

Start solution calibration: low, providing known value (or pH auto-buffer)

Start solution calibration: high, providing known value (or pH auto-buffer)

Determine when calibration (low or high) is complete

Release output hold

There are two HART hold commands:

Activate Output Hold

Release Output Hold

There are three HART auto-calibration commands:

Start Calibration

Check Calibration Status

Finish Calibration

There are two commands used to save changes

Write Entity Byte Base

Read Entity Byte User Attributes

The following calibrations may be performed:

1,2,3,4,5 point manual measurement calibration

1,2,3,4,5 point smart measurement calibration

1,2 point temperature calibration

1 point ORP calibration

2 point mA calibration

#### Calibration Parameters

Use the following values for:

Calibration Type (1 byte)

Measurement Calibration 1st point - 102

Measurement Calibration 2nd point - 103

```
Measurement Calibration 3rd point - 104
   Measurement Calibration 4th point - 105
   Measurement Calibration 5th point - 106
   ORP - 107
   Temperature 1st point - 110
   Temperature 2nd Point -111
   mA Calibration 4 mA - 112
   mA Calibration 20 mA - 113
Number of Calibration Points - 1,2,3,4 or 5
Calibration Source
   Manual - 2
   Smart - 5
Application to calibrate - 1
Calibrator's Initials - 6 characters
Calibration Date - Hart Date format (year, month, day + 1900)
Calibration Units -
   рH
          - 11
   ORP - 14
   degC - 4
   degF - 3
   mΑ
          - 2
   %
          - 1
   ppm - 12
         - 13
   ppb
   custom - 15
```

### Command Sequence

- 1. If explicit output hold is required, issue Activate Output Hold (0x92). Otherwise, automatic hold ensues.
- 2. Activate automatic system to provide calibration buffer to the sensor.
- 3. Send Start Cal (0x94) command
- 4. Send Cal Status (0x95) command, read until measurement is stable
- 5. Send Finish Cal (0x96) command (unless Smart Cal)
- 6. Repeat steps 2-5 for each calibration point
- 7. Save changes by writing to save changes and check changes entities.

- a. Write 1 to byte entity 10.
- b. Write 0 to byte entity 11 R
- c. Read entity attributes (8F02000B)
- d. Repeat steps b & c until entity goes invisible.
- 8. Release any output hold (0x93)

#### Cmd 148 (0x94): Start Cal

(This command holds off QuickStart)

HART Command Type : Device Specific

HART Versions : 5 6 7

HART Operation Type : COMMAND

Code Section

Support In Boot : False
Support In Main : True
Support Function : StartCal.

#### Request: 22 (0x16) bytes (plus preambles)

Size	Туре	Fixed/V	HART Ver #	Example	Description
Size	Турс			Lxampic	1
1	byte	Fixed	567	0x82	Request Delimiter
5	byte	Var	567	0x;;;;;;;	Device Address
1	byte	Fixed	567	0x94	Command 148
1	byte	Fixed	567	0x0D(13d)	Data Length
					(not including checksum)
1	byte	Var	567	0x??	CalType
1	byte	Var	567	0x??	CalPoints
1	byte	Var	567	0x??	CalSource
1	byte	Var	567	0x??	AppIndex
3	date	Var	567	DDMMYY	CalDate
6	char	Var	567	xxxxxx	CalPerson
1	byte	Var	567	0x??	HART Checksum

#### Response: 24 (0x18) bytes (plus preambles)

Size	Туре	Fixed/V ar	HART Ver #	Example	Description
1	byte	Fixed	567	0x86	Response Delimiter
5	byte	Var	567	0x;;;;;;;;	Device Address
1	byte	Fixed	567	0x94	Command 148
1	byte	Fixed	567	0x0F(15d)	Data Length (not including checksum)
1	byte	Var	567	0x00	HART Command Status
1	byte	Var	567	0x??	HART Device Status (Configuration Changed Flag set)
1	byte	Var	567	0x??	CalType
1	byte	Var	567	0x??	CalPoints
1	byte	Var	567	0x??	CalSource
1	byte	Var	567	0x??	AppIndex
3	date	Var	567	DDMMYY	CalDate
6	char	Var	567	XXXXXX	CalPerson
1	byte	Var	567	0x??	HART Checksum

## Cmd 149 (0x95): Read Cal Status

(This command holds off QuickStart)

HART Command Type : Device Specific

HART Versions : 5 6 7

HART Operation Type : COMMAND

Code Section

Support In Boot : False Support In Main : True

Support Function : RdCalStatus.

#### Request: 10 (0x0A) bytes (plus preambles)

Size	Туре	Fixed/V ar	HART Ver #	Example	Description
1	byte	Fixed	567	0x82	Request Delimiter
5	byte	Var	567	0x?????????	Device Address
1	byte	Fixed	567	0x95	Command 149

Size	Туре	Fixed/V ar	HART Ver #	Example	Description
1	byte	Fixed	567	0x01(1d)	Data Length (not including checksum)
1	byte	Var	567	0x??	CalType
1	byte	Var	567	0x??	HART Checksum

## Response: 18 (0x12) bytes (plus preambles)

Size	Туре	Fixed/V ar	HART Ver #	Example	Description
1	byte	Fixed	567	0x86	Response Delimiter
5	byte	Var	567	0x;;;;;;;;	Device Address
1	byte	Fixed	567	0x95	Command 149
1	byte	Fixed	567	0x09(9d)	Data Length (not including checksum)
1	byte	Var	567	0x00	HART Command Status
1	byte	Var	567	0x??	HART Device Status (Configuration Changed Flag set)
1	byte	Var	567	0x??	Cal Type
1	byte	Var	567	0x??	CalStable
1	byte	Var	567	0x??	CalUnits
4	real	Var	567	? 0.0	CalValue
1	byte	Var	567	0x??	HART Checksum

### Cmd 150 (0x96): Finish Cal

(This command holds off QuickStart)

HART Command Type : Device Specific

HART Versions : 5 6 7

HART Operation Type : COMMAND

Code Section

Support In Boot : False
Support In Main : True
Support Function : FinishCal.

#### Request: 15 (0x0F) bytes (plus preambles)

Size	Туре	Fixed/V ar	HART Ver #	Example	Description
1	byte	Fixed	567	0x82	Request Delimiter
5	byte	Var	567	0x;;;;;;;;	Device Address
1	byte	Fixed	567	0x96	Command 150
1	byte	Fixed	567	0x06(6d)	Data Length
					(not including checksum)
1	byte	Var	567	0x??	CalType
1	byte	Var	567	0x??	CalUnits
4	real	Var	567	? 0.0	CalValue
1	byte	Var	567	0x??	HART Checksum

### Response: 17 (0x11) bytes (plus preambles)

Size	Туре	Fixed/V ar	HART Ver #	Example	Description
1	byte	Fixed	567	0x86	Response Delimiter
5	byte	Var	567	0x?????????	Device Address
1	byte	Fixed	567	0x96	Command 150
1	byte	Fixed	567	0x08(8d)	Data Length (not including checksum)
1	byte	Var	567	0x00	HART Command Status
1	byte	Var	567	0x??	HART Device Status (Configuration Changed Flag set)
1	byte	Var	567	0x??	CalType
1	byte	Var	567	0x??	CalStable
1	byte	Var	567	0x??	CalUnits
4	real	Var	567	? 0.0	CalValue
1	byte	Var	567	0x??	HART Checksum

### Cmd 142 (0x8E): Write Entity Byte Base

(This command holds off QuickStart)

HART Command Type : Device Specific

HART Versions : 5 6 7
HART Operation Type : WRITE

Code Section

Support In Boot : False Support In Main : True

Support Function : HARTE\_BytWrBase.

#### Request: 12 (0x0C) bytes (plus preambles)

Size	Туре	Fixed/V ar	HART Ver #	Example	Description
1	byte	Fixed	567	0x82	Request Delimiter
5	byte	Var	567	0x?????????	Device Address
1	byte	Fixed	567	0x8E	Command 142
1	byte	Fixed	567	0x03(3d)	Data Length (not including checksum)
2	int	Var	567	0	EntityIndex
1	byte	Var	567	0x00	EntityValue
1	byte	Var	567	0x??	HART Checksum

### Response: 15 (0x0F) bytes (plus preambles)

	_	Fixed/V			
Size	Туре	ar	Ver #	Example	Description
1	byte	Fixed	567	0x86	Response Delimiter
5	byte	Var	567	0x;;;;;;;;	Device Address
1	byte	Fixed	567	0x8E	Command 142
1	byte	Fixed	567	0x06(6d)	Data Length
					(not including checksum)
1	byte	Var	567	0x00	HART Command Status
1	byte	Var	567	0x??	HART Device Status
					(Configuration Changed Flag set)
2	int	Var	567	3 0	EntityIndex
1	byte	Var	567	0x??	EntityValue
1	byte	Var	567	0x??	Error
1	byte	Var	567	0x??	HART Checksum

## Cmd 143 (0x8F): Read Entity Byte User Attributes

HART Command Type : Device Specific

HART Versions : 5 6 7
HART Operation Type : READ

#### Code Section

Support In Boot : False Support In Main : True

Support Function : HARTE\_BytRdUserAtt.

#### Request: 11 (0x0B) bytes (plus preambles)

Size	Туре	Fixed/V ar	HART Ver #	Example	Description
1	byte	Fixed	567	0x82	Request Delimiter
5	byte	Var	567	0x????????	Device Address
1	byte	Fixed	567	0x8F	Command 143
1	byte	Fixed	567	0x02(2d)	Data Length (not including checksum)
2	int	Var	567	1	EntityIndex
1	byte	Var	567	0x??	HART Checksum

### Response: 20 (0x14) bytes (plus preambles)

Size	Туре	Fixed/V ar	HART Ver #	Example	Description
1	byte	Fixed	567	0x86	Response Delimiter
5	byte	Var	567	0x;;;;;;;;	Device Address
1	byte	Fixed	567	0x8F	Command 143
1	byte	Fixed	567	0x0B(11d)	Data Length (not including checksum)
1	byte	Var	567	0x00	HART Command Status
1	byte	Var	567	0x??	HART Device Status (Configuration Changed Flag set)
2	int	Var	567	3.0	EntityIndex
1	byte	Var	567	0x??	InVisibility = 0x80 bit
4	byte	Var	567	0x???????	PicksInVisible
1	byte	Var	567	0x??	Error
1	byte	Var	567	0x??	EntityValue
1	byte	Var	567	0x??	HART Checksum

# Cmd 146 (0x92): Activate Output Hold

(This command holds off QuickStart)

HART Command Type : Device Specific

HART Versions : 5 6 7

HART Operation Type : COMMAND

Code Section

Support In Boot : False Support In Main : True

Support Function : ActivateOutputHold.

### Request: 30 (0x1E) bytes (plus preambles)

Size	Туре	Fixed/V ar	HART Ver #	Example	Description
1	byte	Fixed	567	0x82	Request Delimiter
5	byte	Var	567	0x;;;;;;;;	Device Address
1	byte	Fixed	567	0x92	Command 146
1	byte	Fixed	567	0x15(21d)	Data Length (not including checksum)
1	byte	Var	567	0x??	Hold Mode
4	real	Var	567	3.6	Hold mA
4	real	Var	567	7	Hold PV
4	real	Var	567	25	Hold SV
4	real	Var	567	0	Hold TV
4	real	Var	567	109.73	Hold QV
1	byte	Var	567	0x??	HART Checksum

### Response: 32 (0x20) bytes (plus preambles)

Size	Туре	Fixed/V ar	HART Ver #	Example	Description
1	byte	Fixed	567	0x86	Response Delimiter
5	byte	Var	567	0x;;;;;;;;	Device Address
1	byte	Fixed	567	0x92	Command 146
1	byte	Fixed	567	0x17(23d)	Data Length (not including checksum)
1	byte	Var	567	0x00	HART Command Status
1	byte	Var	567	0x??	HART Device Status (Configuration Changed Flag set)
1	byte	Var	567	0x??	Hold Mode

Size	Туре	Fixed/V ar	HART Ver #	Example	Description
4	real	Var	567	3.6	Hold mA
4	real	Var	567	7	Hold PV
4	real	Var	567	25	Hold SV
4	real	Var	567	0	Hold TV
4	real	Var	567	109.73	Hold QV
1	byte	Var	567	0x??	HART Checksum

Possible HART Command Status errors returned:

(5) 0x05 Error Too few data bytes received

### Cmd 147 (0x93): Release Output Hold

HART Command Type : Device Specific

HART Versions : 5 6 7

HART Operation Type : COMMAND

Code Section

Support In Boot : False Support In Main : True

Support Function : ReleaseOutputHold.

#### Request: 9 (0x09) bytes (plus preambles)

Size	Туре	Fixed/V ar	HART Ver #	Example	Description
1	byte	Fixed	567	0x82	Request Delimiter
5	byte	Var	567	0x;;;;;;;;	Device Address
1	byte	Fixed	567	0x93	Command 147
1	byte	Fixed	567	0x00(0d)	Data Length (not including checksum)
1	byte	Var	567	0x??	HART Checksum

### Response: 11 (0x0B) bytes (plus preambles)

Size	Туре	Fixed/V ar	HART Ver #	Example	Description
1	byte	Fixed	567	0x86	Response Delimiter
5	byte	Var	567	0x;;;;;;;;	Device Address

Size	Туре	Fixed/V ar	HART Ver #	Example	Description
1	byte	Fixed	567	0x93	Command 147
1	byte	Fixed	567	0x02(2d)	Data Length (not including checksum)
1	byte	Var	567	0x00	HART Command Status
1	byte	Var	567	0x??	HART Device Status (Configuration Changed Flag set)
1	byte	Var	567	0x??	HART Checksum

# Index

<ul><li>A</li><li>Auto Calibration 77</li></ul>
Cable Length, Sensor 16 Calibration Mode 29 Changing and Viewing Data 20 Configuration Mode 33 Configuration Structure Diagrams 61 Configuration Table 71 Controls and Indicators 17
<b>D</b> Diagnostic Mode 45
Factory Configuration Values 71 Factory Default Passcode 1
<ul><li>H</li><li>HART Communicator, Operation Via 49</li><li>Hold Mode 27</li></ul>
Indicators and Controls 17 Installation 11
L Local Display, Operation Via 17
M Maintenance 57 Measure Mode 21 Mounting 11
<b>O</b> Operation

Via HART Communicator 49

#### Via Local Display 17

#### P

Passcode Access 19 Passcode, Factory Default 1

#### $\boldsymbol{Q}$

Quick Start 3

#### R

Reference Documents 1

#### S

Specifications
Functional and Physical 7
Product Safety 8
Status Mode 23
Structure Diagrams, Configuration 61

#### T

Timeout 20

#### U

Unpacking 11

#### V

Viewing and Changing Data 20 Voltage Load Requirements 16

#### W

Wiring 14

ISSUE DATES MAY 2010

Vertical lines to the right of text or illustrations indicate areas changed at last issue date.

Invensys Operations Management 5601 Granite Parkway Suite 1000 Plano, TX 75024 United States of America http://www.iom.invensys.com

Global Customer Support
Inside U.S.: 1-866-746-6477
Outside U.S.:1-508-549-2424 or contact
your local Invensys representative.

Email: support@invensys.com Website: http://support.ips.invensys.com Invensys, Foxboro, and I/A Series are trademarks of Invensys plc, its subsidiaries, and affiliates. All other brand names may be trademarks of their respective owners.

Copyright 2010 Invensys Systems, Inc. All rights reserved

MB 123

0810

