

Bettis Canada Ltd. 4112 91A Street Edmonton, Alberta, Canada T6E 5V2

Tel: (403) 450-3600 Fax: (403) 450-1400

CUSTOMER:

Edmonton

SERVICE MANUAL No. I-0019

SELF CONTAINED HYDRAULIC ACTUATOR

	P.O.#:	=	
	W.O.#:	_	
	TAG:	_	
	DATE:		
APPL	LIES TO OPERATOR MODEL:		
	DESCRIPTION	DWG.NO	PAGE
	INTRODUCTION	C-0251	2
I	INSTALLATION AND OPERATION		3
П	SPECIFICATIONS		5
	RESET VALVE	C-0069	6
	HANDPUMP	AB0188	7
	REGULATOR PARTS LIST		8
Ш	PRESSUREMATIC		10
	PRESSUREMATIC ASSEMBLY	APB0570	11
	PRESSUREGUARD ASSEMBLY	CB0065-10	12
	PRESSUREGUARD ASSEMBLY AND DIMENSIONAL	CB0065-00	13
	TYPICAL GVO-HP-FS CLOSE COUPLED ASSEMBLY	CB0210	14
	TYPICAL GVO-HP-FS-UM ASSEMBLY	AB0444-10	15
	TYPICAL QUARTERTURN HYDRAULIC SERIES ASSEMBLY	AB0520	16
IV	NOTES		17

SELF CONTAINED HYDRAULIC MODULE

The compact Bettis Self Contained Hydraulic Module is designed to offer reliable emergency shutdown capability, using clean hydraulic fluid, when an external power source is either not available or not reliable.


The module is used in conjunction with Bettis linear or rotary spring return hydraulic operators to provide a fail safe system adaptable to ball, plug and other quarter turn valves as well as reverse acting gate and other linear operated valves.

The module has built—in temperature compensation and pressure relief and is proven reliable under the most demanding operating and environmental conditions.

The module is the foundation for a flexible system, and the example below, while not typical, does illustrate the operating method and a variety of available sensing and control options.

Operation:

- Shown with line valve closed, reset valve unlatched
- Latch reset valve (23), then operate handpump (3) to open line valve (2)
- System enters automatic mode when pilot (14) senses pressure within setpoints and solenoid (20) is energized
- Line valve closes if:
 - i) Reset valve (23) is switched manually, or
 - ii) Pilot (14) senses pressure out of range, or
 - iii) Selector valve (16) is switched to "MANUAL", or
 - iv) Solenoid (20) is de-energized



I INSTALLATION

Refer to schematic drawing C-0251.

The self contained hydraulic esd module is usually factory installed on the operator, but can be field installed by the user.

The module type may be:

- a) low pressure MAWP 200 psi.
- b) high pressure MAWP 1500 psi.

It is mounted on the operator with bracket(s) and mounting bolts.

Identified on manifold assembly:

- (H) High pressure hydraulic supply to the operator
- (L) Low pressure hydraulic supply for monitoring/devices
- (S) Low pressure hydraulic signal for RESET VALVE from monitoring/ESD devices
- (V) Vent or return line to allow off panel devices to return oil to the reservoir

Connections are as shown on the schematic, and also tagged at the factory. Solenoid valve(s), if applicable, have been factory installed and tubed, ready for electrical connections. The breather/fill port of the reservoir may be plugged with a metal or plastic plug, if so remove and replace with breather provided in bag attached to the unit.

An aviation grade hydraulic fluid (ESSO UNIVIS or EQUIVALENT) is used in all BETTIS operator systems, or per customer request.

OPERATION

- a) MANUAL MODE (TO START-UP/ RESET)
 - 1. Lift the toggle on the manual pilot valve and latch in the up position. Refer to drawing C-0069 for "Manual Reset" position.
 - 2. Operate handpump to open/close line and pressurize system.
 - 3. Stop pumping when high pressure gauge reading is approximately 10% above the minimum value required to hold line valve in position.
 - 4. At this point, hydraulic pressure opposing the operator spring holds the line valve in position.

NOTE: To start-up without complete system connections PLUG (L) LOW PRESSURE to prevent fluid flow off the panel. Follow instructions above to operate unit.

b) AUTOMATIC MODE (TO RUN)

- 1. Lower the toggle on the manual pilot valve. Refer to drawing C-0069 for "Auto/Run" position.
- 2. Automatic mode is attained when signal device(s) is satisfied. Solenoid valve(s) is returned to normal operating condition (ie. energized, de-energized).

SHUTDOWN

- a) Signal devices: If the pilot senses pressure outside of the setpoints; or if there is an applied/removed electrical signal to solenoid; it removes the signal to the manual pilot valve. This manual pilot valve switches, which allows the spring in the operator to stroke the line valve to the failsafe position.
- b) **Manual shutdown:** Push toggle to shutdown manually.

MAINTENANCE

NOTE: Regular maintenance should be performed each autumn or as required.

- 1. Drain any accumulated moisture from fluid reservoir.
- 2. Check, clean and/or replace filter element(s).
- 3. Check pressure relief valve(s) setpoints and reset values.
- 4. If possible check operation and calibration of pressure pilot/solenoid.
- 5. Top up hydraulic fluid with compatible fluid.

TROUBLE SHOOTING

NOTE: As shown in the schematic, high pressure side of the system supplies the low pressure regulated side, therefore any leakage on the low side will cause significant changes in high pressure gauge values in a short time period.

Without cycling the unit, but with the pressurized removal of the reservoir and off panel device, vent/return lines will assist in tracing leakage. To accomplish this:

- 1. Remove vent line from pilot/solenoid vent port. This isolates it from the SCH module and allows for observation of any oil leakage through the device
 - NOTE: This checks poppet/spool and spool/sleeve o-ring seal in operating positions.
- 2. Remove reservoir from module to observe components (reliefs and reset valve) for oil leakage while under normal operating pressures.
- Remove filter plug, spring, and filter in handpump subplate to observe backside of HP discharge. Check for leakage across and around it with high pressure being applied.
- 4. Remove fitting and tubing or plug from module second vent port to observe any oil leakage due to manifold porosity between LP channel and VENT channel.
- 5. Remove operator inspection cover/plate and or tubing from cylinder plate port to observe any oil leakage across piston seal and piston centre o-ring.

In the case of pumping problems, access to pump suction valve is gained by removing pump assembly from subplate. Pumping difficulties usually result from dirty filter element, contaminated oil (water, methanol), or incorrect fluid type.


Failure of the regulator to regulate is noticeable in that after two pump strokes low pressure gauge reading is 130 PSI. Service regulator according to enclosed bulletin.


NOTE: Depressurize system before removing/disassembling any components on the manifold.

II SPECIFICATIONS

- 1. High pressure SCH module with HP-2-SC OR BHP 3 handpump, 0-2000 PSI HP gauge, and 0-160 PSI LP gauge:
 - a) HP Relief set at 1500 1750 PSI
 - b) LP Relief set at 130 PSI
 - c) MECO Regulator set at 80 -100 PSI, recommended setting 80 PSI.
- 2. Low pressure SCH module with HP-2-SC handpump, and 0-300 PSI LP gauge:
 - a) LP Relief set at 250 PSI
- 3. Common components to the low and high pressure systems include:
 - a) Pilot to close valve, reset valve, toggle valve, or manual pilot valve requires 40 to 60 PSI on the signal port to sustain auto mode.
 - b) Solenoid valve with voltage of 24 VDC, 125 VDC, or 120 VAC with MAWP 150 PSI to be specified by user.
 - c) High/Low pressure pilot upper block connected to the self contained hydraulic module, with an operating pressure from 60 to 130 PSI. Process sensing pressure MAWP depends on the manufacturer.
 - d) For valve operator, see the service manual for particular type.
 - e) Reservoir is cast aluminum, fabricated steel is optional.

NOTE: If parts are required, advise model and serial number of equipment.





TYPE B INDUSTRIAL REGULATOR PARTS LIST



Stock No.

Description

4527—J-4B Low Pressure Tee Adj. Screw

4528-J-4 High Pressure Tee Adj. Screw

4566—B-7 Diaphragm Assembly

5197 - Filter Screen, Brass

5203—B-12-A Cap Type Bonnet

5204—B-12 Tee Type Bonnet

5215—Sintered Brass Filter

5222—B-1F Body (for flowmeter outlet)

5224-B-1A Industrial Body, 1-HP, 2-LP

5225 - B-1C Industrial Body, 1-HP, 3-LP

5226-A-B-2 Nozzle

5227 - A-B-3 Seat Assembly, Buna-N

Stock No.

Description

5228—A-B-4 Seat Spring

5231-B-1-B Industrial Body, 2-HP, 2-LP

5232—.687 Push Off Pin (for all gases)

5235-Nozzle Seal "O" Ring, Pkg. 12

5236-Diaphragm Seal "O" Ring, Pkg. 12

5237—Seat Assembly, Viton

5251—Seat Assembly, Neoprene

5259-J-5 Spring Button


5263—J-7A Bonnet Spring, 20 PSI

5265-J-7-150 Bonnet Spring, 150 PSI

5273-J-30 Slotted Adjusting Screw

5274—J-31 Hex Protection Cap





Stock No.	Description
4506	Diaphram-Yoke Assembly
4521	Seat Block with White Nylon Seats
4524	Seat Block with Kel-F Seats for CO ₂
4528	Adjusting Screw Assembly
4534	Adjusting Screw Assembly ENVIRO-CAP, Water Heated Back Cap Assembly
5140	Yoke (Part of 4506)
5145	Bonnet Screw 6 required, Pkg. 12
5155	Yoke Gasket, Teflon, Pkg. 12 (Part of 4506)
5158	Nozzle with 5/64" Orifice, Pkg. 6
5177	Rear Spring, for over 500 PSI Inlet Pressure, Standard
5181	Yoke Clamping Screw, Pkg.6
5182	Yoke Guide
5197	Filter Screen, pkg. 6
5215	Sintered Filter, pkg. 12, Standard
5259	Spring Button
5263	Compression Spring for 30 PSI Pressure (Red)
5264	Compression Spring for 125 PSI Pressure (Green)
5265	Compression Spring for 150 PSI pressure (Purple)
5267	Diaphragm Plate (Part of 4506)
5268	Stainless Steel Diaphragm (Part of 4506)
5269	Diaphragm Gasket, Pkg. 6
5272	Diaphragm Plate Nut (Part of 4506)
5273	Slot Type Adjusting Screw
5274 5000	Protection Cap for Slot Adjusting Screw
5369	Compression Spring for 50 PSI pressure (Black)
5400 5411	Compression Spring for 225 PSI pressure (Grey)
5412	Body, 1 inlet, 2 outlets P-1-DA
5412 5413	Rody, 1 inlet, 3 outlets P-1-DC
5418	Body, 2 inlets, 2 outlets P-1-DD.
5419	Bonnet, for "T" Type Adjusting Screw
5423	Bonnet, for Slotted Type Adjusting Screw
5423 5424	Allen Head Adj. Screw
5424 5429	Back Cap Gasket Toflon Pkg 12
JACO	Back Cap Gasket, Teflon, Pkg. 12

III PRESSUREMATIC

Set point adjustment for Series 2000, 2200, 2400:

NOTE: Refer to drawing APB0570.

This is done with the assembly complete and supply air on the pilot valve for P-AR and P-MR models.

NOTE: In the field this requires a calibration kit with the ability to supply high and low setpoint pressures (eg. nitrogen bottle with block & bleed valve).


1. Cases with low and high set points:


NOTE: The low set point must be adjusted first. It will not be affected by the high set point adjustment but the high set point is affected when the low set point is adjusted.


- a) Set the high trip bolt fully away from the trip spring.
- b) Repeatedly adjust the low trip bolt and decrease pressure through the low set point until the low trip occurs consistently at the low set point. Tighten the lock nut and recheck. Check that there is at least 0.02" piston travel from low trip to bottom stop.


NOTE: When adjusting the low trip bolt, the upper arm of the trip spring must be pushed down. This unloads the bolt and allows it to be turned by hand.


- c) Repeatedly adjust the high trip bolt and increase pressure through the high set point until the high trip occurs consistently at the high set point. Tighten the lock nut and recheck.
- 2. Cases with low set point only:
 - a) Set high trip bolt fully away from the trip spring.
 - b) Adjust the low set point as described in 1.b) above.
 - c) To disable high trip, increase pressure until piston is at upper stop. Adjust high trip bolt downward until high trip occurs then retract 1/2 turn. Check that high trip does not occur when piston travels to upper stop. This high trip bolt adjustment is to prevent the trip spring from placing unnecessary force on the spool.
- 3. Cases with high set point only:
 - a) To disable low trip, adjust low trip bolt until low trip occurs when piston is within 0.020" of bottom stop. Then adjust 3 turns upward (ccw viewed from above).
 Tighten locknut and check that low trip does not occur when piston travels to bottom stop.
 - b) Adjust the high set point as described in 1.c) above.














/	SELF CONTAINED HYDRAULIC MODULE NOTES