magicplan

Onboarding Guide

Everything your team needs — from first scan to exporting your ESX.

Kyle Morin
Senior Solutions Consultant
813-851-4658
kyle.morin@magicplan.app
helpdesk@magicplan.app

Contents

01 Getting Started

- Create your account & join your workspace
- Switch to your company workspace
- Create your first project

02 Scanning

- Confirm your device compatibility
- Prepare the space
- Scanning workflow
- Best practices

03 Editing

- Pair your Bluetooth laser
- Verify dimensions
- Split rooms
- Fill structural gaps
- Elevation view
- Details panel

04 Photos, Videos & 360s

- Attach photos
- Annotate & redact
- Tag every photo
- Connect your 360 camera
- Share a 360 tour

05 Exporting

- Export ESX for Xactimate
- Export FML
- PDF photo report
- Wall alignment & Xactimate

06 magicplan Cloud

- Workspace setup
- Team visibility
- Settings to enable
- Invite your team

07 Quick Solutions

- Common questions answered

01 — Getting Started

Getting Started

Three steps to get you up and running.

1. Create your magicplan account

Download the app from the Apple App Store or Google Play Store and open it. Select the sign-up option, enter your email, and create a password. Agree to the terms and conditions to complete registration.

> i For a full walkthrough including signing up via the magicplan Cloud, visit help.magicplan.app/create-your-magicplan-account

2. Switch to your company workspace

If your team is already using magicplan, you will receive an email invitation to join your company workspace — this is the most common way new team members get set up. Accept the invite and you'll be added automatically. Once in the app, tap the workspace name at the top left of the home screen to confirm you're in the correct company workspace. You only have to do this once.

3. Create your first project

Tap the + sign on the home screen → New Project. Name it using your team's convention (typically: owner name + address + claim number). Add the address using geolocation or enter it manually. Then tap + next to Floor Plans to start the floor plan.

> v During training, prefix your project name with "Test" + your first name. Your solutions consultant can credit those back after the session.

02 — Scanning

Auto Scanning

The core workflow for building an instant floor plan in the field.

1. Confirm your device compatibility

magicplan's AutoScan feature requires an iPhone 12 Pro or newer, or an iPad Pro (2020 generation or newer). Non-Pro devices can still use Manual Scan with corner detection, photo documentation, connecting a 360 camera, and all other core functionality.

> ¡ For a full list of supported devices, visit help.magicplan.app/supported-devices

2. Prepare the space

Turn on all lights. In a power-out scenario, use a portable battery-powered floodlight — the scan will still work in dim conditions, but maximum light gives the best result. Close doors to rooms you're not yet scanning.

3. Tap the red record button, then select the room type

Go to Insert → Room → Auto Scan and tap the red record button to start. Then select the room type (kitchen, bedroom, bathroom, etc.). This ensures any photos you take during the scan are automatically labeled and associated to the correct room in your photo report.

4. Move slowly — sweep the device up and down

Move around the room at a moderate pace, tilting the device up toward the ceiling and down toward the floor as you go. This gives the app enough data to accurately detect walls, windows, and ceiling height.

> ¡ Toggle the 2D view (button next to the record button) to see a map of what you've captured so far and confirm no walls are missing.

5. Scan section by section — not the whole floor at once

After finishing one room or area, tap the red record button to stop and confirm the scan. Then move to the next section and tap "Scan another room." Only tap Done when you've finished the entire floor.

> ! Scanning more than 2,000 sq ft in a single session will strain the app. Break very large floors into two sessions and join them in the editor.

6. Leave closets and pantries closed

Small closets and pantries are full of shelves and clutter, making it hard for LiDAR to measure depth accurately. Leave them closed during the scan. After, you can fill them in with the Filler Room tool in about 10 seconds.

7. Take photos and dictate notes while scanning

Use the shutter button (above the record button) to take photos mid-scan — they auto-tag to the current room. Use the microphone button (above the shutter) to dictate a voice note describing what you observe.

> i Voice transcript is a public beta feature. Ask your solutions consultant to enable it for your account.

8. Choose which objects to include when finishing

After tapping Done, a window lets you include or exclude object categories (furniture, appliances, plumbing fixtures). Furniture rarely needs to come through to Xactimate — deselect it and check "Remember my choices" so it stays off by default.

> v Save scan recording videos. They're stored in the magicplan Cloud at no extra cost and can be valuable if a dispute arises later.

03 — Editing

Floor Plan Editing

How to verify, adjust, and complete your scan in the editor.

Manual Room Methods

Add square room — drops an 8×2 default; drag to resize or verify with your Bluetooth laser

Draw room — tap points to map any irregular shape

Filler room — fills structural gaps in the floor plan instantly

Filler wall — use if filler room snaps to the wrong wall

1. Pair your Bluetooth laser

To verify measurements, open any dimension in the editor and tap "Laser." The app detects your device make and model. Tap Connect. After the first pairing, it reconnects automatically whenever the laser is on.

2. Verify dimensions with your Bluetooth laser

Tap any blue dimension on the floor plan, open your laser, and click once. The measurement locks with a padlock icon. Verify any dimension critical to your estimate — the scan is fast and accurate, but a laser gives you certainty.

3. Split open-concept rooms

If rooms scan together as one open space, select a wall point → Split Room → delete the dividing wall that appears. Repeat for each split. Open each section's Details panel and change the room type. They'll now have separate labels and surface area calculations.

4. Fill structural gaps after scanning

Insert → Room → Add Filler → Filler Room. Drop the bullseye indicator into the structural gap. If filler room snaps to the wrong wall, use Filler Wall instead, then open Details and change the room type.

5. Use elevation view for windows and cabinets

Switch to Elevation View at the bottom of the screen to see walls vertically. You can verify "distance from floor" for windows and reposition cabinets with precision. Cycle between walls using the left/right arrows.

6. Open the Details panel for any element

iPad: tap the eye icon at top right. iPhone: swipe up from the bottom of the screen. Details let you change room type, set ceiling height, adjust wall thickness, attach photos or notes, and add affected areas for scoping.

Photos, Videos & 360s

Building a complete, organized photo report alongside your floor plan.

1. Attach photos at the right level

Photos can be attached at the project level (exterior shots), floor level, room level, or even to individual walls and objects. Use project-level for exterior documentation, room-level for damage documentation, and object-level for specific elements like windows or cabinets.

2. Annotate and redact within the app

After taking photos, tap Next → Edit. Use arrows to indicate source of loss, add text boxes, draw shapes, and change annotation colors. Use the redaction tool to blur family portraits or sensitive information before anything goes into the report.

3. Tag every photo

After photos, tap Tags to apply labels like "pre-mitigation," "daily departure," "emergency," or create a custom tag. Tags let you filter quickly when building reports on the magicplan Cloud.

> ✓ This feature saves significant time at the reporting stage — make it a habit from day one.

4. Connect your Ricoh or Insta360 camera

In the camera app, select 360. First time only: enter the serial number from the bottom of your camera. After that, the camera is remembered and connects automatically.

> ! If only the first 360 uploads then stalls, update magicplan via the App Store and restart your camera. If the issue persists, remove the camera from saved Bluetooth devices and re-pair. Still stuck? Note your Ricoh model and contact your solutions consultant.

5. Share a 360 tour with adjusters and homeowners

On the magicplan Cloud, open your project photos → Export Photos → 360 Tour. Name it and publish. A shareable link is generated instantly. Anyone with the link can view the tour in a browser — no magicplan account required.

05 — Exporting

Exporting Files

Getting your sketch, photo report, and tour out of magicplan and into Xactimate or your inbox.

! Sync before you export. magicplan works fully offline — scanning, editing, photos, 360s — but you need a data connection to generate exports. Pull down on the home screen to manually sync first.

1. Export the ESX for Xactimate

From the floor plan view: tap the two squares + arrow icon at top right → Verisk. Or from project overview, tap Export on the left. Enable photo compression to maximize how many photos are included.

! Xactimate limits ESX files to 100MB of photos. With compression, you can fit roughly 200 photos. Above that, exclude photos from the ESX and share them via the photo report PDF or 360 tour link instead.

2. Export the FML for Cotality

Same export menu → tap Integrations to find the FML option. You can generate and re-export as many times as needed within a project at no additional cost.

3. The file doesn't appear right away — here's why

Files are generated in the magicplan Cloud, not on your device. After exporting, pull down on the home screen to sync. Go back into the project and scroll down to the File section — it'll be there.

4. Generate the PDF photo report

On the magicplan Cloud: open project photos → Export Photos → PDF. Choose photos per page, toggle date/time/author display. The PDF is interactive — recipients can click embedded videos and 360s directly from the file.

5. Wall alignment and Xactimate

If walls look misaligned in Xactimate after importing the ESX, this is a known behavior resulting from how the two platforms store floor plans differently — not a measurement error in your original sketch. Objects added in magicplan before export will import correctly and deductions will work as expected when preferences are correctly configured in Xactimate.

¡ For a full guide on reference block placement, ask your solutions consultant for the ESX to Xactimate Reference Block Placement Guide.

06 — magicplan Cloud

magicplan Cloud

What to set up once, and how your office team can access everything at cloud.magicplan.app.

1. Check your workspace when you first log in

You may land in your personal workspace. Click the workspace name at top left and switch to your company workspace. Do this once and it will persist.

2. See all team projects

By default the magicplan Cloud only shows your own projects. Click "See all projects of workspace members" to view everything your colleagues are building.

3. Reassign projects between team members

Open a project → Assign To → select a colleague. They receive an email notification and can continue the work. Make sure the project is fully synced before reassigning.

> i Where possible, have the same person start and finish a job. Reassigning mid-job works fine, but keeping one owner reduces confusion on large projects.

4. Two settings worth turning on

In Settings on the magicplan Cloud: (1) Convert 360 spherical images to cubic faces when downloading — every 360 photo automatically generates 6 flat images, useful if your team or carriers need standard flat images. (2) File versioning — each new export creates a new file rather than overwriting the previous one.

> v Neither setting is required, but both are low-effort to enable and can save time down the line.

5. Set up company profiles per office

In Company Profile: upload your logo and enter contact details. If you have multiple offices, create a team for each and configure a separate profile per team.

6. Invite your whole team — it's unlimited users

Go to Members → enter email and name → assign to a team. magicplan Pro has no per-user charge, so invite everyone who will ever need to view or work on projects.

07 — Quick Solutions

Quick Solutions

Fast answers to the most common questions.

The ESX file isn't generating. What's wrong?

1. Check your sketch for overlapping walls. Open the floor plan editor and look for any areas that appear incorrect or misaligned — overlapping walls are a common cause of export failures. Make the necessary corrections and try re-exporting. 2. Check your photo size. The ESX file has a 100MB photo limit set by Xactimate/Verisk — not magicplan. Go to export settings, turn off photo inclusion, and export again. Enable photo compression to include around 200 photos.

Walls look misaligned in Xactimate after importing the ESX.

This is known behavior resulting from how the two platforms store floor plans differently — not a measurement error in your sketch. Objects added in magicplan before export will import correctly. See the ESX to Xactimate Reference Block Placement Guide for full details.

Two rooms scanned as one. How do I separate them?

Open the floor plan editor, select a point on the wall where you want to divide the space, and tap Split Room. A wall line appears — delete it. Repeat for additional splits. Open each section's Details panel and change the room type. They'll now have separate labels and surface area calculations.

The filler room snapped to the wrong exterior wall.

Undo, then go to Insert → Room → Add Filler → Filler Wall. Drop it into the gap. Then select it, open Details, and change the room type to Closet or whatever is appropriate.

The 360 camera only uploads the first photo, then stalls.

Start by making sure you're running the latest version of magicplan — search for magicplan in the App Store and update if one is available. Then restart your 360 camera. If the problem persists, remove the camera from your saved Bluetooth devices and re-pair it to magicplan. This is a known issue that varies by camera model and firmware. Recent models like the Ricoh 360 X3 should not experience this under normal conditions. If the problem continues, note your specific model and contact your solutions consultant.

I don't see my colleagues' projects on the magicplan Cloud.

Click "See all projects of workspace members" on the magicplan Cloud home screen — by default you only see your own. Also confirm you're in the correct company workspace, not your personal one.

Can a colleague pick up and continue a project I started?

Yes, but only one person can be the active owner at a time. Sync the project fully, then reassign ownership in the magicplan Cloud (open the project → Assign To → select the colleague).

Can I use magicplan without a LiDAR device?

Yes, however AutoScan will not be available. Manual Scan with corner detection will still be accessible along with full photo documentation, connecting a 360 camera, floor plan editing, and all exports. If your role is office-based — estimating, project management, reviewing — desktop access to the magicplan Cloud is often all you need.

Kyle Morin

Senior Solutions Consultant

Available during regular business hours — call, text, or email anytime.

813-851-4658

kyle.morin@magicplan.app

helpdesk@magicplan.app