1. Under /etc directory, make 【hostname】 file

TODO:

vi /etc/hostname

Nova

2. Modify the /etc/init.d/rcS

TODO:

vi /etc/init.d/rcS

/bin/hostname -F /etc/hostname

3. Under /etc directory, make [profile] file

TODO:

vi /etc/profile

PS1='[\u@\h\W]\#' (注:#后有一个空格) HOSTNAME=`/bin/hostname` export PS1 HOSTNAME

4. Under /etc directory, make 【passwd】 file

TODO:

vi /etc/passwd

root::0:0:root:/:/bin/sh

5. Reset the board