



## Note:


The LF-RAC shown in the Generator schematic (543020XX) is a basic documentation, only for interconnection purposes.


Follow this schematic for detailed component
information of the LF-RAC board.


																061109
					NAME	DATE	SHEET / OF	DWC	ā:	A3096-02						
				DRAWING	F. GARCIA	21/09/97	4.4			A3090-02						
				REVISED	A. DIAZ	21/09/97	1/1								$\blacksquare$	REV
							)									
					Ω						LF - R	AC B	oard			
В	CN 03/004	F. García	13/01/03	ΙΓ	- SE	EDECAL		1	l ine l	Frequenc	ry Rots	tory i	Anode	Con	trolla	r)
REV	DESCRIPTION	ISSUED BY	DATE					( '	Lille	requeri	y 110ta	iloi y z	-110ac	0011	ii Oile	'




















					NAME	DATE	SHEET / OF	A3212-02							
				DRAWING	A.Querol	03/11/03	1/1	A3212-02							
				REVISED	A.DIAZ	03/11/03	17 1	Ø <b>◆</b> -REV						<b>◆</b> -REV	
					0 05				<i>.</i>	_		_	_		
Ø	First Issue	A.Querol	03/11/03	llr	<u>ظ</u> SE		Charge/Discharge Board								
REV	DESCRIPTION	ISSUED BY	DATE				J								

