

#### Charging + Programming VBUS USB BATT VBAT GND GND CHG DC C13 0.1u C12 △ DHAX1555 QTLP601CEBTR 0.1u GND GND GND D4 SCHTTKY\_DIODE U7 VBUS D-D+ ID GND VBUS USBDM USBDP POS@1 TXD RXD RX\_PRE TX\_PRE ID GND VCC 3V3OUT VCCIO CTS RTS DTR DSR DCD RI VBUS RST\_PRE RST\_SW TCK\_PRE C14 0.1u C15 OSCI OSCO RESET TEST AGND GND GND GND 0.1u U8 U9 GND TXLED RXLED PWREN TXDEN SLEEP NO1 V+ N01 V+ TX\_PRE RST\_PRE COM1 IN1 COM1 IN1 GND IN2 COM2 RX\_PRE IN2 COM2 TCK FT232RQ TCK\_PRE GND NO2 GND NO2 GND TS5A23166 TS5A23166 GND GND









# Humidity Electrochemical Sensor Socket HTVDD HTSCK HTDATA GND 0087954874 External Switch 0 E× JP3 vcc ↑ 1 2 3 4 5 6 7 8 9 1 2 3 4 5 6 7 8 9 MENAB ASIG UCC ↑ JP1 GND GND

#### and Temperature Sensor



### cternal Switch 1



## Ambient Light Sensor



