TROUBLESHOOTING HINTS

CONDITION	POSSIBLE CAUSE	ACTION
• Wipers do not operate. (All switch positions)	• No power or ground to Wiper Control Module (WCM).	• With Ignition Switch in RUN, check for battery voltage between pin 2 and pin 3 or 5 of the Wiper Control Module, and between circuit 65 and 875 of the Wiper Control Module. Service for open fuse or circuits if voltage is not present.
	• Open circuits between wiper motor and WCM. • Open circuit between WCM and Multifunction switch. • Damaged Multifunction switch. • Damaged wiper motor or linkage. • Damaged WCM.	• With WCM connected, ignition in RUN, and Multifunction Switch turned to HIGH, check for battery voltage between circuits 61 and 58 of the wiper motor connector. • If voltage is present, check for damaged wiper motor or linkage. • If no voltage present: a) With multifunction switch at HIGH, Check resistance between circuit 993 and 589 at the WCM connector. If resistance is greater than five ohms, service for open circuit or damaged Multifunction Switch. b) Check continuity of circuits 61 and 56. If OK, replace WCM.
• LOW speed inoperative. (HIGH speed OK)	• Open circuits between wiper motor and WCM. • Damaged Multifunction switch. • Damaged wiper motor or WCM.	• Unplug Wiper Motor connector. With Ignition Switch in RUN and Multifunction Switch at LOW, check for battery voltage between circuits 61 and 56. • Voltage present: check for damaged wiper motor. • No voltage: a) With multifunction switch at LOW, check that resistance between circuits 993 & 589 is 3.5K-4.5K ohms. If resistance is out of range, check for damage, check for damaged multifunction switch, If switch is OK, go to b. b) Check continuity of circuit 56 between WCM and wiper motor. If OK, replace WCM.
• INT inoperative. (LOW and HIGH speed OK)	• Open interval control circuit. • Damaged Multifunction switch. • Damaged WCM.	• Disconnect WCM and check that resistance between circuits 993 and 589 is 10.5K-12K ohms. • Resistance OK: a) Measure resistance between circuits 590 and 993 while rotating INT control from MIN to MAX. If observed resistance is less than 104K ohms, replace WCM. If resistance is greater than 104K ohms, check for open circuits or damaged Multifunction Switch. • Resistance not OK: check for damaged Multifunction Switch, or open circuits 993/589.

81-5 INTERVAL WIPER/WASHER

TROUBLESHOOTING HINTS

CONDITION	POSSIBLE CAUSE	ACTION
• Wipers will not turn off.	• Unseated connectors or open circuits. • Damaged wiper motor or WCM. • Damaged Multifunction switch.	• Check that wiper motor and WCM connectors are not unseated. If OK, disconnect wiper motor connector. With ignition in RUN and Multifunction switch at OFF, check continuity between circuits 28 and 56 and between circuits 61 and 875. • If continuity is OK, check for damaged wiper motor. • If no continuity: a) Check continuity of above circuits between wiper motor and WCM connector. Check for open in circuit 875. b) With Multifunction switch at OFF, measure resistance between circuits 589 and 993. If resistance is between 45K to 50K ohms, replace WCM. If resistance is out of range, check for open circuits between WCM and Multifunction switch or for damaged switch.
• Wipers will not park.	• No power or ground at wiper motor. • Damaged wiper motor, wiper linkage or WCM. • Damaged Multifunction switch.	• Turn Ignition Switch to RUN and Multifunction switch to OFF; disconnect wiper motor connector. Check for battery voltage at circuit 65 and ground at circuits 28 and chassis ground at the motor connector. Service for open circuit if voltage and ground are not present. • Check continuity between circuits 28 and 56 as in case where wipers will not turn OFF. Service circuits, wiper motor, WCM, or Multifunction switch as required.
• Windshield washer not operative; wipers operate when washer switch is depressed. (Fluid Level OK)	• No power or ground at washer pump motor. • Damaged washer pump motor or Multifunction switch. • Damaged WCM	• With ignition in RUN, depress washer switch and check for battery voltage between circuits 941 and 57 of the washer pump motor. • If voltage is present check for damaged washer pump motor. • If no voltage: a) While pressing the washer switch, check for continuity between circuits 993 and 590. If resistance is greater than 5 ohms, service for open circuit or damaged Multifunction switch. b) Check continuity of circuit 941 between the washer pump and WCM. Also check ground connection to washer pump. If OK then replace WCM.