C175 Gasoline engines

12A581

Powertrain Control Module (PCM) (12A650)



F104001

* with automatic transmission
** California

Pin	Circuit	Circuit function
1	1025 (OG/YE)	Ignition coil (12029), control
2	–	not used
3	570 (BK/WH)	Ground
4	322 (LB/YE)	Customer access 1
5	–	not used
6	*237 (OG/YE)	Shift solenoid A
7	–	not used
8	–	not used
9	–	not used
10	–	not used
11	*315 (VT/OG)	Shift solenoid B
12	*911 (WH/LG)	Transmission Control Indicator Lamp (TCIL)
13	107 (VT)	Module programming signal
14	–	not used
15	915 (PK/LB)	SCP Bus –
16	914 (TN/OG)	SCP Bus +
17	–	not used
18	–	not used
19	–	not used
20	*924 (BN/OG)	to transmission coast clutch solenoid
21	349 (DB)	Crankshaft position sensor (6C315) +
22	350 (GY)	Crankshaft position sensor (6C315) –
23	570 (BK/WH)	Ground
24	570 (BK/WH)	Ground
25	567 (LB/YE)	Ground

Pin	Circuit	Circuit function
26	1024 (LG/WH)	Ignition coil (12029), control
27	1021 (LG/YE)	Ignition coil (12029), control
28	–	not used
29	224 (TN/WH)	Powertrain Control Module (PCM) (12A650), to transmission overdrive cancel switch
30	–	not used
31	–	not used
32	311 (DG/VT)	Knock sensor (12A699)
33	676 (PK/OG)	Vehicle Speed Sensor (VSS) –
34	1144 (YE/BK)	Digital Transmission Range (DTR) sensor TR1
35	**392 (RD/LG)	Heated Oxygen Sensor (HO2S) #21 (9F472), input
36	968 (TN/LB)	Mass Air Flow (MAF) sensor (12B579), signal, return
37	*923 (OG/BK)	Transmission Fluid Temperature (TFT) sensor, input
38	–	not used
39	743 (GY)	Intake Air Temperature (IAT) sensor (12A697), input
40	238 (DG/YE)	Fuel pump, monitor
41	439 (TN/LG)	A/C pressure switch, signal
42	1101 (GY/RD)	Fuel injector 10 (9F593), control
43	71 (OG/LG)	Powertrain Control Module (PCM) (12A650) – Data output link
44	–	not used
45	–	not used
46	–	not used

Pin	Circuit	Circuit function
47	**360 (BN/PK)	EGR Vacuum Regulator (EVR), control
48	76 (LG/WH)	Customer access 1
49	1145 (LB/BK)	Digital Transmission Range (DTR) sensor, TR2
50	*1143 (WH/BK)	Digital Transmission Range (DTR) sensor TR4
51	570 (BK/WH)	Ground
52	1028 (WH/PK)	Ignition coil (12029), control
53	1030 (DG/VT)	Ignition coil (12029), control
54	*480 (VT/YE)	Torque Converter Clutch (TCC) solenoid
55	729 (RD/WH)	Voltage supplied at all times (overload protected)
56	191 (LG/BK)	EVAP canister purge valve, control
57	310 (YE/RD)	Knock sensor (12A699)
58	679 (GY/BK)	Vehicle Speed Sensor (VSS) +
59	*970 (DG/WH)	Powertrain Control Module (PCM) (12A650) – Turbine Shaft Speed (TSS) sensor
60	74 (GY/LB)	Heated Oxygen Sensor (HO2S) #11 (9F472), input
61	–	not used
62	**791 (RD/PK)	Fuel tank pressure transducer sensor (9C968)
63	–	not used
64	199 (LB/YE)	Digital Transmission Range (DTR) sensor, TR3A
65	**352 (BN/LG)	Differential Pressure Feedback EGR (DPFE) sensor, input
66	1102 (YE/LG)	Cylinder–head temperature sensor (6G004), to, Powertrain Control Module (PCM) (12A650)
67	**91 (VT/WH)	Canister vent
68	1100 (GY/BK)	Fuel injector 9 (9F593), control
69	331 (PK/YE)	A/C clutch relay, control
70	–	not used
71	361 (RD)	Voltage supplied in Start and Run (overload protected)
72	561 (TN/RD)	Fuel injector 7, control
73	559 (TN/BK)	Fuel injector 5, control
74	557 (BN/YE)	Fuel injector 3, control

Pin	Circuit	Circuit function
75	555 (TN)	Fuel injector 1, control
76	570 (BK/WH)	Ground
77	570 (BK/WH)	Ground
78	1027 (PK/LB)	Ignition coil (12029), control
79	1029 (WH/RD)	Ignition coil (12029), control
80	926 (LB/OG)	Fuel pump relay, control
81	*925 (WH/YE)	Electronic Pressure Control (EPC) solenoid, control
82	1142 (WH/RD)	Ignition coil (12029), control
83	264 (WH/LB)	Idle Air Control (IAC) valve (9F715), control
84	136 (DB/YE)	Powertrain Control Module (PCM) (12A650) – Output Shaft Speed (OSS) sensor (7M101)
85	795 (DG)	Camshaft position sensor (6B288), signal
86	–	not used
87	94 (RD/BK)	Heated Oxygen Sensor (HO2S) #21 (9F472), input
88	967 (LB/RD)	Mass Air Flow (MAF) sensor (12B579), output
89	355 (GY/WH)	Throttle Position Sensor (TPS) (9B989), input
90	351 (BN/WH)	Reference, voltage
91	359 (GY/RD)	signal, return
92	810 (RD/LG)	Brake pedal position switch (13480), input
93	387 (RD/WH)	Heated Oxygen Sensor (HO2S) #11 (9F472), heater
94	388 (YE/LB)	Heated Oxygen Sensor (HO2S) #21 (9F472), heater
95	**389 (WH/BK)	Heated Oxygen Sensor (HO2S) #12 (9G444), heater
96	–	not used
97	361 (RD)	Voltage supplied in Start and Run (overload protected)
98	562 (LB)	Fuel injector 8, control
99	560 (LG/OG)	Fuel injector 6, control
100	558 (BN/LB)	Fuel injector 4, control
101	556 (WH)	Fuel injector 2, control
102	1141 (YE/BK)	Ignition coil (12029), control
103	570 (BK/WH)	Ground
104	1026 (PK/WH)	Ignition coil (12029), control

C175 7.3L Diesel

12A581

Powertrain Control Module (PCM) (12A650)



F104001

* with automatic transmission

Pin	Circuit	Circuit function
1	–	not used
2	–	not used
3	3996 (RD/YE)	Manifold intake air heater relay, monitor
4	–	not used
5	162 (LG/RD)	Parking brake switch (15A851)
6	*237 (OG/YE)	Shift solenoid A
7	–	not used
8	1277 (WH/LG)	Glow plug relay, monitor
9	–	not used
10	1285 (RD/LG)	Idle validation switch
11	*315 (VT/OG)	Shift solenoid B
12	*911 (WH/LG)	Transmission Control Indicator Lamp (TCIL)
13	107 (VT)	Module programming signal
14	–	not used
15	915 (PK/LB)	SCP Bus –
16	914 (TN/OG)	SCP Bus +
17	*1144 (YE/BK)	Digital Transmission Range (DTR) sensor, TR1
18	331 (PK/YE)	A/C clutch relay, control
19	76 (LG/WH)	Tachometer output
20	*924 (BN/OG)	Powertrain Control Module (PCM) (12A650), to transmission coast clutch solenoid
21	795 (DG)	Camshaft position sensor (6B288)
22	–	not used
23	–	not used

Pin	Circuit	Circuit function
24	357 (YE/WH)	Accelerator pedal position sensor, Ground
25	567 (LB/YE)	Ground
26	–	not used
27	–	not used
28	–	not used
29	224 (TN/WH)	Powertrain Control Module (PCM) (12A650), to transmission overdrive cancel switch – Automatic
	306 (TN/LB)	Clutch switch – Manual
30	553 (VT/LB)	Exhaust Back Pressure (EBP) sensor, monitor
31	307 (BK/YE)	Brake pressure switch (2B264), input
32	–	not used
33	–	not used
34	–	not used
35	1183 (WH/YE)	Generator
36	1280 (GY/RD)	Water–in–fuel sensor
37	923 (OG/BK)	Transmission Fluid Temperature (TFT) sensor, input – Automatic
	923 (OG/BK)	Engine Oil Temperature (EOT) sensor, signal – Manual
38	354 (LG/RD)	Engine Oil Temperature (EOT) sensor, signal
39	743 (GY)	Intake Air Temperature (IAT) sensor (12A697), input
40	787 (PK/BK)	Fuel pump, monitor
41	439 (TN/LG)	A/C high pressure switch (19D594)
42	318 (GY/RD)	Exhaust Pressure Regulator (EPR), control

Pin	Circuit	Circuit function
43	71 (OG/LG)	Powertrain Control Module (PCM) (12A650) – Data output link
44	–	not used
45	203 (OG/LB)	Cruise set, indicator, control
46	–	not used
47	1275 (WH/RD)	Waste gate solenoid, control
48	818 (GY/WH)	Injector Driver Module (IDM)
49	*1145 (LB/BK)	Digital Transmission Range (DTR) sensor TR2
50	*1143 (WH/BK)	Digital Transmission Range (DTR) sensor TR4
51	570 (BK/WH)	Ground
52	–	not used
53	–	not used
54	*480 (VT/YE)	Torque Converter Clutch (TCC) solenoid
55	729 (RD/WH)	Voltage supplied at all times (overload protected), keep alive memory
56	–	not used
57	–	not used
58	679 (GY/BK)	Vehicle Speed Sensor (VSS) +
59	*136 (DB/YE)	Powertrain Control Module (PCM) (12A650), – Output Shaft Speed (OSS) sensor (7M101)
60	1185 (YE)	Generator and Regulator
61	151 (LB/BK)	Speed control switch, input
62	1291 (RD/YE)	Air Charge Temperature (ACT) sensor
63	–	not used
64	199 (LB/YE)	TR3A – Automatic Clutch pedal position switch – Manual
65	796 (LB)	Camshaft position sensor (6B288), Signal return
66	322 (LB/YE)	PTO control
67	904 (LG/RD)	Generator/Battery indicator, control
68	–	not used
69	–	not used
70	–	not used
71	361 (RD)	Voltage supplied in Start and Run (overload protected)

Pin	Circuit	Circuit function
72–76	–	not used
77	570 (BK/WH)	Ground
78	–	not used
79	358 (LG/BK)	Manifold Absolute Pressure (MAP) sensor, to, Powertrain Control Module (PCM) (12A650)
80	814 (WH/BK)	Injector Driver Module (IDM) power relay, control
81	*925 (WH/YE)	Electronic Pressure Control (EPC) solenoid
82	–	not used
83	552 (YE/RD)	Injection Pressure Regulator (IPR), control
84	970 (DG/WH)	Turbine Shaft Speed (TSS) sensor
85	–	not used
86	–	not used
87	812 (DB/LG)	Injection pressure sensor, monitor
88	–	not used
89	355 (GY/WH)	Accelerator pedal position sensor, input
90	351 (BN/WH)	Reference voltage
91	359 (GY/RD)	Signal return
92	810 (RD/LG)	Brake pedal position switch (13480), input
93	–	not used
94	926 (LB/OG)	Fuel pump relay, control
95	821 (BN/OG)	fuel delivery command signal output
96	817 (YE/LB)	Injector Driver Module (IDM), cylinder identification
97	361 (RD)	Voltage supplied in Start and Run (overload protected)
98	462 (VT)	Manifold intake air heater relay, control
99	–	not used
100	–	not used
101	1086 (VT/OG)	Glow plugs, control
102	–	not used
103	570 (BK/WH)	Ground
104	–	not used