C111

12B637

Coil On Plug (COP)
1 (12029)

F02371

Pin	Circuit	Circuit function
1	16 (RD/LG)	Voltage supplied in Start and Run (overload protected)
2	1024 (LG/WH)	Switched ground

C112

12B637

Coil On Plug (COP)
2 (12029)

F02371

Pin	Circuit	Circuit function
1	16 (RD/LG)	Voltage supplied in Start and Run (overload protected)
2	1026 (PK/WH)	Switched ground – 5.4L
	1027 (PK/LB)	Switched ground – 6.8L

C113

12B637

Coil On Plug (COP)
3 (12029)

F02371

Pin	Circuit	Circuit function
1	16 (RD/LG)	Voltage supplied in Start and Run (overload protected)
2	1026 (PK/WH)	Switched ground – 6.8L
	1028 (WH/PK)	Switched ground – 5.4L

C114

12B637

Coil On Plug (COP)
4 (12029)

F02371

Pin	Circuit	Circuit function
1	16 (RD/LG)	Voltage supplied in Start and Run (overload protected)
2	1141 (YE/BK)	Switched ground – 6.8L
	1030 (DG/VT)	Switched ground – 5.4L

C115

12B637

Coil On Plug (COP)
5 (12029)

F02371

Pin	Circuit	Circuit function
1	16 (RD/LG)	Voltage supplied in Start and Run (overload protected)
2	1028 (WH/PK)	Switched ground – 6.8L
	1021 (LG/YE)	Switched ground – 5.4L

C116

12B637

Coil On Plug (COP)
6 (12029)

F02371

Pin	Circuit	Circuit function
1	16 (RD/LG)	Voltage supplied in Start and Run (overload protected)
2	1025 (OG/YE)	Switched ground