Aviator Wiring Diagrams

Table of Contents

Table of Contents 1-1
Index 2-1
Introduction....3-1
Symbols 4-1
Connector Repair Procedures 5-1
Systems Overview 8-1
Wiring Harness Overview....9-1
Grounds....10-1
Fuse and Relay Information....11-1
Charging System....12-1
Power Distribution....13-1
Module Communications Network....14-1
Starting System....20-1
Engine Ignition 21-1
Engine Controls (4.6L) 24-1
Transmission Controls 29-1
Vehicle Speed Control 31-1
Navigation System....32-1
Electronic Shift Control....34-1
Shift Lock 37-1
ABS....42-1
Variable Assist Power Steering....43-1
Horn/Cigar Lighter/Clock....44-1
Air Bags 46-1
Auxiliary Air Conditioner/Heater 52-1
EATC 55-1
Rear Window Defrost 56-1
Instrument Cluster....60-1
Warning Devices....66-1
Illumination....71-1
Wipers and Washers....81-1
Liftgate Wiper....82-1
Headlamps 85-1
Fog Lamps 86-1
Courtesy Lamps 89-1
Turn/Stop/Hazard Lamps....90-1
Exterior Lamps 92-1
Reversing Lamps 93-1
Trailer/Camper Adapter 95-1
Daytime Running Lamps....97-1
Power Windows 100-1
Roof Opening Panel....101-1
Overhead Console....102-1
Power Door Locks 110-1
Anti-Theft 112-1
Remote Control Alarm and Locks 117-1
Pressure Alert System 118-1
Climate Controlled Seats 119-1
Power Seats....120-1
Memory Seats 123-1
Power Mirrors....124-1
Adjustable Pedal 127-1
Radio....130-1
Parking Aid 131-1
Rear Seat Entertainment 132-1
Vehicle Emergency Messaging System 136-1
Component Testing 149-1
Connector Views....150-1
Component Location Views....151-1
Component Location Charts 152-1
Vehicle Repair Location Charts 160-1
S.P.E.C.S. Submission Form