124-1 POWER MIRRORS

2001 CROWN VICTORIA/GRAND MARQUIS

For diagnostic information, refer to Section 501-09 of the Workshop Manual.

Directs current to power mirror motors, and controls mirror movement.

HOT AT ALL TIMES

CENTRAL JUNCTION BOX *PAGE 13-6*

23

15A

SEE POWER DISTRIBUTION *PAGE 13-9*

54 **LG/YE**

12V **C550F C550M**

EXTERIOR REAR VIEW MIRROR SWITCH

151–9 A3

U D U D

L R

DIRECTIONAL CONTROL SWITCH

LEFT/RIGHT MIRROR SELECTOR SWITCH

C550M C550F

544 VT

543 DG

541 DB

540 RD

542 YE

C608M C608F

C508M C508F

S246

C508F C508M

542 YE

C608F C608M

545 WH

UP/DN MOTOR

L/R MOTOR

M

1 2 3

RIGHT EXTERIOR REAR VIEW MIRROR

151–11 A4

LEFT EXTERIOR REAR VIEW MIRROR

151–9 A2

Reversing current in two bi-directional motors enables mirror to move both horizontally (left and right) and vertically (up and down).

0V **C550M C550F**

57 BK

S500

SEE GROUNDS *PAGES 10-8, 10-9*

57 BK

G200

Reversing current in two bi-directional motors enables mirror to move both horizontally (left and right) and vertically (up and down).

Refer to Location Index, Cell 152, for Component, Connector, Splice, Ground and Base Part Number descriptions and locations.