Harnesses

14401 IP harness B2

C Numbers

C123 Inline (14401 to 14305) G5
C124 Inline (14401 to 12A581) F5
C132 Inline (14401 to 14406) G5
C201 Central Junction Box (CJB)....F7
C202 GEM module E8
C203 GEM module E8
C204 Clutch switch G6
C205 Main lamp switch....D8
C206 Main lamp switch....D8
C208 Brush assembly....F6
C213 Instrument cluster....B7
C214 Instrument cluster....B8
C215 Instrument cluster....B6
C217 Data link connector....F3
C218 Park brake switch....F3
C220 Air pressure illumination F3
C221 Blend door pot....B5
C222 Climate switch illumination A5
C224 Blower speed control switch A5
C226 Cigar lighter A3
C227 Blend door actuator F2
C232 Power point B4
C233 Daytime running lights A5
C235 Radio A4
C236 Inline (14401 to 14A005)....G5
C237 Inline (14401 to 14A005) F4
C238 Throttle sensor (with CAT engine) G4
C245 Inline (IP harness to MD jumper harness) G7
C252 Cruise control set-resume switch B7
C253 Cruise control on-off switch....B7
C254 Auto traction control switch....A4
C258 Air suspension dump switch A4
C259 Exhaust brake switch A6

C Numbers

C266a Two speed axle switch B6
C266b Diff lock switch....B6
C329 Shift selector....E3
C452a 2 speed relay F6
C452b Diff lock relay....F6
C599 Flasher & power window relay block C8
C610 Hydraulic ABS event relay....E3
C611 Hydraulic ABS warning relay E7
C705 Speed control....E1
C1650 Engine diagnostic conn....F7
C1657 Terminating resistor....E2
C1804 Accel pedal (with V8 AVNT engine) G4
C1808 BAP sensor F3
C2011 Air solenoid power F3
C2013 Ground splice A3
C2014 Stop power adapter....C8
C2015 Panel power feed F7
C2016 CJB-F29 adapter G6
C2017 Power adapter....G4

Grounds

G200 Left cowl ground F7
G201 Center instrument panel ground....G4
G202 Right cowl ground F1