C111 (BK)

14A103

N400
Washer fluid level switch



F02167

Pin	Circuit	Circuit Function
1	NFE1 (BK)	Ground
2	NF01 (GN/BK)	Low washer fluid indicator

C113 (GY)

12B559

B105
Knock sensor 1

F02137

Pin	Circuit	Circuit Function
1	–	not used
2	AV27 (WH)	Knock sensor

C115 (BK)

14A103

N17
Oil pressure switch



F01035

Pin	Circuit	Circuit Function
1	MD01 (RD)	Engine oil pressure indicator, control

C116 (GY)

14A103

M8
Starter motor



F01037

Pin	Circuit	Circuit Function
1	ST02 (RD/WH)	switched power, to starter solenoid

C117 (WH)

14A103

O5
Generator



F02146

Pin	Circuit	Circuit Function
1	DA28 (YE/BK)	Generator/Battery indicator, control
2	DA27 (BU)	Voltage supplied at all times (overload protected)

C120 (BN)

14A103

B15
Wheel speed sensor, left front

F02169

Pin	Circuit	Circuit Function
1	BS05 (BU/GN)	Wheel speed sensor, left front
2	BS04 (BU/YE)	Wheel speed sensor, left front

C121 (GY)

14A103

B14
Wheel speed sensor, right front

F02169

Pin	Circuit	Circuit Function
1	BS23 (GN)	Wheel speed sensor, right front
2	BS21 (RD)	Wheel speed sensor, right front

C122 (GY)

14A103

N1
Brake fluid level switch



F02133

Pin	Circuit	Circuit Function
1	NB01 (YE/VT)	Brake indicator, control
2	NBE1 (BK)	Ground