Distributed Splice

Crossed Wiring Without Connection


Splice

Removable Connection

Ground

Connector

Female Connector


Male Connector

Entire Component

Part Of A Component

Component Case Directly Attached To Metal Part Of Vehicle (Ground)


Component With Screw Terminals


Connector Attached To Component

Hall Sensor


Connector Attached To Component Lead (Pigtail)

Resistor Or Heating Element

Potentiometer (Pressure Or Temperature)

Potentiometer (Outside Influence)

Battery

Fuse

Circuit Breaker

Heating Element, Conductor Loop