## Master window adjust switch (14529) (continued)

### Component testing procedure

| Circuit to test | Connect self–powered test light or ohmmeter to terminals | Move switch to these positions | A good switch will indicate |
|---|---|---|---|
| **Power and Ground Checks Before Any Other Tests** | 7 and 6 | All window switches, all positions | Open circuit |
| | 6 and 4, 5, 2, 1, 7, 6, 5, 4 | All window switches, at rest | Closed circuit |
| **Left front window circuit** | 7 and 4 | Down | Closed circuit |
| | 7 and 5 | Up | Closed circuit |
| **Right front window circuit** | 7 and 1 | Up | Closed circuit |
| | 7 and 2 | Down | Closed circuit |
| **Left rear window circuit** | 7 and 2 | Up | Closed circuit |
| | 7 and 6 | Down | Closed circuit |
| **Right rear window circuit** | 7 and 5 | Up | Closed circuit |
| | 7 and 4 | Down | Closed circuit |
| **Window lockout** | 7 and 3 | Window lockout, closed | Closed circuit |
| | | Window lockout, Open | Open circuit |
| **Automatic, switch** | 7 and 3 | Automatic, switch, On | Closed circuit |
| | | Automatic, switch, at rest | Open circuit |