Fuse	Amps	Circuits protected
F1.01	10	Coolant control valve solenoid (18495), Auxiliary coolant pump relay, A/C clutch relay
F1.02	–	not used
F1.03	15	Fog lamp relay
F1.04	20	Horn relay
F1.05	15	Mass Air Flow (MAF) sensor (12B579), Variable valve timing solenoid 1, Variable valve timing solenoid 2, Engine cooling fan motor, Fuel injector 1 (9F593), Fuel injector 2 (9F593), Fuel injector 3 (9F593), Fuel injector 4 (9F593), Fuel injector 5 (9F593), Fuel injector 6 (9F593), Fuel injector 7 (9F593), Fuel injector 8 (9F593)
F1.06	15	Brake pressure switch (2B264), Evaporative emission (EVAP) canister vent valve (9F945), Automatic transmission (7C078), EVAP canister purge valve, Exhaust Pressure Transducer (EPT) sensor, IMRC Solenoid 1, IMRC Solenoid 2
F1.07	–	not used
F1.08	–	not used
F1.09	–	not used
F1.10	–	not used
F1.11	15	Heated Oxygen Sensor (HO2S) #11 (9F472), Heated Oxygen Sensor (HO2S) #21 (9F472), Heated Oxygen Sensor (HO2S) #22 (9G444), Heated Oxygen Sensor (HO2S) #12 (9G444), A/C clutch relay

Fuse	Amps	Circuits protected
F1.12	10	Coil On Plug (COP) 1 (12029), Coil On Plug (COP) 2 (12029), Coil On Plug (COP) 3 (12029), Coil On Plug (COP) 4 (12029), Coil On Plug (COP) 5 (12029), Coil On Plug (COP) 6 (12029), Coil On Plug (COP) 7 (12029), Coil On Plug (COP) 8 (12029), Ignition transformer capacitor 1 (18801), Ignition transformer capacitor 2 (18801)
F1.13	30	Heated wiper park relay
F1.14	30	ABS control module (2C219), ABS test connector
F1.15	–	not used
F1.16	30	Blower motor relay
F1.17	–	not used
F1.18	–	not used
F1.19	30	Electronic park brake module
F1.20	30	Windshield wiper motor (17508)
F1.21	30	Starter relay (11450)
F1.22	40	ABS control module (2C219)
F1.23	10	not used
F1.24	–	not used
F1.25	60	Engine cooling fan motor