C501

14B188

Y28
Speaker, left front
(18808)



F02263

Pin	Circuit	Circuit function
1	RA50 (GY/BU)	Speaker, left front (18808)
	RA40 (GY/BU)	Speaker, left front (18808)
2	RA51 (YE/BU)	Speaker, left front (18808)
	RA41 (YE/BU)	Speaker, left front (18808)

C502a (WH)

14B188

M220
Exterior rear view
mirror, driver side
(17682)

F05087

Pin	Circuit	Circuit function
1	KAE2 (BK)	Ground
2	KA20 (GN)	Rear window defrost relay, switched output
3	KA51 (YE/GN)	Mirror motor, feed
	KA11 (YE)	Mirror motor, feed
4	KA13 (YE/BK)	Right/Left mirror movement
5	KA15 (OG)	Up/Down mirror movement

C502b (GY)

14B188

M220
Exterior rear view
mirror, driver side
(17682)

F05087

Pin	Circuit	Circuit function
1	KA23 (WH)	Exterior rear view mirror switch (17B676) - position sense
2	KA29 (BU/WH)	Exterior rear view mirror, driver side (17682) - position sense
3	KA31 (GY/RD)	Exterior rear view mirror, driver side (17682) - position sense
4	KA45 (BK/BU)	Exterior rear view mirror switch (17B676) - position sense
5	KA62 (YE)	Mirror motor, feed

C503 (BK)

14B188

M80
Power window mo-
tor, driver side front
(23395)



F02125

Pin	Circuit	Circuit function
1	PD15 (VT)	Master window adjust switch (14529), feed, Down
2	PD14 (BU/RD)	Master window adjust switch (14529), feed, Up