14398 - S26

Splice Location: B8 - Near Battery Junction Box (BJB)

- 12 to 14401
- 697 to 14401 Multi-function switch
- 697 to Battery Junction Box (BJB)

14398 - S27

Splice Location: C1 - Near Auxiliary Junction Box (AJB) (F4), RH Side

- 1153 to Engine cooling fan relay
- 1153 to Engine cooling fan relay
- 1153 to Battery Junction Box (BJB)

14398 - S28

Splice Location: E8 - Engine Compartment, LH Side Front

- 914 to Powertrain Control Module (PCM)
- 914 to 14398 ABS control module
- 914 to Splice 14401-S22

14398 - S29

Splice Location: E8 - Engine Compartment, LH Side Front

- 915 to Powertrain Control Module (PCM)
- 915 to 14398 ABS control module
- 915 to Splice 14401-S23

14398 - S31

Splice Location: G7 - On ABS Control Module T/O (C155)

- 1576 to ABS control module
- 1003 to 14401 Steering position sensor
- 1574 to 2C011 Yaw velocity sensor, 4x2

14398 - S32

Splice Location: G6 - On ABS Control Module T/O (C155)

- 1577 to ABS control module
- 1571 to 14401 Steering position sensor
- 1575 to 2C011 Yaw rate sensor

14398 - S33

Splice Location: G5 - Engine Compartment, Center Front

- 478 to Fog lamp, right front
- 478 to Battery Junction Box (BJB)
- 478 to Fog lamp, left front

14398 - S34

Splice Location: A6 - Near Brake Fluid Level Switch T/O (C124)

- 374 to 14401 Multi-function switch
- 374 to Splice 13B431-S2
- 374 to Battery Junction Box (BJB)

14398 - S35

Splice Location: C9 - Passenger Compartment LH Cowl Side

- 162 to Daytime Running Lamps (DRL) module
- 162 to 14A488 Park brake switch
- 162 to 14401 Instrument cluster, inboard

14398 - S44

Splice Location: C8 - Below Battery Junction Box (BJB)

- 175 to Battery Junction Box (BJB)
- 175 to 14A488
- 175 to Battery Junction Box (BJB)
- 175 to Battery Junction Box (BJB)

14A280 - S1

Splice Location: A5 - Engine Compartment, LH Side Near Battery Junction Box (BJB)

- 35 to Generator
- 292 fusible link C to Splice 14A280-S2

14A280 - S2

Splice Location: A5 - Engine Compartment, LH Side Near Battery Junction Box (BJB)

- 292 fusible link C to Splice 14A280-S1
- 38 to Generator
- 290 fusible link A to Splice 14A280-S3
- 290 fusible-link B to Splice 14A280-S3

14A280 - S3

Splice Location: A5 - Engine Compartment, LH Side Near Battery Junction Box (BJB)

- 290 fusible link A to Splice 14A280-S2
- 290 fusible link B to Splice 14A280-S2
- 36 to Battery Junction Box (BJB)

Note: T/O = Take Out