Fuse	Amps	Circuits protected
F4.10	30	SSP 2 relay
F4.11	–	not used
F4.12	–	not used
F4.13	30	Rear window defrost relay
F4.14	30	Rear Electronic Module (REM)
F4.15	30	SSP 1 relay
F4.16	30	Seat adjust switch, passenger side front
F4.17	20	Subwoofer amplifier (18C804)
F4.18	15	Fuel pump relay
F4.19	–	not used
F4.20	5	Generator
F4.21	5	Convertible top raise relay, Convertible top lower relay
F4.22	–	not used
F4.23	5	Rear Electronic Module (REM)
F4.24	–	not used
F4.25	–	not used
F4.26	40	Central Junction Box (CJB) (14A068)
F4.27	30	SSP 3 relay

Fuse	Amps	Circuits protected
F4.28	30	SSP 4 relay
F4.29	20	Ignition switch (11572)
F4.30	–	not used
F4.31	30	Front Electronic Module (FEM) (13C788)
F4.32	30	Seat adjust switch, driver side front (14A701)
F4.33	–	not used
F4.34	5	High mounted stoplamp (13A613)
F4.35	10	Side lamp, right rear (13411), Lamp assembly, right rear (13404), Trailer exterior lamp relay
F4.36	10	Reversing lamp, left (13411), Reversing lamp, right (13411)
F4.37	–	not used
F4.38	10	Luggage compartment lamp (13A756)
F4.39	10	Lamp assembly, left rear (13405), Side lamp, left rear (13411)
F4.40	5	License lamps (13550)
F4.41	15	Rear Electronic Module (REM)