Battery Junction Box (BJB) (14A003)

Maxi–fuse	Amps	Circuits protected
F1.1	50	Ignition switch (11572), Starter relay (11450), Generator
F1.2	40	Ignition switch (11572)
F1.3	50	High speed fan control relay
F1.4	30	PCM power relay
F1.5	40	Central Junction Box (CJB) (14A068)
F1.6	–	not used
F1.7	40	Central Junction Box (CJB) (14A068)
F1.8	30	Central Junction Box (CJB) (14A068), F2.30, Lumbar adjust switch, right front, Lumbar adjust switch, left front (14B691), Driver seat module (14C718), Seat adjust switch, passenger side front, Power seat switch, left, Adjustable pedal switch
F1.9	40	ABS control module (2C219)
F1.10	40	Rear window defrost relay
F1.11	40	Accessory delay relay, Central Junction Box (CJB) (14A068)
F1.12	30	Air suspension compressor relay
F1.25	30	Lumbar adjust switch, right front, Seat adjust switch, passenger side front
F1.26	30 c.b.	Low speed fan control relay
F1.27	20	ABS control module (2C219)

Mini–fuse	Amps	Circuits protected
F1.13	30	Heated seat module, left rear, Heated seat module, right rear
F1.14	20	Rear power point
F1.15	20	Rear power point
F1.16	30	Heated seats
F1.17	10	Air suspension module (3C142)
F1.18	15	Horn relay
F1.19	30	Subwoofer amplifier (18C804), Central Junction Box (CJB) (14A068)
F1.20	15	Fuel injectors, Powertrain Control Module (PCM) (12A650), Idle air control valve (IAC) (9F715), Mass Air Flow (MAF) sensor (12B579)
F1.21	15	4R70W transmission, Heated Oxygen Sensor (HO2S) #12 (9F472), Heated Oxygen Sensor (HO2S) #22 (9F472), EVAP canister vent control solenoid, Electr. Vacuum Regulator (EVR) solenoid valve, Heated Oxygen Sensor (HO2S) #21 (9G444), Heated Oxygen Sensor (HO2S) #11 (9G444), EVAP canister purge valve
F1.22	20	Fuel pump relay
F1.23	15	Generator
F1.24	20	Power point (19N236)