Battery Junction Box (BJB) (14A003)

Fuse	Amps	Circuits protected
F1.1	20	Power point (19N236)
F1.2	30	PCM power relay
F1.3	30	Main light switch (11654), Headlamp relay, Multifunction switch
F1.4	20	Power point, console (19N236)
F1.5	20	Trailer tow relay, parking lamp, Trailer tow relay, reversing lamp
F1.6	15	Main light switch (11654), Park lamp relay
F1.7	20	Horn relay
F1.8	15	Central security module
F1.9	15	Daytime running lamps resistor, Fog lamp relay
F1.10	20	Fuel pump relay
F1.11	20	Generator
F1.12	20	Power point, rear (19G247)
F1.13	15	A/C clutch relay
F1.14	–	not used
F1.15	10	Running board lamp, left front, Running board lamp, left rear, Running board lamp, right front, Running board lamp, right rear
F1.16	15	Alternative Fuel Control Module (AFCM), Alternative fuel indicator switch, Fuel injectors
F1.17	2	Brake pressure switch (2B264)
F1.18	15	Mass Air Flow (MAF) sensor (12B579), Powertrain Control Module (PCM) (12A650), Fuel injector 1 (9F593), Fuel injector 2 (9F593), Fuel injector 3 (9F593), Fuel injector 4 (9F593), Fuel injector 5 (9F593), Fuel injector 6 (9F593), Fuel injector 7 (9F593), Fuel injector 8 (9F593), Idle Air Control (IAC) valve (9F715), Fuel pump relay, Fuel pump cutoff relay
F1.19	10	Trailer tow connector (15A416)
F1.20	10	Trailer tow connector (15A416)
F1.21	–	not used
F1.22	–	not used
F1.23	15	Evaporative emission (EVAP) canister vent valve (9F945), EVAP canister purge valve, Heated Oxygen Sensor (HO2S) #21 (9F472), Heated Oxygen Sensor (HO2S) #11 (9F472), A/C clutch relay, Heated Oxygen Sensor (HO2S) #22 (9G444), Heated Oxygen Sensor (HO2S) #12 (9G444), Automatic transmission module (7G422), Camshaft position sensor (6B288), Intake Manifold Runner Control (IMRC) module, Bi–Fuel power relay
F1.24	–	not used
F1.101	30	Trailer tow relay, battery charge
F1.102	50	ABS control module (2C219)
F1.103	50	Central Junction Box (CJB) (14A068)
F1.104	30	Transfer case relay module, Transfer case electric clutch relay, Mechanical Shift On the Fly (MSOF) relay
F1.105	40	Blower motor relay
F1.106	20	Charge air cooler pump relay
F1.107	–	not used
F1.108	30	Trailer tow connector (15A416)
F1.109	–	not used
F1.110	30	Accessory delay relay
F1.111	40	Ignition switch (11572)
F1.112	30	Adjustable pedal switch, Power seat switch, left
F1.113	40	Ignition switch (11572)
F1.114	–	not used
F1.115	20	Central security module
F1.116	40	Rear window defrost relay
F1.117	40	audio
F1.118	30	Heated seat module, passenger side front, Heated seat module, driver side front (14C724)
F1.601 C.B.	30	Accessory delay relay
F1.602 C.B.	–	not used