C112

12B637

P67
Coil On Plug (COP)
2 (12029)

F02109

Pin	Circuit	Circuit Function
1	91S-RR6 (BN/RD)	Ground, Switched
2	15-RR6 (GN/BU)	Voltage, ignition switch in Start or Run (not overload protected)

C113

12B637

P68
Coil On Plug (COP)
3 (12029)

F02109

Pin	Circuit	Circuit Function
1	91S-RR7 (BN/BU)	Ground, Switched
2	15-RR7 (GN/RD)	Voltage, ignition switch in Start or Run (not overload protected)

C114

12B637

P69
Coil On Plug (COP)
4 (12029)

F02109

Pin	Circuit	Circuit Function
1	91S-RR8 (BN/GN)	Ground, Switched
2	15–RR8 (GN/BK)	Voltage, ignition switch in Start or Run (not overload protected)

C115

12B637

P70
Coil On Plug (COP)
5 (12029)

F02183

Pin	Circuit	Circuit Function
1	91S-RR9 (BN/YE)	Ground, Switched
2	15-RR9 (GN/OG)	Voltage, ignition switch in Start or Run (not overload protected)

C116

12B637

P71
Coil On Plug (COP)
6 (12029)

F02183

Pin	Circuit	Circuit Function
1	91S-RR10 (BN/WH)	Ground, Switched
2	15-RR10 (GN/WH)	Voltage, ignition switch in Start or Run (not overload protected)

C117

12B637

P72
Coil On Plug (COP)
7 (12029)

F02183

Pin	Circuit	Circuit Function
1	91S-RR11 (BN)	Ground, Switched
2	15-RR11 (GN/YE)	Voltage, ignition switch in Start or Run (not overload protected)