Fuse	Amps	Circuits protected
F1.1	15	Main lamp switch, Door heated & lighted mirror (left), Heated/lighted mirror (right), Marker light (left & right front), Trailer tail lamp relay, Trailer marker lamp relay, Rear tail lamps, Marker lights, Heated mirrors, F2.18
F1.2	–	not used
F1.3	–	not used
F1.4	15	Washer pump relay, Washer pump
F1.5	15	Exhaust brake relay (CAT, Cummins), Exhaust brake solenoid (CAT)
F1.6	15	Air intake heater conn (CAT)
F1.7	15	W/Hydraulic brakes: Stop lp sw (N.O.), Tractor stop lp sw (N.O.) W/Air brakes: Stop lamp switch (N.O.), Stop lamp switch (N.O.)
F1.8	20 - V8 25 - CAT	Fuel heater - fuel transfer pump relay, Fuel filter, F1.18
F1.9	–	not used
F1.10	15	Drain valve heater relay, Heated drain(left side #1), Heated drain #2, Heated drain #3
F1.11	–	not used
F1.12	–	not used
F1.13	–	not used
F1.14	–	not used
F1.15	7.5 (V8 Only)	Back of cab: Trailer stop lamp relay Body & trailer: Trailer stop lamp relay, Customer access
F1.16	5	Wabco Hyd ABS ECU - black
F1.17	–	not used
F1.18	10	Fuel transfer pump
F1.19	–	not used
F1.20	10	ECM ISO relay (V8), ECM2 connector, IDM2 connector
F1.21	10	Central Junction Box (CJB), GEM module
F1.22	10	IDM2 connector
F1.23	–	not used
F1.24	–	not used
F1.101	30	W/Air brakes: Air ABS relay, Air ABS ECU #1 W/Hydraulic brakes: Hydraulic modulator relay, Wabco Hyd ABS ECU - black, Pump assembly
F1.102	20	Key switch, Customer access run circuit

Fuse	Amps	Circuits protected
F1.103	50	Key switch, Central Junction Box (CJB) F2.8, F2.9, F2.10, F2.11, F2.19, F2.20, F2.22, F2.23, F2.24, F2.25, F2.29, F2.30, F2.31
F1.104	20	Power point
F1.105	20	Door lock switch (left front), Door power lock switch (right front)
F1.106	30	Main lamp switch, Multi-function switch, DRL relay #2, Central Junction Box (CJB) F2.16, F2.26, F2.28 Less DRL: Daytime running lights cap With DRL: Daytime running lights
F1.107	50	Central Junction Box (CJB) F2.1, F2.2, F2.3, F2.4, F2.12, F2.13, F2.14, F2.15
F1.108	40	Fuel heater - fuel transfer pump relay, Fuel heater thermostat, F2.?
F1.109	40	Flasher & power window relay block, One touch down relay, Door power window switch (right front) Less crew cab: Window switch #1 (left, with reg & super cab) With crew cab: Window switch #1 (left, with crew cab)
F1.110	30	Seat regulator control
F1.111	30	Park lamp relay, Body builder conn
F1.112	40	Blower motor relay, Blower motor
F1.113	30	Heated seat module (drivers side), Heated seat module (pass side)
F1.114	25	Wabco Hyd ABS ECU - black
F1.115	40	Key switch, Central Junction Box (CJB) F2.5, F2.8, F2.9, F2.10, F2.11, F2.21
F1.116	30	Stop-turn relay (left), Stop-turn relay (right), Back-up lamps relay, Body builder conn
F1.117	20	Stop lamp relay (CAT, Cummins) Back of Cab Trailer Socket: Trailer stop lamp relay End of Frame: Trailer stop lamp relay, Body builder conn
F1.118	30	Passenger seat adjust switch
F1.119	60	Trailer Relay Fuse Box (TRFB) F3.2, F3.3
F1.120	60	Trailer Relay Fuse Box (TRFB) F3.2, F3.3
F1.121	60	Hydraulic Brakes: Hydromax realy, Hydra-Max pump motor, F1.21 Air Brakes: Trailer Relay Fuse Box (TRFB) F3.1, F3.4
F1.122	60	Hydraulic Brakes: Hydromax realy, Hydra-Max pump motor, F1.21 Air Brakes: Trailer Relay Fuse Box (TRFB) F3.1, F3.4