Instrument Panel and Console
501–12–00

Multifunction Electronic Control Modules
419–10–00

Anti–Theft – Passive
419–01B–00

Anti–Theft – Active
419–01A–00

Speakers
415–03–00

Audio Unit
415–01–00

Horn
413–06–00

Instrument Cluster
413–01–00

Instrument Cluster and Panel Illumination
413–00–00

Air Conditioning
412–03A–00

Heating and Ventilation
412–02A–00

Fuel Charging and Controls – ZETEC–E
303–04B–00

Fuel Charging and Controls – SPI
303–04E–00

Fuel Charging and Controls – Duratec–ST
303–04G–00

Starting System –
303–06–00

Electronic Engine Controls – ZETEC–E
303–14B–00

Electronic Engine Controls – SPI
303–14E–00

Electronic Engine Controls – Duratec–ST
303–14G–00

Vehicle Speed Control
310–03–00

Engine Ignition – ZETEC–E
303–07B–00

Engine Ignition – SPI
303–07E–00

Engine Ignition – Duratec–ST
303–07G–00

Module Communications Network
418–00–00

Interior Lighting
417–02–00

Wipers and Washers
501–16–00

Rear View Mirrors
501–09–00

Exterior Lighting – License Plate Illumination
417–01–00–18



Exterior Lighting – Stoplamps
417–01–00–3

Exterior Lighting – Back-up Lamps
417–01–00–20

Exterior Lighting – Headlamps
417–01–00–1

Exterior Lighting – Turn Signal Lamps
417–01–00–11

Exterior Lighting – Position and Parking Lamps
417–01–00–15

Exterior Lighting – Fog lamps
417–01–00–19

Daytime Running Lamps
417–04–00

Engine Cooling
303–03–00

Generator and Regulator
414–02–00

Anti–Lock Control
206–09A–00

Anti–Lock Control – Anti–Wheelspin Control
206–09B–00

Anti–Lock Control – Stability Assist
206–09C–00

Seating
501–10–00

Glass, Frames and Mechanisms
501–11–00

Occupant Restraints – Active
501–20A–00

Occupant Restraints – Passive
501–20B–00

Handles, Locks, Latches and Mechanisms
501–14A–00