Battery Junction Box (BJB) (14A003)

Maxi–fuse	Amps	Circuits protected
F1.1	25	Subwoofer amplifier (18C804), Radio (18806), CD changer (18D806)
F1.2	20	Power point (19N236)
F1.3	25	Heated seat module, driver side front, Heated seat module, passenger side front
F1.4	15	Horn relay
F1.5	20	Fuel pump relay
F1.6	20	Police auxiliary junction box, rear
F1.7	25	Roof opening panel relay
F1.8	20	Driver Door Module
F1.9	–	not used
F1.10	–	not used
F1.11	20	Daytime Running Lamps (DRL) module
F1.12	–	not used
F1.13	–	not used
F1.14	–	not used
F1.15	–	not used
F1.16	–	not used
F1.17	–	not used
F1.18	–	not used
F1.19	15	Natural Gas Vehicle (NGV) module, Mass Air Flow (MAF) sensor (12B579), Powertrain Control Module (PCM) (12A650), Heated Oxygen Sensor (HO2S) #22 (9G444), Idle air control valve (IAC) (9F715), Differential pressure feedback EGR (DPFE) sensor (9J460), Fuel injectors
F1.20	15	Vapor management valve, Differential pressure feedback EGR (DPFE) sensor (9J460), 4R70W transmission, Heated oxygen sensors (HO2S), Evaporative emission (EVAP) canister vent valve (9F945)
F1.21	–	not used
F1.22	–	not used
F1.23	–	not used
F1.24	–	not used
F1.101	30	Starter relay (11450), Generator, Ignition switch (11572)
F1.102	50	Engine cooling fan motor
F1.103	40	Blower motor relay
F1.104	40	Rear window defrost relay

Maxi–fuse	Amps	Circuits protected
F1.105	30	Powertrain Control Module (PCM) (12A650), PCM power relay, Natural Gas Vehicle (NGV) module, Data Link Connector (DLC) (14489)
F1.106	40	ABS control module (2C219)
F1.107	–	not used
F1.108	–	not used
F1.109	50	not used
F1.110	50	Police auxiliary junction box, front, Police auxiliary junction box, rear
F1.111	30	Police power relay
F1.112	50	Central Junction Box (CJB) (14A068), Ignition switch (11572)
F1.113	50	Central Junction Box (CJB) (14A068)
F1.114	30	Variable Assist Power Steering (VAPS) module, Air suspension module (3C142), Air suspension compressor relay, Instrument cluster
F1.115	50	Ignition switch (11572)
F1.116	30	Windshield wiper motor (17508)
F1.117	50	Police auxiliary junction box, front, Police auxiliary junction box, rear
F1.118	20	ABS control module (2C219)
F1.602	20cb	Seat adjust switch, driver side front (14A701), Lumbar adjust switch, left front (14B691), Fuel door release switch, Luggage compartment lid release switch 2, Adjustable pedal switch, Lumbar adjust switch, right front, Seat adjust switch, passenger side front, Door lock switch, driver side (14028), Luggage compartment lid release switch 1, Door lock switch, passenger side (14028)