C107 (GY)

14405, 14A584

E174
High mounted sto-plamp



F02047

Pin	Circuit	Circuit Function
1	15S-LG6 (GN/YE)	Voltage, ignition switch in Start or Run (not overload protected), switched
2	31-LG6 (BK)	Ground

C120

12A522

F01009

M8
Starter motor

Pin	Circuit	Circuit Function
1	50-BB12 (GY)	Battery voltage, hot in Start only (not overload protected)
	50S-BB12 (GY)	Battery voltage, hot in Start only (not overload protected), switched