Components — Cell 151

	Location	Page/coordinates
P72	Coil On Plug (COP) 7 (12029) engine, LH side	1 – D 2
P73	Coil On Plug (COP) 8 (12029) engine, LH side	1 – E 2
P89	Coil On Plug (COP) 9 engine, LH side	1 – E 2
P91	Central Junction Box (CJB) (14A068) in Central Junction Box (CJB)	9 – B 1
P93	Battery Junction Box (BJB) (14A003) in Battery Junction Box (BJB)	5 – A 1
P111	Auxiliary relay box 1 engine compartment, LH side	6 – D 1
P140	Air bag sliding contact (14A664) Steering Column	7 – C 1
P150	Coil On Plug (COP) 10 engine, LH side	1 – E 2
R5	Daytime running lamps resistor engine, front	5 – B 1
U10	Ignition transformer capacitor 1 (18801) engine, RH side	3 – A 3
U11	Ignition transformer capacitor 2 (18801) engine, front, LH side	2 – A 2
V7	A/C Compressor clutch diode engine, front, RH side	
V34	PCM Module power diode in Battery Junction Box (BJB)	5 – A 1
V61	Brake warning indicator diode in Battery Junction Box (BJB)	5 – A 1
V67	Diode 1 behind dash panel	
V68	Diode 2 behind dash panel	
V69	Diode 3 behind dash panel	
V70	Diode 4 behind dash panel	
Y52	A/C clutch field coil (19D798) engine, front, RH side	4 – E 3
Y108	Injector 1 (9F593) engine, RH side	4 – A 4
Y109	Injector 2 (9F593) engine, RH side	4 – B 4
Y110	Injector 3 (9F593) engine, RH side	4 – A 3
Y111	Injector 4 (9F593) engine, RH side	4 – B 3
Y112	Injector 5 (9F593) engine, LH side	4 – A 3
Y113	Injector 6 (9F593) engine, LH side	2 – A 3
Y133	Idle air control valve (IAC) (9F715) engine, RH side	1 – B 3
Y134	EVAP canister purge valve engine bulkhead, RH side	7 – E 5
Y207	Injector 7 (9F593) engine, LH side	2 – B 3
Y209	Injector 8 (9F593) engine, LH side	2 – A 4
Y215	Brake shift interlock (3Z719) Steering Column, LH side	7 – C 1
Y240	Injector 9 (9F593) engine, LH side	2 – B 5
Y241	Injector 10 (9F593) engine, LH side	2 – B 5